



ADVANCED LOGISTICS DEVELOPMENTS

Quality Solutions for Quality People

RAM Commander User Manual



RAM Commander User Manual

© 2014 ALD Software Ltd.

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Printed: 2014

Publisher:

ALD Software Ltd.

Pazgaz Building,
Entrance D, 2nd Floor.
46 Maccabim Road,
Rishon-le-Zion, 7535986, Israel
Phone: + 972 3 7913200
Fax: + 972 3 7913210
E-mail: support@ald.co.il
Web: www.aldservice.com
www.aldsoftware.com

The information in this document is subject to change without prior notice and does not represent a commitment on the part of Advanced Logistics Developments Ltd. (A.L.D.).

No part of this document may be used or reproduced in any manner whatsoever without written permission from Advanced Logistics Developments Ltd. (A.L.D.).

The software described in this document is furnished under a license agreement or non-disclosure agreement. The software may be used or copied only in accordance with the terms of the agreement. It is against the law to copy the ALD Software Tools on cassette tape, disk or any other medium for any purpose other than the purchaser's personal use.

Copyright 1995-2014 by Advanced Logistics Developments Ltd.

MS-DOS and Windows are registered trademarks of Microsoft Corporation

Any other references to a trademark and/or copyrighted material are unintentional.

Generated by EC Software - HELP & MANUAL tool.

Table of Contents

Foreword	0
Part 1 Welcome to RAM Commander	16
Part 2 Introduction	18
1 RAM Commander History	19
2 Modules Overview	20
3 Useful Features	21
4 Technical Overview	22
5 What you need to know	23
6 Getting Help	23
Part 3 Getting Started	26
1 Introduction	26
2 Editions	29
3 Installation	29
Installation Requirements	30
Standalone Installation	31
Network Installation	37
Server Installation	37
Workstation Installation	44
Standalone Installation + Common Network Database	50
Multiple versions	52
4 Licensing	56
Local USB plug	56
Updating plug configuration	56
Reporting plug configuration	57
Network USB plug	58
Local License File	60
Deleting license	62
Sending License Report	64
Network License File	65
5 Running RAM Commander	73
6 Major Upgrade	75
Standalone Configuration - Upgrade	75
Network Configuration - Upgrade	77
7 Minor Update	80
8 Uninstall or Modify	80
9 Install Component Library	81
10 Administration	82
Users Management	83
Projects Management	85
Libraries and Defaults Management	86

Settings Management	86
User authentication using AD/LDAP	88
User Activity Log	89
11 Troubleshooting	89
Installation	90
Licensing and Plugs	92
Access to Data	94
Reporting	100
General Problems	101
12 Summary	101
Part 4 RAM Commander Concepts	103
1 RAM Commander Process	103
Stage 1: Project Creation	106
Stage 2: Product Tree Building	106
Stage 3: Reliability and Maintainability Calculations	107
Stage 4: Reliability Analysis	108
Stage 5: Reliability and Availability Modeling	109
Stage 6: Failure Analysis	111
Stage 7: Safety Analysis	113
Stage 8: Additional Analysis Types	113
Stage 9: Next steps/recurrent analysis	113
2 RAM Commander Data Flow	114
3 RAM Commander Data Organization	114
4 Summary	115
Part 5 RAM Commander Fundamentals	117
1 Windows	117
2 Toolbar	118
3 Status Bar	119
4 Lists	119
5 Projects	120
6 Product Tree View	122
7 Reports	126
Text Reports	126
Customization	128
View Stored Reports	129
Report Generator	130
Reports by MS Word Template	133
Graphs	137
8 Data Exchange	138
9 Spelling checker	139
Part 6 Working with Projects	142
1 Projects list	142
Working with the project list	143
2 Multi-user access	144

3	Creating a new project	146
4	Managing permissions	147
	Advanced Permissions	148
5	Opening project	150
6	Backup/Restore	152
7	Project copies/revisions	153
8	Additional Operations	153
9	Project Translation to Different Languages	154

Part 7 Product Tree 157

1	Activating the Product Tree View	158
2	Product Tree Navigation	158
	Selecting Current Analysis	158
	Expanding and Collapsing	160
	Opening items	160
	Search	160
	Changing tree presentation	162
	Changing "Name" of tree items	162
	Custom tree fields	163
	Normal/Functional View	164
3	Product Tree Building	164
	Project Configuration	164
	Top item definition	165
	New item creation	167
	New item defaults	168
	Quick Create	169
	Item data editing	169
	Environment and Temperature Definition	172
	Standard Environments	174
	Additional operations with items	175
	Deleting items	175
	Copy/Move items	175
	Global Change	176
	Massive Entry	178
	To open the Massive Entry list	179
	To add new items in a Massive Entry list	179
	Additional operations with the list	180
	Count Parts Utility	181
	Massive Entry Reports	182
	Copy between fields	182
	Marking with Colors	183
	Organize	183
4	Import/Export	184
	Import Wizard	184
	Step 1	185
	Step 2 - Text files	186
	Step 3 - Text files	187
	Step 2 - Mentor Graphics	187
	Step 2 - Excel/Access files	188
	Troubleshooting	188

Step 3/4 - Mapping	190
Database Fields Index	192
Item Code abbreviations	195
Depth field	200
Parent Ref.Des. field	200
Hierarchical Parent Ref.Des. field	201
Stress	202
Search in Library	205
Level of replace/repair	205
Failure Rate source sw itch	206
MCT/MLH source sw itch	206
Step 4/5 - Finish	206
Using Import Wizard for tree update	207
Export	207
5 Reports	208
Part 8 Reliability Calculation	211
1 Configuring Reliability Module	212
Operating vs Non-Operating Mode	212
Choosing suitable Reliability Prediction Method	212
2 Item FR Calculation	215
Component Failure Rate prediction	217
Special Fields in the Prediction Method Screens	220
Junction Temperature	220
Stress values	221
Method-Specific features	222
NPRD-95	222
NPRD-2011	224
IEC, FIDES, 217Plus	226
FIDES 2009	228
Non-Operating MIL-HDBK-217E	233
Notes on Environments and Methods	235
Stress/Strength	236
Hybrid and Substrate	238
Specify known fixed FR	239
Specify known temperature-dependent FR	240
Failure Rate Allocation	241
3 Project Recalculation	242
Log File	243
4 Reports	243
Part 9 Reliability Libraries and Defaults	246
1 Global and Project Libraries	247
2 Component Library	248
To view the project component library	249
To view the global component library	249
Working with the Component Library	250
To edit component data	251
To delete component from the library	251
To insert new component into the library	251
To find component	251

Transfer data from a project to global library	252
Reports	252
Data Import	253
Using Component Libraries in Reliability Prediction	256
Retrieve or save single component data	257
Load from Library	258
Load to Library	259
3 Cross-Reference	259
Using Cross-Reference Library in Reliability Prediction	261
Data Import	264
4 Part Number Recognition	264
5 GPRD	265
Entering the GPRD Library	266
General Part Data	267
FMECA data	268
Field Failure Rate Tables	268
Manual FR Table Data Entry	269
Pack to Box	270
Import	272
Import from ASCII file	272
Import Wizard	273
Copying and Deleting Failure Rate Tables	274
Using GPRD Library in Reliability Prediction	274
Failure Rate Table Formulae	275
Copying GPRD Library between projects	277
Reports	277
6 Calculation Defaults	278
7 Managing Libraries	282
Copy libraries between projects	282
Global Library Files Location	283
Back Up and Restore of Global Libraries	283
Part 10 Reliability Analysis	286
1 Temperature Curve	286
2 Pareto	287
3 Mission Profile	289
Defining a Mission Profile	290
To add a mission profile	291
To add a mission profile phase	291
To delete a mission profile phase	292
To copy a mission profile	293
To delete a mission profile	293
Mission Profile Calculation	293
Summary	295
4 Burn-In Report	295
Part 11 Maintainability Prediction	297
1 Philosophy and Assumptions	297
Information Required	298
2 Maintainability Prediction Modeling	298

Maintenance Corrective Time	299
Mean Time to Repair	299
Ambiguity Factor	300
Maximum Corrective Maintenance Time	301
Mean Maintenance Man-hours per Maintenance Action	301
Maintainability Allocation	302
3 Preliminary Steps	303
Customize Organizational Levels	303
Set Mct max Calculation Method	304
4 Performing Maintainability Analysis	307
To enter Mct data	308
MIL-HDBK-472 Procedure 5A	309
To define MIL-472 Procedure 5A maintainability task information	310
MIL-472 Procedure 5 Task Definition	313
To define a tasks using user-defined times	313
To retrieve a standard time from the standard times library	313
To retrieve a standard task from the task library	314
To define a task's maintenance data	314
Mean Time To Repair - MTTR	315
To compute MTTR	315
To calculate MTTR and Mct in Quick mode	315
Recalculate All	316
To calculate MTTR and Mct in Recalculate All mode	316
Fault Isolation and Ambiguity	316
Maintainability Allocation	317
To perform maintainability allocation	317
To copy maintainability tasks data to other items	317
5 Maintainability Libraries	317
To access the Standard Times Library	319
To add or edit a record in the Standard Times Library	319
To delete a record in the Standard Times Library	320
To access the Standard Tasks Library	320
To add a new task to the Standard Tasks Library	320
To delete a task from the Standard Tasks Library	320
To edit a task in the Standard Tasks Library	321
Standard Tasks/Times Library Reports	321
To access the Maintenance Library	321
6 Maintainability Reports	322
7 RCM Module	323
8 Summary	326
Part 12 Derating/Stress Analysis	328
1 Defining Derating Guidelines	329
To define Derating Guidelines	330
Print Derating Guidelines	333
2 Entering Actual Stress Values	334
3 Derating Reports	336
4 Summary	338
Part 13 Reliability Block Diagrams	340

1 RBD Basics	341
2 Drawing the Diagram	342
To create a new RBD diagram	342
To change an RBD configuration	343
To add an element to an RBD	344
To enter data for an RBD element	344
K/N Element Configuration	346
To create a SubRBD	348
To delete an RBD element	349
Saving and Opening Reliability Block Diagrams	349
Working with Diagrams	349
Elements Color	349
To fold a series of RBD elements to fit the screen	350
To zoom in or out of an RBD	351
To copy an RBD element	352
Update RBD Information	352
Export to MEADEP	352
Export to MS Word, Excel etc.	352
Global Changes	353
3 RBD Calculations	354
To calculate an RBD	354
Formulas	355
Reliability Distributions	355
Availability Distributions	356
Basic calculations	357
K-out-of-N With Repair	358
K-out-of-N Without Repair	361
Equivalent Lambda/MTBF	361
MTBCF and R(t)	362
To calculate MTBCF and R(t)	364
Monte Carlo Simulations	365
To initiate a Monte Carlo simulation	366
4 RBD Reports	368
5 Summary	369
Part 14 System Configuration	371
1 To open the configuration system list	371
2 To create a new configuration	372
3 Adding Blocks to Configuration	373
4 Working with existing configurations	374
To update RAM info	374
To delete an item	375
To locate an item in a tree	375
To reorder items inside the Configuration	375
To edit an item	375
5 RBD diagram building	376
6 MTBCF Calculation	377
7 Reports	377
8 Summary	378

Part 15 Reliability Growth	380
1 Reliability Growth Modeling	381
2 To view reliability growth data	383
3 To enter reliability growth data	383
4 To compute reliability growth planning parameters	384
5 Reliability Growth Formula	386
6 Reliability Growth Reports	386
To generate reliability growth reports	387
7 Summary	389
Part 16 Spare Parts Analysis	391
1 Operation Modes	391
2 Product Tree Data	391
3 Spare Parts Calculation	392
To add an operation scenario	393
Working with existing Scenarios	394
To copy a spare parts operation scenario	394
To delete a scenario	394
To edit a scenario	395
Generating Spare Parts Reports	395
4 Spare Parts Optimization	395
Optimization CriteriaThe spare parts module supports the computation of two optimization criteria:	
Constraint	396
Optimization Algorithm	397
Optimization Parameters	397
To set operation scenario parameters	397
Generating Optimization Reports	399
To generate an optimization report	399
To review optimal spare part quantities	401
5 Spare Parts Analysis Formulae	403
6 Possible Important Applications	403
Compound Operation Modes	403
Spares and Level of Repair Decisions	404
7 Summary	404
Part 17 Markov Analysis	406
1 Initiating Markov module	407
2 Drawing the diagram	408
Draw a state	408
Draw a Transition	409
State Data	410
Transition Data	411
Diagram data	412
Working with diagram	413
3 Calculation	413
4 Reports	414

Part 18 FMECA	422
1 Initiating FMECA module	423
2 FMECA Module Basics	424
3 Configuring FMECA module	426
FMEA or FMECA	426
FMECA Library	427
FMECA Grid Customization	428
Phase selection	429
4 FMECA Libraries	430
To access FMECA libraries	431
FMECA Libraries Definition	431
Generating a Library Report	432
Global Change of the End Effect Library	432
Copy FMECA Libraries Between Projects	432
5 Entering FMECA data for Item	433
Entering Next Higher Effects	435
To define a single NHE.....	436
To select affected assembly	437
To define multiple NHEs for a single FM.....	437
To define NHE for NHE.....	438
Additional operations in FMECA grid	440
FM Column Pop-up Menu Options	441
Alpha Column Pop-up Menu Options.....	442
NHE Column Pop-up Menu Options	443
End Effect Column Pop-up Menu Options	443
6 Testability Analysis Module (TAM)	444
To define tests for FM	444
Testability Analysis Reports	446
7 Functional Blocks	448
To create functional blocks	449
Working with Functional Blocks	451
8 FMECA Reports	451
To Generate an FMECA Report	453
9 Import/Export	453
Functional Blocks Import	456
10 Summary	457
Part 19 Fault Tree Analysis	459
1 FTA basics	460
2 FTA module initiation	463
3 Building FTA Diagrams	464
Creating a new Fault Tree	465
Define FTA properties	465
FTA diagram building	467
Transfers	469
Events library	469
Delete elements	470
Copy & Paste	471

Remarks	472
Automatic FTA building	473
Print preview, Print, Zoom	473
Export Diagram as Picture	473
Using Common Cause Failures	474
Global Change	475
Importing Fault Trees	478
Import FT from RiskSpectrum.....	478
Import FT from Isograph FT+.....	478
Import FT from CAFTA	480
Import FT from Aralia Simtree.....	481
4 Analysis & Calculation	481
Basic Event Types	482
MCS Calculation	484
Tree Unavailability calculation.....	487
Easary-Proschan Formula	487
Frequency W(t) Calculation	488
PFH and PFD Calculation.....	488
Lambda Equivalent.....	489
House Event Profiles	489
Importance / Sensitivity Analysis	490
FALSE/TRUE Propagation	491
Repeated Events Indication	494
5 Reports	494
6 Summary	495
Part 20 Event Tree Analysis	497
1 ETA module initiation	498
2 ETA diagram building	500
Events library	503
Delete	504
Export Diagram as Picture	504
Print preview, Print, Zoom	504
3 Analysis & Calculation	504
4 Reports	504
5 Summary	506
Part 21 Process/Design FMEA	508
1 FMEA Basics	509
2 FMEA module initiation	510
3 Defining FMEA Properties	511
4 Drawing the Diagram	512
Drawing a Node	512
Drawing a Link	513
Multiselection	513
Stretching a Link	514
Drawing a Reflexive Link	514
Delete	514
Copy & Paste	515

Sub-diagrams	515
Print, Zoom, Undo	516
Export Diagram as Picture	516
Inserting nodes from Product Tree	516
5 Failure Modes, Causes and Effects	516
To create a new Failure Mode	517
To create a new Failure Cause	518
To edit or delete Failure Modes	519
To copy failure mode	519
Spelling checker	519
To work with cumulative list of failures	520
6 Selecting Critical Failure Causes	521
7 Team Collaboration	524
To define the expert team	525
To collect rankings manually	525
To collect rankings automatically	526
Voting System Installation	526
To install and configure the Voting System.....	527
8 Making Decisions on Corrective Action	529
9 Libraries	531
To view and update FMEA libraries	532
To update a library during FMEA data input	532
To select a field value from a library	533
To copy libraries between projects	533
Load to Library	534
10 Reports	534
To print the report	536
11 Summary	536
Part 22 Safety Analysis	538
1 Safety Module Basics	538
2 Safety module initiation	540
3 Safety Libraries	541
Working with Libraries	541
4 Building the Functional Tree	543
5 Working with different standards/recommendations	545
6 Working with Failure Conditions	546
7 Probability Calculation	551
8 Reports	551
Part 23 MMEL	556
1 Prerequisites for MMEL generation using RAM Commander MMEL Module	556
2 MMEL Analysis process	557
3 To perform MMEL analysis	557
4 1st step: MMEL Quantitative Analysis	560
MMEL Module Quantitative Analysis Algorithm	560
To select a required algorithm	562

To activate quantitative analysis	563
5 2nd step: MMEL Five Column Format Report Preparation	565
6 MMEL Module Reports	566
7 Summary	569
Part 24 MSG-3	571
1 Systems and Power Plant Analysis	571
Initiating MSG-3 Module	572
MSG-3 Procedure Steps	572
Step 1 – System Definition	572
Step 2 – MSI Selection	573
Step 3 – FMECA	575
Step 4 – Failure Effect Categorization	576
Step 5 – Task Selection	578
Step 6 – Task Interval	579
Step 7 – MSG-3 Report	580
2 Structural Analysis	582
3 Zonal Analysis	583
4 L/HIRF Analysis	584
Index	586

Chapter




1

**Welcome to RAM
Commander**

1 Welcome to RAM Commander

RAM Commander is the pioneering Reliability and Safety software for reliability professionals and design engineers, developed by the [ALD Reliability and Safety Solutions](#). RAM Commander combines ingenuity of approach, calculation accuracy, convenience of use. Designed by reliability engineers, RAM Commander covers the entire scope of engineering tasks related to reliability of electronic, electro-mechanical and mechanical systems.



List of RAM Commander modules contains Reliability, Maintainability, RBD, Fault Tree Analysis, Event Tree Analysis, Safety Assessment, Spare Parts optimization, Derating, FMECA and Testability Analysis, Process&Design FMEA, FTA and more.

This manual is designed as installation and upgrade guide for IT staff, course in using RAMC for new users and ongoing reference to program functions for users already working with the software.

Chapter



2

Introduction

2 Introduction

This chapter tells you about **RAM Commander**, its purpose, its history and useful features.

RAM Commander (Reliability, Availability, Maintainability Prediction and Analysis) is a 32-bit integrated LAN-compatible Windows software package for:

- **System structure definition**, graphical presentation and impact;
- **Reliability, availability, and maintainability prediction**;
- Reliability and maintainability **allocation** with user-defined complexity factors;
- Reliability and maintainability parameter trade-offs and optimization in accordance with multiple **mission profile** definitions such as environment, temperature and phase times for operating and non-operating phases;
- Building, maintaining and evaluating functional **reliability block diagrams** using a graphical interface;
- Reliability and availability estimation for a multitude of graphically presented system configurations.
- A definition of **derating** guidelines and an analysis of the overstressed components;
- **Spare parts** quantity estimation and optimizations;
- Failure modes and effects criticality analysis (**FMECA**);
- **Testability** analysis;
- Process and Design **FMEA**;
- **Fault Tree** Analysis
- **Event Tree** Analysis
- **Markov Chains** Analysis
- **Safety** Analysis (including **FHA**, **SSA**, **PHA**, **MMEL**, **SHA**)
- **MSG-3** Analysis
- Automatic data validation and correction;
- Generating professional reports.

The partial list of RAM Commander customers is provided below:



2.1 RAM Commander History

In 1988, ALD released the first DOS version of reliability software called **RPTB**. In 1992, **RAM Commander** for DOS was released followed by the Windows version in late 1995. In 1998, Spares Optimization, derating modules and Monte-Carlo simulation modules were added. Since then, RAM Commander has quickly become the world's leading software in the area of reliability and maintainability prediction with the fully integrated FMECA and design/process FMEA. You will not find another R&M software package providing all the modules, options, interface and quality documentation that RAM Commander does.

RAM Commander history milestones:

- 1995 - RAM Commander 6.0 for Windows replaces the RPTB
- 1998 - Spares Optimization, Derating Modules and Monte-Carlo Simulation modules
- 1999 - RAM Commander 7.0, the 32-bit version is released
- 2001 - Fully integrated FMECA and design/process FMEA
- 2002 - Functional FMECA, ILS support and NSWC
- 2003 - Integrated Fault Tree Analysis and Siemens prediction method
- 2004 - Integrated Safety module and FIDES prediction method
- 2005 - Multi-user work support and IEC 62380 prediction method
- 2006 - Stress/Strength Analysis, Siemens SN 29500-2005-1 and HTML reports
- 2006 - Event Trees, FMECA report generator and RCM
- 2007 - Markov Analysis, Telcordia Issue 2, 217Plus and multilingual database support
- 2008 - MMEL (Master Minimum Equipment List) Module

2009 - MSG-3, faster FTA calculation and advanced security
 2010 - New look, FIDES 2009 and reports by MS Word template
 2011 - MSG-3 Structural, Zonal and L/HIRF Analysis
 2013 - Telcordia Issue 3, NPRD-2011, Binary Decision Diagrams
 2014 - UI face-lift, FIDES 2009 Part count and Family count methods, FDAL allocation support

To maintain our competitive edge, we have been collecting customer responses and questions. In addition, we have added many new functions to keep RAM Commander current with state-of-the-art technologies.

As always, ALD is interested to know how you use RAM Commander. If you have any special applications or hints, or have come across any particular problems, do not hesitate to write us at the addresses listed in the [Getting Help](#) section of this manual or use our [ALD Software Feedback Form](#).

2.2 Modules Overview

RAM Commander is the pioneering Reliability and Safety software for reliability professionals and design engineers. RAM Commander combines ingenuity of approach, calculation accuracy, convenience of use. Designed by reliability engineers, RAM Commander covers the entire scope of engineering tasks related to reliability of electronic, electro-mechanical and mechanical systems.


RAM Commander is **modular software** allowing a customer the flexibility of gradual addition of the modules to the package in accordance with the requirements of a project or the budget constraints. List of RAM Commander modules contains Reliability, Maintainability, RBD, Fault Tree Analysis, Event Tree Analysis, Safety Assessment, Spare Parts optimization, Derating, FMECA and Testability Analysis, Process&Design FMEA and more.

Table below provides brief information about software modules:

Module	Description
Basic (Reliability Prediction and Analysis)	Reliability Calculation for Operating and Non-operating state, using more than 25 reliability prediction standards such as MIL-STD-217, FIDES, BELLCORE, GJB299, Telcordia, NSWC, NPRD-95 and more). Reliability data libraries. Reliability analysis using reports, Pareto , Temperature Curve , Mission Profile and more.
Import Wizard	Customizable BOM import from ASCII, Access, Excel
Report Generator	Customizable user-defined reports generator for BOM, reliability, maintainability, FMECA, ILS and more
RBD	Reliability Block Diagram analysis module for reliability modelling of serial, parallel, K-out-of-N (partially loaded, with/without switch, with/without repair) redundancy configurations. Monte Carlo simulation, MTBCF calculation.
Markov	Markov chains analysis for steady-state and time-dependent mode.
Maintainability Prediction	Maintainability analysis according to MIL-STD-472 Procedure A, maintenance analysis, RCM Module , MSG-3
Spare parts	Spare parts calculation and optimization, based on two cost optimization criteria: Total No Shortage Probability & Availability. Integrated with Reliability and Maintainability modules.
Derating/Stress Analysis	Analyze overstress of components under current temperature conditions. The module provides a tool to define Derating curves and identify overstressed components, i.e., those working under stress exceeding the specified rating value.

FMECA	Failure Modes, Effects and Criticality Analysis according to MIL-STD-1629 and other standards. Hardware and functional FMECA, Testability Analysis.
Process/Design FMEA	Potential Failure Mode and Effects Analysis (FMEA) described by AIAG, QS-9000, SAE J 1739, IEC 60812, JEP131 and other standards, sometimes called "automotive" or "AIAG" (Automotive Industry Action Group) FMEA.
FTA	Fault Tree Analysis - building Fault Trees, Minimal Cut Sets generation and Unavailability calculation. Integrated with Product tree/Reliability/Maintainability/FMECA modules.
ETA	Event Tree Analysis. Integrated with Product tree/Reliability/Maintainability/FMECA/FTA modules.
Safety	Safety assessment module performing tasks required by safety standards like SAE ARP 4781, MIL-STD-882 and others. FHA, PHA, SSA, SHA, O&SHA analysis. Integrated with Product Tree, FMECA and FTA modules.
MMEL	Master Minimum Equipment List (MMEL) is a document which lists the equipment that may temporarily be inoperative, subject to certain conditions, whilst maintaining an acceptable level of safety as intended in the applicable documents. MMEL analysis is required for all aircraft manufacturers to certify aircraft safety in different aviation authorities such as FAA, EASA etc. RAM Commander integrated MMEL module supports Master Minimum Equipment List generation using Reliability, FMECA, FHA (Safety) and FTA modules results.

All the modules are integrated into single software package and stored in a single database. Each RAM Commander project (database) is a briefcase of different analysis types performed by the modules stated above, for specific product, device or system:



Customer may purchase license for any subset of available modules.

2.3 Useful Features

In addition to the modules and features covering all the scope of RAM analysis, **RAM Commander** is supplied with the following useful features:

- **Extensive set of component libraries** - **RAM Commander** is equipped with an extensive set of

libraries for more than 60,000 standard components. You can easily locate devices in the library and insert them directly into your project.

- **Importing files from external applications** - Do you have an existing product tree on another application? Use **RAM Commander's** import wizard to safely and completely migrate all the data into RAM Commander's database.
- **Copying data between projects** - Use **RAM Commander's** copy utilities to quickly build new projects based on previous ones.
- **Context-sensitive help** - Press F1 at any time to view online help about a dialog box, menu or window.
- **Multiple windowing** - You can open several windows simultaneously, allowing easy access to information in different sections of one project or in different projects.
- **Network operation** - You can run **RAM Commander** under LAN, allowing you to install the software on one computer and making it available to all network users.
- **Variable access privileges** - System managers assign various access levels to **RAM Commander** users. You can protect sensitive information and provide the flexibility for easy information flow between users.
- **Product tree presentation** - Navigating through a project is very similar to navigating through any commonly used hierarchical structures, such as exploring folders in MS Windows.
- **Operating data grids** - Many of the **RAM Commander** features use a grid displaying only the most important fields that allows editing essential data directly on the grid.
- **Automatic tree recalculation option** - There is an option of automatic recalculation when defining the project properties to ensure that the **RAM Commander** output is based on the latest updated data.
- **Report Generator**
- Documents Generation using **MS Word templates**

2.4 Technical Overview

RAM Commander is a 32-bit MS Windows Application which can work in both standalone mode on a single computer with locally located database and in client/server configuration with common database located on server. RAM Commander Database contains multiple projects, where each project is a folder containing all available studies and analysis types (reliability, safety, Fault Trees, etc.).

Deployment

See [Getting Started - Introduction](#) paragraph for more information about installation models. See also [Getting Started - Installation requirements](#) paragraph.

Connectivity

Import/Export data from/to text, CSV, Excel, Access. Flexible import Wizard and Report Generator. Web services (SOAP) connectivity to FavoWeb FRACAS (RAM Commander calls FavoWeb web services).

Special format for electronic components library import and reliability data import.

GUI Language

English, Russian, Chinese. Other languages are available on demand.

Licensing

Multiple flexible licensing models - floating network license, computer-locked hardware key, computer-locked software license and more. See [Getting Started - Licensing](#) paragraph for more information about different licensing models.

Technology used

Database: Pervasive SQL + MS Access

Application: Windows application, MFC. Some modules use .NET Framework 2.0. Some modules use .NET Framework 4.0.

2.5 What you need to know

To effectively operate the **RAM Commander**, as well as understand concepts presented in this manual, you need to know the following:

- Intermediate user knowledge and skills of Microsoft Windows and Microsoft Office.
- Fundamentals of reliability and maintainability prediction modeling.
- Depending on module selection, you need to know also theory and practice of such analysis types as FTA, FMECA, be familiar with specific standards (MIL-STD-1629, SAE ARP 4761 etc.).

With this background, you can start using **RAM Commander** in a quick and efficient manner.

2.6 Getting Help

There is a number of different sources of information on RAM Commander software.

In addition to this manual you can also access **online knowledge base** (for registered customers only - contact ALD Software Technical support for link and access details), online manual at <http://www.aldsoftware.com/download/ramc/UserManual/html/index.html> and ALD Software Technical support.

Information about software updates, hot fixes and service packs is available on our website at http://www.aldsoftware.com/download/ramc/RAMC_Updates.html.

Direct email support is available from the **ALD Software Technical Support** team at support@ald.co.il.

Find more information visiting our websites: www.aldservice.com, www.aldsoftware.com.

Please tell us what you think about our software and services using [ALD Software Feedback Form](#).

ALD provides **training for software products**, general and specialized, at ALD headquarters or at customer's location:

- RAM Commander basic training
- RAM Commander advanced training
- Module-specific training:
 - Reliability Prediction and Analysis
 - Failure Analysis (FMECA, FTA, ETA)
 - Safety Assessment/Hazard Analysis
- Industry-specific training:
 - Aviation Safety
 - Railway Safety

- Reliability for Electronics/Telecommunications industry
- Reliability/Safety for Military applications
- and more.

[Contact us](#) for more information about training programs.

Chapter

3

Getting Started

3 Getting Started

This chapter provides instructions on the RAM Commander **installation, configuration, first time running and administration**.


It explains how to solve the following tasks:

- Choosing the suitable installation model
- Choosing the suitable licensing model
- [Installing RAM Commander in different modes](#)
- [Configuring RAM Commander license](#)
- [Installation Troubleshooting](#)
- [First time use](#)
- [Administration](#)
- [Upgrade](#)
- [Troubleshooting](#)


3.1 Introduction

RAM Commander is a 32-bit Windows application which should be physically installed on all computers where it should be used.

There are two main RAM Commander installation configurations: **Standalone** and **Network**. In a **Standalone** configuration there is no dedicated server. RAM Commander is installed on multiple computers, each of them may use local database (set of projects and libraries) or use database located on any shared network drive.





In **Network** (client-server) configuration separate RAM Commander server should be installed. Then multiple workstations may be installed for this server, RAM Commander software main components and databases are located on the server.



Standalone configuration is better when users mainly work with local databases and also work in disconnected mode with their notebook computers. **Network** configuration is better when there is a large number of users which work with common database.

In addition to RAM Commander software itself, **license** is required for both RAM Commander installation configurations.

There are 4 licensing models:


<p>Local USB plug</p> 	<p>USB plug which should be inserted into the USB port of PC where RAM Commander is installed. May be exchanged among users and computers, but grants access to its current holder only.</p>
<p>Network Floating USB plug</p> 	<p>USB plug which should be inserted into the USB port of PC which is constantly available through the network to all RAM Commander client PCs (License Server). Network plug contains purchased number of licenses, which may be used simultaneously and concurrently by multiple RAM Commander users. Requires installation of HASP Plug Driver and HASP License Manager (Windows Service). License Server may be installed on the same computer where RAM Commander Server is installed.</p> <p>Requirements on the license server:</p> <ul style="list-style-type: none"> - Windows XP/7/2003/2008 - Real PC (not virtual PC) with USB 2.0 port - Possibility to communicate with the server by TCP/IP through port 475 - TCP/IP Broadcast enabled <p>Note: In case of segmented network, some additional configuration of HASP License Manager is required.</p> <p>Newer and more reliable licensing method is recommended instead of this method - Network Floating License file - see later in this table.</p>
<p>Local Computer-Locked License file</p>	<p>License file placed on PC where RAM Commander is installed. It grants access to RAM Commander to this PC user only and can't be exchanged between computers.</p>
<p>Network Floating License file</p>	<p>License file placed on PC (License Server) with ALD license manager installed. License Server PC is constantly available through the network to all RAM Commander client PCs. License file contains purchased number of licenses, which may be used simultaneously and concurrently by multiple RAM Commander users. Requires installation of ALD License Manager (Windows service). License Server may be installed on the same computer where RAM Commander Server is</p>

installed.

Requirements on the license server:

- Windows XP/7/2003/2008/8/2012
- May be both Real or Virtual PC
- Possibility to grant full access permissions and sharing to a folder accessible by all users.

All four licensing models may be used no matter which RAM Commander installation configuration is selected; e.g. license files for each PC may be used with RAM Commander network configuration or Network plug may be used with multiple standalone installations. The network diagram below displays the most complex case, when RAM Commander is installed in network configuration and also Network plug license model selected:



Except number of users' limitation, license also contains information about the set of RAM Commander modules purchased.

Only after proper RAM Commander installation and license configuration you may start working with the software.

Several licensing methods may be used concurrently, RAM Commander will search for the license by the following priority:

1. Local computer-locked license file
2. Local USB plug
3. Network floating license file
4. Network floating USB plug.

For example, a company could have network floating license file and also local USB plug. All engineers in the office are concurrently using the floating network license. If any engineer should work offline with his laptop, he takes local USB plug, connects to his PC and works disconnected from the network (in this case he should also have "Standalone", and not "Workstation", installation of RAM Commander on his laptop).

Please choose your preferred RAM Commander installation configuration and your preferred licensing model and see corresponding paragraphs of this chapter:

[Installation Requirements](#)

[Installation](#)

[Licensing](#)

3.2 Editions

There are several RAM Commander editions: **Full** version, **Student** Version and **Demo** Version.

See the comparison matrix below for more information about differences:

Feature	Full Version	Student Version	Demo Version
Purpose	Commercial version for professional reliability, availability, maintainability and safety analysis	Educational purposes	Evaluation purposes
Functional limitations	None, unlimited	None, unlimited	Only 4 prediction methods supported (MIL-217, Telcordia 1, GJB299B, UTEC)
Database size limitations	None, unlimited	Limited, per project: 20 product tree items, 5 FMECA failure modes per item 10 Fault Trees 20 Gates per FTA 10 Event Trees 6 Events per ETA 7 functions in Safety 5 hazards/failures per function 10 Markov diagrams 8 states per Markov diagram 10 elements per FMEA 8 failures per FMEA element	Limited 2 FMECA failure modes per item 3 Fault Trees 15 Gates per FTA 3 Event Trees 4 Events per ETA 5 functions in Safety 2 hazards/failures per function 3 Markov diagrams 5 states per Markov diagram 5 elements per FMEA 3 failures per FMEA element
Activity period	Unlimited	Semester (6 months)	Unlimited
Availability	Download after purchase - contact sales	Download after purchase or agreement - contact sales	Free from web site

The entire manual relates to all available editions.

3.3 Installation

Your RAM Commander software kit includes:

- Installation CD
- Security Plug (optional)
- User Manual

Installation package and User Manual available also online - please ask your software vendor for URL and access code.

RAM Commander may be installed in two different modes - **Standalone** and **Client/Server**. See [Introduction](#) paragraph earlier in this chapter for more information about these modes. When the suitable installation mode is selected (Standalone or Client/Server) the installation process may be started - see next paragraphs in this manual section.

Check also [Installation Requirements](#) before you start.

Note: RAM Commander installation requires **administrative privileges**. Make sure you are logged in with administrative privileges before installing RAM Commander. Make sure RAM Commander users have full access rights to RAM Commander installation folder.

3.3.1 Installation Requirements

Hardware and Software Requirements for RAM Commander installation:

- **Client/Standalone:**

OS: MS Windows XP / Vista / 7 / 8

Both 32-bit and 64-bit processors and OS supported.

Hardware: Desktop/Laptop PC with recommended hardware configuration for installed OS version.

Generally it is:

- 3 GHz or higher Windows-compatible processor (Intel Pentium/Celeron family, i5/i7, or AMD K6/Athlon/Duron)
- 4GB RAM
- Free 100MB Hard Drive space (for software installation only, required capacity depends on expected database sizes)
- 1024x768 x 24bit colors video adapter and monitor
- Keyboard and Mouse

MS Word reports generation requires .NET Framework 2.0 installed.

Charts generation requires .NET Framework 4.0 Full installed.

Some modules require MS Office (MS Word and MS Excel) installed.

- **Server** (if client/server configuration is used - not required for standalone):

OS: Windows XP/Vista/7/2003 Server/2008 Server/2012 Server

Both 32-bit and 64-bit processors and OS supported.

Hardware: Recommended hardware configuration for installed OS version.

Generally it is:

- 3 GHz or higher Windows-compatible Dual-core processor (Intel Pentium/Celeron family, or AMD K6/Athlon/Duron, i5/i7)
- 4GB RAM
- Free 1GB Hard Drive space (for software installation only, required capacity depends on expected database sizes)

Some modules require .NET Framework 2.0 installed.

Requirements listed above are minimal requirements for running the software. Optimal recommended requirements depend on the nature of projects and calculations planned to perform, size of product trees, complexity of fault trees, number of products being analysed etc. Better processors and larger RAM size will improve the calculation speed.

3.3.2 Standalone Installation

Note: RAM Commander installation requires **administrative privileges**. Make sure you are logged in with administrative privileges before installing RAM Commander. Make sure RAM Commander users have full access rights to RAM Commander installation folder.


1. Run RAM Commander installation package (run installation file downloaded from our web site or RAMC\setup.exe file from RAM Commander installation CD).
2. The Installation Wizard will go through a sequence of the setup screens asking the user to make the appropriate selections. Press Next on the first screen.




3. Confirm the License Agreement (Yes button):




4. Choose "Single user installation" on "Setup type selection" screen:




5. Select the drive and folder you wish to install RAM Commander into. Default value is C:\RAMC32. Click **Next**.




6. RAM Commander Setup displays a Select Components dialog box. Click **Next**.




7. Select Start menu folder where RAM Commander icons will be located and Click **Next**.




8. Press Next on the "Review settings" screen:



9. The Installation Wizard will copy necessary files:



10. If this is the first time Ram Commander is installed on the computer, the Edit user parameters dialog box is displayed. Enter your User Name and Password (optional) and click OK:



Password is optional.

Groups are used by RAM Commander to control *access privileges*. Access to the projects may be denied for the users according to their groups (see Project Definition in Chapter 8).


Level is optional.

See [Users Management](#) paragraph later in this manual for more information about the user parameters definition.

11. Windows Security Center / Windows Firewall Warning message may appear - press "Unblock" button:



12. Choose **Finish** on the last installation wizard screen:



13. RAM Commander is now installed on your computer.

14. Install and configure the RAM Commander security plug or license file (see "[Licensing](#)" paragraph later in this chapter).

3.3.3 Network Installation

Network installation involves two steps: RAM Commander **Server** Installation and RAM Commander **Workstations** Installation.

First step is the [Server Installation](#) .

Then valid license should be obtained, installed and configured - see [Licensing](#).

Then RAM Commander client should be installed on all workstations - see [Workstation Installation](#).

See next paragraphs for procedures description.


3.3.3.1 Server Installation

Note: Only an authorized network administrator should perform this installation procedure.


1. Log in into the server PC with **administrative privileges**. **Server installation procedure should be run from the server PC**.
2. Choose (or create if needed) RAM Commander installation folder. It must be shared with full access rights and mapped as a network drive for all RAM Commander users on the network. Folder name should contain only Latin characters and numbers, without spaces or special and national characters (Hebrew, Chinese etc.). For example, choose C:\APP\RAMC32. Then C:\APP folder should be shared on server and mapped as network drive by workstations.

Note: It is highly recommended to set up a automated backup procedure for this RAM Commander folder on the server (e.g. C:\APP\RAMC32 in the example above) to prevent loss of valuable data like reliability data libraries, particular projects and analysis cases.


3. Run RAM Commander installation package (run installation file downloaded from our web site or RAMC\setup.exe file from RAM Commander installation CD).
4. The Installation Wizard will go through a sequence of the setup screens asking the user to make the appropriate selections. Press Next on the first screen.




5. Confirm the License Agreement (Yes button):




6. In the Setup Type Selection box, choose **Server (Network) Installation**:




7. Specify the RAM Commander installation folder – it should be the folder which will be shared later for all RAM Commander workstations plus RAMC32 subfolder, for example C:\APP\RAMC32, where C:\APP will be shared on server and mapped by workstations.




8. RAM Commander displays a Select Components dialog box. Click Next.




9. Select Start menu folder where RAM Commander icons will be located and Click Next.




10. Press "Next" on "Review settings" dialog:



11. The Installation Wizard will copy necessary files:



- 12.If this is the first time Ram Commander is installed on the computer, the Edit user parameters dialog box is displayed. Enter system manager User Name, Password (optional) and Group (optional) and click OK:




Password is optional.

Groups are used by RAM Commander to control *access privileges*. Access to the projects may be denied for the users according to their groups (see Project Definition in Chapter 8).


Level is optional.

See [Users Management](#) paragraph later in this manual for more information about the user parameters definition.

- 13.Windows Security Center / Windows Firewall Warning message may appear - press "Unblock" button (message may appear on different installation steps or event when the installation is finished):




- 14.Choose **Finish** on the last installation wizard screen in the last screen of the Installation Wizard.:




15. RAM Commander is installed on the server.

16. Share selected installation folder (e.g. C:\APP in this example) for all RAM Commander users, give full control permissions for this folder to all RAM Commander users:

a. Enable folder sharing:



b. Give Full Control permissions to all RAM Commander users:




17. Now that you have installed RAM Commander on the server, the next steps are to [install RAM Commander on workstations](#) and install/configure [software license](#).

Note: You cannot run RAM Commander on the server.


3.3.3.2 Workstation Installation

Note: RAM Commander installation requires **administrative privileges**. Make sure you are logged in with administrative privileges before installing RAM Commander. Make sure RAM Commander users have full access rights to RAM Commander installation folder.


1. Log in into the workstation PC with administrative privileges.
2. Map RAM Commander Network server's shared folder (C:\APP for example) where RAM Commander server components are installed on the network drive. All workstations should use the same drive letter for this folder. For example, map server's C:\APP folder as R: drive:




Then R: folder on workstation will contain RAMC32 folder where RAM Commander Server was installed:




3. Run RAM Commander installation package (run installation file downloaded from our web site or RAMC\setup.exe file from RAM Commander installation CD).
4. The Installation Wizard will go through a sequence of the setup screens asking the user to make the appropriate selections. Press Next on the first screen.




5. Confirm the License Agreement (Yes button):




6. In the Setup Type Selection box, choose **Workstation (Network) Installation**:




7. When prompted for the "Full path to RAM Commander in Network", specify the RAM Commander location on the server folder which is mapped as network drive. If RAM Commander is installed on the server's C: drive to folder C:\APP\RAMC32, and server's C:\APP folder is mapped as R: on workstations, enter R:\RAMC32 in this field:




8. Select Start menu folder where RAM Commander icons will be located and Click Next.




9. Press Next on the "Review settings" dialog:



10. The Installation Wizard will copy necessary files.
11. Windows Security Center / Windows Firewall Warning message may appear - press "Unblock" button (message may appear on different installation steps or event when the installation is finished):



12. Question about adding a new user to users list will appear - choose Yes if you wish to add user. Edit user parameters dialog box will appear - provide user name and other details and press OK:




Password is optional.

Groups are used by RAM Commander to control *access privileges*. Access to the projects may be denied for the users according to their groups (see Project Definition in Chapter 8).

Level is optional.

See [Users Management](#) paragraph later in this manual for more information about the user parameters definition.

13. Choose Finish on the last installation wizard:



14. RAM Commander is installed on the workstation.

15. Continue installation for other workstations.

3.3.4 Standalone Installation + Common Network Database

As it was stated before, the standalone installation is useful when each user wishes to work with his own database or work disconnected, and network installation provides possibility to work through the central database located on the server.

However it is still possible for multiple users to work with Standalone installation using **common projects database** located on the network server and/or **common libraries** located on the network server.

To allow RAM Commander users to work with common libraries:


1. Common libraries should be placed on the network shared folder.
2. RAM Commander Standalone computers should be configured to use this network folder as a library location. See "Reliability Libraries and Defaults" chapter and also "[Settings Management](#)" paragraph later in this chapter.

To allow RAM Commander users to work with common database when users have Standalone RAM Commander configuration:


1. Choose PC which will act as a file server. It can't be one of RAM Commander workstation/client/standalone computers. You will not be able to run RAM Commander and work on this file server PC.
2. Share any folder on this PC, give full access rights to all RAM Commander users to this folder. Folder name should contain only Latin characters and numbers, without spaces or

special and national characters (Hebrew, Chinese etc.).

3. Run RAM Commander's installation package on this server PC, choose the "Projects Network Service" option:



4. Map this folder as network drive on all RAM Commander client computers; use the same letter for all mappings.
5. Each RAM Commander user will be able to open this mapped network drive and create or open projects on this drive (RAM Commander supports multiple users access to the same project):



RAM Commander should be installed to the same folder on all client computers. If it is not possible, it is required to set the same RAM Commander working folder on all computers – use Library -> Location -> Project files folder option of the main menu.


3.3.5 Multiple versions

RAM Commander does not support 2 different versions running on one PC by default. RAM Commander installation always upgrades the older version already installed, so that you can't use both versions simultaneously.


If you really need to have multiple standalone versions (for testing or compatibility purposes) - there is a way to perform such an installation.

If you have, for example, RAM Commander version X.XX installed in C:\RAMCXX folder and you wish to install RAM Commander Y.YY to another folder C:\RAMCYY, use the following procedure to install a new version while preserving the old version.


1. Create a folder **Ram Commander** on the Desktop. Place the RAM Commander X.XX shortcut icon in it (you may copy it from ALD Engineering group in the Startup->Programs folder) and change the shortcut's name to display software version (X.XX).




2. Click **Start** button and choose the **Run** option.
3. Enter **regedit** in **Run** dialog box and click **OK**.



4. Browse to locate the key HKEY_LOCAL_MACHINE\SOFTWARE\Advanced Logistics Developments and select the key.




5. Choose **Export Registry file** from **Registry** menu.
6. Enter the file name (for example, ramcwXX) and choose the **RAM Commander** folder (which you created in step 1 on your Desktop) as the place where you want to save the file.
7. Click **Save**.




8. For all registry values inside the Advanced Logistics Developments key, change RAMCXX to RAMCYY:

Name	Type	Data
ab(Default)	REG_SZ	(value not set)
abDB_Mode	REG_SZ	Normal
abGPRDPath	REG_SZ	D:\RAMC32\LIB\GPRD.MDB
abLibrary	REG_SZ	D:\RAMC32\Lib\Library.dat
abPrjPath	REG_SZ	RAMC32\PRJ
abProcPath	REG_SZ	D:\RAMC32\PRC
abRootPath	REG_SZ	D:\RAMC32
abVersion	REG_SZ	8.1
abXref	REG_SZ	D:\RAMC32\LIB\XREF.DAT


9. Copy C:\RAMCXX folder to C:\RAMCYY.
10. Install the new version of RAM Commander Y.YY to RAMCYY folder.
11. Open folder **Ram Commander** located on the Desktop.
12. Place the **RAM Commander Y.YY** shortcut icon in it (you may copy it from ALD Engineering group in the Startup->Programs folder) and change the shortcut's name to display software version (Y.YY).




13. Click **Start** button and choose **Run**.
14. Enter **regedit** in **Run** dialog box and click **OK**.



15. Browse to locate the key HKEY_LOCAL_MACHINE\SOFTWARE\Advanced Logistics Developments and select the key.



16. Choose **Export Registry file** from **Registry** menu.
17. Enter the file name (for example, ramcwYY) and choose the **RAM Commander** folder (which you created in step 1 on your Desktop) as the place where you want to save the file.
18. Click **Save**. Now two RAM Commander versions are installed. You have **RAM Commander** folder with two icons for each RAM Commander version on the Desktop.

**NOTES:**

- Before any operation (run, uninstall, service pack installation, etc.), you should run the corresponding version's configuration icon and confirm the changes (click Yes and then OK). Only after doing this can you run or update RAM Commander.
- Do not use the Start > Programs menu icons to run RAM Commander.
- To transfer a project from an older version to a newer version, use the Backup and Restore modes.

3.4 Licensing

There are 4 licensing models: Local USB plug, Network USB plug, Local license file, Network License file. You may find comparison and overview of these models in the [Introduction](#) paragraph earlier in this chapter.

The next paragraphs provide installation procedure for each of these licensing models.

3.4.1 Local USB plug

Local USB plug should be inserted into the USB port of PC where RAM Commander is installed. It may be exchanged among users and computers, but grants access to its current holder only.

Before running RAM Commander, ensure that the local plug is connected to the USB port of your computer.

If not, then switch off your computer, connect the plug and switch on again. The plug driver is installed automatically during the RAM Commander installation. If plug problems appears after the installation, you can install plug driver manually.

To install a local plug driver manually:

1. Run the program HASPUserSetup.exe from the RAM Commander installation CD \HASP\Driver HL" folder with the latest version number in folder's name. You may also download the drivers setup package from our web site: <http://www.aldsoftware.com/download/download/HASPUserSetup.exe>
2. Choose the Yes button to install.
3. Follow the interactive instructions. The plug driver will be installed.
4. Now you may run RAM Commander.

3.4.1.1 Updating plug configuration


To request plug configuration update

To request a plug configuration update (new modules and permissions etc.), please don't forget to send us a plug number (5-digit number written on the plug).


Note: For the local (white) plug, all operations are performed on the local computer, where the plug is connected. For the network (red) plug, all operations are performed on the plug server computer, where the plug is connected (it means operations performed physically logging into the computer, **not through Remote Desktop** etc.).

To update plug using plug update file

1. If the file you received is a ZIP archive, first extract it.
2. Run the **WclnCf** utility from **A.L.D. Engineering** program group in the **Start** menu (or run **Wclntcfg.exe** file from your RAM32/BIN/ folder) on the computer where the hardware plug is **physically attached** to the computer parallel or USB port and the RAM Commander or HASP License Manager is installed. **Do not use Remote Desktop** utility for it.
3. Choose **Edit by file** from the **Configuration** menu.




4. Browse to the required directory and select the received file.



5. Click **OK**. The Plug configuration is updated.

To update plug using plug update data received by FAX

1. If the file you received is a ZIP archive, first extract it.
2. Run the **WclnCf** utility from **A.L.D. Engineering** program group in the **Start** menu (or run **Wclntcfg.exe** file from your RAM32/BIN/ folder).
3. Choose **Edit by command line** from the **Configuration** menu.




4. Enter the line from the file and click **OK**.
5. If the file contains additional lines, repeat steps 3 and 4 for the next lines. The Plug configuration is updated.

3.4.1.2 Reporting plug configuration


To report current plug configuration

Note: For the local (white) plug, all operations are performed on the local computer, where the plug is connected. For the network (red) plug, all operations are performed on the plug server computer, where the plug is connected (it means operations performed physically logging into the computer, **not through Remote Desktop** etc.).

1. Run the **WclnCf** utility from **A.L.D. Engineering** program group in the **Start** menu (or run **Wclntcfg.exe** file from your RAM32/BIN/ folder).
2. Choose **Display** from the **Configuration** menu.



3. The following screen appears:



4. Copy the screen to the clipboard (by pressing the **Alt+Print Screen** keys) and paste it in the email message (pressing **Ctrl+V** in the body of the message) or into Word document/ Paint image and then save and attach this image to your email.

3.4.2 Network USB plug

Network USB plug contains purchased number of licenses, which may be used simultaneously and concurrently by multiple RAM Commander users.


Network USB plug should be physically connected to a computer which is always connected to the network and available to all other RAM Commander user computers. "License Manager" software (Windows Service) should be installed and running on this computer.

Before the installation, select a computer to act as the "plug server". The network plug must always be attached to this computer so that users can access RAM Commander. The plug server does not need to be the application server - any other server or workstation will do. The only requirement is that this PC must be switched on whenever someone is using RAM Commander. Plug server and RAM Commander network server could reside on the same PC.


Note Only an authorized network administrator should perform this installation procedure.

The installation procedure is provided below:

1. Choose Plug Server PC.
2. Connect Network plug to the USB port of the Plug Server computer.
3. Run HASP License Manager Setup utility - Run the program Imsetup.exe from the RAM Commander installation CD "\HASP\Servers" folder with the latest version number in folder's name. You may also download the License Manager Setup from our website: http://www.aldsoftware.com/download/download/HASP_LM_setup.zip
4. Choose option to install it as Windows Service - see the picture below:



5. Proceed with the installation, selecting default options.
6. Choose to start the HASP License Manager immediately:



7. After the successful installation, License manager service will be installed and started automatically. RAM Commander users may run their software using network plug.
8. Install Plug Monitor (Optional) - If there is a need to monitor real-time plug status (how many active users connected, who exactly is connected etc.) the Plug Monitor software may be installed – run the setup from RAM Commander installation CD:
HASP\MONITOR\AKSMON32.EXE.

See the [Troubleshooting](#) paragraph for information about different NetHASP plug problems solution. See [Updating plug configuration](#) [Reporting plug configuration](#) and paragraphs for information about updating, checking and reporting your plug configuration (allowed modules, number of licenses etc.)

Plug update on a virtual server

If your plug server is a virtual machine and you can't perform plug update operations physically on this server PC as required by instructions, you may use another PC and the following procedure:

1. Install RAM Commander (Standalone configuration) on the selected PC (or use any PC with RAM Commander already installed).
2. Install HASP driver: <http://www.aldsoftware.com/download/download/HASPUserSetup.exe>
3. Take the red USB plug from the server and insert into the USB port of the selected PC.
4. Proceed to the required procedure - [Updating plug configuration](#) or [Reporting plug configuration](#).
5. Return the plug back to the server.

3.4.3 Local License File


License file is placed on PC where RAM Commander is installed. It grants access to RAM Commander to this PC user only and can't be exchanged between computers.

License file performs unauthorized software copy protection and locks RAM Commander installation


to your PC. To get the license file, you should use supplied License Manager Utility to create a "site code" file. You should send the site code file to your software vendor, and he will create and supply a valid license file locked to your PC and containing purchased software options and modules.

To initiate the license file

1. Click the **Start** menu; choose **Programs** and then **A.L.D. Engineering**.
2. Open Tools submenu, run Licensing Wizard utility. Select "Computer-Locked License File" option, press "Next":



3. The following dialog box appears:



4. Click **Generate site code**. You will receive a message providing you with the file name containing your site (computer) code.
5. Send this file to your software vendor (or support@ald.co.il). Please write also your full name, company name and contact information.
6. You will receive an e-mail containing your RAM Commander license file.
7. Save your license file to RAM Commander installation folder, BIN subfolder (usually C:\RAMC32\BIN).
8. You may run RAM Commander now.


Note If you plan to change software (Operating System) or hardware (whole computer or hard drive or motherboard or processor) on the computer where RAM Commander is installed, you should delete your license before (using License Manager Utility) and send us the license delete confirmation file. After the changes are completed, you should repeat the site code generation and send us the new site code - then you will be able to receive a new license.

3.4.3.1 Deleting license


If you are going to perform hardware changes or wish to transfer ALD Software from one PC to another, you should delete the existing license first and send us the delete confirmation file. When the hardware changes are performed or software is installed on the new PC, you should perform the site code generation procedure again and send us the new site code file. This way we will know that the old license is deleted and will provide you with the new license.

To delete existing software license file:

1. Click the Start menu; choose Programs and then A.L.D. Engineering.
2. Open Tools submenu, run Licensing Wizard utility. Select "Computer-Locked License File" option, press "Next":



3. The following dialog box appears:



4. Click "Delete license". You will receive the message providing you with the file name containing your license delete confirmation file.
5. Send this file to your software vendor (or support@ald.co.il). Please write also your full name, company name and contact information. We will register that you license is deleted – then you


will be able to get a new license file instead of the deleted one for another computer or another system configuration later.

3.4.3.2 Sending License Report


License report helps with troubleshooting of problems with ALD Software computer-locked license. Send us the report with the description of your problem if you got license-related error or warning messages from ALD Software - like "Plug not found" or "License expired".

To generate the license report:

1. Click the Start menu; choose Programs and then A.L.D. Engineering.
2. Open Tools submenu, run Licensing Wizard utility. Select "Computer-Locked License File" option, press "Next":



3. The following dialog box appears:



4. Click "Generate license report". You will receive the message providing you with the file name containing your license report.
5. Send this file to your software vendor (or support@ald.co.il) together with your problem description.

3.4.4 Network License File

Network License file contains purchased number of licenses, which may be used simultaneously and concurrently by multiple RAM Commander users.

Network License file should be placed on the computer which is always connected to the network and available to all other RAM Commander user computers. "ALD License Manager" software (Windows Service) should be installed and running on this computer.

Before the installation, select a computer to act as the "license server". The License server does not need to be the application server - any other server or workstation will do. The only requirement is that this PC must be switched on whenever someone is using RAM Commander. License server and RAM Commander network server could reside on the same PC.


Notes:

- a. Only an authorized network administrator should perform this installation procedure.
- b. License Manager installation requires **administrative privileges**.
- c. If you install License Manager on a Virtual Machine, set **MAC address to Static** (not Dynamic) before LM installation:




The licensing server installation procedure is provided below:


1. Choose License Server PC.
2. DOT.NET Framework 2.0 is required - if it is not installed download it from Microsoft website or run it from RAM Commander installation CD - \RAMC\Tools\dotnetfx20.exe. You may also download it from our website: <http://www.aldsoftware.com/download/download/dotnetfx20.exe>.
3. Run ALD License Server Setup utility - Run the program ALDLicenseMngrServiceSetup.msi from the RAM Commander installation CD "HASP\ALDLicenseManager" folder. You may also download it from our web site: <http://www.aldsoftware.com/download/download/ALDLicenseMngrServiceSetup.msi>.
4. Setup wizard will guide you through the setup process - press Next on the first screen:



5. Choose license manager installation folder:




6. Press Next on the next screens. Press Close on the final screen:




7. ALD License Manager Windows Service and ALD License Manager Monitor will be installed.


8. ALD License Manager Monitor will be started immediately:




- License manager service will communicate with RAM Commander workstations using shared folder placed on the license server - "Working folder".
By default it is "C:\ALDLicenseServer". This folder should be shared, visible and available for writing for all RAM Commander users.
Change this working folder if required: press the "Browse" button, select the desired folder (or just enter the folder name in the "Working folder" field) and press "Save settings" button.
- Working folder should be shared with full control access rights to all RAM Commander users.
Share the working folder and grant "Full Control" access rights to this share:



11. Press "Generate Site Code" button. Site code file containing unique identification of your License Server PC will be generated in the working folder:



12. Please send this site code file to ALD Software (support@ald.co.il) or your software vendor.
13. We will generate and send license file back to you - put it to the working folder.
14. Press "Start Licensing Server" button. Service Status and License status indicators should appear in green and show "Ok" and "Active" state:




Press "Refresh" button several times if service status is not switching to green.

On the license server monitor screen you may find also other useful information like number of available concurrent licenses, number (and full list) of currently connected users, number of unique users etc. You may use the ALD Licensing Service Monitor utility on the licensing server to monitor license status, see number of connected users, see list of currently connected users ("Connected users" button) and perform maintenance of the license - report license status, delete license etc.


15. Now the server is configured. The next step is to configure workstations to use ALD License Manager. This configuration should be done on any one of workstations (in case of client/server installation) or on each PC with RAM Commander installed as standalone application.

To configure workstations to use ALD License Manager:

1. Log into PC with RAM Commander installed in Workstation or Standalone (Single user) mode.
2. Select "Licensing Wizard" from Start->Programs menu, "ALD Engineering" group, "Tools" folder.
3. The Licensing Wizard utility screen will appear. It will help you in license configuration:



4. Select the option "Network floating license file".
5. Press the "Next" button - the next wizard step will appear:



6. Press the "Browse" button and open the license manager shared working folder on the license server, select the ServerLicense.cfg file which should be located in this folder and press Ok. Then


press the "Save&Close" button to finish the configuration.

Now you may start working with RAM Commander software.

3.5 Running RAM Commander

When RAM Commander is installed and license is installed and configured, you may start using the software.

New Start menu program group will be created by RAM Commander Installation Wizard called "ALD Engineering":




Six new icons will be added to your shortcuts in the ALD Engineering program group as the result of the installation process:



- RAM Commander – click to run RAM Commander Application.
- User Manager – click to change the name of the system manager.
- Licensing Wizard – used to configure license (create a site code for computer-locked licensing etc.)
- HASP Plug Manager – use when you need to update the USB plug configuration.
- Configuration Report – click to create a RAM Commander configuration log, send it to RAM Commander support team if you report a bug or problem
- HASP Plug Driver – USB plug driver (it is installed automatically but sometimes there is a need to re-install it manually)


You may copy the RAM Commander icon to your desktop to create a convenient shortcut for running the software.

To run RAM Commander

1. From the A.L.D. Engineering program group, choose the RAM Commander icon ; the Login dialog box appears:



2. Enter your user name and password.
3. Choose OK; RAM Commander welcome screen appears:



4. Choose one of recently used projects,
or
choose "Open DEMO TUTORIAL project" button to open the TUTORIAL project,
or
close this window and choose "Open drive" from the Drive menu to get the list of projects on specific drive. Then select the drive where your project is located and press Ok. List of projects on this drive will appear. Here you may open existing project or create a new one.

See "[Working with Projects](#)" and other chapters for instructions on navigating through a RAM Commander project.

3.6 Major Upgrade

RAM Commander Upgrade is required if you wish to install newer RAM Commander version over existing older RAM Commander version. (If you wish to upgrade to newer Service Pack of the same version - see [Minor Update](#) paragraph later in this chapter). The procedure slightly differs depending on current RAM Commander installation configuration (standalone or client/server). Next paragraphs explain the upgrade procedure for each configuration type:

- [Standalone Configuration - Upgrade](#)
- [Network Configuration - Upgrade](#)


It is highly recommended to perform RAM Commander installation folder and database backup before the upgrade. It could be done by backing up the whole RAM Commander installation folder - local (e.g. C:\RAMC32) for the local installation and server-located RAM Commander installation folder (e.g. D:\APP\RAMC32) for the client/server installation.

Note: RAM Commander upgrade procedure does not require license upgrade; all installed licensing components should continue working after RAM Commander update without any changes.


3.6.1 Standalone Configuration - Upgrade

Note: RAM Commander installation requires **administrative privileges**. Make sure you are logged in with administrative privileges before installing RAM Commander. Make sure RAM Commander users have full access rights to RAM Commander installation folder.

1. Check where the current RAM Commander is installed. Usually it is C:\RAMC32.
2. Run installation package of the newer RAM Commander version.
3. If it displays dialog offering to Modify/Repair/Remove the previous version, choose "Remove", proceed with the removal procedure and run the newer version installation package again. Removal procedure will not remove your data, just the older software modules.
4. Choose "Single user installation" on "Setup type selection" screen:



5. Choose the same folder where the previous version was installed on the next screen:



6. Proceed with the next screens of installation procedure, clicking "Next".
7. New version will be installed.

3.6.2 Network Configuration - Upgrade


Network installation consists of server and workstations. Server should be upgraded first, then all workstations.

Note: RAM Commander installation requires **administrative privileges**. Make sure you are logged in with administrative privileges before installing RAM Commander. Make sure RAM Commander users have full access rights to RAM Commander installation folder.


I. Server Upgrade

Server upgrade procedure should be run from the server PC.

1. Log in into the server PC with administrative privileges. (Server upgrade procedure should be run from the server PC.)
2. Make sure that all RAMC users are disconnected (there are no running RAM Commander workstation instances on user computers).
3. Check installation folder of the current RAM Commander version. Usually it is C:\APP\RAMC32, where C:\APP folder is shared for all workstations.
4. Run installation package of the newer RAM Commander version.
5. If it displays dialog offering to Modify/Repair/Remove the previous version, choose "Remove", proceed with the removal procedure and run the newer version installation package again. Removal procedure will not remove your data, just the older software modules.
6. Choose "Server" installation type:




7. Choose folder where the previous version server components were installed:




8. Proceed with the rest of the setup process.

II. Workstations Upgrade

1. Log in into the workstation PC with administrative privileges.
2. Run installation package of the newer RAM Commander version.
3. If it displays dialog offering to Modify/Repair/Remove the previous version, choose "Remove", proceed with the removal procedure and run the newer version installation package again. Removal procedure will not remove your data, just the older software modules.
4. Choose "Workstation" installation type:



5. Choose the folder where the previous version components were installed (it is folder C:\APP\RAMC32 on the server. C:\APP should be shared and mapped as network drive on a workstation with the same letter, for example R:. Then required destination folder of workstation installation will be R:\RAMC32):



6. Proceed with the rest of the setup process.

7. Perform this procedure for all workstations.

3.7 Minor Update

RAM Commander Minor Update is required if you wish to install the latest RAM Commander **Service Pack** for your version.

The procedure slightly differs depending on current RAM Commander installation configuration (standalone or client/server):

- In case of Standalone configuration the procedure is performed in each PC with RAM Commander in standalone configuration installed.
- In case of Client/Server configuration the procedure is performed in any one workstation PC connected to the common server.

Service Pack installation procedure itself is described below:

1. Run installation package of the RAM Commander Service Pack.
2. The Installation Wizard will go through a sequence of the setup screens asking the user to make the appropriate selections - just press Next button on each screen without any changes.
3. Installation Wizard will copy files and display final dialog with "Finish" button - press Finish.


Note: RAM Commander installation requires **administrative privileges**. Make sure you are logged in with administrative privileges before installing RAM Commander.

3.8 Uninstall or Modify

The user may modify the RAM Commander configuration adding or canceling modules, as well as uninstalling the RAM Commander.

To uninstall or modify the RAM Commander installation

1. From the **Start** menu, choose **Settings** and then **Control Panel**
2. Double click the **Add/Remove** programs icon.
3. From the list of the installed programs, select RAM Commander for Windows, and choose the **Add/Remove** button.
4. The Installation Wizard displays the following dialog box:



5. Choose the desired option and follow the Installation Wizard instructions.


3.9 Install Component Library

After installing RAM Commander, install the component libraries purchased (optional). There are two Component Library installation modes:


- **Overwrite Library** – use this mode if you are a new user. The existing library (for a new user - a default, empty file) is overwritten with the library from the enclosed disk. Once you start the library installation process, you will not be able to recover your original library.
- **Merge Library** – use this mode if you already have a library of your own. The library from the enclosed CD is appended to the existing library in your RAM Commander package. In this case, the information in your current library is not erased.

To install libraries

1. Run RAM Commander. (If RAM Commander is already running – close all windows.)
2. From the **Library** menu, choose **Archive**:



3. The Backup-Restore Data dialog box appears:



4. In the Backup - Restore Data dialog box, do one of the following:
 - To install the library and erase your existing library - choose the **Restore with overwrite** option button.
 - To append the new library to your existing library, choose the **Restore with merge** option button.
5. In the list box with library names, select the Component library and Cross Reference and choose **OK**.
6. In the Restore Library dialog box, browse to the file located on RAM Commander installation CD - \RAMC\LIBRARY\GLOBAL.RMW (or the same file downloaded from our web site using the link below and authorization code provided by ALD/software vendor: <http://www.aldsoftware.com/download/download.aspx?id=57>. Download and store this file on your local hard drive first).
7. Choose **OK**.

RAM Commander updates your current libraries with the latest version using the mode selected in step 3 above.

3.10 Administration

RAM Commander Administration includes users management, project management, permissions management, global libraries management and global RAM Commander settings management.

RAM Commander provides a rich, system-wide environment that ensures uniformity and simplicity. All users have access to uniform data, project trees and evaluation methods. This system-wide environment provides simplicity in that global changes are instantly available to all users. The RAM Commander system environment includes global component library, cross reference library, GPRD (Failure Rate tables) Library, Calculation Defaults.

Whoever installs RAM Commander automatically becomes the **System Manager**. During the installation process, use the Edit user parameter dialog box to assign a user with system manager capability. The system manager's password and group may be changed at any time. (You can use the User Manager external utility to change the system manager).

Only RAM Commander System Manager may manage users and global libraries.


The next paragraphs explain how System Manager may add users, change their permissions, backup/restore projects and more.

3.10.1 Users Management

The system manager may create additional users, change their passwords, group assignments and levels of expertise.

To review users and their definitions:

1. Open RAM Commander, close all windows and list of projects to leave only the main application frame:



2. Select "**User Administrator**" from the Administration menu.
3. RAM Commander displays the User Administrator list:




The list displays users with level, name and group of each user.

An icon appears to the left of each user name showing the user's expertise level:

Icon	User Level
	System Manager
	Expert
	Advanced
	Beginner

To create a new user

1. Open User Administrator window
2. From the **User** menu, choose **Create**. The Edit user parameters dialog box opens.



3. Enter the user name, password, group and level.
Name and Password should be alphanumeric characters.
Group is used later for permissions assignment (e.g. all group members may get permissions to use some project).
User level is currently not used.

4. Choose **OK**.

The new user will appear in the User Administrator list.

To edit an existing user

1. Open User Administrator window.
2. Double-click on a user's row in the User Administrator window - the Edit user parameters dialog box opens.
3. In the Edit user parameters dialog box, change the required information (except the name).
4. Press **OK**.

RAM Commander updates the user list. If a user's level is changed, RAM Commander displays the corresponding icon in the User Administrator window.

To delete user

1. Open User Administrator window.
2. Right-click the user's row in the User Administrator window, popup menu will appear.
3. Choose the Delete option, confirm the deletion.

After deletion, RAM Commander displays the updated User Administrator window.

To create a new System Manager


1. Start the User Manager utility from the Start->Programs->ALD Engineering->Tools menu group.
2. Press the "New manager" button.
3. Enter current System Manager password.
4. User data screen will appear.
5. Provide the new manager name, password and group and press Ok.
6. Close the User Manager utility.

The same procedure may be used to change the existing user manager password.
See also [User authentication using AD/LDAP](#) topic later in this chapter.


Each user may change his own password.

To change your own password:

1. Close all open windows in RAM Commander.
2. From Menu, choose Administration->User Administrator->Change User Password:



3. Password changing dialog appears:



4. Type the new password twice.
 5. Press OK.
- Your password will be changed.

3.10.2 Projects Management

Projects may be deleted, backed up, restored from the backup, renamed, copied from one drive to another etc. Administrator may also set up [project permissions](#) separately for each project.

See "[Working with Projects](#)" chapter for more information about RAM Commander projects management.

3.10.3 Libraries and Defaults Management

System Manager has access to RAM Commander Global Libraries and may perform the following functions:

- Updating the Global Component Library
- Updating the Global Cross Reference Library
- Updating the Global Calculation Defaults Data
- Back up libraries and defaults
- Restore libraries and defaults from the backup

See "Libraries and Defaults" chapter for more information.

3.10.4 Settings Management

RAM Commander has several configuration settings which may be changed after the installation:


- Global libraries location and Projects database folder location
- Additional application settings

Global libraries location and Projects database folder location


Several users may use the same shared component library, cross reference and GPRD library. These libraries should be placed on a shared network drive. In case of Client/Server installation it is performed by installation procedure, in case of multiple standalone installation it should be done manually. In any case RAM Commander administrator may change the location of library files. RAM Commander projects may be located on any available local or network drive. By default projects are located in folder RAMC32\PRJ on each drive.

However this location may be changed:

1. Open RAM Commander, close all windows and list of projects to leave only the main application frame:



2. Choose "Data Files Location" from the "Administration" menu.
3. Settings dialog will appear:



4. For each corresponding library type, use "Select" button to point to another existing library file or "Create" button to create a new empty library file at the new location.
5. Change Project files folder location, if required.
6. Press Ok and restart RAM Commander.
7. Repeat this procedure for each RAM Commander installation (workstation or standalone).

Note: you should have read/write access rights to Windows registry (HKEY_LOCAL_MACHINE\SOFTWARE\Advanced Logistics Developments branch) in order to change these settings.

Additional application settings

RAM Commander contains additional application settings stored in RAMC32\BIN\ramc.ini file, such as:

- User Interface "Skin":
 - RAM Commander software "look" is customizable. Users preferring the standard MS Windows look may switch the "skin" off by removing comments from the line " // Skin=NONE" in RAMC32\BIN\ramc.ini file.
 - Advanced users may also select another look by providing MS Windows "skin" file (*.msstyles) – put the file to RAMC32\LIB folder and set Skin parameter in RAMC32\BIN\ramc.ini file to skin file name.
- Regional Settings
- Results formatting options
- User authentication mode (built-in or [Active Directory/LDAP](#))
- and more.

Please see ramc.ini file or contact RAM Commander technical support for more information.

3.10.4.1 User authentication using AD/LDAP

RAM Commander supports two user authentication modes:

- Internal built-in
Users are stored in the internal RAM Commander Database and administrator may manage users (add, remove, password change etc.) using RAM Commander. It is the default authentication mode.
- Active Directory / LDAP
Users are stored in the internal RAM Commander Database but authentication is performed by Microsoft Active Directory. RAM Commander authenticates user against the Active Directory using LDAP protocol/API with optional SSL encryption.

The Active Directory authentication advantage is that this mode ensures that users have the same RAM Commander login credentials as they have in corporate Windows network, and that organizational security policy rules related to passwords (password strength, password regular change etc.) are enforced.

By default, RAM Commander uses built-in users database for authentication. In order to switch to LDAP authentication ramc.ini file located in the RAM Commander installation folder, BIN sub-folder should be updated. The [Authentication] section of the file contains authentication-related parameters, which should be defined to enable LDAP authentication:

Parameter name	Description
AuthType	Authentication type. Set LDAP for LDAP or RAMC for build-in users database (default is RAMC).
LDAPPath	The full LDAP path to Active Directory, for example: LDAP://<server address>:port. By default, ports are 389 for regular connection and 636 for SSL.
LDAPSSL	LDAP Connection encryption: 0-regular or 1-SSL
LDAPCheckGroup	Group Check - if set to 1, login will be allowed only if user belongs to the specified group
AllowedUserGroup	Group name - login will be allowed only if user belongs to the specified group, case-sensitive
DomainSuffix	Constant Domain name suffix - the defined string will be added as suffix to user domain
DefaultUserNameMode	Possibility to offer current MS Windows user name as default in RAM Commander login dialog: 0-no (user login field is empty), 1-Windows user name, 2-Windows domain\user

See the sample part of ramc.ini file with authentication set to LDAP with SSL:

```
[Authentication]
AuthType= LDAP
LDAPPath=LDAP://DC001.NorthWoods.com
LDAPSSL=1
```



```
LDAPCheckGroup=0
AllowedUserGroup=RAMCUsers
DomainSuffix= NorthWoods
DefaultUserNameMode=1
```

Please note that you need to take care of projects and permissions before switching to LDAP. It is possible that the same person has different user name in RAM Commander that his/her user name in LDAP.

Then, if this person has projects with permissions level set to "Owner" or projects locked by that person, he/she will not have access to these projects after changing authentication mode to LDAP (because now he/she will have different user name now).

So, before switching to LDAP, all users should review their projects and "unlock" projects which are locked (green background color) by using the "Select/Deselect" option from the project's popup menu and also change permissions level of their projects (projects where user is an "Owner") to "All".

3.10.5 User Activity Log

RAM Commander records major user activities in the central application activity log file to give system manager better control over system use and information access.

Among logged events are login into the system, log off, project operations (backup, restore, delete, rename), data access (open project, open FTA, open RBD, open Safety module, open Library), import/export operations. For each operation exact time, computer name, user name, target project name and operation description are stored.

Only System Manager may view the User Activity Log.

Here are two options to view the user activity log:

1. Open RAM Commander, close Welcome window, choose "User Administrator" from the "Administration" menu, and select "User Activity Log" option from the "User" menu.
2. Run User Manager Utility from the Start-Programs-ALD Engineering menu and press "User Activity Log" button.

Then the user activity log will appear on the screen in Notepad.

You may clear it periodically if it becomes too large.

3.11 Troubleshooting

This topic provides solution to common problems. The following sections will describe different problems, symptoms and solutions, grouped by problem types.

If you are not able to solve a problem using this troubleshooting guide and need our assistance, please see the instruction below about how to report about your problem:


How to report about troubles with RAM Commander

If all these advices did not help you and you still have problems with RAM Commander, give us more

information about your RAM Commander configuration:

1. Run Configuration report utility:


Run the "Configuration report" utility from Start->Programs->ALD Engineering->Tools menu:



or

Run ConfRep.exe program, located in RAMC32\BIN folder.

2. The program generates file "RAMC32\BIN\ramconf.txt", containing information about system parameters and RAM Commander parameters. You may see the exact file name on the Configuration report utility dialog:



3. Please send this file to RAM Commander support team.
4. If you use client-server configuration, perform this operation on both client and server computers and send both files "ramconf.txt" to us.

Please send us also the precise specification of your problems, error messages and screenshots. Then we will be able to take care of your problem quicker without wasting time on additional questions about RAM Commander version, Windows version etc.

3.11.1 Installation

Problem 1: during or after the installation the error messages appears: "Oper=<11>" "Microkernel error = 11 The specified pre-imaging filename is invalid"

Solution:

The problem is Novell Client v4.91 SP2. Novell accepts this problem and provides a fix.

See the article in Novell Support database for more information: <http://www.novell.com/support/php/>

[search.do?](#)

[cmd=displayKC&docType=kc&externalId=10100441&sliceId=&docTypeID=DT_TID_1_1&dialogID=167515003&stateId=1%20%2083914073](#)

Use this link to download the Novell patch: [http://www.novell.com/support/search.do?](http://www.novell.com/support/search.do?cmd=displayKC&docType=kc&externalId=InfoDocument-2974113&sliceId=&dialogID=42935816&stateId=0%20%2042943684)


[cmd=displayKC&docType=kc&externalId=InfoDocument-2974113&sliceId=&dialogID=42935816&stateId=0%20%2042943684](#)

We suggest that only experienced network administrator should install this update.

Problem 2: during the server installation – after 61% of installation, message appears: “Component transfer error: File *.rra”

Solution:


1. Run the installation, and make sure that the option Hasp Drive (see the picture) is UNCHECKED exactly as it is on the picture:



2. Finish the installation of RAM Commander, but do not run it.

3. From the RAM Commander program group in the Start menu, choose and run program “HDD32”. It will install HASP driver. (installation is described in RAM Commander installation guide).

Problem 3: during the workstation installation message "The following error occurred on file *.rra " and "Access is denied" appears:



Solution:

During RAM Commander workstation you should provide shared server folder where RAM Commander server is installed (like R:\RAMC32). The message above appears when you do not have "Full Control" access rights to this shared server folder and all its sub-folders and files. Grant valid access rights and try again.

Problem 4: RAM Commander can't be completely uninstalled

Solution:

If you want to reinstall RAM Commander, we recommend to uninstall it (with the help of Windows Add/Remove Programs dialog from Control Panel or with the help of RAM Commander installation) and then install it. There could be a problem, when after uninstalling software, installation program gives you option to Remove RAM Commander once more. If you choose option remove, finish removing and start installation once more – you get Modify/Remove option again. To remove the problem:

1. Uninstall RAM Commander,
2. Enter registry (from Start menu, choose Run, type "regedit", choose Ok.
3. Go by the path:
 - HKEY_LOCAL_MACHINE
 - Software
 - Microsoft
 - Windows
 - CurrentVersion
 - Uninstall
4. Choose "Uninstall", press right mouse key, choose "Find"
5. Enter "RAM Commander" and press Enter.
6. Program will find and show you one line in the right part of the screen. Press TAB, cursor will move to the left part of the screen. Press Del, confirm "Yes".

When you start RAM Commander installation again, it will not offer you Modify/Remove option again, but will offer to install RAM Commander – perform the usual installation steps.

3.11.2 Licensing and Plugs

Problem 1: The PC used as a network plug server has Windows 95 operating system, and plug driver should be started manually after server reboot

Solution: On the server, copy NHSRVW32.EXE to the SYSTEM directory in the Windows root directory (c:\WINDOWS\SYSTEM).

Create NHSRVW32.EXE shortcut in the Startup group of the Start menu. (Open Windows Explorer,

find and select c:\WINDOWS\SYSTEM\NHSRVW32.EXE file. Right-click on Start button, choose Explore, open folder Programs, then subfolder Startup. Drag&Drop c:\WINDOWS\SYSTEM\NHSRVW32.EXE file to StartUp folder.)

Restart the computer. Now you may remove installation CD from server, and HASP manager should start automatically after login to windows (please note - not after server OS loading, as in WinNT, but after successful user login).

Problem 2: "HASP Plug can't be found" on Windows 2000, XP

Installation is completed, but RAM Commander can't be started and gives error message about Local and Network Plugs.

Solution:

You should install new HASP plug drivers. If you have our installation CD, open folder "HASP\Driver Ver. 4.99" and start file HDD32.EXE. Install the driver for Parallel port and reboot your computer. If you have no CD, please ask your RAM Commander suppliers for the new plug driver version 4.99. If 4.99 version driver does not help, please try to install HASPUserSetup.exe driver from the installation CD "HASP\Driver HL" folder.

Another option is to download the latest HASP driver from ALD web site: http://www.aldsoftware.com/download/download/HASPUserSetup_6x21.exe.

Problem 3: "HASP Plug can't be found" in segmented network / VLAN

Solution:

License Manager developers give the following solution:

- a) There is a file nethasp.ini.
- b) Place this file to RAMC32\BIN folder.
- c) Open this file with Notepad.
- d) Find section [NH_TCPIP] (line 96), find key NH_SERVER_ADDR = 111.111.111.111,
- e) modify its value to the License server's IP address, for example NH_SERVER_ADDR = 192.114.176.65
- f) save the file

RAM Commander should be able to find the plug.

There could be some more surprises in the network:

The server has more than 1 network adapter

If after steps from a) to f) you still have the same message about "plug not found", and you have a possibility that some computers are connected through other network adapter, do the following:

- g) There is a file nhsrv.ini.
- h) On the server, place this file to license manager folder, where the executable is.
- i) Open this file with Notepad.
- j) Find section [NHS_SERVER] (line 12), find key NHS_ADAPTER_IP, remove ";" comment sign from the left side, and write network adapter data like is shown in comments (<IpAddr-SubMask> [, <IpAddr-SubMask> ...]). Network administrator should assist you.
- k) save the file
- l) reboot the server

If after steps from a) to l) you still have the same message about "plug not found", there could be **problems with server ports**.

You should consult the network administrator about specific ports.

In the file nethasp.ini there are key NH_PORT_NUMBER (exactly after the key NH_SERVER_ADDR we modified in paragraph 3). Remove ";" from the left side and set the TCP/IP port number. This is optional. The default number is 475.

3.11.3 Access to Data

Problem 1: RAM Commander user can't access network drive with projects sometimes ("Fatal error"), when other user(s) are already working with it. If nobody else is working with drive user may access it.

Additional symptoms: Network drive is shared with full access rights. If user is first on the drive he enters successfully. May appear sporadically (depending on the first user who access the network drive). For some user combinations may work, for some user combinations may not work.


Reason:

Second user connecting to the network drive will try to use Pervasive Database Engine of the first user connected to the drive. It will search second user PC and try to access Pervasive Database Engine network service. If second user can't find other user PC (DNS, sub-net, VPN etc.) or can't access other user's Pervasive Engine (Firewall) then the connection attempt will fail.

Solution:

1. Check and ensure that all RAM Commander users may "ping" each other computers by computer name.
2. Check and ensure that Pervasive Database Engine is included into the list of exceptions on all RAM Commander user computers and that Firewall exceptions are not disabled.


Pervasive Database Engine is usually added to the Firewall exceptions list when RAM Commander is installed. Setup procedure gives Windows Firewall Unblock question:




If user answers yes (or Unblock, or Allow Access), Pervasive Engine is added to the exceptions list. For all RAM Commander user computers, perform steps described below:

To check that the Pervasive Database Engine is allowed by Windows Firewall:

- i. Open Control Panel from Start menu, Settings section.
- ii. Open "Windows Firewall"
- iii. If Firewall is off, no need to continue, you may close the Firewall dialog.
- iv. If Firewall is on, make sure that "Don't allow exceptions" check box is empty:



- v. Switch to "Exceptions" tab of the dialog.
- vi. Make sure that there is "Database Service Manager" program in the list:



- vii. If there is no "Database Service Manager", click "Add program" button, then click "Browse" and select W3dbsmngr.exe program in RAM Commander working folder

- (usually RAMC32\BIN). Then press Ok. "Database Service Manager" should now appear in the list of exceptions.
- viii. You may need to provide also access for "Database Service Manager" to TCP ports 3351, 137-139, and 2441.
 - ix. Press Ok on the Firewall dialog to close it and store changes.

Problem 2: All RAM Commander users can't access network drive with projects, users unable to open projects list on a network drive

Additional symptoms: Initially network drive works fine, and then this problem could suddenly appear. Could be accompanied with error message "OPERR=<116> in X:\RAMC32\BIN\DRIVE.DRV". The drive.drv file exists, project folders exist, access to the network shared folder is available with full access rights to all users.

Reason:

Users connecting to the network drive try to use Pervasive Database Engine of the first user connected to the drive. If the first user's Pervasive Database Engine on PC in general is stuck, the described problem will appear. This stuck user's PC should be restarted.

Solution:


1. Try to restart the Pervasive Database Engine which is stuck.
 - a. Open the folder where the projects you can't access are located, for example X:\RAMC3\PRJ.
 - b. Try to open the X:\RAMC3\PRJ~PVSW~.LOC file using Notepad (Windows Explorer, locate file, right click – open).
 - c. You will see a computer name of a PC which acts as Pervasive Gateway and which has problem with Pervasive Database Engine.
 - d. Restart this computer.
 - e. Delete the X:\RAMC3\PRJ~PVSW~.LOC file.
 - f. Try opening the list of projects again.
2. If the previous recommendation did not help, please restart the RAM Commander database server and try again.
3. If the previous recommendation did not help, please ask all the engineers working with RAM Commander to restart their computers.

In addition, it is recommended that the PC where the network drive with shared projects is physically located to have RAM Commander server installed (see [Server Installation](#)) or to have RAM Commander's Projects Network Service installed (see [Standalone Installation + Common Network Database](#)).

Problem 3: RAM Commander installed, but user login name and password were not defined during the installation.

Solution:

1. Run UserMngr utility from Start->Programs->ALD Engineering menu group.
2. Choose "New manager" button. Manager password dialog will appear – just press Ok.
3. "Edit user parameters" dialog will appear:




4. Enter desired user name (password and group fields are optional) and press Ok.
5. Close "User manager" utility
6. Start RAM Commander and enter the user name you've just defined.

Problem 4: Error message with code "3105" after starting RAM Commander. Does not happen when starting RAMC with administrative privileges.

Reason 1: Pervasive Database Engine network protocols are set to support not only TCP/IP (but also SPXII and NETBIOS).

Solution: Manually change Pervasive Database Engine network protocol settings to contain only TCP/IP protocol, without SPXII and NETBIOS, using Windows Registry Editor, as shown below. Open the key HKEY_LOCAL_MACHINE\SOFTWARE\Pervasive Software\MicroKernel Workstation Engine\Version 7\Settings , value name Supported Protocols, and change value data to TCP/IP:



Do it also for key HKEY_LOCAL_MACHINE\SOFTWARE\Pervasive Software\Communications Requester\Version 7\Settings, value name "Supported protocols" (if key exists).

Do it on all RAM Commander workstations, servers or standalone PCs.

Reason 2: No write permissions for Pervasive Database Engine service and log files.

Solution:

We can suggest two options to solve this issue:

1. Give write permissions to C:\Windows\MKDE folder for RAMC users on the RAMC Server (in client/server configuration) and on PC which makes the problem.
2. Change settings in registry for each RAMC workstation.

Find Key HKEY_LOCAL_MACHINE\SOFTWARE\Pervasive Software\MicroKernel Workstation Engine\Version 7\Settings, then change value names:

DBNamesDirectory - <RAM Commander installation folder> (for example C:\RAMC32)

Home Directory - <RAM Commander installation folder>\BIN (for example C:\RAMC32\BIN)

Trace File - <RAM Commander installation folder>\BIN\MKDE.TRA (for example C:\RAMC32\BIN\MKDE.TRA)

Transaction Log Directory - <RAM Commander installation folder>\BIN\MKDE\LOG (for example C:

\\RAMC32\BIN\MKDE\LOG)

Problem 5: Error message with code “OPER=100” while working with large project

Solution: Problem with Pervasive database engine settings - allocated cache size is too small - increase it to 4000000.

Perform the following changes:

1. Press Start button
2. Choose Run
3. Type regedit and press ok
4. Open HKEY_LOCAL_MACHINE group, then Software, Pervasive Software, Microkernel Router, Version 7, Settings (key HKEY_LOCAL_MACHINE\SOFTWARE\Pervasive Software\MicroKernel Workstation Engine\Version 7\Settings)
5. Double click on “Cache Size” key in the right part of the window.
6. Change key value to “4000000” (hex)
7. Press Ok.
8. Restart the PC and continue working.

If this does not help - try increasing the value up to 40000000.

Problem 6: Error message with code “1022” or “1032” after starting RAM Commander

Solution: Problem could appear on Windows 95/98 on RAM Commander workstation. Do the following:

9. Press Start button
10. Choose Run
11. Type regedit and press ok
12. Open HKEY_LOCAL_MACHINE group, then Software, Pervasive Software, Microkernel Router, Version 7, Settings
13. Double click on “Target Engine” key in the right part of the window.
14. Change key value to “0”
15. Press Ok.

Problem 7: Error message with code “8020” after starting RAM Commander

Solution:

In client-server configuration, can appear on client if connection with the server was terminated. User should ensure the server is on, the connection is established (network drive etc.), and reboot the workstation.

Problem 8: Error message “W3DBSMGR: Error 8509: Timeout occurred during the initialization of MKDE” or error message with code “3012” inside it

Solution:

The most common reason of the problem – absence or old version of Microsoft dll files \\WINDOWS\SYSTEM\MSVCP60.DLL and \\WINDOWS\SYSTEM\MSVCRT.DLL. Both files must be present and their creation year must be later then 1998. If you need the files – contact our support service or take them from other computer with the same operating system.

Problem 9: Error 1021

Sometimes happen because there is not enough free space on the system disk (disk where

Windows installed) or insufficient access rights to RAM Commander folders with database files.

Solution:

1. Check free disk space, if low - free some disk space and try once again.
2. Make sure that user has full access rights to RAM Commander installation folder (by default C:\RAMC32\) and all its sub-folders and files on all levels. Just Read/Write permissions are not enough - file creation/deletion, folder creation/deletion should be also allowed, so "Full Control" permissions are required.
3. If previous advices do not help, grant "Full Control" access rights to Windows folder and try again.

Problem 10: Error message "The setup routines for the Microsoft Access Driver (*.mdb) could not be loaded due to system error code 126."**Solution:**

See Microsoft KB article:

<http://support.microsoft.com/default.aspx?scid=kb:EN-US:q260558>

There are two possible causes for this problem:

- Incorrect registry settings for MDAC components.
- Incompatible .dll files.

These problems may have arisen because of an installation of older software that changed the registry settings of the ODBC drivers or replaced some .dll files with incompatible versions.

Resolution for incorrect registry settings problem:

1. Start Registry Editor (Regedt32.exe).
2. Locate the following key in the registry:
HKEY_LOCAL_MACHINE\SOFTWARE\ODBC\ODBCINST.INI
Installation information for ODBC drivers is stored in this key. Make sure that all the required ODBC driver files are in the correct folder as described by the registry keys. For example, assume that you have the following information in your registry for the Microsoft Access ODBC driver:
HKEY_LOCAL_MACHINE\SOFTWARE\ODBC\ODBCINST.INI\Microsoft Access Driver (*.mdb)
Driver = C:\WINNT\System\Odbcjt32.dll
Setup = C:\WINNT\System\Odbcjt32.dll
This will cause an error if the Odbcjt32.dll file is in the C:\WINNT\System32 folder. You can modify the registry key values to C:\WINNT\System32\odbcjt32.dll to solve this problem. Also verify that the Odbcinst.ini file has the correct entries in the same way.

Any wrong value in HKEY_LOCAL_MACHINE\SOFTWARE\ODBC\ODBCINST.INI under the Setup key will cause this error.

Resolution for incompatible .dll files problem:

Reinstall your current version of MDAC, or install the latest version. See the "References" section of this article for more information on reconfiguring an MDAC installation. The latest version of MDAC can be downloaded from the following Microsoft Web site:

<http://msdn.microsoft.com/dataaccess>

Problem 11: RAM Commander works fine for user with PC administrator access rights, but does not work for another user.**Solution:**

The reason is insufficient user rights to access system resources required for RAM Commander. Grant full access rights to the user for the following resources:

Folders:

RAM Commander installation folder (usually C:\RAMC32)
Project folders on all local and network drives where user wishes to store his projects

Registry branches:

HKEY_LOCAL_MACHINE\SOFTWARE\Advanced Logistics Developments
HKEY_LOCAL_MACHINE\SOFTWARE\Pervasive Software

Problem 12: RAM Commander workstation can't start (error 94) or can't access network drive. Also, server alias is used (FQDN or CNAME), server OS is Windows Server 2003 SP1.**Solution:**

Do not use FQDN/CNAME from workstations, but use full not-aliased server name instead. If you still wish to see alias - see the next paragraph.

This problem occurs because Windows Server 2003 SP1 includes a new security feature named loopback check functionality. By default, loopback check functionality is turned on in Windows Server 2003 SP1, and the value of the DisableLoopbackCheck registry entry is set to 0 (zero).

The loopback check functionality is stored in the following registry subkey:

HKEY_LOCAL_MACHINE\SYSTEM\CurrentControlSet\Control\Lsa\DisableLoopbackCheck.

Set this key value to 0 in the registry on the server.

Then reboot the server.

3.11.4 Reporting

Problem 1: MS Word reports generation does not work in Client/Server installation**Additional fault isolation:**

Try running WordRepGenerator.exe application in RAM Commander installation folder, BIN subfolder from the client PC. If RAMC server has shared folder with RAM Commander installed, and this folder is mapped as network drive (e.g. R:) on client PC, then run R:\RAMC32\BIN\WordRepGenerator.exe. If it does not run, copy it to local drive C: and try running it again. If it runs now and program screen appears - the reason is insufficient security permissions for running .NET applications from intranet locations.

Solution:

Grant FullTrust security level to "local intranet" zone or to R:\RAMC32\BIN folder, on all workstations.

The best way to achieve this is to run the following command (using command prompt or Start->Run menu):

```
c:\windows\microsoft.net\framework\v2.0.50727\caspol.exe -cg LocalIntranet_Zone FullTrust
```

Confirmation message will appear - answer Yes.

If you wish to grant FullTrust to the required folder only, issue the following command:

```
c:\windows\microsoft.net\framework\v2.0.50727\caspol.exe -m -ag 1.2 -url file://R:/RAMC32/BIN/* FullTrust
```

Confirmation message will appear - answer Yes.

Then try running R:\RAMC32\BIN\WordRepGenerator.exe from the network again - it should work now.

If you wish to insert such command to batch (login script etc.), use additional commands to switch the prompting off and then on:

```
CasPol.exe -pp off
```

```
c:\windows\microsoft.net\framework\v2.0.50727\caspol.exe -cg LocalIntranet_Zone FullTrust
```

```
CasPol.exe -pp off
```

Problem 2: MS Word reports generation does not work - message about required .NET Framework 2.0 appears.**Solution:**

Install Microsoft.NET Framework 2.0 - take the setup package from ALD Installation CD (\RAMC\Tools\dotnetfx20.exe) or from Microsoft web site (<http://www.microsoft.com/downloads/details.aspx?familyid=0856eacb-4362-4b0d-8edd-aab15c5e04f5&displaylang=en>). Alternative solution for Windows 7 and up - install the Microsoft.NET Framework 4.0 Full from the Microsoft website.

Problem 3: MS Word reports generation does not work, generation window shows message like "Critical failure: Exception generating report: System.Runtime.InteropServices.COMException (...): Bad parameter at Word.Options.set_Pagination..."**Options.set_Pagination..."**

Reason: For some reason, Microsoft Word 2007 automation does not work properly if no user name and initials are defined during the MS Office installation.

Solution:

See Microsoft knowledge base article <http://support.microsoft.com/kb/948682/en-us> : To resolve this issue, add the user name and the initials in the Word Options dialog box. To do this, open the MS Word, click the Microsoft Office Button, click Word Options, enter a user name and initials under Personalize your copy of Microsoft Office, and then click OK.

Problem 4: Error messages while trying to open the generated MS Word document

Reason: Document to be opened contains macros and MS Word security is set to not allow Macros.

Solution: Enable opening documents with Macros in MS Word, or remove Macro commands from default.dot template used to generate the MS Word document from the software.

3.11.5 General Problems

Problem 1: Context-sensitive help does not appear on Windows Vista or Windows 7**Solution:**

Microsoft decided not to support "hlp" format context-sensitive application help files in Windows versions starting from Windows Vista. Use User Manual in "chm" format (run it from Start->Programs->ALD Engineering menu) or download and install the following Microsoft update:

For Windows Vista: <http://www.microsoft.com/downloads/details.aspx?familyid=6EBCFAD9-D3F5-4365-8070-334CD175D4BB&displaylang=en>

For Windows 7: <http://www.microsoft.com/downloads/en/details.aspx?FamilyID=258aa5ec-e3d9-4228-8844-008e02b32a2c&displaylang=en>

3.12 Summary

In this chapter you found out how to get started, install and run the program and libraries, about security plugs, upgrades and uninstalling the software.

Chapter

4

RAM Commander Concepts

4 RAM Commander Concepts

This chapter deals with the Reliability, Availability, Maintainability and Safety analysis process using **RAM Commander**, the principles of RAM Commander module organization and RAM Commander data management.


4.1 RAM Commander Process

The Reliability, Availability, Maintainability and Safety analysis process using **RAM Commander** software comprises of multiple stages, some of them optional:

1. [Project Creation](#)
2. [Product Tree Building](#)
3. [Reliability and Maintainability Calculations](#)
4. [Reliability Analysis](#)
 - a. [Pareto](#)
 - b. [Mission Profile](#)
 - c. [Temperature Curve](#)
5. [Reliability and Availability Modeling](#)
 - a. [RBD](#)
 - b. [Markov](#)
6. [Failure Analysis](#)
 - a. [FMECA](#) with Testability Analysis
 - b. [FMEA](#)
 - c. [FTA](#)
 - d. [ETA](#)
7. [Safety Analysis](#)
 - a. FHA
 - b. SSA
 - c. Hazard Analysis
 - d. [MMEL](#)
8. [Additional analysis types](#)
 - a. Derating/Stress Analysis
 - b. [Spare parts optimization](#)
 - c. RCM
 - d. MSG-3
 - e. [Reliability Growth](#)

- f. Dispatch Reliability
- 9. [Next steps/recurrent analysis \(DLCC, FRACAS\)](#)


The diagram below illustrates the RAM Commander process:



Next paragraphs provide detailed explanation of the process stages.

4.1.1 Stage 1: Project Creation

Project is the major information unit in RAM Commander. Project is a sort of a "briefcase" containing all the information, available analysis types and cases, diagrams, calculations, predictions and reports for specific system, product or equipment unit. This way different analysis types may be conducted separately or benefit from the integrated environment and common database, sharing data between them.



Name	Description	Owner	Owner group	Locked By	Date	Project group
RAMC_PRJ_OVERV		ALD			2010.03.01	
S18_AIRCRAFT	Safety Assessment Process Example	SVETA	ALD		2010.06.01	Tutorial
SAFETY_NEW	qweiou tio[qweru io[qweru io[wery io[wery	ALD			2010.06.17	
TANK_SAMPLE		MOTI			2010.03.01	Tutorial
TUTORIAL	Communication System	ALD	ALD	ALD	2010.06.28	TUTORIAL
TUTORIAL_DISPREL	Dispatch Reliability testing and demo	ALD			2010.05.24	TUTORIAL
TUTORIAL_MMEL	Sample project with MMEL analysis	SVETA	ALD		2010.06.23	TUTORIAL
TUTORIAL_MSG3	Sample project with MSG3 analysis example	ALD			2010.06.01	Tutorial
TUTORIAL_NOKIA		ALD			2010.06.22	
TUTORIAL_VALVE		ALD		ALD	2010.06.14	TUTORIAL
VALVES		RAFI	ALD		2010.06.01	

Projects may be backed up, sent by email, restored, placed on your local or network drive. Multiple users may work with the same project simultaneously over the network. Administrator may set up project access permissions. You should create a project in order to start building the Product Tree or use any one of available analysis types.

4.1.2 Stage 2: Product Tree Building

Inside the project, **Product Tree**, or Bill of Materials should be built. It represents full hierarchical product/system structure from main subsystems to the smallest blocks and components like springs, capacitors and resistors, with detailed information about each block or component.

Ref.Des.	ID	Name	Qty	Opr. FR [10 ⁻⁶]	Status
TUTORIAL	1	Communication System	1	187.0768	++
Communic	1	COMM001	1	100.2550	++
Main Switch	1	SW888	2	8.7416	++
U1	1	8086A	1	0.2442	++
U9	2	80C88	1	0.0000	--
U10	3	80C31	1	0.0862	++
U12	4	LM299	1	0.0625	++
U13	5	74LS30	1	0.0367	++
R1-10	6	RLR	10	0.0890	++
R11-12	7	RN	2	0.0365	++
R30-34	8	RZ	5	0.0849	++
CC1	9	CK	1	0.0619	++
CC2	10	CK	1	0.0619	++
CC3	11	CK	1	0.0595	++
CC4	12	CK	1	0.0607	++
CC5	13	CK	1	0.0614	++
L0-4	14	HLMP-2450	4	0.0144	++
L5-6	15	HLMP-2400	2	0.0072	++
Sw1-2	16	DP2	2	3.1361	++
Receiver	2	RC004	10	82.8214	++
Transmitter	3	TR987-001	1	0.3419	++
PS	4	Power Supply	1	8.3500	Us
Control	2	Control Unit	1	75.4953	++
Pedestal	3	PD001	1	11.3265	++

During the *product tree building* phase, enter or import the product tree. Using a top-down process, you decompose the system into a tree of assemblies, subassemblies and components. For each element in the tree, define all required parameters such as environment, reference designator, part number and quantity. RAM Commander increases your productivity by allowing you to retrieve data from various external sources, such as:

- Import of CAD files of most commonly used file types, such as: ASCII, MS Excel, MS Access, Mentor Graphics etc.
- Predefined sets of default values
- Component libraries

4.1.3 Stage 3: Reliability and Maintainability Calculations

RAM Commander performs *reliability* and *maintainability calculations*. You can allow the calculation to span the entire product tree, or restrict the calculations to a particular item (component or block) or part of a project (sub-tree). More than 30 different calculation methods/standards are supported, like MIL-217, Telcordia, FIDES, GJB299, 217 Plus, NPRD-95 and more.

IC Digital MIL-HDBK-217FN2

Ref. des.: U9 QTY: 1 ENV: GF Temp: 51.7 °C

Part name:

Mil. num.:

Cat. num.:

Generic name: 80C88

Type: Microprocessor

Tech: NMOS # of bits: 16

of gates: --- Range: ---

Range: --- # of Pins: 40

Package: DIP Herm w/Solder,Weld Seal

VHSIC / VLSI CMOS

Manufacturing Process: ---

Die Area: ---

FeatureSize: ---

Vth: ---

Years in production: ---


Quality: ---


PI q: ---

1: --- 2: --- 3B: --- 3S: ---







4: --- 5: --- 6: --- 7: ---

8: --- 9: --- 10: --- 11: ---

Delta T_{jc}: --- or  ---


 ---

Lead Configuration: --- Distance: --- (mils)

    54HC00 54HC08 54HC36  54F280 68000 80386 


4.1.4 Stage 4: Reliability Analysis

RAM Commander displays analysis and prediction results in a wide variety of *reports* and *graphs*. You can export these reports to such programs as MS Word, or spreadsheet programs like MS Excel, for a customized analysis. You may find components with largest contribution to product MTBF, examine system behaviour under different environment conditions and temperatures, analyse product mission reliability and more.




4.1.5 Stage 5: Reliability and Availability Modeling

RAM Commander provide tools to model system reliability and availability using **Reliability Block Diagram (RBD)**, specifying different redundancy models (serial, parallel and K-out-of-N) and calculating reliability/availability and MTBCF:



Markov module allows system states and transition between states modeling with calculation of availability, reliability, downtime/uptime, performance etc:



Both RBD and Markov modules may use product tree data and reliability/maintainability analysis results.

4.1.6 Stage 6: Failure Analysis

RAM Commander contains multiple **failure analysis** methods:

FMECA (MIL-STD-1629A, GJB 1391, GJB 1392 etc.) with Testability Analysis

Ref.Des.	ID	Name	Qty	Opr. FR [10 ⁻⁶]	Status	MTBF	Temp.
TUTORIAL	1	Communication System	1	187.0768		5345.398	35.0
Communic	1	COMM001	1	100.2550		9974.567	35.0
Control	2	Control Unit	1	75.4953		1.3E+004	25.0
Monitor	1	MON001	1	8.0000		1.3E+005	25.0
Keyboard	2	KB003	1	17.0000		5.9E+004	25.0
SystemBlock	3	MB665	1	50.4953		2.0E+004	25.0
HardDrive	1	HDD002	1	11.4844		8.7E+004	25.0
CD-ROM	2	CD98AB1	1	14.4300		6.9E+004	25.0
Floppy	3	F99	1	12.5810		7.9E+004	25.0
MotherBrd	4	MB00887	1	12.0000		8.3E+004	25.0
Pedestal	3	PD001	1	11.3265		8.8E+004	35.0
Antenna	1	ANT555	1	6.6583		1.5E+005	35.0
Motor	2	MOT978	1	4.5000		2.2E+005	35.0
Bearing	3	B0896	1	0.1682		5.9E+006	35.0


#	FM			NHE		EE			Detection	Con p
	Description	Alpha	Cause	IDN	Description	Beta	Description	Beta		
1	Bearing Failure	0.280	...	1.1	No movement	1.000	Communication Loss	1.000	II	Visual Inspection
2	Fail Run After Strt	0.230	...	1.1	No movement	1.000	Communication Loss	1.000	II	Visual Inspection
3	Fails to Start	0.180	...	1.1	No movement	1.000	Communication Loss	1.000	II	Noise receive test
4	Winding Failure	0.310	...	1.1	Wrong movement	1.000	Communication Degradation	1.000	III	...

Process/Design **FMEA** (AIAG, QS-9000, SAE J 1739, IEC 60812, JEP131)


#	Potential FM	End Effect of Failure	Severity	Cause	Occurrence	Controls	Detection	RPN
1	Users report often system crashes	Impossible to work	9	Hardware is not stable	3		10	270
				Operating system is not stable	4		10	360
				OS configuration is invalid	7		10	630
2	Users report often physical damages	Equipment is not reliable	10	The equipment is not armored	7	Check armor	1	70

Fault Tree Analysis - deductive analysis performed to determine all combinations of events leading

to a single general conclusion or hazard/failure.



Event Tree Analysis - inductive failure analysis performed to determine the consequences of single failure for the overall system risk or reliability.




Mentioned failure analysis methods may use product tree data and reliability/maintainability analysis results.

4.1.7 Stage 7: Safety Analysis

RAM Commander **Safety** module helps to perform Functional Hazard Assessment, Preliminary Hazard Analysis, System Safety Assessment, System Hazard Analysis and other analysis types required by different standards (SAE ARP 4781, MIL-STD-882D, AFO etc.).

It allows building functional tree and performing qualitative analysis by defining all possible failure conditions and their consequences. Then it allows performing quantitative analysis, calculating probabilities of all failure conditions using FTA module.



4.1.8 Stage 8: Additional Analysis Types

RAM Commander contains also additional analysis types, like Stress analysis, Spare parts, RCM/MSG-3, MMEL, Dispatch Reliability, Weibull and more.


4.1.9 Stage 9: Next steps/recurrent analysis

After all the required analysis types are done in RAM Commander, all the required reports are printed out, your product is designed, analyzed and certified as reliable and safe, RAM Commander may do for you the following:

1. Export product data to product monitoring/failure reporting system like ALD **FRACAS**.
2. Export product data to life cycle cost decision making software like ALD **DLCC**.
3. **Reuse** the project data for next versions/revisions of your product or for similar product/system analysis.
4. Perform **recurrent analysis** on the same system, based on some new requirements or field data coming from failure reporting system (for example, import real field failure statistics and perform reliability analysis, FMECA, safety analysis etc. based on real MTBFs instead of predicted ones).

4.2 RAM Commander Data Flow

The diagram below provides illustration to the RAM Commander process and explains the data flow between different available analysis types and software modules:



The described data flow is possible due to RAM Commander module integration and common data use by the modules:


- Reliability (for both Operating and Non-operating mode), Maintainability and Stress Analysis use the same common Product Tree.
- FMECA module is based on the same product tree as reliability/maintainability analysis
- RBD module blocks may be linked to Product Tree items and their FMECA Failure Modes, using their calculated MTBF and MTTR.
- Spare Parts module uses the same Product Tree and Reliability/Maintainability calculation results.
- FTA module Basic Events may be linked to Product Tree items and their FMECA Failure Modes, using their calculated MTBF and MTTR.
- Safety Module uses Fault Trees for failure conditions probability calculation.

4.3 RAM Commander Data Organization

Project is the major information unit in RAM Commander. Project is a sort of a "briefcase" containing all the information, available analysis types and cases, diagrams, calculations, predictions and reports for specific system, product or equipment unit.

RAM Commander database may contain multiple projects located on multiple local and network drives, project libraries and global libraries. Each project contains data for performed analysis types (reliability, FTA, Safety etc.). Each project contains its own libraries (reliability, FMECA, FTA Events etc.). All projects share common ("Global") libraries - component reliability data, cross reference, calculation defaults etc.

The diagram below explains the RAM Commander database organization:



4.4 Summary

In this chapter you saw the basic **RAM Commander process**, from product tree building and data management to output reporting.

Chapter

5

**RAM Commander
Fundamentals**

5 RAM Commander Fundamentals

This chapter deals with the basic tools repeatedly used in accessing and navigating through RAM Commander data: list of projects, the product tree view, project data lists, report etc. As these tools are used throughout RAM Commander, a familiarity with them will allow you to work quickly and efficiently.

RAM Commander provides maximum flexibility for best exploiting the time devoted to reliability and maintainability studies. The extensive library structure, combined with window and graphic interfaces, ensures productivity, efficiency and consistency.

The next paragraphs will explain in brief main RAM Commander User Interface elements such as Windows, Toolbar, Status bar, Lists and more.

5.1 Windows

RAM Commander User Interface type is MDI - Multi Document Interface. You may open multiple windows at the same time, switch between windows, arrange and close them. You may drag&drop and copy/paste information between certain window types.

The screenshot displays the RAM Commander software interface with several windows open:

- Project Tree:** Shows a hierarchical view of the project structure, including 'TUTORIAL', 'Communic', 'Main Switch', and various components like 'U1', 'U9', 'U10', etc.
- Current Analysis:** A table listing components and their status.

Ref.Des.	ID	Name
TUTORIAL	1	COMMUNOC
Communic	1	COMMOC
Main Switch	1	SW888
U1	1	8086A
U9	2	80C88
U10	3	80C31
U12	4	LM299
U13	5	74LS30
R1-10	6	RLR
R11-12	7	RN
R30-34	8	RZ
CC1	9	CK
CC2	10	CK
- Graph Generator for RAM Commander, version 3.0:** Displays a 3D donut chart titled 'Pareto analysis (by item type)'. The chart shows the following data:

Item Type	Percentage
Capacitor	42.2%
Antenna	44.8%
Switch	3.6%
IC-Digital	3.4%
Motor	2.6%
Other	2.4%
Other	1.1%
- FTA Tutorial for Project TUTORIAL on Drive C:** Shows a Sample Fault Tree diagram for the project, detailing failure modes and their probabilities.
- RBD Standard for Project TUTORIAL Drive C:** Shows a Reliability Block Diagram (RBD) for the project, illustrating the system's reliability structure.

Working with RAM Commander you will typically have Projects List window and main project view window (Product Tree, or Bill of Materials) open, and also you may open additional project windows like FTA diagram, RBD diagram etc. Windows belonging to different projects may also be opened simultaneously.

Apart from the usual Windows features referred to below, the advantage of working with RAM Commander is that you can work on several parts of the project or with many projects in different windows. The possibility in RAM Commander of opening and working in several windows simultaneously, allows you to access **various** parts of the project, such as the Product tree, Libraries, RBD, etc, in many projects, facilitating reliability task execution.














RAM Commander supports most of the window management features provided by Microsoft's File Manager. You can cascade and tile open windows, and arrange the icons of minimized windows. Using these functions, you can work simultaneously with many open lists operating on several projects or parts of projects. For an explanation of window management techniques, refer to the *Microsoft Windows User's Guide*.


5.2 Toolbar

The *toolbar* displays buttons that are equivalent to common RAM Commander menu choices. Some toolbar buttons are grayed out when the corresponding menu selection cannot be performed within an activated list:



The following is a description of toolbar buttons:

Click...	To...
	Open projects list from the selected drive
	Print
	Copy the selected element
	Paste copied data
	Edit current item data
	Create a new item
	Delete the current item
	Select/Deselect the current list item
	Calculate
	Display Reports selection dialog
	Show hierarchical structure (nested RBD, FMEA diagrams, FTA diagrams etc)
	Edit project remarks
	Display context Help


Click...	To...
	Display "About RAM Commander"

To toggle the toolbar display, choose **Toolbar** from the **View** menu.

5.3 Status Bar

The *status bar* contains summary information (e.g., ID and data output) about the open list. Its contents change depending on what type of list is activated. For instance, the status bar for a product tree view displays the current item ID. For an RBD window, the status bar shows the result of the last reliability calculation.

The viewing area of a list may be increased by removing its status bar. To toggle a status bar, choose **Status Bar** from the **View** menu.



5.4 Lists

A *list* is a window that scrolls over records. You can sort and filter the displayed records. RAM Commander lists have the added feature of allowing you to directly manipulate records. Lists are used in RAM Commander for projects and library records.

Note Even though all the examples below refer to the Library list, they can equally apply to all the other lists generated by RAM Commander such as component libraries and cross-reference libraries.

Data Manipulation Using Lists

Using the various lists, you can add, edit and delete RAM Commander's databases records.

To add a record using a Component Library list

1. Activate the Library list.
2. From the **Item** menu, choose **Create**
 - or -
 - Press F7.
 - or -
 - Press "+" icon in the Toolbar
3. Enter information in the dialog box and choose **OK**.
4. RAM Commander redisplay the Library list with the new record.

To edit a record using a Library list

1. Activate the Library list.

2. Double-click the item

- or -

From the **Item** menu, choose **Edit**

- or -

Press Alt+Enter

- or -

Right-click and choose **Edit** from the pop-up menu.

3. Modify the information in the dialog box and choose **OK**.

RAM Commander redisplay the Library list with the updated record.

To delete a record using a Library list

1. Activate the Library list.

2. From the **Item** menu, choose **Delete**

- or -

Press **Del**

- or -

Right-click and choose **Delete** from the pop-up menu.

- or -

Press "X" icon in the Toolbar

Caution Be careful when deleting records. There is no undo facility to restore data to a previous state.

3. Enter your confirmation in the **Attention** dialog box.

RAM Commander redisplay the Library list without the deleted record.

5.5 Projects


RAM Commander Project is a separate database for a single analysis case. It contains all information you enter or calculate for single analysis case for all the possible analysis types you use – Reliability, Maintainability, RBD, FTA, etc.

Each local or network drive may contain one list of multiple RAM Commander projects:


Name	Description	Owner	Owner group	Locked By	Date	Project group
RAMC_PRJ_OVERV		ALD			2010.03.01	
S18_AIRCRAFT	Safety Assessment Process Example	SVETA	ALD		2010.06.01	Tutorial
SAFETY_NEW	qweiou tio[qweru io[qweru io[wery io[wery	ALD			2010.06.17	
TANK_SAMPLE		MOTI			2010.03.01	Tutorial
TUTORIAL	Communication System	ALD	ALD	ALD	2010.06.28	TUTORIAL
TUTORIAL_DISPREL	Dispatch Reliability testing and demo	ALD			2010.05.24	TUTORIAL
TUTORIAL_MMEL	Sample project with MMEL analysis	SVETA	ALD		2010.06.23	TUTORIAL
TUTORIAL_MSG3	Sample project with MSG3 analysis example	ALD			2010.06.01	Tutorial
TUTORIAL_NOKIA		ALD			2010.06.22	
TUTORIAL_VALVE		ALD		ALD	2010.06.14	TUTORIAL
VALVES		RAFI	ALD		2010.06.01	

To open a RAM Commander project list

1. From the **Drive** menu, choose **Open**:



2. The **Open Drive** dialog box opens.



3. The **Open Drive** dialog box displays a list of the drives to which your computer has access (both local and network drives).
4. Select the drive where your projects are (or will be) located.
5. Choose **OK**.
6. RAM Commander displays a project list. A project list shows a list of all the RAM Commander projects stored on the selected drive.

You may create, open in different modes, delete, copy, backup, restore and rename projects.

To open a project in main analysis mode

1. Activate the Project list.
2. Select the project you wish to open.
3. From the **Project** menu, choose **Open**, or right-click and choose **Open** from the pop-up menu, or press **F2**.
4. RAM Commander displays the [Product tree view](#). See “Product Tree” chapter for more information about the Product tree view.

To create a new project

1. Activate the Project list.
2. From the **Project** menu, choose **Create** or press F7. The **Edit project properties** dialog box opens.
3. Enter the Project name, Group, Description, FR units and Permission.
4. Choose **OK**.
5. RAM Commander updates the Project list. See chapter “Project building” for more information about project definition.

See "[Working with Projects](#)" chapter for more information about the projects management, advanced operations, project permissions management and more.

5.6 Product Tree View

The RAM Commander Product tree view is a graphical hierarchical presentation of the project's items (Bill Of Materials, Product breakdown). Navigating through a project is very similar to navigating through any commonly used hierarchical structures, such as exploring folders in *Microsoft Windows*.

Ref.Des.	ID	Name	Qty	Opr. FR [10 ⁻⁶]	Status
TUTORIAL	1	Communication System	1	187.0768	++
Communic	1	COMM001	1	100.2550	++
Main Switch	1	SW888	2	8.7416	++
U1	1	8086A	1	0.2442	++
U9	2	80C88	1	0.0000	--
U10	3	80C31	1	0.0862	++
U12	4	LM299	1	0.0625	++
U13	5	74LS30	1	0.0367	++
R1-10	6	RLR	10	0.0890	++
R11-12	7	RN	2	0.0365	++
R30-34	8	RZ	5	0.0849	++
CC1	9	CK	1	0.0619	++
CC2	10	CK	1	0.0619	++
CC3	11	CK	1	0.0595	++
CC4	12	CK	1	0.0607	++
CC5	13	CK	1	0.0614	++
L0-4	14	HLMP-2450	4	0.0144	++
L5-6	15	HLMP-2400	2	0.0072	++
SW1-2	16	DP2	2	3.1361	++
Receiver	2	RC004	10	82.8214	++
Transmitter	3	TR987-001	1	0.3419	++
PS	4	Power Supply	1	8.3500	Us
Control	2	Control Unit	1	75.4953	++
Pedestal	3	PD001	1	11.3265	++

The RAM Commander Product tree view appears when you open RAM Commander project in main analysis mode (see previous paragraph - "[Projects](#)").

When you run the RAM Commander for the first time, the Product tree view opens in the Operating mode. Afterwards it opens in the analysis mode last used for a current project.

There are several analysis modes performed on the Product Tree View window:

Current Analysis	Description	Result
Operating	Reliability prediction for equipment in operating mode	Failure rate: operating
Non-operating	Reliability prediction for equipment in non-operating mode, such as storage	Failure rate: non-operating
Maintainability	Maintainability Prediction	MTTR and Mct
Derating	Derating analysis	Component stress values

Current Analysis	Description	Result
FMECA	Failure modes and effects criticality analysis. Testability analysis	FMECA report


In addition to its core product analysis modes, RAM Commander has numerous modules performing many extremely important and valuable Reliability and Safety tasks (see "[Modules Overview](#)" paragraph).

There are several ways to access RAM Commander modules:


- The **Modules buttons** on the Product tree view, to the left from the tree:




- The **Modules menu**:



- **Project Overview** Screen



These additional modules initiate a new window or dialog:



You may switch between all open windows and open additional projects views and module windows. Refer to the specific chapter for more information about each module.

5.7 Reports

All RAM Commander modules provide data output using **reports** and/or **graphs**. Reports may be generated as [regular tabular data sheets](#) (in HTML or RTF format) or as [MS Word documents](#) using customizable templates. Users may use predefined reports or use powerful [Report Generator](#) to create additional reports. Users may generate, store and customize reports and [graphs](#).

The screenshot displays two overlapping windows from the RAM Commander application. The primary window, titled 'Applied Values (+Defaults) Report', shows a table of component data and an FMEDA summary. The secondary window, 'Graph Generator for RAM Commander, version 3.0', displays a 3D bar chart titled 'Criticality Matrix - Counting Items'. The chart's vertical axis is marked with Roman numerals I, II, III, and IV. A legend on the right side of the chart maps colors to severity levels: A (red), B (orange), C (yellow), D (green), and E (dark green). The bars represent the count of items for each severity level, with the highest count being for level B (orange).

ID	Ref.des.	PN	Techn	Type	# of elements	Active pins	Package	Years in production	Qual	Theta (c/°)
1.1.1.1	U1	8086A	NMOS	MicroProcessor	16	40	DIP Harm	2.0	B-1	---
1.1.1.2	U9	80C88	NMOS							
1.1.1.3	U10	80C31	CMOS							
1.1.1.4	U12	LM299	CMOS							
1.1.1.5	U13	74LS30	TTL							

Item Information	FM Description	FM Ratio (Alpha)	End Effect	FM Crit. IV	FM Crit. III	FM Crit. II	FM Crit. I	Detectable	Test Name	Minor Detected	IV Undetected	Marginal Detected	III Undetected	Critical Detected	U
IDN:1.1.2 Name: Receiver FR(x10-6):82.8214	1 No output	1.000	Communication Degradation	82.82				Yes	Noise receive test -->			82.821			

The following paragraphs explain reports and graphs usage and generation basics.

5.7.1 Text Reports

RAM Commander displays text reports inside a report view window. This display makes it easy for you to position a report next to another RAM Commander window and perform on-screen analysis.

To generate a report, use "Reports" menu of currently selected/required RAM Commander module. Choose the required report, specify report filter and conditions and wait for the report generation. Then the report window will appear:

Assembly Composite Report for Project TUTORIAL Drive C:

Assembly Composite Report

Project name: TUTORIAL

Assembly Ref.Des.: TUTORIAL, ID: 1, Description: Communication System.
 Environment: GF, Temperature: 35.00 °C,F.R.(xE-6): 309.08 , MTBF(hours): 3235.37

ID	PN	RefDes	Qty	F.R. xE-6	F.R.(K,Qty) xE-6	Contrib. to NHA[%]
1.1	CN017000	Communic	1	229.92	229.92	74.39
1.2	CN017334	Control	1	74.50	74.50	24.10
1.3	CN017880	Pedestal	1	4.67	4.67	1.51

Assembly Ref.Des.: Communic, ID: 1.1, Description: Rx/Tx system.
 Environment: GF, Temperature: 35.00 °C,F.R.(xE-6): 229.92 , MTBF(hours): 4349.34

ID	PN	RefDes	Qty	F.R. xE-6	F.R.(K,Qty) xE-6	Contrib. to NHA[%]
1.1.1	CN017004	Main Switch	2	4.23	8.46	3.68
1.1.2	CN017016	Receiver	10	21.31	213.11	92.69
1.1.3	CN017009	Transmitter	1	0.003183	0.003183	1.38434E-003
1.1.4	CN017201	PS	1	8.35	8.35	3.63

The following basic functions are available from the report viewer:

- **Search:** press Ctrl+F or choose "Find" from the edit menu.
- **Text selection:** just select the required portion of report with your mouse. Press Ctrl+C to copy the selection to the Clipboard.
- **Printing:** press the printer icon in the toolbar or choose "Print..." from the "Report" menu.
- **Page and Printer setup:** choose appropriate options from the "Report" menu.
- **Save report file:** choose "Save as..." option from the "Report" menu, provide file name and location.
- **Open report in MS Word, Excel, Internet Explorer:** Choose the appropriate option from the "Report" menu.
- **Open report inside MS Word template:**
 1. choose "Publish with MS Word template" option from the "Report" menu.
 2. Document parameters dialog will appear – provide information which will appear in report header and footer (if it does not appear - press Cancel and choose "Template Page Setup" option from the "Report" menu). Fill the data and press Ok.
 3. Templates list will appear. Select template and press the Select button.
 4. The same report will appear inside the templated document with required headers and footers. The template may be customized - you may write your own header, footer, put your organization logo etc.


You may also customize reports appearance and view previously generated reports - see next paragraphs for more information.

5.7.1.1 Customization

You can customize the appearance and columns width of your RAM Commander reports. The customization settings are stored for each RAM Commander user separately.

To customize report appearance

1. Activate the Product tree view or another module view.
2. From the **Reports** menu, choose **Setup – Appearance**; the Report Style Setup dialog box opens.




3. In the Report Group list box, select the report group you are customizing.
4. Select Thick or Thin from the Box Style field.
5. Make font selections for Title, Text, Head, and Table; the selections are displayed in the Report Style Setup dialog box.
6. Choose **OK**.

These settings are effective for future reports. Previous reports generated are not affected by the new settings.

To customize report columns

1. Activate the Product tree view or another module view.
2. From the **Reports** menu, choose **Setup – Columns**; the Report Columns Setup dialog box opens.




3. Select report from the list
4. You will see a list of columns names and their sizes in characters for the selected report – you may change it by double-clicking on corresponding row and changing the width . Zero column length removes a column from report.
5. Use Restore Defaults button in the lower right corner of the dialog to return columns width to the initial values.
6. Press Ok to close the dialog and save the changes

5.7.1.2 View Stored Reports

RAM Commander saves the last report of each kind generated for each project. You can review a previous report at any time - even during subsequent RAM Commander sessions. Since you can view more than one report at a time, this utility provides the benefit of performing an on-screen comparison analysis between different projects.

To view a previous report:

1. Activate the Product tree view.
2. From the **Reports** menu, choose **View Report**; the Reports for the current project selection box opens.



3. In the Select report list box, select the report you wish to view.

4. Choose **OK**.

RAM Commander displays the report on your screen. Repeat this procedure to open several reports at once.

To delete a report, select it and choose **Delete**. To delete all reports, choose **Delete all**.

5.7.2 Report Generator

In addition to the standard set of custom reports, RAM Commander provides a **Report Generator** for designing and printing custom reports. The report generator requires experience in RAM Commander operation. Before generating a new report, examine an existing report definition to understand the report generator's primary principles and options.

Report definition involves two phases. The first phase is building the report by selecting which data fields to include, sort orders, column widths, and optional column headings. The report's appearance can now be customized as described below (Report Style Setup dialog box).

Report Generator may generate reports based on the product tree structure, reliability, maintainability and FMECA data of product tree elements. It does not provide information on FTA, RBD and other modules.

To add a tree data report using the Report Generator

1. Activate the Product tree view.
2. From the **Reports** menu, choose **Report Generator**; the Report Definition dialog box opens.

Report Generator

Report Definition

BOM Import Add Delete

Title: _____

Report

Scan method: D - by tree

Separate levels Depth: 9

Include items: Items&Assy

Project Drive Current Date

Project name

Generate Setup Close

#	Group	Field	Width	Column Name	Sort Order
1	GN	Depth	2.0	Depth	No
2	GN	Item family	10.0	Family	No
3	GN	Item code	15.0	Item code	No
4	GN	Ref. designator	11.0	Ref. des.	No
5	GN	Part name	31.0	Part name	No
6	GN	Generic name	21.0	Generic name	No
7	GN	Quantity	4.0	QTY	No
8	OP	Rel. Prediction method	20.0	Rel. pred. method	No

Field

Add Delete Edit Move Up Move Down

- In the Report Definition selection box at the top of the Report Generator dialog box, choose **Add** and enter a new report name.
- In the lower Field box, choose **Add**; the Add/Edit Field dialog box opens:

Add/Edit Field

Group: Tree General

Field Name: Generic name

Width: 21 / 0

Column Name: Generic name

Sort Order: No

Formula: _____


OK Cancel Edit formula

- In the Add/Edit Field dialog box, select a screen name to which the field belongs from the Group list box (General/Operating/Non-operating/Maintainability/ILS/Miscellaneous/FMECA).
- In the Field name list box, select a field.
- In the Width field, enter a field width. If a floating-point field is selected, enter the number of decimal places. Make sure to provide enough space for your numeric values. For example, width = 10 and decimal places = 3 will give output like 12.345. However, if the number is smaller

than 1e-3 and it is not possible to display the most significant part of it using 3 decimal places, this number will be displayed in engineering form like 1e-4.

8. If required, change the column name to the desired column name you wish to appear in table header of the report.
9. To define the current field as a sorting key, choose **First** or **No** to set the sorting priority.
10. Choose **OK**.
11. Repeat steps 3-10 to add more fields to the report.
12. Choose **Generate**.
13. RAM Commander displays your customized report in a window. Since RAM Commander automatically saves the report definition, it can be used during subsequent sessions.

Report Generator supports calculated fields, where user may define a formula and report will display calculated values. In order to create calculated field, add a field with Group="CA" and Field="Formula" in the Report Generator. Then select this newly added field in the list and press Edit button. Field data dialog will appear with the formula field available. You may enter formula manually, however, it is recommended to use formula editor instead – press the "Edit Formula" button to get the formula editor:



Compose the formula by double-clicking on fields list, functions, and operators lists to insert them into the formula at current cursor position. The generated report will contain column with values calculated for each item according to the defined formula. Each report definition may contain multiple

formulas.

Existing customized reports may be edited.

To edit a customized report

1. From the Report Generator dialog box, select the report from the Report Definition list box.
2. Select the required field by clicking on its number under the # column.
3. Choose **Edit** from the lower Field box; make the required changes to parameters in the Add/Edit Field dialog box
 - or -
 - change the parameters from within the grid by clicking on it.
4. Choose **OK**.
5. RAM Commander redisplay the updated Report Generator dialog box. To delete a particular field from your report, select it and choose **Delete** from the field group. You can change the order of the fields using the **Move up** and **Move down** buttons.

RAM Commander automatically saves your report definitions as you create them. To delete unneeded reports, select them from the Report Definition list box and choose **Delete**.

You can customize the appearance of your report. From the Report Generator dialog box, choose **Setup**. The Report Style Setup dialog box opens.


The customizations apply to *all* user-defined reports, not just the one selected in the Report Definition list box.

5.7.3 Reports by MS Word Template


Several reports may be generated based on RAM Commander project data and customizable MS Word report template. It is a powerful tool to generate final documents for customers or safety/reliability authorities directly from RAM Commander, according to your organizational documents standard and requirements.

To generate report with MS Word template:

1. Choose the appropriate menu item in Reports menu of required module (see particular module chapter for module-specific report description).
2. Available report templates list will appear:




3. Press ""Page setup"" button to change/enter information appearing in report header and footer like Author, Document Number, Department etc.
4. Select the template from the list and press "Select" button to proceed to the report generation.
5. RAM Commander will launch report generation. During the generation do not work with MS Word or other MS Office applications (Excel, PowerPoint etc.)
6. The generated report will appear on the screen:




User may also add his own templates, edit and delete existing user-defined templates.

To create a new user-defined template:

1. Choose the appropriate item in Reports menu of required module.
2. Available report templates list will appear:




3. Choose template which is close to your required report
4. Find the template file in RAMC32/LIB folder
5. Copy the template file to another file name in the same directory LIB.
6. Open the newly created file in MS Word and perform the required changes in document design.
MS Word Template is a regular MS Word document with RAM Commander - specific fields.
7. Save the template.
8. Return to RAM Commander, "MS Word Template Selection" dialog.
9. Press "Add" button - template definition dialog will appear:



10. Select the newly created template file in LIB folder using the Browse button and provide the new template description.
11. Press Ok.
12. Template will appear in templates list and may be used for report generation.
13. Select it and press the "Select" button to initiate the report generation.

To add user-defined template created by another user:

1. Copy the template file to RAM Commander installation folder, LIB sub-folder
2. Choose the appropriate item in Reports menu of required module.
3. Available report templates list will appear.
4. Press "Add" button - template definition dialog will appear:




5. Select the newly copied template file in LIB folder using the Browse button and provide the new template description.
6. Press Ok.
7. Template will appear in templates list and may be used for report generation.
8. Select it and press the "Select" button to initiate the report generation.

5.7.4 Graphs

RAM Commander provides a convenient graphics package that offers a wide variety of graph types. The report may be viewed using 2D and 3D bar, pie, line graphs in a variety of customizations.

Different RAM Commander modules provide different graphs - like Pareto in Reliability prediction or "Unavailability curve" in FTA module. See particular module chapter for more information.



Once the graph is displayed in the Graph View dialog box, its appearance may be changed - press the **"Setup"** button and make required selections on the graphs setup dialog.

To print the graph, press the **"Print"** button on the Graph View dialog box.

Export the graph as image using the **"Save"** button.

Choose **"Clipboard"** button to place the graph image to the clipboard. Then you may switch to another application like MS Word and paste the graph to your document.

Press the **"Close"** button to return back to RAM Commander main window.

You may also zoom in/out the graph using mouse wheel and rotate the graph using mouse pointer and left button to achieve the desired presentation of the graph.

5.8 Data Exchange

RAM Commander has multiple options for data exchange with other applications.

Different modules of RAM Commander has Import/Export Facilities:

Module	Data Exchange Options
Product Tree / BOM	Customizable Import Wizard for Excel, Access and ASCII files (Import Wizard), Report Generator for data export (Export)
Reliability Data Component Library	Import from Excel (Data Import)

Module	Data Exchange Options
GPRD Library	Customizable Import Wizard for Excel, Access and ASCII files (Import)
FMECA	Import/Export using predefined MS Excel file format (Import/Export)
Safety / FHA / SHA	Import/Export using predefined MS Excel file format
Process & Design FMEA	Import/Export using predefined MS Excel file format

Please contact our support service for data exchange information in other modules.

In addition, any report in RAM Commander may be exported to MS Excel or to ASCII/CSV format. User may create his own report formats by defining the required columns in the report (using the [Report Generator](#)) and then user may generate the reports and export them into MS Excel or other formats - this way Report generator becomes a data exporting tool.

Additional data exchange option is data exchange with ALD Favoweb FRACAS application using web services - please contact our support service for specification.

5.9 Spelling checker

RAM Commander has a built-in Spelling Checker with 16 dictionaries in the following languages:

SpellUS.lex - US English	SpellLAT.lex – Latin
SpellUK.lex - British English	SpellNL.lex – Dutch
SpellGER.lex – German	SpellPL.lex – Polish
SpellESP.lex – Spanish	SpellCRO.lex – Croatian
SpellFRA.lex – French	SpellSLO.lex – Slovenian
SpellDAN.lex – Danish	SpellSVE.lex – Swedish
SpellITA.lex – Italian	SpellCZ.lex – Czech
SpellHE.lex – Hebrew	SpellRU.lex – Russian

English UK and US, German and French dictionaries are included with the standard installation; other dictionaries are available by request from our support service.

To set up Spelling Checker:


1. Open your project.
2. From the **Tools** menu, choose **Spell checker dictionary**.
3. Select a dictionary from RAMC32/BIN folder (see the above explanation for a list of dictionary file names).

You can now initiate the spell checker in any cell of different RAM Commander grids or any field of the data dialogs.

To use Spelling Checker:

1. Select any cell of different RAM Commander grids or any field of data dialog.
2. From the **Tools** menu, choose **Check spelling** or press **Ctrl+S**.

3. The standard **Spelling** dialog box is displayed with options for replacing the misspelled word.



Chapter

6

Working with Projects

6 Working with Projects

RAM Commander **Project** is a separate database for a single analysis case. It contains all information you enter or calculate for single analysis case for all the possible analysis types you use – Reliability, Maintainability, RBD, FTA, etc.

Several facts about what you can do with the projects:

- Each **local or network drive** may contain a single database with list of projects.
- Projects located on a local network drive may be accessed by the PC user only. Projects located on a shared network drive (or on RAM Commander server computer) may be shared and **used simultaneously by multiple users**.
- You may **create, open and delete** projects.
- You may open windows from multiple projects simultaneously.
- You may copy projects from one local/network drive to another.
- You may **Backup** each project into a single compressed file which may be stored or sent by email. Then the project may be restored from this compressed file.
- **Project permissions** may be set by RAM Commander administrator or by project owner - for the whole project or per modules (like FTA, FMECA etc.). Permissions may be set for each user or for groups of users.


See the next paragraphs for information about working with projects.

6.1 Projects list


List of projects displays all projects located on a specified local or network drive.

To open a RAM Commander projects list

1. From the **Drive** menu, choose **Open**:



2. The **Open Drive** dialog box opens.



3. The **Open Drive** dialog box displays a list of the drives to which your computer has access (both local and network drives).
4. Select the drive where your projects are (or will be) located.
5. Choose **OK**.
6. RAM Commander displays a project list:

Name	Description	Owner	Owner group	Locked By	Date	Project group
RAMC_PRJ_OVERV		ALD			2010.03.01	
S18_AIRCRAFT	Safety Assessment Process Example	SVETA	ALD		2010.06.01	Tutorial
SAFETY_NEW	qweiou tio[qweru io[qweru io[weru io[wery	ALD			2010.06.17	
TANK_SAMPLE		MOTI			2010.03.01	Tutorial
TUTORIAL	Communication System	ALD	ALD	ALD	2010.06.28	TUTORIAL
TUTORIAL_DISPREL	Dispatch Reliability testing and demo	ALD			2010.05.24	TUTORIAL
TUTORIAL_MMEL	Sample project with MMEL analysis	SVETA	ALD		2010.06.23	TUTORIAL
TUTORIAL_MSG3	Sample project with MSG3 analysis example	ALD			2010.06.01	Tutorial
TUTORIAL_NOKIA		ALD			2010.06.22	
TUTORIAL_VALVE		ALD		ALD	2010.06.14	TUTORIAL
VALVES		RAFI	ALD		2010.06.01	

You may select single projects and use popup menu and upper main menu to perform operations on the selected project.

Each project record in the list has its state (indicated by color and icon). They are important especially when the projects list is located on a shared network drive and multiple users are working with that list simultaneously - see "[Multi-user access](#)" paragraph later in this chapter.

6.1.1 Working with the project list

You may sort, filter and group projects in the list.

Sorting

Click on column header in the list of projects to sort the list by this column. Click the same column again to change the direction of sorting.

Filter

Open the "Filter" option from the "View" menu and choose the filtering condition. List of projects will be updated and will show only the projects satisfying the filtering condition.

Grouping

Each project has a setting called "Project Group". Project group may be anything that unifies different projects of the same product, customer, year, version etc. Hierarchical projects view puts each project group to the separate tree branch, providing more convenient operations with multiple projects from different products:

Select "Tree View" option from the View menu in Projects List window to use this option.

6.2 Multi-user access

RAM Commander allows simultaneous work of a number of users on the same project. The project should be located on a shared network drive with "Full Control" access permissions for all users.

Some of the users may perform Reliability analysis, while other users input FMECA, or draw RBD diagrams or work with Fault Trees – all inside the same project and simultaneously.

Some resources in a project cannot be edited simultaneously (e.g., FTA diagrams, RBD diagrams, etc.) When a user tries to access one such resource currently occupied by another user, a warning message appears. For example, if one user is editing specific RBD diagram, another user cannot open the same diagram. However, he can open another RBD diagram or create a new one.

RAM Commander allows (or restricts) performing different operations with projects (open, change, delete, back up, calculate) according to two possible limitations: **permissions** and **other users activity**.

Permissions


The **permission level** is set individually for each project from one of the following options:






User	Only the project author may access the project.
Group	Only members of the same user group as the project author may access the project.
All	Anyone can access the project
Advanced	Permissions are set individually for each user/group for each module/operation

User will not be able to open the project or perform specific operation on that project if he does not have corresponding access permissions. See more information about [Permissions management](#) later in this chapter.

Other users activity

Each project has its owner (author) and its current manager:



Name	Revision	Owner	Owner group	Manager	Date	Project group
 TUTORIAL		ALD	ALD	ALD	2010.08.25	TUTORIAL
 TUTORIAL_DISPREL		ALD		ALD	2010.08.12	TUTORIAL
 TUTORIAL_MMEL		SVETA	ALD		2010.08.16	TUTORIAL
 TUTORIAL_MSG3		ALD			2010.08.23	Tutorial
 TUTORIAL_NOKIA		ALD			2010.08.23	





The user who creates a new project (owner) or the first user who enters a non-selected project (project without current manager) becomes the **project manager**. Only this user can change project default settings (default prediction methods, FMECA Criticality settings, etc.). All other users can enter the project and work with it. However, only the project manager can perform backup/restore/rename operations, and only when there are no other active users currently working on the project. The current project manager may decline his status by closing the project and de-selecting it in the project list. Then another user may select the project and become the project manager.

User opening a project without current manager becomes its temporary manager until he finishes working with this project and closes the "Product Tree" view window of that project.

If user wishes to become a permanent manager of a particular project should select the project in the list of projects and perform the "Select" operation (right-click the project and choose "Select" from the popup menu). To stop being a manager of the project, user should perform the "Deselect" operation on this project. Then any other user will be able to become a manager of the project.

Project states

Each project may be in different accessibility state depending on the permissions and other user operations as explained earlier. The table below provides description of different projects states and available operations for each state:

State	Meaning	What to do
Project line is red:  TUTORIAL	No permission to access the project.	You cannot open the project. Ask project owner or RAM Commander administrator to grant you the access (see permissions selection in project settings)
Project line is gray:  TUTORIAL	Project is not selected, project manager position is empty; maybe other users are working on the project	You may open the project, and become project manager.
Project line is green:  TUTORIAL	You have selected the project; you are the project manager of this project	You may enter the project, change default settings of the project, rename, backup, copy and delete the project (if there are no active users currently working).
Project line is yellow:  TUTORIAL	Another user selected the project and he is the current project manager (See "Manager" field to see current manager name)	You may enter the project and work on it, but you cannot change default calculation methods and delete, rename, backup or copy the project.

If there are other users working currently in the project, you will not be able to perform global project operations like backup, rename, copy etc. even if you are project manager and have all the required permissions - you have to wait while all users will leave the project.

6.3 Creating a new project

To create a new project:

1. Activate the Project list for a desired local or network drive.
2. From the **Project** menu, choose **Create** or press F7. The **Edit project properties** dialog box opens:

3. Enter the Project name and other optional information:

Field	Description
Project name	Unique project name, only alphanumeric characters without spaces, max.length is 16 characters.
Project Description	Optional
Project Group	Optional, used to sort or arrange projects in the list hierarchically by groups
Revision	Optional, project version name/number
Failure rate units	<p><i>Failure rates</i> are expressed as the number of failures per million hours or per billion hours.</p> <p>To express failure rates as failures per million hours, use 10^{-6}. To express failure rates as failures per billion hours, use FIT. (MIL-HDBK-217 uses 10^{-6}, while Telecordia (formerly Bellcore) and French Telecom use FIT.)</p>

Permission	<i>Permission</i> refers to the access level assigned to the project. The following settings are possible: Owner user, Owner group, All, Advanced. See more information in the Permissions management paragraph later in this chapter.
Automatic tree recalculation	Changes to the product tree do not automatically initiate the reliability/maintainability/FMECA recalculation process. For a correct analysis, the product tree must be recalculated prior to creating reports. Check the "Automatic tree recalculation" checkbox if you want RAM Commander to automatically recalculate the entire project before any report is produced. This option is not recommended for large projects since the recalculation takes a long time and is performed before each report generation.

4. Choose **OK**.
5. RAM Commander updates the Project list. Now you may open the project and work with the desired module or modules - see corresponding module manual chapter for further directions.


You may return to project properties editing any time later:

1. Close the project if it is open.
2. Activate the Project list.
3. Double-click on the project you want to edit.
4. In the **Edit Project Properties** dialog box, enter the new values.
5. Choose **OK**.

6.4 Managing permissions

The **permission level** is set individually for each project from one of the following options:

User	Only the project author may access the project. Only project manager may change the permissions.
Group	Only members of the same user group as the project author may access the project. Only project manager may change the permissions.
All	Anyone can access the project. Only project manager may change the permissions.
Advanced	Permissions are set individually for each user/group for each module/operation:



These options may be defined on the project properties screen which you get when create a new project or when edit project properties. User will not be able to open the project or perform specific operation on that project if he does not have corresponding access permissions.

If the project permissions level is set to one of the first 3 levels (User, Group or All) then only the project owner (author) will be able to change the permissions.

For the [Advanced permissions](#) case see related paragraph later in this chapter.


6.4.1 Advanced Permissions

"Advanced permissions" is the most flexible type of project permissions, allowing specifying a list of allowed operations and modules for each particular user or user group per project.

To enable the advanced permissions for project:

Note: **Only project owner (author) may switch advanced permissions on.** He should define security administration code for the project, and any user may manage access control list for this project using this code. Project permissions level may be also switched back to "All" or "User" level using the same administration code.

1. Select the desired project in the list of projects.
2. Open project data (Right click on project and select Edit from popup menu).
3. Select "Advanced" in the "Permission" drop-down list (only project owner may perform this operation):



Access Rights

Locked by user: ALD


Owner: ALD

Owner group:

Permissions: **Advanced** (highlighted with a red box)

Advanced permissions

4. Define administration code which will be used later to manage the permissions:



Advanced Security Administration Code


Please define the new code for advanced project permissions administration:

OK

Cancel

This code may be defined separately for each project or RAM Commander administrator may use the same code for all projects.

5. The access control list will appear. It contains list of users in the upper part of the screen and list of permissions for the selected user in the lower part of the screen. Selected (blue) permissions are granted, not selected permissions are denied for the selected user:



Advanced permissions for the project

Users and Groups:	Permissions for the selected user:
ALD	Project - Open
	Project - Backup
	Project - Overwrite using Restore
	Project - Delete
	Project - Rename
	Project - Copy
	Product Tree (Reliability, Maintainability)
	FMECA
	RBD - Reliability Block Diagrams
	Markov Chains
	FTA - Fault Tree Analysis
	ETA - Event Tree Analysis
	Process/Design FMEA
	Safety
	MMEL - Master Minimum Equipment List
	Libraries - Component Library
	Libraries - GPRD
	Libraries - Calculation Defaults
	Libraries - Cross Reference

Add user... Remove user... OK Cancel

6. Press "Add user" button to add more users to the list. You may select users from the list or enter user name manually.

in square brackets ([group name]). Specific user permissions always override group permissions (so if user A is a member of group B and the list of users and groups contains both permissions for A and [B], permissions set for A will be taken into consideration).

7. Press Ok. New user/group will appear in the list.

8. To delete specific user, select user in the list and press "Remove user" button.

9. To view or set permissions for specific user, select user in the list above and his permissions will appear in the list below. Select (grant) / deselect (deny) permissions by clicking them in the list. Permission called "Project-Open" overrides all specific module permissions. If you wish to give access to all modules, select "Project-Open" in the list. If you wish to give permissions to specific modules only, deselect "Project-Open" and select specific modules such as "FMECA", "FTA" etc.
10. Press "Ok" button to save the permission changes.
11. Press "Ok" on the project data screen to save the changes.

To change the advanced permissions for project:

1. Select the desired project in the list of projects.
2. Open project data (Right click on project and select Edit from popup menu).
3. Press "Advanced permissions" button in Access Rights group.
4. Enter the administration code (defined by the project owner during initial advanced permissions definition)
5. The access control list will appear - manage advanced permissions as described above - "To enable the advanced permissions for project".

Another way to enter permissions management for the project is:

1. Select the desired project in the list of projects.
2. Select "Advanced permissions" from the "Project" menu.
3. Enter the administration code (defined by the project owner during initial advanced permissions definition)
4. The access control list will appear - manage advanced permissions as described above - "To enable the advanced permissions for project".

This second option is better when RAM Commander administrator (or any person who manage permissions) is not defined as project manager.

To switch advanced project permissions off

1. Open project data (Right click on project and select Edit from popup menu).
2. Change the value of "Permission" drop-down list.
3. You will be asked for administration code – enter administration code defined before (when the advanced permissions were switched on and configured for the first time).
4. Project permissions setting will be changed.
5. Press Ok button to save the changes.

Please note that advanced permissions definition is stored inside the project database and is still effective after project backup and restore - even if it is restored in completely different environment in another network with different list of RAM Commander users.

6.5 Opening project

Each project may contain multiple analysis types - Reliability, FMECA, FTA, Safety etc. Some of them are based on the product tree (Reliability for operating and non-operating modes, stress analysis, Maintainability and FMECA) and some of them are not (FTA, ETA, Markov etc.). There are multiple ways to open the project in the desired analysis mode.

To open the project:


1. Open the list of projects for the desired drive (see "[Projects list](#)").

2. Select the desired project in the list of projects.
3. Use one of these three options:
 - a. Right-click the project record and select "Open" in the popup menu (or just press F2). The RAM Commander Product Tree view for this project will appear. Then you may switch to the desired analysis mode or open the desired module using the Modules menu or vertical button bar to the left of the product tree view:

Ref.Des.	ID	Name	Qty	Opr. FR [10 ⁻⁶]	Status
[-] TUTORIAL	1	Communication System	1	187.0768	++
[-] Communic	1	COMM001	1	100.2550	++
[-] Main Switch	1	SW888	2	8.7416	++
U1	1	8086A	1	0.2442	++
U9	2	80C88	1	0.0000	--
U10	3	80C31	1	0.0862	++
U12	4	LM299	1	0.0625	++
U13	5	74LS30	1	0.0367	++
R1-10	6	RLR	10	0.0890	++
R11-12	7	RN	2	0.0365	++
R30-34	8	RZ	5	0.0849	++
CC1	9	CK	1	0.0619	++
CC2	10	CK	1	0.0619	++
CC3	11	CK	1	0.0595	++
CC4	12	CK	1	0.0607	++
CC5	13	CK	1	0.0614	++
L0-4	14	HLMP-2450	4	0.0144	++
L5-6	15	HLMP-2400	2	0.0072	++
SW1-2	16	DP2	2	3.1361	++
Receiver	2	RC004	10	82.8214	++
Transmitter	3	TR987-001	1	0.3419	++
PS	4	Power Supply	1	8.3500	Us
Control	2	Control Unit	1	75.4953	++
Pedestal	3	PD001	1	11.3265	++

This way is the best if you are working mainly with the product tree. See also the [Product Tree View](#) paragraph earlier in this manual.

- b. Double-click the project. Project overview window will appear. It provides shortcuts to almost all the available analysis types and modules and also provides module usage statistics in this project. Click the corresponding module/analysis type "Open" button to go directly to this module:



c. Right-click the project record and select "FTA", "ETA" or other module from the popup menu. The selected module will be initiated. It is the quickest way if you work only with the particular module available in the popup menu.

6.6 Backup/Restore

Project may be compressed to a single file with RMW extension. You may store this file as a backup, you may create multiple backups (we recommend to perform backups daily/weekly and store all previous versions of the project). You may send the backup file by email or copy it to another media. Later you may restore the project from the backup file.

To backup a project

1. Activate the Project list.
2. Select the project you want to backup.
3. From the Project menu, choose Backup, or right-click and choose Backup from the pop-up menu. The Backup Project dialog box opens.
4. Select the destination drive and folder where the backup will be created. Note that the backup file name should be not longer that 16 characters, only Latin alphanumeric characters are allowed.
5. Choose Save.

RAM Commander backs up your project onto the designated floppy disk / other data storage medium drive.

Note: Be sure to back up your RAM Commander projects frequently. Correct backup procedures eliminate the need to redo your work due to power failures, disk crashes, network faults or other computer problems.

To restore a project

1. Activate the Project list.
2. From the Project menu, choose Restore; the Restore Project dialog box opens.
3. Select the drive of the data storage medium.
4. Select the project backup file you wish to restore. Note that the backup file name should be not longer that 16 characters, only Latin alphanumeric characters are allowed.
5. Choose OK.

RAM Commander restores your project and displays it in the destination drive's list. If the project already exists, enter your confirmation to overwrite it.

6.7 Project copies/revisions

You may copy projects from one drive to another. You may maintain multiple copies of the project in the same project list. You may reuse previous project for the new system analysis if they are similar. You may also create project templates and then create new projects by copying templates.

To copy project from one drive to another:

1. Activate the Project list.
2. Select the project you wish to copy.
3. Activate another Project list on the drive where you wish to copy (Destination list).
4. "Drag and drop" the project you wish to copy from its project list to another project list (Destination list).

RAM Commander copies the project and updates the destination Product tree view.

To create a project copy on the same drive:

1. Activate the Project list.
2. Select the project you wish to copy.
3. Provide unique name for the new project. If you create a new revision of the project, add some revision index to the name of the project (like X1, X2, X3).
4. Press Ok.

RAM Commander copies the project and updates the Product tree view.

6.8 Additional Operations

There are multiple operations available from the Project menu:

Field	Description
Open	Open project's product tree view.
Overview	View the project overview screen with usage statistics and shortcuts to modules
Edit	Edit project properties (description, permissions, FR unit, Revision etc.)
Advanced permissions	Manage project advanced permissions (for project manager, owner or administrator only)
Create	Create a new project
Rename	Change the name of the project
Copy	Create a project copy on the same drive, with different name
Delete	Deletes the project (creating backup in TMP folder under RAM Commander installation folder).
Delete (no backup)	Deletes the project without backup .

Field	Description
Select/Deselect	Toggle project state - Select (or lock) the project and become its manager - or unlock the project and stop being its manager.
Compress	Delete all temporary files inside the project database
Backup	Create a compressed backup file of the project
Restore	Restore project from the compressed backup file

Select the desired project and choose one of the listed operations.

6.9 Project Translation to Different Languages

Sometimes there is a need to translate project data (failure modes, descriptions etc.) to another language (for example, project is created in English but some reports should be provided in French language). The RAM Commander project translation utility helps in performing this task.


The procedure of project translation contains 3 steps:

1. Generate project dictionary
2. Translate dictionary from primary project language to another language
3. Generate translated copy of the project.


This process may be performed multiple times. On the first process iteration you will get a dictionary from all RAMC modules and all textual fields found in the selected project. All these dictionary terms should be translated, and then the translated copy of the project will be generated. On the next stages you will have to translate only new terms, which were added to the source project since the last translation.

The translation process works only in one direction; it means that all changes to the translated copy project will be lost on the next translation iteration. All changes should be applied to the source project, and then they will be copied to the translated project copy after the next translation.

To use this feature, select the source project in the project list and open "Translation" item of the main menu:



Select ""Generate dictionary" item first. When the dictionary is generated, select "Edit dictionary" item and translate all dictionary terms:



After the translation choose "Generate translated copy" menu item, define new project name and the translated copy of the project will be generated.

Perform this process again when the source project is changed and you wish to have the translated copy updated.

Chapter



7

Product Tree

7 Product Tree

Product tree building is the second stage (after [Project Creation](#)) in RAM Commander Reliability, Availability, Maintainability and Safety analysis process.

Product Tree represents full hierarchical product/system structure from main subsystems to the smallest blocks and components like springs, capacitors and resistors, with detailed information about each block or component.

Ref.Des.	ID	Name	Qty	Qpr. FR [10 ⁻⁶]	Status
TUTORIAL	1	Communication System	1	187.0768	++
Communic	1	COMM001	1	100.2550	++
Main Switch	1	SW888	2	8.7416	++
U1	1	8086A	1	0.2442	++
U9	2	80C88	1	0.0000	--
U10	3	80C31	1	0.0862	++
U12	4	LM299	1	0.0625	++
U13	5	74LS30	1	0.0367	++
R1-10	6	RLR	10	0.0890	++
R11-12	7	RN	2	0.0365	++
R30-34	8	RZ	5	0.0849	++
CC1	9	CK	1	0.0619	++
CC2	10	CK	1	0.0619	++
CC3	11	CK	1	0.0595	++
CC4	12	CK	1	0.0607	++
CC5	13	CK	1	0.0614	++
L0-4	14	HLMP-2450	4	0.0144	++
L5-6	15	HLMP-2400	2	0.0072	++
SW1-2	16	DP2	2	3.1361	++
Receiver	2	RC004	10	82.8214	++
Transmitter	3	TR987-001	1	0.3419	++
PS	4	Power Supply	1	8.3500	Us
Control	2	Control Unit	1	75.4953	++
Pedestal	3	PD001	1	11.3265	++

During the *product tree building* phase, enter or import the product tree. Using a top-down process, you decompose the system into a tree of assemblies, subassemblies and components. For each element in the tree, define all required parameters such as environment, reference designator, part number and quantity. RAM Commander increases your productivity by allowing you to retrieve data from various external sources, such as:

- Import of CAD files of most commonly used file types, such as: ASCII, MS Excel, MS Access, Mentor Graphics etc.
- Predefined sets of default values
- Component libraries

Product tree is a pre-requisite for such analysis types as reliability, maintainability, stress analysis, FMECA, Spare parts. Product tree is used by such modules as RBD, FTA, Markov, System Configuration and more.

7.1 Activating the Product Tree View

To activate the Product Tree View

1. Activate the Project list (see [Projects list](#) paragraph in [Working with Projects](#) chapter).
2. Select the project you wish to open.
3. From the **Project** menu, choose **Open**, or right-click and choose **Open** from the pop-up menu, or press **F2**.
4. RAM Commander displays the [Product tree view](#).


7.2 Product Tree Navigation

Product Tree window displays product tree and vertical button bar.

Vertical button bar "Current Analysis" section buttons allow switching the product tree from one analysis type (such as Reliability, Maintainability or FMECA) to another. "Modules" section buttons allow opening additional windows for other analysis types such as RBD, FTA, Safety etc.

Product tree viewer displays the bill of materials. Initially it displays the first level only, but user may open all its sub-levels hierarchically by pressing "+" and "-" buttons. Product tree items may be created, edited, deleted, copied to another location or another project. User may search for items, perform "global change" operations, copy values from one field to another and more.

Product Tree consists of **Items - components** and **assemblies**. **Assemblies** are those items to which children or other components can be added. **Components** are items that cannot have children added to them.

In the Product tree view, RAM Commander displays a  icon next to assembly items. For component items, RAM Commander displays the relevant component icon.

The next paragraphs of this section will explain the navigation in the product tree.

7.2.1 Selecting Current Analysis

There are 5 analysis types based on the same product tree:

Analysis	Description	Examples	Result
Operating	Reliability prediction for equipment in operating mode	Airplane in flight, communications board operating	Failure rate–operating
Non-operating	Reliability prediction for equipment in non-operating mode, such as storage	Airplane in storage; communications board waiting for signal	Failure rate–non-operating
Maintainability	Maintainability prediction	Airplane and communications	MTTR and Mct

Analysis	Description	Examples	Result
y		board under maintenance	
Derating	Derating Analysis	Components' electrical stress conditions	Component stress values
FMECA	Failure modes and effects criticality analysis, Testability analysis	What happens when a failure occurs in one of the system items and how this failure is detected	Criticality, Coverage and Fault Isolation

Product tree is opened in the Operating Reliability analysis type by default. Changing the analysis type changes product tree presentation (relevant fields are shown, like FR, or MTTR and Mct etc.). The list of available reports is also affected by the selected analysis type.

To select the current analysis method

1. Open a Product tree view by selecting the project from the project list and pressing F2 (or right-click and Open).
 2. Select the Current analysis method from the Product tree view button bar.
- or -

From the Project menu, choose Configuration.

The Project Configuration dialog box opens:

Select the required analysis type by clicking the relevant radio-button.
Press Ok.

7.2.2 Expanding and Collapsing

To expand the lower level tree elements

1. Double click on the element with the "+" at the node
 - OR -
2. Click the "+" node

To collapse the lower level elements


1. Double click on the element with a "-" at the node
 - OR -
2. Click the "-" node

To expand all elements of all successor tree levels

1. Select a Product Tree item
2. Choose Expand all tree from the View menu.

7.2.3 Opening items

Product Tree consists of **Items - components** and **assemblies**. **Assemblies** are those items to which children or other components can be added. **Components** are items that cannot have children added to them. There is one special assembly item in each project which represents product tree **Top item**.

In the Product tree view, RAM Commander displays a  icon next to assembly items. For component items, RAM Commander displays the relevant component icon.

To view item data:

1. Open the product tree view.
2. Navigate to the desired item and select it.
3. Double-click the item if it is component or right-click it and choose "Edit" from the popup menu.
4. Item data screen will appear.

The screens are different for top item and for regular components/assemblies.

Regular components/assemblies data dialog contains multiple pages. The page which is related to the currently selected analysis type (Operating, FMECA etc.) is active by default.

See more about item data editing later in this chapter: [Top Item Definition](#) paragraph and [Item Data Editing](#) paragraph..

7.2.4 Search

You may search items in the product tree by combining conditions:

1. Activate the Product Tree view
2. From the Tree menu, choose Search
3. Enter search criteria in the Item Data - Conditions dialog box:

You may put desired filter values in multiple fields, using wildcards. "****" value in the field indicates that this field will not participate in the search filter.

4. Press Ok.

5. The search results are displayed in a separate list:

ID	Ref.Des.	Name	
1.1.1.6	R1-10	RLR	
1.1.1.7	R11-12	RN	
1.1.1.8	R30-34	RZ	
1.1.2	Receiver	CN017016	


6. You may browse the list and use "Locate" button to get the position of the item in the tree. Press "Report" button to print out the list of found items.

You may also locate item in the product tree by the known hierarchical ID (like 1.2.4.5):

1. Activate the Product Tree view

2. From the Tree menu, choose "Go to item".

3. Provide the item hierarchical ID:



4. The item will be located in the product tree.

7.2.5 Changing tree presentation

You may change the source of item "Name" column shown in the product tree, get additional fields displayed in the product tree and switch tree presentation between hardware items and functional blocks.

7.2.5.1 Changing "Name" of tree items


The Product tree view uses the Name column to display one of the following item identifiers:

- Generic Name
- Part number
- Catalog Number
- Military Number

Each item has four identifiers. One of them is always displayed in the Product tree view and in the various reports. The Item ID Priority dialog box sets the order of priority of which name to display for an item in the Product tree view and printed out in the reports. If one field with higher priority is empty for some item, value will be taken from next by priority field. If it is empty too, the next highest priority field value will be taken.

To choose the item identifier you'd like to display / print out as item "name":

1. From the View menu, choose Item ID Priority:



2. Select the priority of the Item ID display.

3. Choose OK.


7.2.5.2 Custom tree fields

The default Product tree presentation may be changed by adding new columns. User can create unlimited number of predefined views, each one with its own set of additional columns such as MTBF, temperature, environment etc:

Ref.Des.	ID	Name	Qty	Opr. FR [10 ⁻⁶]	Status	MTBF	Temp.	Env
TUTORIAL	1	Communication System	1	184.7516	++	5412.674	35.0 GF	
Communic	1	CN017000	1	100.2550	++	9974.565	35.0 GF	
Control	2	CN017334	1	75.4954	++	1.3E+004	25.0 GF	
Pedestal	3	CN017880	1	9.0012	++	1.1E+005	35.0 GF	

To customize the product tree view:

1. Open product tree
2. Choose "Custom Tree fields" from the "View" menu.
3. Click "Add" button, define the profile name.
4. Pick up the desired columns from the list of available RAM Commander database fields. Set width and caption for each field:



RAM Commander database fields are divided into several groups:

Group	Description
GN	General fields
OP	Operating reliability - related fields
NO	Non-Operating reliability - related fields
MN	Maintainability fields

Group	Description
MI	Miscellaneous (price, weight, volume etc.) fields
IL	ILS user-defined fields

5. Press Close.
6. The Product Tree display will be updated to show the user-defined fields.

7.2.5.3 Normal/Functional View

There are two product tree view modes for FMECA module – Normal View (with components) and Functional Blocks View (with FB displayed instead of assemblies). To switch from one mode to another, use **View** menu – **Normal/Functional Block View** mode. See more in [FMECA](#) chapter, [Functional Blocks](#) paragraph.

7.3 Product Tree Building

Product Tree building is usually the next stage after the the new project creation.

Product Tree building involves:


1. General [Project Configuration](#) definition.
2. [Top item data definition](#) (including ambient temperature, environment conditions etc.)
3. Hierarchical tree structure creation with item data input using:
 - a. [Manual data input](#)
 - b. [Import Wizard](#)

7.3.1 Project Configuration

Project-related information like default reliability prediction methods, Maintainability organizational levels or FMECA current phase are defined using Project Configuration dialog.

To change Project Configuration settings:

1. Open a Product tree view.
2. From the Project menu, choose Configuration.
3. The Project configuration dialog box opens:



4. See each specific module chapter for more information about module-specific settings. For reliability prediction you should set required default reliability prediction methods for each family of components (except Assembly) - as shown on the screen above - see [Configuring Reliability Module](#) paragraph. For FMECA you should select phase and criticality - see [Configuring FMECA module](#) and [FMECA Grid Customization](#) paragraphs. For Maintainability you may select different calculation methods and customize levels of replace/repair - see [Customize Organizational Levels](#) and [Set Mct max Calculation Method](#) paragraphs.

7.3.2 Top item definition

Top item is the top level product tree item representing the whole system, device or product.

Top item contains definition of environment conditions and temperature for the whole product. Product subsystems, assemblies and components inherit this information from the top item. Assemblies and components may also have their own definition of temperature and environment. Top items contains also information about Failure Rate allocation to subsequent elements and Maintainability information. See relevant module chapter for setting module-specific information.

To edit top item data:

1. Open product tree view.
2. Select the highest-level tree item (for the newly created project it will be the only item in the tree).
3. Right-click the item and choose "Edit" from the popup menu.
4. Item data screen will appear:

Top item

Reference designator: TUTORIAL

Description: Communication System

Part name: Communication System

Catalog number:

Operating

Environment: GF

Fixed Temp.: 35. °C

Current Environment: GF

Cur. Temp.: 35. °C

FR predicted: 184.752

FR allocated: 0.

Nonoperating

Environment: GF

Fixed Temp.: 25. °C

Nc: 1.

Current Environment: GF

Cur. Temp.: 25. °C

Cur. Nc: 1.

FR predicted: 15.4868

FR allocated: 0.

Maintainability

Level of repair: Organizational

Fault Isolation % to RI Quantity:

N1	1	%1:	92
N2	2	%2:	95
N3	3	%3:	97
N4	4	%4:	98
N5	5	%5:	100

Ambiguity Factor: 1.18

MTTRa, hours: 0.

Confidence level: 70 %

MTTR, hours: 0.374304

Mct max, hours: 0.518208

MLH: 0.374304

Burn-in Temperature: 0. [°C] Burn-in Time: 0 [hours]

OK Cancel

The table below provides explanations for dialog fields abbreviations:

Field	Description
Cur. Temp.	Actual current temperature
FR allocated	Allocated failure rate. Takes effect only if FR source is Allocated
Nc	Number of on/off cycles per 1000 hrs
Cur. Nc	Current number of on/off cycles per 1000 hrs (set to parent's Nc if --- in Nc field)
MLH	Mean labour hour
Level of repair	Level of repair - Inapplicable, Organizational, Intermediate, Depot, Discard
Ambiguity factor	
MTTRa	Allocated Mean Time To Repair
Conf. Level	Confidence level - 70%, 75%, 80%, 85%, 90%, 95%, 98%, 99%, 99.5%, 99.9%
Mct	Maintenance Corrective Time
MTTR	Mean time to repair
Mct max	Mct Calculation result for a given confidence level
N1...N5	Fault isolation to N1...N5 parts with probability %1...%5. User defined non-negative integer values.
%1...%5	Probability of fault isolation to N1...N5 parts. User defined integer between 0-100.

For Environment field you should select one of the standard environment codes defined in different reliability prediction methods - see [Standard Environments](#). Select the environment describing operating (or storage, for non-operating mode) conditions of your product/system.

Set also an ambient operating temperature for your product.

5. Change the required parameters and press Ok.


7.3.3 New item creation

There are two ways of new item creation:

- **Insert** – Inserts an item above the item that was highlighted:



- **Create** – Appends an item as the last 'child' of the parent item highlighted:



To add or insert an item into the Product tree:

1. Activate the Product tree view.
2. Select item in the product tree which will be parent item for the newly created item (Create) or next item in the same level for the newly created item (Insert).
3. From the Tree menu, choose Create or Insert
 - or -
 - right-click the selected item and choose Create or Insert from the popup menu
 - or -
 - press F7 (for Create operation only).
4. Item data dialog will appear:

To add an assembly, select --- in the Family and Item type list boxes.

To enter a component, make the appropriate selections in the Family and Item type list boxes. Define Reference Designator of the item (Ref.Des.).

Then you may define other item information and perform reliability, maintainability prediction and more.

Item data dialog contains multiple pages. The page which is related to the currently selected analysis type (Operating, FMECA etc.) is active by default. Switch between pages to enter the available information.

See "[Item Data Editing](#)" paragraph later in this chapter for more information about the available fields.

5. Choose OK. The product tree view will show the newly created item.

7.3.3.1 New item defaults

One way to speed manual data entry is to set defaults for all new items. When you set such defaults, RAM Commander uses them in the corresponding Item Data dialog box fields during item creation.

To set new item defaults:

1. Activate the Product tree view.
2. From the Project menu, select "New item defaults".
3. Enter default values into the Item Data dialog box. See "[Item Data Editing](#)" paragraph later in this chapter for more information about the available fields.
4. Choose OK.

Next items created in the product tree of this particular project will have predefined values taken from the "New item defaults".

7.3.3.2 Quick Create

Quick Create is used for the fast creation of the component in the Product Tree when the component is located in the [Component Library](#) or when the Part number and Manufacturer is recognized by the [Part Number Recognition](#) algorithm.

In the Product Tree, choose Quick Create from the Tree menu. Enter the information about the component – Generic name (GN) for search in the Component Library, Part number (PN) and Manufacturer for use of recognition algorithm etc.:

Click to select the Open method data screen check box for checking and editing of the component data before inserting it into the tree or leave it cleared if you wish to create the component without additional editing. Click OK.

	C36	17	T491B105M035AS	1	2.490E-004	++
--	-----	----	----------------	---	------------	----

If the component is found in the Library or recognized, it will be added to the Tree.

7.3.4 Item data editing

To edit item data:

1. Open the product tree view.
2. Navigate to the desired item and select it.
3. Double-click the item if it is component or right-click it and choose "Edit" from the popup menu.
4. Item data screen will appear:

Item data dialog contains multiple pages. The page which is related to the currently selected analysis type (Operating, FMECA etc.) is active by default. Switch between pages to enter the available information.

The General page contains general item information like Part Number, Catalog Number, Description and more:

Field	Description
Family	Component family - Electronic or Mechanical. Leave "---" for assembly.
Item type	Component Item type, like resistor, capacitor or spring. Each family has its own list of Item types. See the full list of all possible Item types later in this manual: Item type abbreviations
Ref.Des.	Reference Designator
Part Number	Part Number
Quantity	Quantity of components in the current assembly
Catalog number	Item catalog number typically in-house part identifier
Military number	Item military number
Generic name	Item generic name used in library searches for component data
Description	Item description
Remark	Item remarks
Item Function	Description of item function
Manufacturer	Component manufacturer. Allows manual input or selection from drop-down list of manufacturers.

Field	Description
Background color	Item background color in the tree view. Press "Change" button to set the color using color picker. Colors are convenient way to mark items in the product tree - problematic with red, approved with green etc. - according to your needs.
LCN	Logistics Control Number
ATA Number	The ATA Chapter numbers provide a common referencing standard for all commercial aircraft documentation. This commonality permits greater ease of learning and understanding for pilots and engineers alike. The standard numbering system is controlled and published by the Air Transport Association . The unique aspect of the chapter numbers is its relevance for all aircraft. Thus a chapter reference number for a Boeing 747 will be the same for a Airbus 380. Examples of this include Oxygen (Chapter 35), Electrical Power (Chapter 24) and Doors (Chapter 52).
Repair turnaround time	Time (days) required to send the failed part for repair and get it back repaired. Used in Spare parts calculation/optimization.
SMR Code	Usually 5-character "Source Maintenance Recoverability" code, used for ILS (Integrated Logistics Support)
Condemnation rate	Percent of items needing repair that will not be repaired
Spare parts min	Minimal number of spare parts to be on stock at all times. Used in Spare parts calculation/optimization.
Spare parts max	Maximal number of spare parts allowed. Used in Spare parts calculation/optimization.

Miscellaneous page contains additional optional parameters:

Field	Description
Item price	Item's price in selected currency
Currency	Currency code (USD, EUR etc.)
Item weight	Item weight in kilograms
Item volume	Item volume
Power consumption	Power consumption in watts
Current consumption	Current consumption in Amperes
Burn-in Temperature	Burn-in temperature in degrees centigrade (see Burn-In Report for more information)
Burn-in Time	Burn-in time in hours (see Burn-In Report for more information)
PI FY	Result from burn-in calculation. First year multiplier (ratio of the first year failure rate to the steady state failure rate).
ILS Data	Integrated Logistics Support user-defined fields. You may change both field name and field value to specify additional information which does not fit the predefined Item Data dialog fields

For reliability prediction and analysis you should also define the environment and temperature of product tree assemblies and components - see next paragraph [Environment and Temperature Definition](#) for more information.

See more information about other Item data dialog pages related to the specific analysis type (Operating/Non-operating reliability, Maintainability, FMECA etc.) in relevant chapters later in this manual.

5. Press Ok - product tree view and the database will be updated.

7.3.4.1 Environment and Temperature Definition

For reliability prediction and analysis you should also define the environment and temperature of product tree assemblies and components.

Product environment and temperature should be defined on the top item data screen - see paragraph [Top item definition](#).

All underlying components and assemblies in the product tree inherit their environment and temperature settings from higher level items, if their Environment is set to "---" and temperature is set to Delta=0 (in red):

Environment/Profile and Temperature	
Set specifically for the current item	Effective/inherited from parent item
Environment: ---	GF
Temperature: Delta 0. °C	35. °C

Parent item has environment=GF and temperature = 35, this assembly has default (---) environment and no temperature raise (Delta=0) so its current conditions are GF and 35 degrees too (in green). You do not need to set or change environment or temperature of items if they are the same as for their parent items.

If environment of some assembly differs from parent items, change its Environment (see [Standard Environments](#)).

If temperature of some assembly differs from parent items, there are two options:

- **Delta**

Select "Delta temp" and set the difference if there is some relative temperature change on some assembly. In example below we have 5 degrees temperature raise, from 35 degrees of parent assembly to 40 degrees on current assembly:

Environment/Profile and Temperature	
Set specifically for the current item	Effective/inherited from parent item
Environment: ---	GF
Temperature: Delta 5. °C	40. °C

Please note that if parent assembly temperature will be changed, the temperature of this sample assembly (and all its sub-levels) will be recalculated automatically, keeping the relative raise of 5 degrees.

- **Fixed**

Select "Fixed temp" and set the fixed temperature on assembly if you have some block with controlled constant temperature which does not depend on whole product's operating temperature (for example, aircraft operating at -50 degrees but having cockpit temperature +15 degrees). In example below we have fixed temperature of 15 degrees set for some assembly which parent assembly has temperature of 35 degrees:

Environment/Profile and Temperature	
Set specifically for the current item	Effective/inherited from parent item
Environment: ---	GF
Temperature: Fixed 15. °C	15. °C

See several product tree examples for one more illustration of this concept:
In the first image top item temperature is set to 35:

Ref.Des.	Temp.Settin...	Resulting Cur. Temp.
TUTORIAL	...	35.0
Communic	. Delta=0 ...	35.0
Receiver	. Delta=10 ...	45.0
Main Switch	. Delta=10 ...	45.0
U1	. Delta=0 ...	45.0
U10	. Delta=0 ...	45.0
U12	. Delta=0 ...	45.0
U13	. Fixed=40 ...	40.0
U9	. Delta=0 ...	45.0
PS	. Fixed=23 ...	23.0
Transmitter	. Delta=5 ...	40.0
C1-2	. Delta=0 ...	40.0
C3-5	. Delta=4 ...	44.0
Pedestal	. Fixed=15 ...	15.0
Antenna	. Delta=0 ...	15.0
Motor	. Delta=5 ...	20.0
Bearing	. Delta=0 ...	15.0

Then it is changed to 20 degrees:

Ref.Des.	Temp.Settin...	Resulting Cur. Temp.
TUTORIAL	...	20.0
Communic	. Delta=0 ...	20.0
Receiver	. Delta=10 ...	30.0
Main Switch	. Delta=10 ...	30.0
U1	. Delta=0 ...	30.0
U10	. Delta=0 ...	30.0
U12	. Delta=0 ...	30.0
U13	. Fixed=40 ...	40.0
U9	. Delta=0 ...	30.0
PS	. Fixed=23 ...	23.0
Transmitter	. Delta=5 ...	25.0
C1-2	. Delta=0 ...	25.0
C3-5	. Delta=4 ...	29.0
Pedestal	. Fixed=15 ...	15.0
Antenna	. Delta=0 ...	15.0
Motor	. Delta=5 ...	20.0
Bearing	. Delta=0 ...	15.0

Pay attention to temperature change (keeping relative deltas) of items with "delta" temperature settings and no change for items with "fixed" temperature settings.

7.3.4.2 Standard Environments

For Environment field you should select one of the standard environment codes defined in different reliability prediction methods. The standard list of environments appears below, but some prediction methods (GJB, FIDES, IEC, 217 Plus) may provide different list:

Abbreviation	Definition
AIA	Airborne, Inhabited, Attack
AIB	Airborne, Inhabited, Bomber
AIC	Airborne, Inhabited, Cargo
AIF	Airborne, Inhabited, Fighter
AIT	Airborne, Inhabited, Trainer
ARW	Airborne, Rotary, Winged
AUA	Airborne, UnInhabited, Attack
AUB	Airborne, UnInhabited, Bomber
AUC	Airborne, UnInhabited, Cargo
AUF	Airborne, UnInhabited, Fighter
AUT	Airborne, UnInhabited, Trainer
CL	Cannon, Launch
GB	Ground, Benign
GF	Ground, Fix
GM	Ground, Mobile
GMS	Ground, Missile Silos
MFA	Airbreathing, Missile, Flight
MFF	Missile, Free Flight
ML	Missile, Launch
MP	Manpack
NH	Naval, Hydrofoil
NS	Naval, Sheltered
NSB	Naval, Submarine
NU	Naval, UnSheltered
NUU	Naval, Undersea, UnSheltered
SF	Space, Flight
USL	Undersea, Launch

7.3.5 Additional operations with items

7.3.5.1 Deleting items

1. Activate the Product tree view.
2. Click on the item you want to delete
-OR-
Select multiple items using MS-Windows standard line selection conventions.
3. From the Tree menu, choose Delete
-OR-
press the Delete button
-OR-
right-click the item and choose Delete from the pop-up menu.
4. Enter your confirmation in the Attention dialog box (select Yes for single item delete or "Yes to all" to approve the deletion of multiple selected items at once).
5. RAM Commander updates the Product tree view and the database.

Caution: Be careful when deleting items from the Product tree view. There is no Undo facility to easily recover deleted items.

See also [Organize](#) procedure later in this chapter.

7.3.5.2 Copy/Move items

The RAM Commander Product tree view provides support of the drag-and-drop and copy and paste functions. You can copy branches and individual items between projects or inside one project.

To copy items in the same project

1. Open the Product tree view
2. Select one or more items to copy using usual MS-Windows item selection conventions.
3. Choose Copy from the Item menu (or press Ctrl+C, or click Copy on the toolbar)
4. Select the parent Assembly where you wish to copy the selected items
5. Choose Paste from the Item menu (or press Ctrl+V, or click Paste on the toolbar)

To copy items from one project to another or in the same project

1. Open the Product tree view of both the source and target projects
- OR -
From the Windows menu, choose New Window to open the second window of the same project.
2. Activate the source Product tree view.
3. Select one or more items to copy using usual MS-Windows item selection conventions.
4. Hold down the left mouse button and drag the selected item(s) into the target project and drop them on the desired parent.

To "copy with insert" items between projects or in the same project

1. Perform steps 1-3 of the above instruction
2. Hold down the <Shift> button, drag the selected items into the target Product tree view window, and drop the items on the item you want to appear directly after the copied items.

To move items between projects or in the same project

1. Open a Product tree view of both the source and target projects
- OR -

- From the Windows menu, choose New Window to open the second window of the same project.
2. Activate the source Product tree view.
 3. Select one or more items to copy.
 4. Hold down the <Ctrl> button, drag the selected item(s) into the target Product tree view, and drop them on the desired parent.

To “move with insert” components between Product tree views

1. Perform steps 1-3 of the above instruction.
2. Hold down <Shift> + <Ctrl> buttons, drag the selected items into the target Product Tree view window, and drop the item(s) on the item you want to appear directly after the moved item(s).

Note: Do not forget to calculate the project after you have made changes to your Product tree view to ensure that correct data will be displayed in the Product tree view.

Copying Items Between Projects

You can easily copy components from one product tree to another:

1. Open Product tree views for both the source and target projects.
2. Activate the source Product tree view.
3. Select one or more items to copy in the source Product tree view.
4. Hold down the left mouse button and drag-and-drop the selected item(s) onto the target item in the target Product tree view.
5. RAM Commander displays the target Product tree view with the new items.

Note: When copying items into the same project, open a new Product tree view for that project by choosing New Window from the Window menu. Use one Product tree view as the source and the other as the target.


You can also open up several Product tree views for one project and copy components between them. This is useful in cases where you add virtually identical assemblies to a project.

7.3.5.3 Global Change

You can quickly make changes to multiple items in the product tree. You can assign changes to all items within a product tree, or to items that satisfy a search condition. The global change applies from the selected tree item down the tree.

Making Global Changes to a Product Tree View:

1. Activate the Product tree view containing the items you want to change.
2. From the Tree menu, choose Global Change. The settings dialog will appear:



3. In the Global Change dialog box, do one of the following:
 - To make changes to items that satisfy the selection criteria, select the Use Condition check box.
 - To make changes to all product tree items down from the current item, do not select the Use Condition check box.
4. Select one of the following options from the Apply to list:
 - Current level – one level down from the item selected
 - All sub-tree – all levels down from the item selected
5. Select one of the following options from the Type list:
 - Tree – to change product tree item data (like Part Number, temperature, LCN, level of repair etc.)
 - Processor – to change the prediction method-specific data (like resistor type, PSR, Quality level etc.)
6. Choose OK.
7. If the Use Condition check box in step 3 was selected, enter search criteria in the Item Data - Conditions dialog box.

The condition is a logical “AND” between values entered in the fields. For instance, in the illustration below, the search condition is for those optoelectronic LEDs that have 3 character displays AND that include Logic:

OPTOELECTRONIC DEVICES MIL-HDBK-217FN2 : Conditions

Part name: ***

Mil. num.: ***

Cat. num: ***

Generic name: ***

Style: LED DISCRETE

(only for Led Display)

of characters: 3

Logic exists: YES

T junction

Delta Tjc: *** or *** ***

Quality: ***

Pl q: ***

Lead Configuration: *** Distance: *** (mils)

OK

Cancel

Help

*** appearing in a field in the Conditions dialog box means that each field changed from *** to another value will participate in the Global change conditions.

8. In the Item Data: New Values dialog box, select or enter new values in those fields to be modified.

*** appearing in a field in the New Values dialog box means that each field changed will result in a corresponding parameter change for all items (depending on the conditions in Conditions dialog box) during the Global Change.

9. Choose OK.

10. RAM Commander updates the Product tree view with the new values.


7.3.5.4 Massive Entry

One of the most time consuming tasks in reliability analysis is entering component data. RAM Commander provides a fast and convenient way to enter components with the Massive Entry option. You can also use the Massive Entry option to view and edit component data.

7.3.5.4.1 To open the Massive Entry list

1. Activate the Product tree view and highlight the assembly to which the new components will be structured.
2. From the Tree menu, choose Massive Entry; the Massive Entry list window opens:



3. The list initially shows all components belonging to the selected product tree assembly - for the specific prediction method, family and Item type.
4. Change the method, Family and Item type selection to view other components.
5. Press the  icon to the left of the method selection to select another product tree assembly and view its components.

7.3.5.4.2 To add new items in a Massive Entry list

Massive Entry offers four options for adding new items to a project:

- Creating a new item
- Copying a single item
- Creating multiple copies of an item (N-copy)
- Quick create

To create a new item


1. Open the Massive Entry list.
2. Make selections for prediction method, family and Item type in the list's list boxes.
3. From the Item menu, choose Create
 - OR -
 - Press F7
4. The component data entry window opens.
5. Enter component data and choose OK.
6. Repeat steps 2–4 to add more components.

To copy a single item with the Massive Entry list

To copy an item within the Massive Entry list, click on it and select Copy from the Item menu. RAM Commander appends the new item to the end of the list and assigns it the next available number in the # column.

To create multiple copies of an item (N-copy)

1. Click on an item in the massive entry list.
2. From the Item menu, choose N-Copy; the N-Copy dialog box opens:




3. In the Number of Copies field, enter the required number of copies.
4. To give each new item a unique reference designator, select the Increment Ref. Des. check box (works when the last character is a numeric, for example if you create 3 copies of component R1 you will get R2, R3 and R4).
5. Choose OK.

RAM Commander updates the massive entry list and Product tree view with the new items.

Quick Create

Should you have a Generic Name, Part Number, Military Number or Catalog Number, but you don't know the component Item type, choose Quick Create from the Item menu to find the item in the component library.

The Quick Create dialog box opens:



Provide the component identifier you know and RAM Commander will try to find its data in the component library.

The Massive entry list will automatically switch to that group of items.

7.3.5.4.3 Additional operations with the list

To add, edit or delete items in a Massive Entry list:

Right-click and select the appropriate option from the pop-up menu

- OR -

From the Item menu, choose Create, Delete or Edit.

To make global changes to a Massive Entry list:

Select "Global change" from the Item menu - See "[Global change](#)" paragraph for more information.

To select multiple items in a Massive Entry list:

Use the gray asterisk key (*) or right-click and choose Select/Deselect from the pop-up menu to toggle item select.

Use this facility to copy or delete several items at once.


To find the tree location of an item in a Massive Entry list:

From the Item menu, choose Tree Location.

The Select Tree Item dialog box opens, displaying the item's location in the product tree.

7.3.5.4.4 Count Parts Utility

Using the Count Parts utility from the Massive Entry menu, you can view the number of parts by Item type in the current Massive Entry list display:



This can be useful, since the Massive Entry list displays only one Item type at a time.

To invoke the Count Parts utility, activate the Massive Entry list and from the Massive Entry menu, select Count Parts.

To view the Item type in the Massive Entry list, select it and choose Go to.

7.3.5.4.5 Massive Entry Reports

1. Activate the Massive Entry list.
2. Choose Report from the menu bar.
3. The Massive Entry table report window opens:

Massive Entry Report for Project TUTORIAL Drive C:
Method : MIL-217F-2 P. stress

ELECTRONIC
IC-Analog

#	Ref.des.	PN	Type	Application (GaAs MMIC)	# of transist.	Active pins	Package	Years in production	Qual	Theta jc/ja	Power dissipat.
7	U2	26LS32	Linear	---	88	---	DIP Nonh	---	---	---	---

ELECTRONIC
IC-Digital

#	Ref.des.	PN	Techn	Type	# of elements	Active pins	Package	Years in production	Qual	Theta jc/ja	Power dissipat.
5	U1	74HC04	CMOS	GATE/LOGIC ARRAYS	6	14	SMT Nonh	---	Custom	40.0	---
6	U4	74AS1035	TTL	GATE/LOGIC ARRAYS	6	---	---	---	---	---	---
8	U5	74LS123	BICMOS	GATE/LOGIC ARRAYS	12	16	SMT Nonh	---	---	36.0	---
9	U3	Z8001	NMOS	MicroProcessor	---	---	---	---	---	---	---

ELECTRONIC
Resistor

#	Ref.des.	PN	Style	PSR	Poper	DT	Qual
3	UR1	RZ	RZ	---	---	---	---
4	UR2	RZ	RZ	---	---	---	---


7.3.5.5 Copy between fields

Use this option to copy values from one field to another for the entire product tree or for some branch in the product tree, or for some items within the defined condition. For example, you may copy values from Reference Designator to Generic Name field.

To use this option:

1. Activate the Product tree view containing the items you want to change.
2. From the Tree menu, choose Global Change.
3. In the Global Change dialog box, do one of the following:
 - To make changes to items that satisfy the selection criteria, select the Use Condition check box.
 - To make changes to all product tree items down from the current item, do not select the Use Condition check box.
4. Select one of the following options from the Apply to list:
 - Current level – one level down from the item selected
 - All sub-tree – all levels down from the item selected
5. Select one of the following options from the Type list:
 - Tree – to change product tree Item Data
 - Processor – to change the prediction method in Item Data
6. Choose OK.
7. If the Use Condition check box in step 3 was selected, enter search criteria in the Item Data - Conditions dialog box.

8. Choose the source and destination fields to copy data from the drop-down lists.



9. Choose OK.

7.3.5.6 Marking with Colors

You may use color selection for product tree items as a convenient way of item status, importance, responsibility or approval indication.

Ref.Des.	ID	Name	Qty
<input type="checkbox"/> TUTORIAL	1	Communication System	1
<input type="checkbox"/> Communic	1	CN017000	1
<input type="checkbox"/> Main Switch	1	CN017004	2
<input type="checkbox"/> U1	1	8086A	1
<input type="checkbox"/> U9	2	80C88	1
<input type="checkbox"/> U10	3	80C31	1
<input type="checkbox"/> U12	4	LM299	1
<input type="checkbox"/> U13	5	74LS30	1
<input type="checkbox"/> R1-10	6	RLR	10
<input type="checkbox"/> R11-12	7	RN	2
<input type="checkbox"/> R30-34	8	RZ	5
<input type="checkbox"/> CC1	9	CK	1
<input type="checkbox"/> CC2	10	CK	1
<input type="checkbox"/> CC3	11	CK	1
<input type="checkbox"/> CC4	12	CK	1
<input type="checkbox"/> CC5	13	CK	1
<input type="checkbox"/> LD-4	14	HLMP-2450	4
<input type="checkbox"/> L5-6	15	HLMP-2400	2

To mark product tree items with different colors

1. Activate the Product tree view.
2. Select one or more items to mark using usual MS-Windows item selection conventions.
3. Right-click and choose "Color...", and then choose a color using color picker.
4. Click OK. The items change their color.

7.3.5.7 Organize

Each product tree item has its number by order in its level. This number is given automatically by RAM Commander during the tree building. However RAM Commander does not automatically renumber the item numbers as you delete items from an assembly. The sequence in the Product tree view can therefore have "jumps" in it (like 1,2,5,6,8 etc.). To reset the item number sequence (e.g. 1,2,3,4,5,6) you must "organize" the level or the whole tree.

To organize a Product tree:

1. Activate the Product tree view.

2. From the Tree menu, select Organize.
3. RAM Commander displays the Product tree view with a continuous sequence of item numbers.

7.4 Import/Export

RAM Commander has customizable product tree data import and export facilities.

You may import product tree data from various data sources (Excel, Access, Text etc.) using [Import Wizard](#) and Export product tree data into customizable Excel files - see next paragraphs for more information.

7.4.1 Import Wizard

One of the several techniques of populating the product tree is to import components from the BOM (Bill of Materials) or other information sources such as ERP systems, commonly used Reliability Data Bases etc.

The **Product Tree Import Wizard** builds the entire product tree, importing data such as Ref.Des., Qty, Catalog Number or Part number, etc from various formats like MS Excel, MS Access and Text. It may import also thermal analysis results and stress information.

However it does not import component technical data provided by manufacturer such as resistor type, capacitor's capacitance IC-Digital number of gates or bits etc. For this information import you should use Component Library data import - see the [Reliability Libraries and Defaults](#) chapter for more information.

The Import Wizard facilitates the import of the tree data saved in one of the following file types:

- Text
- Mentor Graphics
- MS Access
- MS Excel


Import wizard is customizable and allows mapping of your source file fields to RAM Commander database fields.

To run the Import Wizard:

1. Activate the Product tree view.
2. From the Tools menu, choose Import Wizard.
3. The import wizard [Step 1](#) window will appear - see next paragraphs for further instructions.

7.4.1.1 Step 1

1. Step 1 dialog of the import procedure will appear after the process initiation:



2. Select the desired file type from the list of choices:

- **Text** - for Text/ASCII files, with comma, semicolon or tab delimiters or with fixed-width fields. Suitable also for CSV files.
- **Mentor Graphics** - for Mentor Graphics "BOARD STATION COMPONENTS FILE FORMAT 2.0".
- **MS Access** - for MDB files.
- **MS Excel** - for Excel files (XLS, XLSX).

If the file type is Excel, you will have additional options to choose the MS Excel file access technology:

- **ODBC** – reading Excel data by ODBC driver. Does not require MS Excel installation on your computer, but has different requirements to Excel file format and different limitations (e.g. data type in each column should be consistent, column names should start with Latin letter, worksheet name should start with Latin letter and should contain only letters and digits, without characters like .,()[]{}~+=#\$%^&*~ or spaces, etc.). It is the technology used by previous versions of RAM Commander
- **Excel Automation** – requires MS Excel installed on your computer, may work slower than the ODBC mode, but does not have limitations and requirements listed in the "ODBC" item above. Recommended mode.

3. Select script: the Import Wizard allows you the choice of:


- Importing directly from an import file. Use the Import Wizard screens to assist in the preparing the import file for the data transfer into the RAM Commander.
- Using an already existing script with field mapping information. Using existing scripts saves time and effort when importing similar files. Select an appropriate script from the list. Import Wizard prepares your import file for the data transfer according to the specified script. You may add a new script to the existing list of scripts at the last step of the Import Wizard procedure. Adding a new script is recommended when you plan to import similar files in the future.

4. Select file form import. Press the Browse button, select the file and press "Open".
5. Press Next button.

The next step of the procedure differs for different types of input file: see [Step 2 - Text files](#) , [Step 2 - MS Excel/Access files](#) or [Step 2 - Mentor Graphics files](#).

7.4.1.2 Step 2 - Text files

1. Step 2 text file import dialog will appear:



2. Select the text file format type:

- Delimited – characters such as comma, tab, etc. separate each field.
- OR -
- Fixed Width – fields are aligned in the fixed width columns.

For Delimited type, select delimiter - Comma, Space, Tab or Other (select specific delimiter character).

3. If texts in your file are wrapped by quote marks - select the appropriate "Text qualifier".


4. If first row of your file contains field names/labels/captions - click the "Labels on first line" checkbox. It usually the case with CSV files.

5. Set the "Start at row" value if required - it allows you to begin the data import from any point within the data file being imported.

6. Press Next to go to the [Step 3](#).

7.4.1.3 Step 3 - Text files

1. Step 3 text file import dialog will appear if "Fixed width" text file format is selected - it allows dividing the input file into data columns:



If other text file format was selected during the Step 2 - the Step 4 will be initiated.

2. Follow the instructions on the dialog to set field limits.


3. Press Next to go to the [Step 4](#).

7.4.1.4 Step 2 - Mentor Graphics

The importing procedure for Mentor Graphics files has only 2 steps. After you have browsed to locate the Mentor Graphics import data file, the import procedure takes you to the last stage of the import, see [step 5 of the text file import](#).

7.4.1.5 Step 2 - Excel/Access files

1. Step 2 Access/Excel file import dialog will appear:



2. Select the required table/worksheet and press Next to go to the [next step](#).

Note:

Your excel file sheet names should start with Latin letter and should not contain spaces or special characters - only letters and digits.

Your worksheet used for import should contain column headers in the first line, and data range should start from the second line, without additional sections, empty lines etc.

See the next paragraph for Excel file import troubleshooting.

7.4.1.5.1 Troubleshooting

Q: Not all the worksheets from my Excel file appear in RAM Commander Import Wizard – what should I do?

A: RAM Commander uses Microsoft ODBC drivers to access Excel file. It puts some limitations to Excel file:

- a. Worksheet name should start with Latin letter and should contain only letters and digits, without characters like .,()[]{}-+=#\$%^&*~ or spaces.
- b. Worksheet being imported should contain one consistent table (not multiple tables with spaces between them).
- c. Data type for each column will be defined using first 16 rows. If numeric data is entered to the cell type "Text" they it be interpreted as text, if text data is entered to cells with type "General" or "Numeric" they will be interpreted as numeric.

Q: Why not all the cells of a specific column are imported?

A: All the cells of a specific column should be of the same type in Excel – either numeric or text. If cell types are not consistent some values will not be imported.

If the desired column type is Text, you may:

1. Add ' symbol as prefix to all numbers in the cell

or

2. Create additional column and define a formula =CONCATENATE("",X:X) where X:X is your source column you wish to convert. Then use this new column for the import.

If the desired column type is numeric, you may create additional column and define a formula =VALUE(X:X) where X:X is your source column you wish to convert. Then use this new column for the import.

Q: What should I do when I have to import an Excel file, in which some fields that should be character type are defined as numeric (containing only digits) by Excel and therefore are imported into RAM Commander in numeric format?

A: If you enter data with digits only, Excel automatically defines the data as Numeric. If you wish to use the data as string data later, you should define the column as "Text" **before data input.**

However, there is a way to solve this problem. In the example below, the PartName column is defined as Numeric in Excel.


	A	B	C
1	PartName	RefDes	Qty
2	321432188	R1	1
3	321487328	R2	2
4	324321432	R3	21
5	134543154	C3	1
6	754657656	C2	2
7	874844748	C1	3
8	254636363	U6	2
9	245435786	U17	2
10	321431114	Ctrl	1

To convert the column data to character format, do the following:

1. Create an empty column near the source column and enter the following formula:
=REPLACE(CONCATENATE("",B:B),1,1,"")
where B:B is index of the column you wish to convert.
2. Provide the column name in the first row.
3. Do the same for all columns which require data type conversion.
4. Save the worksheet, open RAM Commander and perform the import, using newly created converted columns instead of the original.

7.4.1.6 Step 3/4 - Mapping

The next step (4 for text files and 3 for Access/Excel files) is the same for different file types. During this step you need to map the columns in your file to corresponding columns in RAM Commander database:



The mapping screen displays a preview of your import file. In each column, first row displays original column name in your import file (if available), second row provides selection with the list of corresponding RAM Commander fields, and all the rest rows show the preview values from import file.

You need to go through all the columns and select a corresponding RAM Commander field from the list of fields in the second row for each data column. Just click the drop-down list arrow on each column's header in the table and then select the corresponding field.

The RAM Commander fields are grouped accordingly to the module they belong to:

- General (Family, Item type, Part number, description, etc.) - see [Item data editing](#) for more information.
- Operating (Environment, temperature, field FR etc.)
- Non-operating (Environment, temperature, field FR etc.)
- Maintainability (level of replace/repair, MTTR, etc.)
- Miscellaneous (Price, volume, etc.) - see [Item data editing](#) for more information.
- ILS / Integrated Logistics Support (user-defined fields) - see [Item data editing](#) for more information.

Full list of fields you may see in the paragraph [Database Fields Index](#) later in this manual.

However there are several entries in the field names list which do not correspond to any of the existing RAM Commander database fields:

- [Ignore](#) – select for fields you wish to ignore (and do not import).
- [Depth](#) – select the data column presenting the imported item level in the tree hierarchy. The Depth field allows the hierarchical construction of the tree.
- [Parent Ref. Des.](#)

- [Hierarchical Parent Ref. Des.](#)
- [Stress](#)
- [Search in library](#)

See next paragraphs for more information about each one of these fields.

There are also several fields which contain list values and not just numeric or character values - these field will be imported correctly if correct values/codes/abbreviations are provided. See more information about correct acceptable values for the following fields later in this chapter:

- [Item type](#)
- Environment (see [Top item definition](#) for environments list). Do not set environment for each item if it is the same for the whole project or assembly - environment and temperature data are inherited from higher level items.
- [Level of replace/repair](#)
- [Failure Rate source switch](#) selection
- [MCT/MLH source switch](#) selection


The bill of materials being imported may contain **hierarchy**. There are several options for hierarchical BOM import which you may choose using the "Tree hierarchy" drop-down list:

- **Plain** – there is no hierarchy, all the file is imported as plain list of parts.
- **Depth** – the hierarchy is based on the Depth field. See for example the Depth field in the import file below and the corresponding tree structure:

Input:

	A	B	C
1	Depth	RefDes	Qty
2	1	System	1
3	2	Assembly 1	1
4	3	Part 1.1	1
5	3	Part 1.2	1
6	2	Assembly 2	1
7	3	Part 2.1	1
8	3	Part 2.2	1

Output:




- **ID** – the hierarchy is based on item hierarchical identifier, like 1.2.3.4, where each number corresponds to the number by order of the element on each level. This format is useful for importing data which were previously exported from RAM Commander and updated outside of RAM Commander (e.g. in Excel file). See for example the ID field in the import file below and the corresponding tree structure:

Input:

	A	B	C
1	ID	RefDes	Qty
2	1	System	1
3	1.1	Assembly 1	1
4	1.1.1	Part 1.1	1
5	1.1.2	Part 1.2	1
6	1.2	Assembly 2	1
7	1.2.1	Part 2.1	1
8	1.2.2	Part 2.2	1

Output:




- **LCN** - the hierarchy is based on item LCN (Logistics Control Number), which reflects each item's position in the product hierarchy. See for example the LCN field in the import file below and the corresponding tree structure:

Input:

Output:

	A	B	C
1	LCN	RefDes	Qty
2	AA	System	1
3	AAAA	Assembly 1	1
4	AAAAAA	Part 1.1	1
5	AAAAAB	Part 1.2	1
6	AAAB	Assembly 2	1
7	AAABAA	Part 2.1	1
8	AAABAB	Part 2.2	1




- **Parent Ref.Des.** - the hierarchy is based on information about Reference Designator of each item and each item's parent item Reference Designator. See for example the Ref.Des. and Parent Ref.Des. fields in the import file below and the corresponding tree structure:

Input:

	A	B	C
1	RefDes	Qty	ParentRefDes
2	System	1	
3	Assembly 1	1	System
4	Part 1.1	1	Assembly 1
5	Part 1.2	1	Assembly 1
6	Assembly 2	1	System
7	Part 2.1	1	Assembly 2
8	Part 2.2	1	Assembly 2

Output:



Please note that if you select some hierarchy mode, you need to have the corresponding column in your input data file.

Perform the mapping for all desired import file fields and press Next to go to the [next step](#).

7.4.1.6.1 Database Fields Index

This paragraph provide an index to all product tree database fields which may be imported using import wizard (and also exported using the Report Generator).

Field name	Remarks
General	
ID	item hierarchical identifier, like 1.2.3.4
Depth	Numeric, 1 or higher. See Depth field
Item type	Component Item type, like resistor, capacitor or spring. Each family has its own list of Item types. See Item type abbreviations
Reference designator	
Quantity	Quantity of components in the current assembly. Numeric, 1 or higher
Generic name	Item generic name used in library searches for component data
Catalog number (Factory ID)	Item catalog number typically in-house part identifier
Military number	Item military number
Part number (Manufacturer ID)	Part number by manufacturer

Field name	Remarks
Description	
Remark	
Item Function	
Logistics Control Number	LCN
Spare Part Turnaround time	Time (days) required to send the failed part for repair and get it back repaired. Used in Spare parts calculation/optimization.
Spare Part Condemnation Rate	Percent of items needing repair that will not be repaired
Spare Part Minimal Qty	Minimal number of spare parts to be on stock at all times. Used in Spare parts calculation/optimization.
Spare Part Maximal Qty	Maximal number of spare parts allowed. Used in Spare parts calculation/optimization.
SMR	Source Maintenance Recoverability code, used for ILS (Integrated Logistics Support)
Manufacturer	
Search in library	See Search in Library
Parent Ref.Designator	See Parent Ref.Des. field
Hierarchical Parent Ref.Des.	See Hierarchical Parent Ref.Des. field
Functional Block	0-regular item/component (default) or 1 - functional block
ATA Number	The ATA Chapter numbers provide a common referencing standard for all commercial aircraft documentation. This commonality permits greater ease of learning and understanding for pilots and engineers alike. The standard numbering system is controlled and published by the Air Transport Association. The unique aspect of the chapter numbers is its relevance for all aircraft. Thus a chapter reference number for a Boeing 747 will be the same for a Airbus 380. Examples of this include Oxygen (Chapter 35), Electrical Power (Chapter 24) and Doors (Chapter 52).
Operating	
Temperature (fix)	See Environment and Temperature Definition
Temperature (delta)	See Environment and Temperature Definition
Environment	Standard environment code, like GB, GF, GM etc. See Standard Environments
Manual FR Source description	
FR up source switch	See Failure Rate source switch
FR Predicted	
FR user-defined	
FR Field	
FR Allocated	
Duty cycle	
Field factor (oper.)	
Reliability allocation weight	See Failure Rate Allocation
MTBF Manual	

Field name	Remarks
Stress information	See Stress
CAP (Applied current)	
CRA (Rated current)	
CSR (Current stress ratio)	
FRA (Frequency Applied)	
FRS (Frequency SR)	
PDI (Power Dissipation)	
PSR (Power Stress ratio)	
PRA (Rated Power)	
TJC (Delta temp. junction to case(ambient))	
VAA (Applied voltage (alternative))	
VAP (Applied voltage (direct))	
VDA (Applied voltage drain source)	
VDR (Rated Voltage drain source)	
VDS (Voltage stress ratio drain source (VSRds))	
VGA (Applied voltage gate source)	
VGR (Rated Voltage gate source)	
VGS (Voltage stress ratio gate source (VSRgs))	
VRA (Rated Voltage)	
VSR (Voltage stress ratio)	
Functional Block FR ratio	
Non-operating	
Non-Operating Temperature (fix)	See Environment and Temperature Definition
Non-Operating Temperature (delta)	See Environment and Temperature Definition
Non-Operating Environment	Standard environment code, like GB, GF, GM etc. See Standard Environments
Non-Operating Manual FR Source description	
Non-Operating FR up source switch	See Failure Rate source switch
Non-Operating FR Predicted	
Non-Operating FR user-defined	
Non-Operating FR Field	
Non-Operating FR Allocated	
Number of cycles / 1000 Hours	
Non-Operating Field factor (nonop.)	
Non-Operating Reliability allocation weight	See Failure Rate Allocation
Non-Operating MTBF Manual	
Maintainability	
Level of repair	See Level of replace/repair
Level of replace	See Level of replace/repair
MCT/MLH up source switch	See MCT/MLH source switch
MCT Predicted	
MCT Manual	
MCT Allocated	
MLH Predicted	

Field name	Remarks
MLH Manual	
Maint. allocation weight	See Maintainability Allocation
Miscellaneous	
Currency	Currency code (USD, EUR etc.)
Price	Item's price in selected currency
Current consumption [A]	Current consumption in Amperes
Power consumption [W]	Power consumption in watts
Weight [Kg]	Item weight in kilograms
Volume [M^3]	Item volume
Customizable	
ILS custom field N1(Char)	
ILS custom field N2(Char)	
ILS custom field N3(Char)	
ILS custom field N4(Char)	
ILS custom field N5(Char)	
ILS custom field N6(Char)	
ILS custom field N7(Char)	
ILS custom field N8(Char)	
ILS custom field N9(Char)	
ILS custom field N10(Char)	
ILS custom field N1(Value)	
ILS custom field N2(Value)	
ILS custom field N3(Value)	
ILS custom field N4(Value)	
ILS custom field N5(Value)	

7.4.1.6.2 Item Code abbreviations

Item type field values in the imported file should contain the following abbreviated values (or Item type values as appears in RAM Commander):

Family = Electronic

Abbreviation	Item type
BUBM	Bubble memory
CAPC	Capacitor
CBRK	Circuit breaker
CIND	Coil, inductive device
CONR	Connector and IC sockets
CONT	Connection
FLTR	Filter (can be tree hierarchy item)
FUSE	Fuse

Abbreviation	Item type
HFDI	High frequency diode
HFTR	High frequency transistor
HYBR	Hybrid IC (tree hierarchy item)
ICAN	IC Analog
ICDI	IC Digital
ICME	IC Memory
LAMP	Lamps incandescent
LFDI	Low frequency diode
LFTR	Low frequency transistor
LGAS	Laser gas
LSEM	Laser Semiconductor device
LSOL	Laser solid state
METR	Meter
MISC	Miscellaneous
OPTE	Optoelectronic device
POTN	Potentiometer
PWBD	Printed wiring board
QCRY	Quartz Crystal
RELY	Relay (can be tree hierarchy item)
RESI	Resistor
ROTD	Rotating device
SACW	Surface acoustic wave
SUBS	Substrate (tree hierarchy item)
SWIT	Switch
TUBE	Tube
UNDF	Undefined tree hierarchy item

Family = Mechanical

Abbreviation	Item type
ACCE	Accelerometer
ACCU	Accumulator
ACTU	Actuator
AIRC	Air Conditioner
ALAR	Alarm

Abbreviation	Item type
ANTE	Antenna
AXLE	Axle
BATT	Battery
BEAR	Bearing
BELL	Bellows
BELT	Belt
BLOW	Blower
BRAC	Bracket
BRAK	Brake
BRUS	Brush
BUSC	Bus Connection
BUSH	Bushing
CABL	Cable
CAMM	Cam
CAME	Camera
CLAM	Clamp
CLIP	Clip
CLUT	Clutch
COPR	Compressor
COMP	Computer peripheral
CONT	Contact
CONC	Connector Accessory
CORD	Cord
CNTE	Counter & Timer
COUP	Coupling
CRAN	Crank
DETE	Detector
DRIV	Drive
DRUM	Drum
DUCT	Duct
ENGI	Engine
FANN	Fan

Abbreviation	Item type
FAST	Fasteners
FITT	Fitting
GASK	Gasket
GAUG	Gauge
GEAR	Gear
GENE	Generator
GIMB	Gimbal
GYRO	Gyros
GYSC	Gyroscope
HEEX	Heat exchangers
HEAT	Heater
HOSE	Hose
HOUS	Housing
IGNI	Igniter
INDI	Indicator
INST	Instrument
INSU	Insulator
INTE	Intercomm
JOYS	Joystick
KEYB	Keyboard
KNOB	Knob
LENS	Lens
LIGH	Light
LOUD	Loudspeaker
MAGN	Magnet
MANI	Manifold
MFLT	Mechanical filter
MMIS	Miscellaneous
MODU	Module
MOTO	Motor
MOUN	Mount
NUTT	Nut

Abbreviation	Item type
OPTI	Optical
PANE	Panel
PINM	Pin mechanical
PWRS	Power Supply
PWRT	Power Transmitter
PRIN	Printer
PROP	Propeller
PULL	Pulley
PUMP	Pump
RECO	Recorder
REGU	Regulator
SEAL	Seal
SENS	Sensor
SEPA	Separator
SERV	Servo
SHAF	Shaft
SHOC	Shock absorber
SOLE	Solenoid
SPRI	Spring
SPRO	Sprocket
STAR	Starter
SYNC	Synchro
TANK	Tank
TELE	Telescope
TERM	Terminal Connection
TRAN	Transducer
TUBI	Tubing
VALV	Valve
WASH	Washer
MONI	Monitor


7.4.1.6.3 Depth field

The Depth column represents the imported item level in the tree hierarchy. The Depth field allows the hierarchical construction of the tree.

For example, for the following BOM file:

Field_1	Field_2	Field_3	Field_4
1	CARD		A12
2	C2	C0603C472K1RAC	A12
2	C3	C0603C472K1RAC	A12

If Field_1 is defined as Depth, then the result will be as follows:




7.4.1.6.4 Parent Ref.Des. field

Parent Ref. Des. (reference designator) contains the parent's name of the component whose data is defined in the current row.

For example, for the following BOM file:

Field_1	Field_2	Field_3	Field_4	Field_5
C2	C0603C472K1RAC	C0603C472K1RAC	A12	DSP
C3	C0603C472K1RAC	C0603C472K1RAC	A12	FLASH
C1	C0603C472K1RAC	C0603C472K1RAC	A12	DSP

If you define Field_5 in the Parent Ref.Des. column, and Field_1 in the Ref.Des. column, the result, after importing, will be:




7.4.1.6.5 Hierarchical Parent Ref.Des. field

Hierarchical Parent Ref. Des. contains parent reference designators of all of the levels above the current component.

For example, for the following BOM file:

Field_1	Field_2	Field_3	Field_4	Field_5
AAA				
BBB				AAA
CCC				AAA
DSP				AAA.BBB
FLASH				AAA.BBB
FLASH				AAA.CCC
C2	C0603C472K1RAC	C0603C472K1RAC	A12	AAA.BBB.DSP
C3	C0603C472K1RAC	C0603C472K1RAC	A12	AAA.CCC.FLASH
C1	C0603C472K1RAC	C0603C472K1RAC	A12	AAA.BBB.FLASH

If Field_5 will be defined as Hierarchical Parent Ref. Des., then the result will be:



7.4.1.6.6 Stress

Stress information for components is used during reliability predictions. RAM Commander Import wizard allows importing multiple types of actual stress values.

There are two possibilities for stress import in Import Wizard:

- If it is constructed of semicolon-delimited abbreviation=value pairs like "TJC=5;VSR=0.4;" - use field "Stress Information" in "Operating" group.
- If each stress (like VSR, PSR etc.) is located in its own separated field in the import file, select field names from the "Operating" group according to stress type.

After successful import you will see imported stress parameters on each component reliability prediction method data screen:

Resistor MIL-HDBK-217FN2

Ref. des.: R1-10 QTY: 10 ENV: GF Temp: 49. °C

Part name:

Mil. num.:

Cat. num.:

Generic name: RLR

Style: RLR - Fixed, Film (Insulated), Est.Rel.

PSR: 0.2

Poper.: ...

Prat.: 1.

Note: Stress information is imported and taken into consideration **only** if all the conditions below are

true:

- Default reliability prediction method was defined for the project (see [Project Configuration](#))
- Load from Library is selected on the last Import Wizard step (see [Step 4/5 - Finish](#))
- Load from library for part was successful (part was found in library/automatic PN recognition etc.)

See the table of available stress types and their abbreviations in the table below:

Abbreviation	Description
CAP	Applied current
CSR	Current stress ratio (CSR)
PDI	Power dissipation
PSR	Power stress ratio (PSR)
TJC	Delta temperature junction to case (ambient)
VAA	Applied voltage (alternative)
VAP	Applied voltage (direct)
VDA	Applied voltage drain source
VDS	Voltage stress ratio drain source (VSRds)
VGA	Applied voltage gate source
VGS	Voltage stress ratio gate source (VSRgs)
VSR	Voltage stress ratio (VSR)
VRA	Rated Voltage
VGR	Rated Voltage gate source
VDR	Rated Voltage drain source
CRA	Rated Current
PRA	Rated Power
FRA	Frequency Applied
FRS	Frequency SR

Each component type (Item type) has its specific list of stress types it could have.

See the matrix below for the list of all Item types and their relevant stresses (split into two tables):

Part I (IC memory - Hf transistor)

Stress parameter	IC memory	IC analog	IC digital	Resistor	Potentiometer	Capacitor	Switch	Relay	Lf diode	Lf transistor	Hf diode	Hf transistor	Stress parameters
TJC	+	+	+						+	+	+	+	TJC
PDI	+	+	+	+	+		+		+	+	+	+	PDI
PSR	+	+	+	+	+		+		+	+	+	+	PSR

VSR		+		+	+	+	+	+	+	+		+	VSR
VAP	+	+	+	+	+	+	+	+	+	+		+	VAP
VAA						+							VAA
VGS	+	+	+							+		+	VGS
VGA	+	+	+							+		+	VGA
VDS										+		+	VDS
VDA										+		+	VDA
CSR		+					+	+	+	+	+	+	CSR
CAP		+					+	+	+	+	+	+	CAP
FRA	+		+										FRA
FRS	+		+										FRS
VRA	+	+	+			+			+	+		+	VRA
VGR										+		+	VGR
VDR										+		+	VDR
CRA							+	+	+				CRA
PRA				+	+					+			PRA
Stress parameters	IC memory	IC analog	IC digital	Resistor	Potentiometer	Capacitor	Switch	Relay	Lf diode	Lf transistor	Hf diode	Hf transistor	Stress parameters

Part II (Optoelectronic - Breaker)

Stress parameters	Optoelectronic	Bubble memory	Connector	Inductive	Fuse	Laser Diode	SAW	Lamp	Filter	Breaker	Stress parameters
TJC	+	+				+					TJC
PDI	+	+				+	+				PDI
PSR	+	+				+	+				PSR
VSR	+		-	+	+			+	+		VSR
VAP	+			+	+			+	+		VAP
VAA											VAA
VGS			+								VGS
VGA			+								VGA
VDS											VDS
VDA											VDA

CSR	+		+	+	+			+	+	+	CSR
CAP	+		+	+	+			+	+	+	CAP
FRA											FRA
FRS											FRS
VRA	+										VRA
VGR											VGR
VDR											VDR
CRA											CRA
PRA											PRA
Stress parameter s	Opto-electronic	Bubble memory	Connector	Inductive	Fuse	Laser Diode	SAW	Lamp	Filter	Breaker	Stress parameters

7.4.1.6.7 Search in Library

Search in library column is used in case when a single column contains more than one type of following item identifiers:

- Generic Name (component library key)
- Catalog Number (Cross-reference key)
- Military Number (Cross-reference key, special military parts library)
- Part number (key in automatic recognition, Cross-reference key)

Map such column of your import file to "Search in library" column.

For example, some specific BOM file may have single identification field named "ID", and for some records it may contain Part Number, for some records it may contain Military Number etc. Each one of these identification types has its own formula for search in libraries, cross-references etc. - so RAM Commander will try to use each value first as GN, then as CN, then as MN and then as PN.

7.4.1.6.8 Level of replace/repair

Level of replace/repair field values in the imported file should contain the following abbreviated values:

Abbreviation	Description
UN	Unapplicable
OR	Organizational, level 1
IN	Intermediary, level 2
DE	Depot, level 3
SU	Supplier, level 4
OE	Manufacturer, level 5
DI	Discard

7.4.1.6.9 Failure Rate source switch

Failure Rate source switch field values in the imported file should contain the following abbreviated values:

Abbreviation	Description
CA	Calculated
MA	Manual / User-defined
FR	Field / FRACAS
AL	Allocated


7.4.1.6.10 MCT/MLH source switch

MCT/MLH source switch field values in the imported file should contain the following abbreviated values:

Abbreviation	Description
CA	Calculated
MA	Manual / User-defined
AL	Allocated

7.4.1.7 Step 4/5 - Finish

Step 5 of the import procedure (for Access/Excel files it is step 4) is the final stage of the import:



Here you can save a new script for future use with similar files. Saving your import definitions (script) can save you time and effort when you import files similar in structure to the one you've just created a script for. You may then choose one of the previously saved import scripts on the first step of

Import Wizard process.

Choose "Load from Library" option if you wish RAM Commander to find your components in the reliability data component library and load their information for reliability prediction/calculation. See the [Load from Library](#) paragraph in [Reliability Libraries and Defaults](#) chapter for more information on this function. You have to select "Load from Library" option to import stresses (like VSR/PSR etc.) successfully.

Then press Finish to start the import process. RAM Commander will load the data and will present the updated product tree.

7.4.1.8 Using Import Wizard for tree update

Import Wizard may be used not only for the product tree initial building, but also for automatic data update in the existing product tree.

File used for update should contain field with exact item product tree item identifier which will be used for finding the corresponding item in existing product tree. It could be:

- Reference Designator (if it is unique in product tree or imported branch)
- ID (hierarchical ID like 1.2.3.4)

You may export product tree from RAM Commander to MS Excel, perform required changes in Excel and import this file back to RAM Commander, updating the existing information. You need to export product tree to Excel if you wish to use unique ID identifier option listed above. For more information about RAM Commander product tree export to MS Excel see "[Export](#)" paragraph of this chapter.

To perform update using Import Wizard:

1. Open product tree view.
2. Select top item or required branch/assembly.
3. Proceed with the standard import wizard procedure - see [Import Wizard](#) paragraph earlier in this chapter.

7.4.2 Export

RAM Commander Report Generator allows custom report definition and generation. Then such report may be saved in Excel file. This way you may export product tree data into Excel file and have the excel file created with only columns you need, in order you need etc.

To perform product tree data export to Excel:

1. Open product tree view.
2. Select top item (or any branch/assembly you wish to export)
3. Open Report generator and create your report (export format) definition. See the [Report Generator](#) paragraph for more information.

Typical export example is shown below:

Report Definition

Export to D-LCC Add Delete

Title: _____

Report

Scan method: W - D by level

Separate levels Depth: 9

Include items: Items

Project Drive Current Date Project name

Generate Setup Close

#	Group	Field	Width	Column Name	Sort Order
1	GN	Depth	2.0	Depth	No
2	GN	Ref. designator	11.0	Ref. des.	No
3	GN	Part name	31.0	Part name	No
4	DP	MTBF selected	10.3	MTBF	No
5	MN	MCT	8.1	MCT	No
6	MN	Level of repair	15.0	Level of repair	No
7	MN	Level of replace	15.0	Level of replace	No
8	MI	Item price	10.2	Price	No

Field

Add Delete Edit Move Up Move Down

4. Generate the report.
5. Select "Public with MS Excel" option from the Report menu.
6. Excel file will be created and open in Excel.

7.5 Reports


You may generate different Product Tree reports using Standard reports or Report Generator.

For standard reports:

1. Select top item in the product tree.
2. Choose "Standard Kit..." from the Reports menu.
3. Select required report type (like Tree diagram), sub-type and parameters.
4. Press Ok.
5. The generated report will appear:

Tree Diagram Report

Project name: TUTORIAL



See RAM Commander Fundamentals Chapter - "[Reports](#)" for more information.

For Report Generator:

Report generator allows designing your own customized reports. See the [Report Generator](#) paragraph for more information and instructions.

Chapter



8

Reliability Calculation

8 Reliability Calculation

The **reliability calculation/prediction** is usually the third stage (after [Project Creation](#) and [Product Tree Building](#)) in RAM Commander Reliability, Availability, Maintainability and Safety analysis process. Create the project and build the product tree before you may proceed with the procedures explained in this chapter.

During this stage user should obtain failure rate for components in the product tree. RAM Commander will then calculate the sum of component failure rates to calculate the FR of assemblies, subsystems, systems and of the whole product:

Ref.Des.	ID	Name	Qty	Opr. FR [10 ⁻⁶]	Status
[-] TUTORIAL	1	Communication System	1	187.1111	++
[-] [-] Communic	1	CN017000	1	100.2550	++
[-] [-] [-] Main Switch	1	CN017004	2	8.7416	++
[-] [-] [-] [-] U1	1	8086A	1	0.2442	++
[-] [-] [-] [-] U9	2	80C88	1	0.2678	++
[-] [-] [-] [-] U10	3	80C31	1	0.0862	++
[-] [-] [-] [-] U12	4	LM299	1	0.0625	++
[-] [-] [-] [-] U13	5	74LS30	1	0.0367	++
[-] [-] [-] [-] R1-10	6	RLR	10	0.0890	++
[-] [-] [-] [-] R11-12	7	RN	2	0.0365	++
[-] [-] [-] [-] R30-34	8	RZ	5	0.0849	++
[-] [-] [-] [-] CC1	9	CK	1	0.0619	++
[-] [-] [-] [-] CC2	10	CK	1	0.0619	++
[-] [-] [-] [-] CC3	11	CK	1	0.0595	++
[-] [-] [-] [-] CC4	12	CK	1	0.0607	++
[-] [-] [-] [-] CC5	13	CK	1	0.0614	++
[-] [-] [-] [-] L0-4	14	HLMP-2450	4	0.0144	++
[-] [-] [-] [-] L5-6	15	HLMP-2400	2	0.0072	++
[-] [-] [-] [-] SW1-2	16	DP2	2	3.1361	++
[-] [-] [-] [-] Receiver	2	CN017016	10	82.8214	++

RAM Commander may perform the reliability prediction for both **Operating** and **Non-Operating** modes.

There is a number of ways to calculate components Failure Rate:

1. Performing [reliability prediction](#) using one from more than 30 reliability prediction methods (such as MIL-HDBK-217, Telcordia, Siemens, FIDES, NPRD-95 etc.)
2. [Specifying \(manually or importing\) fixed Failure Rate](#) received from manufacturer or from field use failure statistics.
3. [Specifying known Failure Rates for known temperatures and environments](#) (using the [GPRD library](#))
4. [Allocating failure rates](#) from assemblies down to the components (assign a required FR to an assembly and have RAM Commander allocate the required FR to each of its children)

Each way has its own advantages and disadvantages and is appropriate in particular conditions.

8.1 Configuring Reliability Module

There is a number of prerequisites and a number of options you may set up before starting the reliability prediction:

1. Create project
See the [Creating a new project](#) paragraph.
Pay attention to FR units selection - it will affect your resulting FR display
2. Build the Product Tree
See the [Product Tree Building](#) paragraph.
Pay attention to specifying the temperature and environment for the top item and also to the assemblies and components (if required).
3. Choose the analysis mode - Operating or Non-operating
See the [Operating vs Non-Operating Mode](#) paragraph
4. Select default Reliability prediction methods.
See the [Project Configuration](#) paragraph and [Choosing suitable Reliability Prediction Method](#) paragraph.

Then you may start components reliability data input and calculation.

8.1.1 Operating vs Non-Operating Mode

RAM Commander supports reliability calculations for both **operating** and **non-operating** modes.

However, reliability calculations are made for the current analysis mode. That is, if you are in operating mode, RAM Commander performs the reliability calculation for operating mode only: it does not perform the calculation for non-operating mode. To compute reliability predictions for non-operating mode, you must set the current analysis to non-operating mode (see the [Selecting Current Analysis](#) paragraph).

If you entered all your tree data in operating mode, you can use the Translate function to migrate the relevant data to non-operating mode.

8.1.2 Choosing suitable Reliability Prediction Method

RAM Commander supports more than 30 different reliability prediction methods. Different methods use different calculation models and assumptions, use different input data and may give different results for the same component. Some methods are suitable for mechanical components only, some for electronic, some methods can't provide prediction results for some temperature ranges, some old methods do not provide results for new component types (like 64-bit microprocessors in old MIL-217) etc. All these characteristics should be taken into consideration during the method selection.

ALD Ltd. does not invent the reliability prediction methods - we just implement and computerize the calculation models described in officially published standards. That's why RAM Commander user manual does not provide help and detailed instructions to specific reliability methods usage - you have to be a reliability engineer, you have to obtain, read and understand the specific reliability prediction standard book you are going to use. Only then there will be a confidence in results you get from RAM Commander.

Classification of reliability prediction methods and some short description for the most popular methods is given in the table below - it may help to choose the required reliability prediction method for your project:

Method	Mode	Supported components	Features	Description
ALCATEL	Operating	Electronic		
BELLCORE Issue 5	Operating	Electronic		Document reference TR-NWT-000332
BELLCORE Issue 6	Operating	Electronic		
BRITISH TELECOM HRD4	Operating	Electronic		
BRITISH TELECOM HRD5	Operating	Electronic		
CNET RDF93 rev 02/95	Operating	Electronic	French	Based on CNET, French reliability prediction method for commercial applications
FIDES 2004	Operating	Electronic	Mission-profile based	The latest reliability prediction standard created by FIDES Group - a consortium of leading French international defense companies: AIRBUS, Eurocopter, Giat, MBDA and THALES.
FIDES 2009	Operating	Electronic	Mission-profile based, New	New version of FIDES 2004, Edition A, September 2010
GJB/Z 299B P. count	Operating	Electronic	Chinese	
GJB/Z 299B P. stress	Operating	Electronic	Chinese	
GJB 299C P. count	Operating	Electronic	Chinese, New	Both import and Chinese parts
GJB 299C P. stress	Operating	Electronic	Chinese, New	Both import and Chinese parts
GPRD	Operating and Non-operating	All		General Part Reliability Data - suitable for storage of temperature-dependent failure rates (see Specify known temperature-dependent FR) and also time-to-failure statistics and Weibull parameters calculation
HDBK-217Plus	Operating	Electronic	Mission-profile based, New	Published in May 2006 by Reliability Information Analysis Center (RIAC)
HRD5 TELECOMM	Operating	Electronic		
IEC 62380	Operating	Electronic	Mission-profile based	RDF 2003. New version of UTE C 80-810.
ITALTEL IRPH93	Operating	Electronic		
MIL-217E-1 P. stress	Operating	Electronic		by Department of Defence, USA
MIL-217F-1 P. count	Operating	Electronic		

Method	Mode	Supported components	Features	Description
MIL-217F-1 P. stress	Operating	Electronic		
MIL-217F-2 P. count	Operating	Electronic		
MIL-217F-2 P. stress	Operating	Electronic		
NPRD-95	Operating and Non-Operating	Mechanical and Electro-Mechanical	Library of aggregated historical failure rates data.	A library of failure rates for a large number of non-electronic components under various environments. The source of this data is the document NPRD-95, "Non-electronic Parts Reliability Data", released by RAC. Part category which provides a rough classification of parts (e.g., actuators, batteries, pumps, etc.) should be selected for each device. Next, the user selects a certain subtype (e.g., for batteries - Carbon Zinc, Lithium, etc.).
NSWC-98/LE1 Mechanics	Operating	Mechanical		US NAVY, Carderock Division of the Naval Surface Warfare Center. Nineteen basic mechanical components have been identified for which reliability prediction equations have been developed. All mechanical equipment is composed of some combination of these nineteen components. A designer can utilize the equations to determine individual component reliability and then combine the results in accordance with the system reliability diagram to determine total system reliability in its operating environment.
Telcordia Issue 1	Operating	Electronic		Telcordia SR332, Issue 1, May 2001
Telcordia Issue 2	Operating	Electronic		Reliability Prediction Procedure for Electronic Equipment, SR-332, Issue 2, September 2006
Telcordia Issue 3	Operating	Electronic	New	Reliability Prediction Procedure for Electronic Equipment, SR-332, Issue 2, January 2011
Siemens SN 29500-1	Operating	Electronic		
Siemens SN 29500-2005-1	Operating	Electronic		
Stress/Strength Analysis	Operating	All	Calculates Unreliability, not Failure Rate	Calculation of Failure Probability (Unreliability) by distribution parameters of Stress and Strength.
UTE C 80-810	Operating	Electronic	Mission-profile based, French	RDF 2000. Provides complex models that can handle permanent working, on/off cycling and dormant applications
MIL-217E-1 draft	Non-operating	Electronic		

Method	Mode	Supported components	Features	Description
RADC-TR-85-91	Non-operating	Electronic		
Reliability Toolkit (1995)	Non-operating	Electronic		Translates operating Failure Rates to Non-operating using coefficients.

When the decision is taken, you may set the default reliability prediction method for the whole project (see paragraph [Project Configuration](#)) or/and set different method for each particular component (see [Item FR Calculation](#) paragraph later in this chapter).

8.2 Item FR Calculation

FR calculation should be performed only for the lowest (component) level of product tree elements. Assembly FR will be calculated then as a sum of failure rates of underlying components.

There is a number of ways to calculate components Failure Rate:

1. Performing [reliability prediction](#) using one from more than 30 reliability prediction methods (such as MIL-HDBK-217, Telcordia, Siemens, FIDES, NPRD-95 etc.)
2. [Specifying \(manually or importing\) fixed Failure Rate](#) received from manufacturer or from field use failure statistics.
3. [Specifying known Failure Rates for known temperatures and environments](#) (using the [GPRD library](#))
4. [Allocating failure rates](#) from assemblies down to the components (assign a required FR to an assembly and have RAM Commander allocate the required FR to each of its children)

See next paragraphs for more information about each of these methods.

For any of these methods, you will need to open item data screen and switch to Operating or Non-Operating tab.

To open the item data screen in Operating or Non-Operating mode:

1. Open the product tree view.
2. Navigate to the desired item and select it.
3. Double-click the item if it is component or right-click it and choose "Edit" from the popup menu.
4. Item data screen will appear.
5. Switch to Operating or Non-Operating tab:

Item Data

General / Logistics | **Operating** | Nonoperating | Maintainability | Derating | Miscellaneous | FMECA

Family: ELECTRONIC Ref.Des.: CC2
 Item type: Capacitor Part number:

Environment/Profile and Temperature

Set specifically for the current item Effective/inherited from parent item

Environment: --- GF
 Temperature: Delta 2. °C 47. °C

FR Prediction/Calculation Settings

Method selection: default
 Method: MIL-217F-2 P. stress MIL-217F-2 P. stress
 Failure distribution: Exponential

Failure Rate / Reliability Data

FR Source: Predicted *Field factor: 1.
 FR predicted: 6.19047e-002 *Duty cycle: 1. Item FR: 6.19047e-002
 FR user-defined: 0. *Mult.factor: 1.
 FR field: 0. +Add. factor: 0.
 FR allocated: 1.5101e-002 *Quantity: 1.
 Complexity for FR allocation: 1.5699e-01 Ka_spec: 1.
 Source of user-defined FR: Kb_spec: 0.

Status
 Check: O.K.
 Calc.: O.K.

OK Cancel Apply Help

You will see the following fields there:

Field	Description
Family	Component family - Electronic, Mechanical or Electro-Mechanical. Leave "---" for assembly.
Item type	Component Item type, like resistor, capacitor or spring. Each family has its own list of Item types.
Ref.Des.	Reference Designator
Part Number	Part Number
Quantity	Quantity of components in the current assembly
Environment	Item environment (see Top item definition for list of environments)
Cur. Environment	Current environment (set to parent's environment if "---" set in Environment field)
Delta/Fixed temperature	Type of ambient temperature. If Fixed temp. is set, the item's temperature is equal to the value entered in the adjacent °C field. If Delta Temp, the item's temperature is equal to the value in the adjacent °C field plus the parent's temperature.
Temperature	Temperature in °C
Cur. Temperature	Actual current temperature
Method of FR p calculation	Set default to use reliability prediction methods defined in Project Configuration (Project Configuration), set "user-defined" to set specific reliability prediction method (other than default) for currently selected component.

Field	Description
Method	Selected reliability prediction method (MIL-217, NPRD, FIDES etc.).
Failure distribution	Failure distribution type: Exponential, Weibull, Time-independent
Source for failure rate	Source of failure rate selection - predicted, user-defined, field or allocated
FR p	Predicted (calculated) failure rate
FR u	User defined failure rate. Takes effect only if FR source is "user defined " (see above)
FR f	Failure rate from field data or from field data/FRACAS. Takes effect only if FR source is "Field" .
FR a	Allocated failure rate. Takes effect only if FR source is "Allocated". See Failure Rate Allocation
Complexity for FRa	Complexity factor for reliability allocation. This parameter is valid if you selected Allocated failure rate
Field factor	Field factor multiplier for computing item failure rate
Duty cycle	Duty cycle multiplier for computing item failure rate
Mult. factor	Multiplicative factor multiplier for computing item failure rate
Add. factor	Additive factor multiplier for computing item failure rate
Item FR	Computed failure rate value of current item. Item FR = (base FR (FR predicted, FR user-defined, FR field or FR allocated, according to FR source switch) * Field factor * Duty Cycle * Mult.Factor + Add. factor) * Quatity.
Status - Check	Data validation status, set automatically: --- = no status Err = Error (appears as - in product tree) Warn = Warning (appears as X in product tree) O.K. = OK (appears as + in product tree)
Status - Calc	FR calculation status, set automatically: --- = no status Err = Error (appears as - in product tree) Warn = Warning (appears as X in product tree) O.K. = OK (appears as + in product tree)
Source of FR u	Description of user-defined or field Failure rate source (manufacturer data, field data, accelerated life testing data, other database etc.)
Nc	Number of on/off cycles per 1000 hrs
Cur. Nc	Current number of on/off cycles per 1000 hrs (set to parent's Nc if — in Nc field)

See next paragraphs for different ways of FR definition or calculation.

8.2.1 Component Failure Rate prediction

RAM Commander provides more than 30 methods/standards for reliability prediction (Failure Rate calculation). See [Choosing suitable Reliability Prediction Method](#) paragraph for their list.

To predict component's reliability:

1. Create component in the product tree. (See [New item creation](#) and [Item data editing](#) paragraphs in the [Product Tree](#) chapter), open component's data screen (double-click it in the product tree).
2. Make sure to define the following data for the component:
 - Family and Item type
 - Part Number or Generic Name
 - Environment and temperature (if applicable and if differs from parent item - see [Environment and Temperature Definition](#) paragraph for more information). Environment and temperature

selection affect predicted failure rate.

3. Make sure that FR source switch is set to "predicted":

FR Prediction/Calculation Settings

Method selection:

Method:

Failure distribution:

Failure Rate / Reliability Data

FR Source: *Field factor: Item FR:

FR predicted: *Duty cycle: *Mult.factor: +Add. factor: Status: Check: Calc.:

FR user-defined: *Quantity: Ka_spec: Kb_spec:

FR field: Complexity for FR allocation: Source of user-defined FR:

FR allocated:

4. Select prediction method:

- To use default prediction method for the selected family, choose Method of FR p calculation = "default":

FR Prediction/Calculation Settings

Method selection:

Method:

Failure distribution:

- To use prediction method other than default, select Method of FR p calculation = "user-defined" and choose required method from the "Method" drop-down list:

FR Prediction/Calculation Settings

Method selection:

Method:

Failure distribution:

Failure Rate / Reliability Data

FR Source:

FR predicted:

FR user-defined:

FR field:

FR allocated:


Complexity for FR allocation:

5. Press the large button with the selected reliability prediction method name.

6. Reliability parameters data screen will appear for the selected component and selected prediction method:

The screen contains all parameters used in calculation model and formulas of the selected reliability prediction method for the selected component type. Each reliability prediction method has its own model, and models differ between component types - so each screen looks differently and has its own list of parameters. These parameters will not be described in this manual - please refer to the handbook/standard of the selected method for more information. However this manual provides some information for some implementation-specific or special cases - see next paragraphs.

7. Fill in known parameter values. For parameters left undefined ("---") some typical default values

will be taken. You may review these default values by pressing the  button. See [Calculation Defaults](#) paragraph for more information about these default values.

8. Instead of filling the required parameters manually, you may use Component Library. You may search component library by component's generic name, and retrieve it's data from the library. You may also insert new components and their data to the component library. See [Using Component Libraries in Reliability Prediction](#) paragraph for more information. See also [Part Number Recognition](#) paragraph and all the [Reliability Libraries and Defaults](#) chapter.

9. After known parameter values are provided, press the Ok button.

10. RAM Commander will calculate the Failure Rate and it will be displayed on the item data dialog:

Failure Rate / Reliability Data

FR Source:	<input type="text" value="Predicted"/>	*Field factor:	<input type="text" value="1."/>	Item FR:	<input type="text" value="3.66604e-002"/>
FR predicted:	<input type="text" value="3.66604e-002"/>	*Duty cycle:	<input type="text" value="1."/>		
FR user-defined:	<input type="text" value="0."/>	*Mult.factor:	<input type="text" value="1."/>	Status	Check: <input type="text" value="O.K."/>
FR field:	<input type="text" value="0."/>	+Add. factor:	<input type="text" value="0."/>		
FR allocated:	<input type="text" value="0.237635"/>	*Quantity:	<input type="text" value="1"/>		
Complexity for FR allocation:	<input type="text" value="1."/>	Ka_spec:	<input type="text" value="1."/>		
		Kb_spec:	<input type="text" value="0."/>		

11. You may press Ok on item data dialog to close it and return to the product tree, where you may open the next component and perform the same procedure again.

The procedure described below is the most basic procedure. You do not have to enter each component screens one by one and set reliability parameters. You may save a lot of time by using advanced procedures, like:

- Import the product tree using [Import Wizard](#), then perform [Load from Library](#) procedure, then run "Recalculate all" (see [Project Recalculation](#)) - all components will be retrieved from the library and calculated.
 - Use Quick Create for manual but quick creation of single components.
- These methods will be useful only if you have Component Library and all (or many) of components you are using in your Bill Of Materials may be found in your libraries.

8.2.1.1 Special Fields in the Prediction Method Screens

8.2.1.1.1 Junction Temperature

Junction temperature is computed as follows:

$$T_J = T_C + \Theta_{JCP}$$

where

T_J = worst case junction temperature (°C)

T_C = case temperature (°C)

Θ_{JC} = junction-to-case thermal resistance (°C/watt)

P = power dissipation

When computing delta junction case temperatures, RAM Commander provides three input parameters:

- Delta junction case temperature (dT_{JC})
- Thermal resistance
- Power dissipation

If you enter a value for delta junction case temperature (dT_{JC}), RAM Commander ignores the others when making computations.

If no value for (dT_{JC}) exists, RAM Commander computes it using values for Q_{JC} and P using the logic shown in the table below.

Input parameters (fields)		Formula for dT_{JC}
Thermal resistance Θ_{JC}	Power dissipation (P)	
User defined	User defined	$\Theta_{JC} \text{ (User)} * P \text{ (User)}$
User defined	—	$\Theta_{JC} \text{ (User)} * P \text{ (Default)}$
—	User defined	$\Theta_{JC} \text{ (Default)} * P \text{ (User)}$
—	—	$dT_{JC} \text{ (Default)}$

Set temperature parameters for an item in its reliability prediction method parameters data screen.

8.2.1.1.2 Stress values

The actual stress values may be provided in multiple reliability prediction method.

Stress group box with values appears on the reliability prediction method data screen for these methods - see MIL-STD-217 for Capacitor for example:

See the full list of available stress parameters for different components in the [Stress](#) of [Product Tree](#) Chapter.

RAM Commander computes stress ratios for passive components such as resistors and capacitors.

There are three fields used in computing stress ratios: ratio itself, applied value, and rated value. For example for the capacitor it is:

VSR	Voltage stress ratio
Vapl	Applied voltage
Vrat	Rated voltage

If you enter a value for VSR, RAM Commander uses it to compute stress ratios using the formulas in MIL-HDBK-217 F. If VSR has no value, RAM Commander computes it using the formula:

$$VSR = Vapl (User) / Vrat(User)$$

Formulas for power stress ratio (PSR) and capacitance stress ratio (CSR) are similar.

8.2.1.2 Method-Specific features

8.2.1.2.1 NPRD-95

RAM Commander incorporates the NPRD-95 (Non-electronic Parts Reliability Data) reliability prediction method. This method is applied to mechanical and other non-electronic parts.

To calculate a failure rate (FR) for a part using NPRD-95, you must first define its calculation method as NPRD.

To define NPRD as the calculation method

1. Activate the Product tree view.
2. Create a new item by pressing **F7**
 - OR -
- Edit an existing item by pressing ALT+Enter,
 - OR -
- Right-click and choose **Edit**
 - OR -

From the **Tree** menu, choose **Edit**.

The **Item Data** dialog box appears.

3. Select **Mechanical** in the **Family** list box.
4. Make a selection from the **Item type** list box.
5. Type a reference designator in the **Ref. Des.** field.
6. Select **User defined** as the **Method of FRp Calculation** (which can be defined as default in Project Configuration).
7. Select the **NPRD-95** option in the **Method** field.

8. Click the **NPRD-95** button.

The part's NPRD dialog box opens:

RAM Commander's NPRD database contains information on failure rates for various Item types keyed by part family, Item type, part description, environment and quality level. NPRD failure rates are not given for all combinations of these parameters. RAM Commander attempts to find the failure rate using two sets of data: primary and secondary. You can tell RAM Commander how to perform the search by:

- Using only the "automatic search" definition
- Using only the "manual selection" definition
- Using the manual selection only if the "automatic search" fails.

On the NPRD-95 screen you need to define the appropriate Part Description which describe, in the best way, your specific part. Then you need to select the Quality level. After all this selections according with Part Description + Environment + Quality – RAM Commander search for FR in NPRD-95 database. Two scenarios may occur: a) the FR exists in the NPRD-95 for selected set of data; b) there isn't FR for selected set of the data (because NPRD failure rates are not given for all combinations of these parameters).

To solve situation for scenario b) you need to use the manual record selection, where you can define similar part/description/quality level/environment – not exact as you have in the system but as close as possible.

"Manual selection" also supports situation when NPRD-95 contains FR for conditions specified (for example for environment GB) (scenario a), but when you change some product tree settings (like environment to GF) in the Product Tree you may come to situation where NPRD-95 does not contain

exact FR for these new settings any more (scenario b) - and then RAM Commander may take data according to the manual selection, if defined.

Note: If you select a manual selection choice, you will always get an FR for a part - even if an FR may not exist for several combinations of the automatic library search.

To search for the NPRD failure rate

1. In the **Automatic search** group box, select a **Part Description**.
2. Select a value from the **Quality** list; if the criteria are found in the NPRD database, the failure rate is displayed in the **Failure Rate** field.
3. Repeat steps 1-2 to define the **Manual selection** choice (alternative choice).
4. Define the search algorithm. Select **Automatic Only**, **Manual Only**, or **Automatic then manual** from the **Search Data for Calculation** list.

8.2.1.2.2 NPRD-2011

RAM Commander incorporates the NPRD-2011 (Non-electronic Parts Reliability Data) reliability prediction method. This method is applied to mechanical and other non-electronic parts.

NPRD database contains information on failure rates for various non-electronic parts keyed by part family, Item type, part description, environment and quality level. NPRD failure rates are not given for all combinations of these parameters. RAM Commander attempts to find the failure rate using two sets of data: Automatic search and Manual selection. You can tell RAM Commander how to perform the search:

- Automatic search only
- Automatic search, then manual selection if not found
- Manual selection only


On the NPRD-2011 screen, you need to define the appropriate Part Description which describes, in the best way, your specific part. Then you need to select the Quality level. After all this selections according with Part Description + Environment + Quality – RAM Commander search for FR in NPRD-2011 database. Two scenarios may occur: a) the FR exists in the NPRD-2011 for selected set of data; b) there is not FR for selected set of the data (because NPRD failure rates are not given for all combinations of these parameters).

To solve situation for scenario b) you need to use the Secondary Choice, where you can define similar part/description/quality level/environment – not exact as you have in the system but as close as possible.


Secondary Choice also exists to support situation when NPRD-2011 contains FR for conditions specified (for example for environment GB) (scenario a), but when you change environment in the product tree settings (e.g. to GF), you may come to situation where NPRD-2011 does not contain exact FR for these new settings any more (scenario b) - and then RAM Commander may take data according to the Secondary choice, if defined.

To calculate a failure rate (FR) for a part using NPRD-2011, you must first define its calculation method as NPRD-2011.

1. Click the **NPRD-2011** button in the Item Data dialog.



The part's NPRD-2011 dialog box opens:




#	Environment	Quality	FR [10 ⁻⁶]
1	---	---	15.333185
2	---	Commercial	27.850321
5	---	Military	12.138937
19	---	Unknown	14.872046
20	A	Unknown	154.376007

The NPRD-2011 provides data form much larger variety of component types than you can find in the standard list of RAM Commander's Item types. Part type may be defined automatically by RAM Commander, or you may use NPRD-2011 search to find the required part type.

To start the search,

1. Press "Search" button. The Search dialog will appear.
2. Type Part number you want to find (or part of it) and press the "Search" button.
3. The list of suitable search results will appear:



4. Select the part from the search results and press OK.

The next steps are very similar to [NPRD-95](#).

8.2.1.2.3 IEC, FIDES, 217Plus

Some new methods like IEC 62380, HDBK-217Plus, FIDES and UTE C 80-810 use complex mission profiles instead of standard environments used by MIL-HDBK-217 like GB, GF etc. These profiles contain information about thermal cycling, humidity, pollution, vibration, process factors and much more.

When one of such profile-based methods is selected as default method in the [Project Configuration](#) dialog, list of Environments on item data dialogs will switch to method - specific missions instead standard list of GB, GF, GM etc.

You may configure these mission profiles for each particular project using mission profile manager.

To open the mission profile:

1. Open a Product tree view.
2. From the Project menu, choose Configuration.
3. The Project configuration dialog box opens:

Project Configuration

Current Analysis

Operating

Nonoperating

Maintainability Repair/Replace Levels

Mct max Calculation based on:

MIL-HDBK-472 (Lognormal distribution)

Derating

FMEA Criticality Analysis

Phase: Table Setup

Default Method

Assembly: ---

Electronic: FIDES 2009

Mechanical: NPRD-95

Electro-Mechanical: NPRD-95

Default Screen

General

Operating

Nonoperating

Maintainability

Derating

Miscellaneous

FMECA

M MEL

JAA

FIDES 2009

OK

Cancel

4. Press the button with default electronic reliability prediction method name.

5. Mission profile manager will appear:

FIDES 2009

Mission Profiles Ruggedising factor Process factor RF and HF process factor

MP Name:

#	Phase name	Application factor	Calendar time (h)	Thermal and Humidity			Thermal cycling				
				On/Off	Amb.temp	Cyclic Ratio	Relative humidity	dT	Cycles/year	Cycle duration	Me
1	Day without use - Protected storage	4.1	3960.0	Off	20.0	0.5000	37.0	5.0	165.0	24.000	20
2	Operation - fixed Functioning	5.6	600.0	On	30.0	0.5000	20.0	15.0	200.0	6.000	30
3	Operation - mobile Functioning	7.7	60.0	On	30.0	0.5000	20.0	-	-	-	-
4	Operation - No fixed functioning	4.3	3200.0	Off	15.0	0.5000	50.0	10.0	200.0	18.000	20
5	Operation - No mobile	7.7	400.0	Off	15.0	0.5000	50.0	-	-	-	-
*											

OK Cancel Apply Help

6. See specific reliability prediction method handbook for more information about profile parameters.

8.2.1.2.4 FIDES 2009

RAM Commander categorizes all components by Item types listed in the [Item type abbreviations](#) paragraph.

FIDES 2009 classification of electronic components is different from RAM Commander classification.

The table below provides all FIDES 2009 component types and their corresponding classification in RAM Commander. It will simplify the search of correct component Item types and types in RAM Commander.

#	FIDES type	Page in FIDES Guide	RAM Commander Item type	RAM Commander type
1	FPGA	115	IC-Digital	FPGA
2	CPLD	115	IC-Digital	CPLD
3	FPGA Antifuse	115	IC-Digital	FPGA (Antifuse)
4	PAL	115	IC-Digital	PAL
5	Analogue circuit	115	IC-Analog	Linear
6	Hybrid circuit	115	IC-Analog	Digital/Linear
7	Microprocessor	115	IC-Digital	Microprocessor
8	Microcontroller	115	IC-Digital	Microcontroller
9	DSP	115	IC-Analog	DSP
10	Flash	115	IC-Memory	FLASH
11	EEPROM	115	IC-Memory	EEPROM
12	EPROM	115	IC-Memory	EPROM
13	SRAM	115	IC-Memory	SRAM
14	DRAM	115	IC-Memory	DRAM
15	Digital circuit	115	IC-Digital	Digital circuit
16	Digital ASIC, simple function	119	IC-Digital	ASIC, simple function
17	Digital ASIC, complex function	119	IC-Digital	ASIC, complex function
18	Analogue, mixed ASIC	119	IC-Analog	Mixed ASIC
19	Signal (Low power)	123	LF Diode	Signal
20	PIN (Signal - Low power)	123	HF Diode	PIN
21	Schottky (Signal - Low power)	123	LF Diode	SCHOTTKY
22	Varactor (Signal - Low power)	123	HF Diode	Varactor
23	Rectifying (Low power & Power)	123	LF Diode	Rectifier
24	Zener regulation (Low power & Power)	123	LF Diode	Zener

#	FIDES type	Page in FIDES Guide	RAM Commander Item type	RAM Commander type
25	Protection (Low power & Power)	123	LF Diode	Protection
26	Thyristors (Power)	123	LF Diode	Thyristors
27	Triacs (Power)	123	LF Diode	Triacs
28	Silicon bipolar (Low power & Power)	123	LF Trans	Silicon bipolar
29	Silicon MOS (Low power & Power)	123	LF Trans	Silicon MOS
30	Silicon JFET (Low power)	123	LF Trans	Silicon JFET
31	IGBT(Power)	123	HF Trans	IGBT
32	LED	125	Optoelectronic s	LED
33	Optocoupler with photodiode	128	Optoelectronic s	Optocoupler/ transistor
34	Optocoupler with phototransistor	128	Optoelectronic s	Optocoupler/ photodiode
35	"Minimelf" high stability (RS) common (RC) low power film	130	Resistor	Minimelf common use high stability low power film
36	Power film	130	Resistor	Power film
37	Low power wirewound accuracy	130	Resistor	Low power wirewound precision
38	Power wirewound	130	Resistor	Power wirewound
39	Trimming potentiometer (CERMET)	130	Potentiometer	CERMET trimming
40	Resistive chip	130	Resistor	Resistive chip
41	SMD resistive network	130	Resistor	SMD resistive network
42	High stability bulk metal foil accuracy	130	Resistor	High stability bulk metal foil precision
43	Fuse	133	Fuse	Fuse (without type)
44	Ceramic capacitor with defined temperature coefficient (Type I)	136	Capacitor	Ceramic (Type I)
45	Ceramic capacitor with non-defined temperature coefficient (Type II)	136	Capacitor	Ceramic (Type II)
46	Ceramic capacitor with polymer terminations with non-defined temperature coefficient (Type II)	136	Capacitor	Ceramic Polymeric (Type II)
47	Aluminium liquid electrolyte	138	Capacitor	Liquid electrolyte aluminum

#	FIDES type	Page in FIDES Guide	RAM Commander Item type	RAM Commander type
48	Aluminium solid electrolyte	138	Capacitor	Solid electrolyte aluminum
49	Wet tantalum capacitor	140	Capacitor	Wet tantalum
50	Dry tantalum capacitor	140	Capacitor	Solid electrolyte tantalum
51	Low current wirewound inductor	142	Inductive	Low current wirewound inductor
52	High current (or power) wirewound inductor	142	Inductive	Power wirewound inductor
53	Multi-layer inductor	142	Inductive	Multi-layer ceramic chip inductor
54	Transformer, Low Power (or Low Level)	142	Inductive	Low power transformer
55	Transformer, High Power	142	Inductive	High power transformer
56	Quartz resonator	144	Quartz Crystal	Quartz resonator
57	Quartz oscillator	144	Quartz Crystal	Crystal quartz oscillator
58	Electromechanical relay	146	Relay	Electromechanical
59	Limit switch	151	Switch	Limit
60	Microcontacts	151	Switch	Microcontacts
61	Toggle	151	Switch	Toggle
62	Slide	151	Switch	Slide
63	Lever	151	Switch	Lever
64	DIP	151	Switch	DIP
65	Rotary	151	Switch	Rotary
66	Encoder wheel	151	Switch	Encoder wheel
67	Momentary push button (monostable)	151	Switch	Momentary push button
68	Permanent push button (bistable)	151	Switch	Permanent push button
69	Printed circuit board (PCB)	155	PWB	PCB
70	Circular	159	Connector	Circular
71	Rectangular	159	Connector	Rectangular

#	FIDES type	Page in FIDES Guide	RAM Commander Item type	RAM Commander type
72	Coaxial	159	Connector	Coaxial
73	Connectors for printed circuits (and similar)	159	Connector	Connectors for PCB
74	Component supports	159	Connector	Component supports
75	Hybrids	162	Hybrid	Hybrid
76	Multi Chip Modules	162	Hybrid	Multi Chip Module
77	Metal case, ceramic substrate	163	Substrate	Metal case, ceramic substr
78	Ceramic case, ceramic substrate	163	Substrate	Ceramic case, ceramic substr
79	Glass-epoxy substrate with moulding	163	Substrate	Glass-epoxy with moulding
80	Glass-epoxy substrate without moulding	163	Substrate	Glass-epoxy without moulding
81	Deposited capacitor	170	Capacitor	Deposited (only undo Hybrid)
82	RF and HF Analogue Circuit (Power amplifier)	183	IC-Analog	Power amplifier
83	RF and HF Mixed circuit	183	IC-Analog	RF and HF Mixed
84	RF and HF Digital Circuit	183	IC-Digital	RF and HF Digital
85	RF HF PIN (Low power)	186	HF Diode	RF & HF PIN
86	RF HF Schottky (Low power)	186	HF Diode	RF & HF Schottky
87	RF HF Tunnel (Low power)	186	HF Diode	RF & HF Tunnel
88	RF HF Varactor (Low power)	186	HF Diode	RF & HF Varactor
89	Silicon, bipolar (Low power & Power)	186	HF Trans	RF & HF Si Bipolar
90	SiGe, bipolar (Low power)	186	HF Trans	RF & HF SiGe Bipolar
91	Silicon, MOS (Power)	186	HF Trans	RF & HF Si MOS
92	AsGa (Low power)	186	HF Trans	RF & HF AsGa
93	AsGa (Power)	186	HF Trans	RF & HF AsGa Power
94	RF and HF SMD resistors	188	Resistor	RF and HF SMD resistors
95	RF and HF SMD ceramic capacitors	188	Capacitor	RF and HF SMD ceramic

#	FIDES type	Page in FIDES Guide	RAM Commander Item type	RAM Commander type
96	RF and HF inductors	188	Inductive	RF and HF inductors
97	RF HF - Fixed Attenuator	188	Miscellaneous	Microwave Attenuator fixed
98	RF HF – Fixed load (50 Ohm)	188	Miscellaneous	Microwave Load fixed (50 Ohm)
99	RF HF – Fixed Filter	188	Filter	Microwave Filter fixed
100	RF HF – Fixed power divider	188	Miscellaneous	Microwave Power Divider fixed
101	RF HF – Variable attenuator	188	Miscellaneous	Microwave Attenuator variable
102	RF HF – Variable tuneable filter	188	Filter	Microwave Tuneable Filter variable
103	RF HF - Passive components with ferrites	188	Miscellaneous	Passive components ferrites
104	RF HF - circulator	188	Miscellaneous	Circulator
105	RF HF - isolator	188	Miscellaneous	Isolator
106	RF HF - phase shifter	188	Miscellaneous	Phase Shifter
107	RF HF - Surface wave filters	188	Filter	Surface wave filters
108	COTS boards (Onboard electronic functions)	192 (195)	PWB	On-Board (Functions)
109	Various subassemblies - LCD screens	206	Optoelectronic s	LCD Screens
110	Various subassemblies - Hard disks IDE	209	Miscellaneous	IDE hard disk
111	Various subassemblies - Hard disks SCSI	209	Miscellaneous	SCSI hard disk
112	Various subassemblies - CRT screens	212	Optoelectronic s	CRT Screens
113	Various subassemblies - AC/DC voltage converters	215	Miscellaneous	AC/DC voltage converters
114	Various subassemblies - DC/DC voltage converters	215	Miscellaneous	DC/DC voltage converters
115	Various subassemblies - Lithium batteries	217	Miscellaneous	Lithium batteries
116	Various subassemblies - Nickel batteries	217	Miscellaneous	Nickel batteries
117	Various subassemblies - Fans	220	Rotating	Fan

#	FIDES type	Page in FIDES Guide	RAM Commander Item type	RAM Commander type
118	Various subassemblies - Keyboard	223	Switch	Membrane keyboard
119	Various subassemblies - Keyboard board	223	Switch	Keyboard board

8.2.1.2.5 Non-Operating MIL-HDBK-217E

Nonoperating Prediction Using MIL-HDBK-217E

RAM Commander supports a modified version of the computation methodology defined in MIL-HDBK-217E, Notice 1 (draft). The modification is that for Item types not listed in 217E, RAM Commander uses data from RADC-TR-85-91. Calculations using this method produce a storage (nonoperating) failure rate and a cycling failure rate.

Cycling reliability for a component is computed as a function of storage (nonoperating) reliability using the following formula:

$$\lambda_{\text{cycling}} = K \square \lambda_{\text{storage}}$$

where K is a multiplier. The table below presents default values for K for the following Item types:

Item type	K
IC-Digital	20
IC-Analog	20
IC-Memory	20
LF and HF Transistor	50
LF and HF Diode	83
Resistor	63
Capacitor	160
Inductive transformer	750
Inductive coil	380

Item types not appearing in this table have a default K value of 0.

You may change default values on the reliability prediction method data screen for each particular component:

IC Digital MIL-HDBK-217EN1


Ref. des.: U10 QTY: 1 ENV: GF Temp: 25 °C

Part name:

Mil. num.:

Cat. num.:

Generic name: 80C31

 Type: Logic Tech: ---

of gates: 8000

Package: Nonhermetic

Quality: Commercial-Not Screened

PI q: ---

K Cycling: ---

Using RAM Commander's Default Manager, you can change the default values for the K multiplier for each component type (and not for each particular component, as above).

To modify default K values:

1. Activate the Product tree view.
2. From the Project menu, select Default Manager; the Default Manager list opens.
3. Make selections in the Item type list box.
4. Click on a specific component type in the list, and from the Item menu, select Edit; the processor dialog box opens.
5. Enter a default multiplier value in the K Cycling field.
6. Choose OK.

RAM Commander normally applies the default value when computing cycling reliability for components of the selected technology. If you enter a specific value in a component's processor dialog box, RAM Commander uses it instead of the default.

Cycling Reliability Reports

RAM Commander uses the value in the K Cycling field to compute cycling reliability. This reliability value appears on a special report which you can produce using the following procedure.

To report cycling reliability values:

1. Recalculate the project.
 2. From the Reports menu, select Tree; the Report Selection dialog box opens.
 3. In the Type list box, select Storage and Cycling.
 4. Enter values for other fields as necessary, and choose OK.
- RAM Commander displays the report in a report window (see sample on the next page).

8.2.1.2.6 Notes on Environments and Methods

Standard environments are listed earlier in this manual - see the [Standard Environments](#) paragraph.

Information below provides detailed information about some environments and explains how they are interpreted by specific reliability prediction methods.

BRITISH TELECOM HRD4

GB Ground, Benign: Nearly zero environmental stress with optimum conditions for operation and maintenance. Typical applications are in main exchange buildings, environmentally controlled remote exchanges or cabinets (including Case Repeater Equipment) and environmentally controlled subscribers' premises. The equipment is operated in a protected environment, free from significant shock and vibration with the temperature of the air immediately surrounding the component not exceeding 55°C and relative humidity rarely exceeding 70% at 15°C.

GF Ground, Fixed: Conditions less than ideal, with some environmental stress and limited maintenance. Typical applications are manholes, remote terminals and areas in subscribed premises subject to shock and vibration or temperature and atmospheric variations.

GM Ground, Mobile: Conditions more severe than for Ground, fixed, mostly for shock and vibration. There is less maintenance attention and equipment is susceptible to operator abuse. Typical applications are mobile telephones, portable operating equipment and test equipment.

Bellcore Issue 5

GB Ground, Fixed: Nearly zero environmental stress with optimum engineering operation and maintenance. Typical applications are central office, environmentally controlled vaults, environmentally controlled remote shelters, and environmentally controlled customer premise areas.

GF Ground, Fixed: Some environmental stress with limited maintenance. Typical applications are manholes, poles, remote terminals, customer premise areas subject to shock, vibration, temperature, or atmospheric variations.

GM Ground, Mobile: Conditions more severe than GF, mostly for shock and vibration. More maintenance limited and susceptible to operator abuse. Typical applications are mobile telephones, portable operating equipment, and test equipment.

Bellcore Issue 6, Telcordia Issue 1

GB Ground, Fixed: Nearly zero environmental stress with optimum engineering operation and maintenance. Typical applications are central office, environmentally controlled vaults, environmentally controlled remote shelters, and environmentally controlled customer premise areas.

GF Ground, Fixed: Some environmental stress with limited maintenance. Typical applications are manholes, poles, remote terminals, customer premise areas subject to shock, vibration, temperature, or atmospheric variations.

GM Ground, Mobile: Conditions more severe than GF, mostly for shock and vibration. More maintenance limited and susceptible to operator abuse. Typical applications are portable and mobile telephones, portable operating equipment and test equipment.

AIC Airborne, commercial: Conditions more severe than GF, mostly for pressure, temperature, shock and vibration. In addition, the application is more maintenance limited than for GF. Typical applications are in the passenger compartment of commercial aircraft.

SF Spacebased, commercial: Low earth orbit. Conditions as for AIC, but with no maintenance. Typical applications are commercial communication satellites.

GJB299

GB Normally weather, almost no mechanical stress, and readily accessible to maintenance, such as laboratory with temperature and humidity controlled or large ground station.

GMS Typical conditions in ground silo in which missiles and its assistant equipment are set.

GF (GF1) Typical conditions in the inside of generic building or on permanent racks with good ventilation. With moderate strike and vibration. Such as environment in which permanent installation radar, communications facilities, TV and recorder etc. are installed.

NUU (GF2) Ground conditions with poor protected facilities for weather and Underground conditions. Severe conditions related to high temperature, low temperature, difference in temperature, severe humidity, mildew, salt vapor and chemic gas, etc.

GM (GM1) Equipment installed on vehicles which moved smoothly. With strike and vibration conditions, such as special vehicle running on highroad, carriage of train.

ARW (GM2) Equipment installed on tracked vehicles. With violent strike and vibration conditions related to violently moving. and with restricted control of ventilation, temperature and humidity.

MP Equipment manually transported in field environment. With poor maintenance conditions.

NSB Typical conditions in submarines.

NS (GS1) Include sheltered or below deck conditions on surface ship which travel smoothly. Unserious exposed to salt vapor and water vapor. Such as air-conditioning cabin of large cargo ship traveling near coastal waters and ship traveling in freshwater.

NH (GS2) Sheltered conditions without exposed to weather conditions, but often with violent strike and vibration. Include sheltered or below deck conditions on surface ship.

NU Typical conditions in board of ship. Unprotected surface ship borne, often with violent strike and vibration, exposed to weather conditions and immersed in salt water.

AIF Typical conditions in fighter which can be occupied by pilots. Without high temperature, high pressure, and violent strike and vibration.

AUF Severe conditions of high temperature, high pressure, and violent strike and vibration, etc., such as equipment compartment and bomb bay in fuselage, tail, wing of fighter.

AIC Typical conditions in cargo compartments which can be occupied by an aircrew.

AUC Environmentally uncontrolled areas which cannot be inhabited by an aircrew during flight.

SF Earth orbital. Approaches benign ground conditions. Vehicle neither under powered flight nor in atmospheric reentry, such as installing environment of electronic equipment in satellites.

ML Severe conditions related to missile launch, solid rocket motor propulsion powered flight, space vehicle boost into orbit, and vehicle re-entry and landing by parachute, such as noise, vibration, strike, and other severe conditions.

8.2.1.2.7 Stress/Strength

Stress/Strength is a new mechanical reliability analysis method in RAM Commander.

Stress/Strength analysis method determines the probability of failure based on the probability of stress exceeding strength.

Having distributions of Stress and Strength, we may calculate failure probability (Unreliability):

$$UR = 1 - \frac{1}{\sqrt{2\pi}} \int_{\frac{-(\mu_S - \mu_S)}{\sqrt{\sigma_S^2 + \sigma_S^2}}}^{\infty} e^{-z^2/2} dz$$

Having variation information between stress and strength (Factor of Safety n and Variations), we may also calculate the unreliability:

$$UR = 1 - \frac{1}{\sqrt{2\pi}} \int_{\frac{-(n-1)}{\sqrt{V_S^2 n^2 + V_S^2}}}^{\infty} e^{-z^2/2} dz$$

To select this method, change Failure Distribution to “Time-independent” and set Method to “Stress/Strength”:

Method of FR p calculation:	default	
Method:	Stress/Strength	
Failure distribution:	Time-independent	Stress/Strength

Then press method button, method screen will appear:

Stress/Strength Analysis

Stress / Strength Analysis is a probabilistic analysis of structural/mechanical components and systems, determines the probability of failure based on the probability of stress exceeding strength.

Calculate by:

Stress/Strength Values

Stress/Strength values

Stress

Distribution: Normal

Mean: 0.


Standard Deviation: 0.

Strength

Distribution: Normal

Mean: 0.

Standard Deviation: 0.



$$UR = 1 - \frac{1}{\sqrt{2\pi}} \int_{-\frac{(\mu_s - \mu_s)}{\sqrt{\sigma_s^2 + \sigma_s^2}}}{\infty} e^{-z^2/2} dz$$

Stress/Strength Variation

Stress/Strength Variation

Distribution: Normal

Factor of Safety: 0. $n = \mu_s / \mu_s$

Coefficient of Variation of Stress: 0. $V_s = \sigma_s / \mu_s$

Coefficient of Variation of Strength: 0. $V_s = \sigma_s / \mu_s$

$$UR = 1 - \frac{1}{\sqrt{2\pi}} * \int_{-\frac{(n-1)}{\sqrt{V_s^2 n^2 + V_s^2}}}{\infty} e^{-z^2/2} dz$$

OK

Cancel

Help

The list of supported distribution combinations is provided below:

Stress distribution	Strength distribution
Exponential	Normal
Normal	Normal
Weibull	Weibull

Enter Stress and Strength data, using either Values data or Variations data. Press Ok. The Unreliability (UR) will be calculated and saved to the item data.

8.2.1.2.8 Hybrid and Substrate

This section describes reliability prediction of a integrated circuit dice mounted in a **hybrid package**. A hybrid is normally made up of one or more **substrate** assemblies mounted within a sealed package. Each substrate assembly contains of active and passive chips with thick or thin film metallization mounted on a substrate, which in turn may have multiple layers of metallization and dielectric on the surface.

To model the hybrid device in your product tree, you should:

1. Create Item in the product tree Family: Electronic, Item Code: Hybrid (no special data needed on the method screen - this screen doesn't exist)
2. Under Hybrid create Substrate (Family: Electronic, Item Code: Substrate) and on the method specific screen enter all information about the substrate.

Note: under one Hybrid user may create more than one Substrate

3. Under Substrate add all components placed on this substrate.

See illustration below for a hybrid structure example:

Ref.Des.	Qty	Opr. FR [10 ⁻⁶]
EXAMPLE	1	0.0995
Hybrid	1	0.0995
Substrate	1	0.0995
C1	1	0.0005
U1	1	0.0351

8.2.2 Specify known fixed FR

If component or assembly failure rate is known (provided by manufacturer, by third-party database, field usage failure analysis, testing/QA failure analysis) you may specify it in the FR u (user-defined) or FR f (FR field) data fields on the item data screen. Be sure to set correct FR source switch.

To specify user-defined FR:

1. Open item data screen.
2. Set FR source switch to User-defined and specify your FR in the "FR u" field:

Failure Rate / Reliability Data

FR Source:	User defined
FR predicted:	0.
FR user-defined:	8.35
FR field:	0.
FR allocated:	0.

3. Press Ok to return to the product tree.

To specify field FR:

1. Open item data screen.
2. Set FR source switch to Field and specify your FR in the "FR f" field:

Failure Rate / Reliability Data

FR Source: Field

FR predicted: 0.

FR user-defined: 0.

FR field: 8.35

FR allocated: 0.

3. Press Ok to return to the product tree.

For both cases you may provide explanation about the FR source in the "Source of FR" text field. Both Failure Rates (User-defined and field) may be imported using [Import Wizard](#).

8.2.3 Specify known temperature-dependent FR

Known Failure Rates for specific environments and temperatures may be placed into [GPRD](#) library - [Field Failure Rate Tables](#) and then GPRD calculation method may be used to calculate FR for the selected component using existing FR data.

For example, manufacturer provided FR data for some part with PN=GA89723 for GB environment and temperatures 20 and 80 degrees. These data may be entered into the GPRD library under specific Part Number:

GPRD - Operating

Part Name: GA89723 Environment: GB Use for conversion

Project F. R. 10e-6 Tmin: 0 Tmax: 75 Source: User Defined

#	Temperature	F. R.
1	0.0	
2	5.0	
3	10.0	
4	15.0	
5	20.0	20.00
6	25.0	
7	30.0	
8	35.0	
9	40.0	
10	45.0	
11	50.0	
12	55.0	
13	60.0	
14	65.0	
15	70.0	
16	80.0	60.00

Close Add Delete Edit Copy to Env Redraw

FR (or MTBF) interpolation/extrapolation is done according to provided FR(temperature) points.
 For electronic family components or assemblies (Family="...") calculation is done according to RAC Reliability Toolkit formulas.
 For mechanical and electro-mechanical family components linear interpolation/extrapolation is used.

Then you have this part in your Bill Of Materials, in device used in GF conditions under 50 degrees

temperature. Using GPRD library and GPRD reliability calculation method, you may get the FR calculated for specific project environment condition and temperature.

See [GPRD](#) paragraph for information about using GPRD Library and [Using GPRD Library in Reliability Prediction](#) paragraph for using GPRD reliability calculation method.

8.2.4 Failure Rate Allocation

You may be faced with a situation where the system or a particular assembly must satisfy a given MTBF or FR. To achieve this reliability goal, you must assign a certain reliability value to the items within the assembly, thus ensuring that these values participate in the reliability calculation. This approach is called a top-to-bottom reliability allocation.

Special fields in the Item Data dialog box are reserved for reliability allocation:

FRa - Allocated or required failure rate

Complexity for FRa - Weight for reliability allocation

Failure Rate / Reliability Data

FR Source: Allocated

FR predicted: 0.

FR user-defined: 0.

FR field: 0.

FR allocated: 87.779

Complexity for FR allocation: 1.

Use the Item Data dialog box fields shown to the right to set reliability allocation parameters. For a given parent part, the reliability allocation for all its children is computed according to the formula:

$$La (son) = \frac{La (parent) * Compl_{La} (son)}{Compl_{La} (son_1) * Qty (son_1) + Compl_{La} (son_2) * Qty (son_2) + \dots}$$

Weights for reliability allocation $Compl_{La}$ have a default value of 1. You can enter or update these values through the Item Data dialog box for each item. RAM Commander allows you to start reliability allocation from one level and to expand it either to the next level or all lower levels.

Reliability allocation for an assembly:

1. In the Product tree view, highlight the assembly for which you want to allocate a failure rate.
2. From the Tree menu, choose Edit
 - OR -
 - right-click the mouse and choose Edit
 - OR -
 - press ALT+Enter
3. In the Item Data dialog box, enter the required failure rate in the FRa field.
4. Choose OK.

5. Enter the data for all those items that need a different Complexity for FRa value. Upon completing this procedure, you are ready to perform the reliability allocation.

To activate the reliability allocation

1. From the Calculation menu, choose Allocation.
2. In the submenu, choose All tree down or Current level.
3. RAM Commander will allocate the required FR for lower levels.

8.3 Project Recalculation

When the reliability parameters for components are provided you may perform recalculation of the Product Tree to get the calculation of Failure Rate for all components and then calculate the sum of component failure rates to calculate the FR of assemblies, subsystems, systems and of the whole product.

You can perform full or quick calculations. You can also assign a required FR to an assembly and have RAM Commander allocate the required FR to each of its children.

After calculating, RAM Commander displays the item reliability in the Opr. FR column (when working under Operating analysis) and other results for other analyses. The symbols "++" in the status field mean that the item has been successfully checked and calculated. If there was an error during the computation (due to missing data or other reasons), the symbol "-" appears in the status field.

Quick Mode

When calculating in *quick mode*, RAM Commander computes R&M using the entire product tree and recalculates items changed since the previous calculation, as well as items for which some conditions have changed.

Note: Changes in defaults do not immediately affect the product tree reliability. You must **Recalculate all** the entire tree to use the new defaults.

To calculate reliability in Quick mode:

1. Activate the Product tree view.
2. If you need to change the Current Analysis, do the following:
 - Click a corresponding icon on the Product tree view button bar.
 - OR -
 - From the **Project** menu, choose **Configuration**.
3. Choose the current analysis in the Project Configuration dialog box.
4. Choose **OK**.
5. From the **Calculation** menu, choose **Quick**.

Note There is an option of automatic recalculation when defining the project properties to ensure that the RAM Commander output is based on the latest updated data (see [Creating a new project](#)).

RAM Commander computes reliability for the entire product tree. Reliability results appear in the Product tree view.

Recalculate All

In *Recalculate All mode*, RAM Commander applies defaults for all items and computes R&M for the entire project. Defaults are only applied to fields containing three hyphens (---). If a field has an actual value, RAM Commander uses that to compute reliability.

To calculate reliability in Recalculate All mode:

1. Activate the Product tree view.
2. From the **Project** menu, choose **Configuration**. Select the current analysis in the Project Configuration dialog box or using the Product tree view button bar.
3. From the **Calculation** menu, choose **Recalculate All**.

RAM Commander computes reliability using the item's current data and current defaults. Reliability results appear in the Product tree view.

8.3.1 Log File

Reliability calculation errors can result from lack of required information. When RAM Commander detects an error, it issues general *system messages* to the screen and records detailed *error messages* to a *log file*.

Note Review the log file each time a message is displayed on the screen. The log file contains information that assists you in pinpointing the source of the computation error.

The log file retains the results of previous reliability computations. To review the log file, from the **Calculation** menu, choose **Log File**.

8.4 Reports

After the FR definition or calculation for all product tree components is done and project total calculation is performed, a number of different reliability reports may be generated:

Report	Description																		
Tree basic structure	List of all tree assemblies and components.																		
Assembly Composite	<p>All tree items by levels, with FR, MTBF, FR contribution to assembly's FR for each item:</p> <p>Assembly Ref.Des.: TUTORIAL, ID: 1, Description: Communication S Environment: GF, Temperature: 20.00 °C,F.R.(xE-6): 84.09 , MTBF(h) 11891.86</p> <table border="1"> <thead> <tr> <th>ID</th> <th>PN</th> <th>RefDes</th> <th>Qty</th> <th>F.R. xE-6</th> <th>F.R. (K,Qt xE-6)</th> </tr> </thead> <tbody> <tr> <td>1.1</td> <td>CN017000</td> <td>Communic</td> <td>1</td> <td>72.76</td> <td>72.76</td> </tr> <tr> <td>1.3</td> <td>CN017880</td> <td>Pedestal</td> <td>1</td> <td>11.33</td> <td>11.33</td> </tr> </tbody> </table>	ID	PN	RefDes	Qty	F.R. xE-6	F.R. (K,Qt xE-6)	1.1	CN017000	Communic	1	72.76	72.76	1.3	CN017880	Pedestal	1	11.33	11.33
ID	PN	RefDes	Qty	F.R. xE-6	F.R. (K,Qt xE-6)														
1.1	CN017000	Communic	1	72.76	72.76														
1.3	CN017880	Pedestal	1	11.33	11.33														
Applied values	Component name and all the input data used in reliability prediction:																		

Report	Description																														
	<p>Assembly Ref.Des.: Transmitter, Capacitor</p> <table border="1"> <thead> <tr> <th>ID</th> <th>Ref.des.</th> <th>PN</th> <th>Style</th> <th>Capacitance</th> <th>VSR</th> <th>Circuit resist. (CSR & CWR)</th> <th>DT</th> <th>Qual</th> </tr> </thead> <tbody> <tr> <td>1.1.3.1</td> <td>C1-2</td> <td>CKR</td> <td>CKR</td> <td>0.100 uF</td> <td>0.300</td> <td>---</td> <td>0.0</td> <td>M</td> </tr> <tr> <td>1.1.3.2</td> <td>C3-5</td> <td>CL</td> <td>CL</td> <td>100.000 uF</td> <td>0.500</td> <td>---</td> <td>0.0</td> <td>Non- Established</td> </tr> </tbody> </table>	ID	Ref.des.	PN	Style	Capacitance	VSR	Circuit resist. (CSR & CWR)	DT	Qual	1.1.3.1	C1-2	CKR	CKR	0.100 uF	0.300	---	0.0	M	1.1.3.2	C3-5	CL	CL	100.000 uF	0.500	---	0.0	Non- Established			
ID	Ref.des.	PN	Style	Capacitance	VSR	Circuit resist. (CSR & CWR)	DT	Qual																							
1.1.3.1	C1-2	CKR	CKR	0.100 uF	0.300	---	0.0	M																							
1.1.3.2	C3-5	CL	CL	100.000 uF	0.500	---	0.0	Non- Established																							
Processor FR data	<p>Intermediary prediction results and Pies for all components:</p> <p>Assembly Ref.Des.: Receiver, Resistor</p> <table border="1"> <thead> <tr> <th>ID</th> <th>Ref.des.</th> <th>PN</th> <th>Lb</th> <th>P_e</th> <th>P_{l p}</th> <th>P_{l s}</th> <th>P_{l q}</th> <th>P_{l t}</th> <th>F.R. (6)</th> </tr> </thead> <tbody> <tr> <td>1.1.2.3</td> <td>UR1</td> <td>RZ</td> <td>1.9E-003</td> <td>4.0</td> <td>0.237</td> <td>1.000</td> <td>3.00</td> <td>1.352</td> <td>0.007</td> </tr> <tr> <td>1.1.2.4</td> <td>UR2</td> <td>RZ</td> <td>1.9E-003</td> <td>4.0</td> <td>0.237</td> <td>1.000</td> <td>3.00</td> <td>1.208</td> <td>0.006</td> </tr> </tbody> </table>	ID	Ref.des.	PN	Lb	P _e	P _{l p}	P _{l s}	P _{l q}	P _{l t}	F.R. (6)	1.1.2.3	UR1	RZ	1.9E-003	4.0	0.237	1.000	3.00	1.352	0.007	1.1.2.4	UR2	RZ	1.9E-003	4.0	0.237	1.000	3.00	1.208	0.006
ID	Ref.des.	PN	Lb	P _e	P _{l p}	P _{l s}	P _{l q}	P _{l t}	F.R. (6)																						
1.1.2.3	UR1	RZ	1.9E-003	4.0	0.237	1.000	3.00	1.352	0.007																						
1.1.2.4	UR2	RZ	1.9E-003	4.0	0.237	1.000	3.00	1.208	0.006																						

All tree reports start processing from the item selected in the Product tree view.

For most of the reports you may define report depth, items type, tree traversal order and more:

Report Selection

Type: Assembly composite

Scan method: W - D with separation by level

Sort on level by: ID

Include items: Both Go under Hybrid

Starting level/item:

Depth from start item: 10

OK Cancel

The symbol W-D refers to searches level by level, while D refers to depth-first-search. The symbol ID refers to an item tree identification number according to the location in the tree.

For all reports, components, assemblies or both can be displayed.

You can limit the report's search by specifying how far down RAM Commander inspects the tree from your starting level.

In addition to the predefined reports, user-defined reports may be defined - see [Report Generator](#) paragraph.

See also advanced [Reliability Analysis](#) reports and methods like [Temperature Curve](#), [Pareto](#), [Mission Profile](#) and more.

Chapter



9

Reliability Libraries and Defaults

9 Reliability Libraries and Defaults

RAM Commander provides multiple libraries for convenient reliability calculation and analysis. The reliability-related libraries include:

1. [Component library](#)

This library may contain technical part data required for the reliability prediction (such as specific capacitor style, capacitance, V rated etc.). The library uses the Generic Name of the component as a key for search and retrieval of the components. Customer may enter/import component data to the library or purchase library from ALD with more than 70,000 widely used active electronic components data.

2. [Cross-Reference Library](#)

Frequently, electronics developers must cope with a variety of part numbering schemes when designing products. Part numbers can be based on a variety of numbering schemes, including military, catalog number, and internal part numbers. RAM Commander provides a flexible cross-reference between generic names and other part numbers using the Cross-Reference Library. It simplifies the component search and retrieval from the Component Library.

3. [Part Number automatic recognition](#)

Leading manufacturers use special algorithms naming their parts. RAM Commander implements these algorithms for the opposite direction in order to get reliability data from Part number. RAM Commander supports algorithms for decoding Part Numbers of Resistors and Capacitors of the following manufacturers:

AVX, ATC, Bourns, Cal-chip, DALE, Hitano, Garrett, IRC, Johanson, Kemet, KOA, Kyocera, Mallory, Meritek, Murata, MSI, NIC, Nichicon, Novacap, Samsung, Siemens, Syfer, OhmCraft, Paccom, Philips, Phycomp, Ralec, ROEDERST, TDK, TaiyoYuden, Vishay, Roedenstein, Vitramon, Yageo.

This works like the component library - the only difference is that component data are not stored in the actual library, but are defined by Part number decomposition and analysis according to a manufacturer's algorithm.

This is much more powerful than the component library because it covers a huge amount of parts, even parts which do not exist at the current moment – as soon as the manufacturer uses the same naming algorithms.

4. [GPRD Library](#)

The GPRD (General Part Reliability Data) Library covers:

- General Part Data (Part and Catalog numbers, manufacturer, price, condemnation rate, Maintainability repair distribution)
- Reliability data (field failure rates tables)
- FMECA data (Failure Modes list for the part)

The GPRD module allows the use of available field and manufacturer's data in the process of reliability analysis, and provides prediction of the Failure Rate for unknown temperature values. Sometimes modules of the system under analysis are off-the-shelf products with existing field reliability data. In such cases, it would be necessary to manually enter or automatically import (such as from FRACAS) the available field data for the reliability analysis.

The GPRD module gives an efficient solution to this problem and extremely useful when:

- Field/Manufacturer's Failure Rates are known only for a few temperature values
- A complex assembly is repeated in the project
- The display of underlying assembly components is not desirable for security or other reasons, but its FR should not be fixed.

5. [Calculation Defaults Library](#)

RAM Commander provides default values for all component information required for reliability prediction. RAM Commander uses these default values for reliability prediction in all places where the necessary data was not entered. Any user can review the defaults for any component type defined for a specific reliability prediction method.


This chapter deals with data management: how to use libraries, cross-referencing, failure rate tables - their reports and formulae, backing-up and restoring libraries, the default manager and project defaults. It will also explain how various values for a project are entered automatically into the project either from the Global Libraries or Project Library or through the management and provision of default values.

See the [Reliability Calculation](#) chapter for more information on libraries usage during the reliability prediction.

See other module-specific chapters for information about other RAM Commander libraries such as FMECA, Maintainability etc. This chapter covers only the reliability prediction-related libraries.

9.1 Global and Project Libraries

Each project has its own **Component Library**, **GPRD Library** and **Calculation Defaults Library**. In addition to Project (local) libraries, RAM Commander central database contains Global Libraries - Component Library, GPRD Library, Calculation Defaults Library and Cross-Reference Library. The diagram below provides illustration to the available library types and their locations:




Project libraries are used by one particular project (there is also an option to copy libraries from one project to another). Global libraries are used by all projects and shared between all network users (in case of client/server installation).

Usually all users may update project libraries, and only Administrator/Manager may review, approve and copy data from project libraries to the global library - otherwise global libraries will turn into garbage collection due to uncontrolled data input from multiple users.

9.2 Component Library

One of RAM Commander's powerful and time-consuming features is its **Component Libraries** containing component information used in reliability prediction. Each component has its own set of parameters (usually taken from the component's data sheet supplied by manufacturer):



Component Library contains only general technical information about each component and does not contain project-specific information like stresses. For example, for Resistors the library may contain "Power Rated" but does not contain "Power operating" - because "Power operating" is specific for each installation of the component and is not part of component data sheet.

RAM Commander provides two types of component libraries:

- The **global library** consists of generic component information to be used in various projects. You may purchase component library with more than 400,000 active and passive electronic components from ALD. You may build your own libraries - manually, using import from other data sources, copying components from multiple project libraries.
- The **project library** consists of components that you can save in the library during project

development.

All users can view, update, insert and delete components in the project library. All users can view records in the global component library and copy them into a project. Only the system administrator can update global component libraries.

The functioning of the Global and project component libraries are similar for the user. The library usage directions provided below apply equally to both libraries.

9.2.1 To view the project component library

1. Activate a Product tree view (see [Activating the Product Tree View](#) paragraph).
2. From the Library menu, choose the "Component Library".
3. In the Library manager window, select a Family Code and an Item type from the drop-down lists:



4. RAM Commander displays the library records matching your selection.


9.2.2 To view the global component library

To view the global component library from within a project:

1. Activate a Product tree view (see [Activating the Product Tree View](#) paragraph).
2. From the Library menu, choose the "Component Library".
3. RAM Commander displays the current project library records from your selection.
4. From the View menu, select Global library. The Global library component list window opens.
5. In the Global library component list window, select a Family Code and an Item type from the drop-down lists.

To view the global component library without opening any project:

1. Open RAM Commander
2. Close all RAM Commander child windows.
3. Choose "Components" from "Library menu":



4. In the Global library component list window, select a Family Code and an Item type from the drop-down lists.


Initially the global library is empty. If you purchased the ALD library you should install it first - see the [Install Component Library](#) in the [Getting Started](#) chapter for directions.

Note: Only the System Manager may perform changes in the Global Component Library. See [Users Management](#) paragraph for more information about defining Manager.

9.2.3 Working with the Component Library

The following illustration explains the Component Library window elements:

Control the display of the component library by selecting family and item code. Families are broad categories, such as electronic or mechanical, and item codes are tighter cuts of the family, such as IC Digital or Resistor.



A tick here means that the component is selected for an operation.

ALD indicates that the component is a part of the ALD component library. U indicates that the component was added or changed by a user

Components Generic Name (key used for search - can be Part Number, Catalog Number etc.

You may [edit](#), [insert](#), rename and [delete](#) components in the library, perform search and global change operations.

9.2.3.1 To edit component data

1. Open component library (global or project)
2. Find and select the desired component (Select the Family and Item type, scroll the library, use Find option)
3. Double-click the component record, or right-click it and choose Edit, or choose "Edit" from the "Item" menu, or press Alt+Enter.
4. Component data screen will appear.
5. Perform the required changes and press Ok.

You will not be able to change the Generic Name field value in the edit procedure - use "Rename" option in the "Item" menu instead.

9.2.3.2 To delete component from the library

1. Open component library (global or project)
2. Find and select the desired component (Select the Family and Item type, scroll the library, use Find option)

If you want to delete more than one component at a same time, click on each record and press the asterisk (*) key on the additional numeric keyboard or right-click the item in the list and choose Select/Deselect from the pop-up menu.

As you select components, the "V" icon appears in the left column of the Library Manager window.

3. Press "Del" key or right-click the component record and select "Delete" option or select the "Delete" option from the "Item" menu.
4. Confirm the deletion.

9.2.3.3 To insert new component into the library

1. Activate the Component library component list.
 2. Select the required Family and Item type.
 3. From the Item menu, choose Create or press F7.
- OR -

If you wish to create a component, which is very similar to one of existing components, select the existing component and choose "Copy..." from the Item menu

4. In the Library Manager dialog box, enter the relevant values. You must enter a value for Generic Name.
5. Choose OK. RAM Commander enters the part in the component library.

9.2.3.4 To find component

Use "Find" option in the "Item" menu to find the component in the library by its Generic Number: You may search by the exact generic number or by the beginning of the number.

The search is performed in the selected library (project/global) and selected family/Item type only.

9.2.3.5 Transfer data from a project to global library

The system manager can transfer information from a project library into the global library.

To transfer data, activate the project library window and from the **Library** menu, select one of the options:

- **Copy to Global – All** - to copy all contents of the project library to the global library (for all families/Item types)
- **Copy to Global – Selected Only** - to copy selected components only from the project library to the global library, for the selected family/Item type only. You may select multiple components using right-click and "Select/Deselect" option. As you select components, the "V" icon appears in the left column of the Library Manager window.

Caution Be careful when copying to the Global library. There is no undo option to easily recover from mistakes.

Another option to reuse project component library in another project is to copy the library from one project to another. See [Copy libraries between projects](#) paragraph later in this chapter.

9.2.4 Reports

To generate a project/global library report:

1. From the Report menu, choose All Library or Current Item type report.
2. The Library Manager Report Selection dialog box opens.
3. In the Library Manager—Report selection dialog box, select report type and filtering conditions:

Generic name search	Start	First position pattern search using the string in the Generic Name field
	Middle	Pattern search starting in any position using string in Generic Name field
	Off	No pattern search
Generic name		Target string for the pattern search
Type of report	Only gname	Include only generic name
	Detailed	Include all library fields
Data source includes	A.L.D.	Include components provided by ALD
	User	Include components entered by user
	Both	Include both ALD and user defined components

4. Choose OK to accept the entered values.
5. RAM Commander displays a report list containing the requested data:

Library Report for Project TUTORIAL Drive C:

Library Report

For ELECTRONIC, IC-Digital

Generic name	Type	Techn	# of gates	# of bits	Package	# of pins	Theta jc/ja	Max P dissipat	Tj max	Vdd	Quality	Manufact Process	Die Area	Feature Size	ESD Suscep.	Years of product.	Maturity year	Manufact year
IC 100EL34	Logic	BIPOLAR	51	---	NHER_SMT	16	---	0.50	125	7.0	2	---	---	---	---	---	1988	1995
IC 10EL89	Logic	CMOS	51	---	NHER_SMT	16	---	0.50	125	7.0	2	---	---	---	---	---	1988	1995
IC 10H105	Logic	CMOS	51	---	NHER_SMT	16	---	0.50	125	7.0	2	---	---	---	---	---	1988	1995
IC 180G16	CGA	MOS	5500	---	NHER_SMT	40	---	0.50	125	7.0	2	---	---	---	---	---	1988	1995
IC 2153	Logic	CMOS	5500	---	NHER_SMT	40	---	0.50	125	7.0	2	---	---	---	---	---	1988	1995
IC 38C43	Logic	CMOS	51	---	NHER_SMT	16	---	0.50	125	7.0	2	---	---	---	---	---	1988	1995

You can view and print the report using the report manipulation techniques described in [Reports](#) paragraph of [RAM Commander Fundamentals](#) chapter.

9.2.5 Data Import

Component Library may be imported from Excel file of predefined format and structure.

RAM Commander package contains formatted Excel template for electronic components data input (RAM Commander Installation folder, LIB subfolder, ComplLibImport.xls file). The template contains separate sheets for each electronic component type (IC Digital, Resistor, Capacitor etc.) with type-specific fields on each sheet. All relevant fields have lookup libraries (drop-down lists with all possible data values appear in these fields):

The screenshot shows an Excel spreadsheet titled "CompLibImport.xls" with the following data:

	A	B	C	D	E
1	IC Memory				
2	ICME				
3	Part Number	Memory type	Technology	Package	Quality
4	PartName	TYPE	TECH	PACK	QUAL
5	MEM_A	4 : UVEPROM	5 : FTTL	17 : CERDIP, CDIP - Ceramic Dual...	D
6	MEM_B	11 : OTP	11 : LSTTL	17 : CERDIP, CDIP - Ceramic Dual-In-Line	: Enhanced
7				18 : PQFP - Plastic Quad Flatpack, L lead	
8				19 : SQFP, TOFP, VQFP, LQFP - Plastic Sh	
9				20 : Power QFP (RQFP, HQFP, PowerQuad	
10				21 : CERPACK	
11				22 : CQFP, Cerquad - Ceramic Quad Flat P	
12				23 : PLCC - Plastic Leaded Chip Carrier J-L	
				24 : J-CLCC - Ceramic Leadless (and Lead	

Such libraries lookup fields contain both general description (like UVEPROM, TTL etc.) and RAM Commander internal code (1,2,3 etc.) required for import, it may be used to create automatic data conversion routines from customer-specific components database to RAM Commander import file. Such conversion routine may be created inside the supplied CompLibImport.xls file – using VB for applications or lookup fields/formulas – see sheet "ConversionExample" of the excel file:

Automatic conversion example of discrete values from customer library code to RAM Commander library code

Part Name	Customer type	RAM Commander Type
234623462346	A	1
234623463444	B	2
234623463424	C	3
234623462346	D	4
234623462346	E	5

Customer code → RAM Commander code is received from customer code using VLOOKUP function and libraries mapping

Type conversion from customer codes to RAM Commander codes. For example, customer code A corresponds to 1 in RAMC, B corresponds to 2 etc. IC Memory types library on sheet _JCMEMORY_Libs contains customer codes column with corresponding values. The table above contains "Customer type code" column with customer code and RAM Commander type code column. Values in RAM Commander type code are taken using VLOOKUP function and values from B column are converted automatically. You may use this approach to create automatic library data conversion procedure for RAM Commander.

When the data transformation/input in the excel file is finished, switch to the first sheet (named "_Main") and follow instructions. Intermediary text file will be created; this text file should be used in RAM Commander Component Library data import:

RAM Commander

Component Library Import Template


Version 8.0

Use this file to import component library into RAM Commander:

- Input components to this workbook, use separate worksheet for each part type (item code). Use lookup libraries (drop down lists) to enter library values for your components.
- After the data input is finished, run data preprocessing using the "Prepare" button on this page. Text file with components data in RAM Commander format will be created.
- Use RAM Commander component library import function to import this file when finished.

Prepare data for import - all sheets

For more information about the Component Library and Import/Export facilities see corresponding User Manual chapters.
 For questions and support please contact support@ald.co.il
www.aldservice.com www.aldsoftware.com



In addition, there is also ASCII file import procedure - contact ALD Software technical support for more information about this option.

9.2.6 Using Component Libraries in Reliability Prediction

During the product tree building and reliability prediction, you have to provide component's details from the component technical data sheet. It is done using the prediction method data screen like the screen shown below:

The screenshot shows a dialog box titled "IC Digital MIL-HDBK-217FN2". It contains the following fields and controls:

- Ref. des.: U12
- QTY: 1
- ENV: GF
- Temp: 50 °C
- Buttons: OK, Cancel, Help
- Part name: (empty)
- Mil. num.: (empty)
- Cat. num.: (empty)
- Generic name: LM299
- Type: Gate/Logic Arrays
- Tech: CMOS
- # of bits: ...
- # of gates: 1200
- Range: ...
- # of Pins: ...
- Package: ...
- VHSIC / VLSI CMOS section:
 - Manufacturing Process: ...
 - Die Area: ...
 - FeatureSize: ...
 - Vth: ...
- Years in production: ...
- Quality: ...
- PI q: ...
- Grid of pin options: 1: ..., 2: ..., 3B: ..., 3S: ..., 4: ..., 5: ..., 6: ..., 7: ..., 8: ..., 9: ..., 10: ..., 11: ...
- Lead Configuration: ...
- Distance: ... (mils)
- Icons at the bottom: Lead Configuration, Zebra, X REF, A, CD

You do not have to provide this information manually for each component. Use the component libraries instead.

You may search and load component data from the library and add/update component libraries during the product tree building and reliability prediction.

Most reliability prediction specifications have different formats for classifying data on various components. For instance, the MIL-HDBK-217F specification contains the formulas and factors for some integrated circuit components under the microcircuits, VHSIC CMOS classification. The Telecordia (formerly Bellcore) specification has the same for the same component type listed under the IC category and CMOS technology.

Using RAM Commander's component library, data may be accessed that is required for reliability prediction under all major specifications. This information is stored in a database keyed by an internal generic name, family and Item type.

To retrieve item data from library, specify at least the following information for the item:

- Family
- Item type

- Reliability prediction method
- Generic Name

RAM Commander then searches the component library for the specific generic name and retrieves the component's reliability data required for the given prediction method. It searches in the project library first and then searches in the global library.

If you do not have the Generic name and use other identifiers (Part Number, Catalog Number etc.) - use the [Cross-Reference](#) library to translate Part Number or Catalog Number into Generic Name.

You may use the component libraries during product tree building and reliability prediction in different ways:







1. [Retrieve/Save single component data from the library](#)
2. Load data for all components in the product tree from the library ([Load from Library](#))
3. Save data for all components in the product tree to the library ([Load to Library](#))

See next paragraphs for more explanations.

9.2.6.1 Retrieve or save single component data

During the product tree building and reliability prediction, you have to provide component's details from the component technical data sheet. It is done using the prediction method data screen or Quick Create option's dialog.

Use the button bar in the lower part of the data screen to find and retrieve component data from the component library. The following options are available:

Button	Name	Description
	Retrieve data from libraries	Retrieve component data from component libraries
	Show defaults	Review defaults for the selected component type. RAM Commander displays default values for the particular reliability prediction method and component type. During calculations, RAM Commander uses default values for all fields containing three dashes (---). See Calculation Defaults paragraph for more information.
	Save data to project library	Add/update project library with new data for the component with the current generic name.
	Add/update cross-reference record	Update cross-reference between the Generic Name and the Part number, Military Number or Catalog Number.
	Search by the beginning of the Generic Name	Location sensitive search - To find component data, use first-position pattern matching of the string in the Generic Name, Part Number, Military Number or Catalog Number field (depending on cursor location). RAM Commander displays a Search Results list box containing generic, part, military or catalog numbers that satisfy the search criteria. When you select one of the entries in the Search Results box, the component library values are loaded into the fields.
	Search by any part of the Generic Name	Location insensitive - To find component data, use any-position pattern matching of the string in the Generic Name, Part Number, Military Number or Catalog Number field (depending on cursor location). RAM Commander

Button	Name	Description
		displays a Search Results list box containing generic, part, military or catalog numbers that satisfy the search criteria. When you select one of the entries in the Search Results box, the component library values are loaded into the fields.

Notes:

- In any search, the Project component library is accessed first and then the Global component library.
- Searches for generic names are keyed by family and Item type. If RAM Commander does not locate the generic name pattern within the family and Item type you entered in the Item Data - Operating dialog box, it issues a message indicating that no such parts exist.

9.2.6.2 Load from Library

Component data required for the reliability prediction that depends on the reliability method can be quickly and accurately loaded using the data stored in the Component Library and GPRD failure rate library - for all product tree items at once.

To load component data from libraries into the project:

1. Activate the Product tree view.
2. From the Library menu, choose Load from Library
3. The Load from Library dialog box opens:

Load From Library

Search for:

Component library:

GPRD:

Use automatic PN recognition algorithms
 Without manufacturer name

PN Partial Match

Allow match of generic PN in BOM to more specific PN in library
 Number of trailing PN symbols which may not match:

Product tree/BOM	Library
MCM01001 ED561	MCM01001 ED561 JF

Allow match of specific PN in BOM to more generic PN in library
 Number of trailing PN symbols which may not match:

Product tree/BOM	Library
MR052A150JAA TR1	MR052A150JAA

Ignore delimiters in PN

Product tree/BOM	Library
MCM-01001 /ED-561-JF	MCM01001 ED561 JF

OK Cancel

4. In the Search for list box, do one of the following:

- To load data for all items, including those that already have data, select All parts.
- To load data for only those items without data, select Parts without data.
- To load data into empty fields only (those marked ---), select Fields without data.

5. In the Component Library and GPRD list boxes, select two different search priorities.
 - N/A - do not use this library at all
 - Low Priority - use this library after the other one
 - High Priority - use this library first

You must select two different search priorities. For example, if you want to use only the component library, select High Priority in its list box and N/A for the failure rate table library. If you want to use both libraries, first search the failure rate table library and then the component library only if no matching entry was found in the failure rate library; select High Priority for the GPRD (FR table) library and Low Priority for the component library.

6. Select "Use automatic PN recognition" if you wish to use it (see [Part Number Recognition](#) paragraph).
7. If partial recognition is acceptable, choose partial recognition which allows finding part data in the library even if PN, as stated in the BOM/product tree, differs from PN stated in the library.
8. Choose OK.

All data from the component or failure rate table libraries for the requested components is loaded into the current project. If RAM Commander cannot find project items in either library, it displays them in a log file.

RAM Commander will run the recalculation automatically to take updated component parameters into consideration and display the updated failure rates.

9.2.6.3 Load to Library

You can copy all the components inserted into the Product tree view to the project library as a group. This feature saves you time when you wish to save several components into the project library.

To load the components from the entire project into the project library:

1. Open the target Product tree view.
2. From the Library menu, choose Load to library.
3. RAM Commander loads all the project's components from the Product tree view into the project's component library.

9.3 Cross-Reference

Frequently, developers must cope with a variety of part identification schemes when designing products. Part numbers can be based on a variety of numbering schemes, including military, catalog number, and internal part numbers. RAM Commander provides a flexible cross-reference between generic names (used as a key for search in Component Library) and other component identifiers.

To activate the Cross Reference Library:


Activate a project window and choose Cross Reference from the Library menu.

In the Cross Reference window first column, RAM Commander displays three category icons:

CN	Catalog Number and it's corresponding Generic Number
----	--

PN	Part Number and it's corresponding Generic Number
MN	Military Number and it's corresponding Generic Number

For example, the Cross-Reference record displayed below tells RAM Commander that if there is component with Catalog Number RR.123.355 in the product tree, it should take it's part data from the component library component with identifier (Generic name) XNA1234:



To create, edit or delete a record in the Cross Reference Library:

1. Activate the Cross Reference Manager list.
2. Do one of the following:
 - To add a record to the Cross Reference Library, choose Create from the Item menu. In the Add/Edit Cross Reference dialog box, enter your data and click OK.
 - To edit a record, choose Edit from the Item menu or right-click on the record and choose Edit from the pop-up menu. In the Add/Edit Cross Reference dialog box, modify the required data and click OK.
 - To delete one or more records, select them using the asterisk (*) key on the additional numeric keyboard. Choose Delete from the Item menu or right-click the item in the list and choose Delete from the pop-up menu. A prompt appears asking if you want to delete the record. Click Yes and the record is deleted.
3. RAM Commander will then update the Cross Reference list.

You may also create a new record in the Cross-Reference library by "XRef" button on the prediction method data screen:

IC Digital MIL-HDBK-217FN2

Ref. des.: U12 QTY: 1 ENV: GF Temp: 35. °C

Part name: RR.123.359

Mil. num.:

Cat. num.:

Generic name: IC 38C43

Type: Gate/Logic Arrays

Tech: CMOS # of bits: ...

of gates: 51 Range: ...

Range: ... # of Pins: 16

Package: SMT Nonherm

T junction

Delta Tjc: ... or ...

Quality

PI q: ...

1: ... 2: ... 3B: ... 3S: ...

4: ... 5: ... 6: ... 7: ...

8: ... 9: ... 10: ... 11: ...

Lead Configuration: ... Distance: ... (mils)

VHSIC / VLSI CMOS

Manufacturing Process: ...

Die Area: ...

FeatureSize: ...

Vth: ...

Years in production: ...

XREF

54 80

54HC00 54HC08 54HC36 54F280 68000 80386

Specify PN, CN or MN (any one of them) and GN field values and press the "XRef" button - the new record will be added to the Cross-Reference Library.

9.3.1 Using Cross-Reference Library in Reliability Prediction

During product tree building and reliability prediction, you need to specify the following information in order to get component data from a library:

- Reliability prediction method
- Family
- Item type
- Generic Name

RAM Commander then searches the component library for the specific generic name and retrieves the component's reliability data required for the given prediction method.

If you do not have the Generic name and use other identifiers (Part Number, Catalog Number etc.) you have to use the Cross-Reference library to define a translation between Part Number or Catalog Number and its corresponding Generic Name.

The following procedure illustrates RAM Commander's library retrieval process using some component example:

1. User creates a new component in the product tree and provides the Part Number:

2. User opens prediction method data screen (MIL-HDBK-217 in this case) and presses the "Retrieve from library" button:



3. Generic Name (which serves for search in the component library) is not defined but the Part Number is defined - so RAM Commander uses the Cross-Reference library to translate the Part Number into corresponding Generic Name and then finds the corresponding record by the Generic Name in the Component Library:

4. Component data are retrieved from the component library:

IC Digital MIL-HDBK-217FN2

Ref. des.: U12 QTY: 1 ENV: GF Temp: 35. °C

Part name: RR.123.355

Mil. num.:

Cat. num.:

Generic name: IC 38C43

Type: Gate/Logic Arrays

Tech: CMOS # of bits: ...

of gates: 51 Range: ...

Range: ... # of Pins: 16

Package: SMT Nonherm Quality

T junction

Delta T_{jc}: ... or ...

Power: 0.5

VHSIC / VLSI CMOS

Manufacturing Process: ...

Die Area: ...

FeatureSize: ...

Vth: ...

Years in production: ...

PI q: ...

1: ... 2: ... 3B: ... 3S: ...

4: ... 5: ... 6: ... 7: ...

8: ... 9: ... 10: ... 11: ...

5. Press Ok to close the prediction method data screen and calculate the Failure Rate:

Item Data

Derating: General / Logistics

Miscellaneous: Operating

Functional Blocks: Nonoperating, Maintainability

Family: ELECTRONIC Ref.Des.: U12

Item code: IC-Digital Part name: RR.123.355

Environment: --- Cur: GF

Delta Temp.: 0. °C Cur: 35. °C

Method of FR p calculation: default

Method: MIL-217F-2 P. stress

Failure distribution: Exponential

FR p: 3.42852e-002 Predicted *Field fact.: 1.

FR u: 0. *Duty cycle: 1. Item FR: 3.42852e-002

9.3.2 Data Import

You may import the Cross-Reference library data from ASCII (text) file.


It should be text file where each line corresponds to one cross reference "pair" (PN->GN, CN->GN or MN->GN) and each line contains three fields:

Field name	Type	Width	Values
Cross reference flag	String	2	Defining the type of the cross reference. It may have one of the following three values: CN - Catalog number PN - Part number MN - Military number
Cross reference name	String	62 - Left justify and add trailing blanks, so that the string is 62 characters long.	Part number, catalog or military number
Generic name	String	42 - Left justify and add trailing blanks, so that the string is 42 characters long	RAM Commander Generic name

See the example file contents below:

```
CN1817450          74HC00
CN1817451          74HC04
CN1817452          74HC05
```

The first line of this file defines import of Cross-Reference Library record which means that the part with Catalog number (CN) 1817450 corresponds to RAM Commander's generic name (GN) 74HC00. The import of such file will result in the following records of the Cross-Reference Library:



Cross Reference Name		Generic Name
CN	1817450	74HC00
CN	1817451	74HC04
CN	1817452	74HC0

To Import Cross-reference Data from an ASCII File:

1. Activate the Product tree view (see [Activating the Product Tree View](#) paragraph).
2. From the Library menu, choose "Cross reference".
3. The Cross reference manager opens.
4. From the Cross-reference menu, choose "Import from ASCII..."
5. Browse to the desired text file and press Open.
6. RAM Commander will perform the import and update the library window.

9.4 Part Number Recognition

PN Automatic Recognition actually enlarges the component library. The only difference is that component data is not stored in the separate library file, but is defined by Part number decomposition and analysis according to manufacturer's algorithms.

Currently supported part types are Capacitors and Resistors.

Currently supported manufacturers are:

AVX, Bourns, Cal-chip, DALE, Hitano, Garrett, IRC, Johanson, Kemet, KOA, Kyocera, Mallory, Meritek, Murata, MSI, NIC, Nichicon, Novacap, Samsung, Siemens, Syfer, OhmCraft, Paccom, Philips, Ralec, ROEDERST, TDK, Taiyo, Yuden, Vishay, Vitramon, Yageo.

To use the Automatic Recognition feature:

1. In the Item Data screen, click the General / Logistics tab.
2. In the Manufacturer field, select the manufacturer's name
3. Enter the Part number.
4. Define the Family Code and the Item type,
5. Open the Method screen (press the large button with the method name).
6. In the Method Data screen, press the Load from Library button. If the Part number and Manufacturer were entered correctly, you will immediately see the data you entered in the item's data fields.

Another way to use this feature is through the Load from Library option. You may use the [Import Wizard](#) or tree editing to enter the Manufacturer and the Part number for items. Then from the Modules menu, choose the Load from library option. If the Part number and Manufacturer were entered correctly, you will immediately see the item's icon changed and FR calculated.

One more way to use the new automatic recognition feature is with the **Quick Create** option. It is used for the fast creation of the component in the Product Tree when the component is located in the Component Library or when the Part number and Manufacturer is recognized by the recognition algorithm.

In the Product Tree, choose Quick Create from the Tree menu. Enter the information about the component – Generic name (GN) for search in the Component Library, Part number (PN) and Manufacturer for use of recognition algorithm etc.:

The screenshot shows a 'Quick Create' dialog box with the following fields and controls:

- Ref.Des.: C36
- QTY: 1
- PN: T491B105M035AS
- MN: (empty)
- CN: (empty)
- GN: (empty)
- Manufacturer: Kemet (dropdown menu)
- Buttons: OK, Cancel, and Open method data screen (checkbox)

Click to select the Open method data screen check box for checking and editing of the component data before inserting it into the tree or leave it cleared if you wish to create the component without additional editing. Click OK.

	C36	17	T491B105M035AS	1	2.490E-004	++
--	-----	----	----------------	---	------------	----

If the component is found in the Library or recognized, it will be added to the Tree.

9.5 GPRD

The General Part Reliability Data Library contains following sections:

- General Part data (Part and Catalog numbers, manufacturer, price, condemnation rate, Maintainability repair distribution)
- FMECA data (Failure Modes list for the part)

- Reliability data (**field failure rates tables**)


The library allows for storing different data for specific parts and retrieves this data for the more convenient creation of new product tree items with the same Part Number.

Two separate GPRD libraries are supported – Global and Local. Global Library is shared for all projects but each project has its own Local Library.

9.5.1 Entering the GPRD Library

To enter the GPRD Library:

1. Activate the Product Tree window.
2. Choose GPRD from the Library menu. The GPRD Library table with Parts data is displayed:



Part Name	Catalog Number	Manufacturer	Description
CD984B1	CN00001	IBM	CD ROM drive
F99	CN00002	IBM	Floppy drive
HDD002	CN00003	IBM	Hard Drive disk
MOT978			

3. Choose Edit, Delete or Create from the main or pop-up menus to update, edit or create records in the GPRD library.
4. Choose Local or Global from the View menu to switch between the Global and Local Libraries.

9.5.2 General Part Data

The first section of GPRD is the General Part Data screen. The screen appears when you choose Edit or Create from the GPRD menu. The screen contains Part Number, Catalog Number, Price and other information about the part:


The screenshot shows a dialog box titled "General Part Reliability Data" with a close button (X) in the top right corner. The dialog is organized into several sections:

- General:** Contains text boxes for "Part Name" (HDD002), "Catalog number" (CN00003), "Manufacturer" (IBM), "Description" (Hard Drive disk), "Item Function" (Data Storage), "Family" (---), "Item code" (---), and "Source of FR" (|).
- Reliability:** Contains two buttons: "Operating" and "Nonoperating".
- Maintainability:** Contains a "Repair Distribution" dropdown menu (Exponential) and an "MCT [hours]" text box (0.1).
- Miscellaneous:** Contains "Price" (90) with a "USD" dropdown, "Weight" (1) with "[Kg]" unit, and "Volume" (0.002) with "[m^3]" unit.
- ILS:** Contains "Condemnation Rate" (0) with a "%" unit and "Shelf Life" (720) with a "days" unit.
- FMECA:** Contains a "Failure Modes list" button.

At the bottom right of the dialog are "OK" and "Cancel" buttons.

9.5.3 FMECA data

Click the **Failure Modes** List button in General Part Data dialog box to see or edit Failure Modes list of the specific part:



The screenshot shows a dialog box titled "Part FM" with a close button in the top right corner. Below the title bar, it says "Part Name : HDD002". The main area contains a table with three columns: "#", "FM Description", and "FM Ratio". The table has three rows: row 1 with "1", "Total drive fail", and "0.30"; row 2 with "2", "Single sector data error", and "0.7"; and a row with "*", an empty cell, and an empty cell. Below the table, there are three buttons: "Delete FM", "OK", and "Cancel".

#	FM Description	FM Ratio
1	Total drive fail	0.30
2	Single sector data error	0.7
*		


These failure modes can be used during [FMECA](#) analysis ("Get from GPRD Library" in the Failure Mode column).

You may fill in the data in this table just by selecting the desired cells and typing.

9.5.4 Field Failure Rate Tables

Very often a reliability engineer has to deal with the problem of unspecified failure rates. The GPRD FR Tables utility provides an effective solution to the problem of unspecified failure rates.

If you have existing field data for reliability prediction and analysis, you can store them in a failure rate table. You can then apply the observed failure rates to tree items and thus override the results based on the standard prediction method. The GPRD FR Table utility allows you to define separate tables for different environments and temperature-failure rate combinations:



Note: The GPRD-field FR table allows you to avoid inaccurate temperature curves or mission profile analysis reports when failure rates are entered manually for a specific temperature-failure rate combination.

RAM Commander extrapolates or interpolates the failure rate for temperatures that are not explicitly defined. Data may be entered for one environment only, and then RAM Commander will use RAC Toolkit formulas to convert this data to different environment according to settings in your specific product tree.

The GPRD-field FR table utility is useful when you need to:

- Perform a reliability analysis for any temperature if you have failure rates for only a few temperature values.
- Apply reliability values to different assemblies in one project or in several projects.
- Access reliability data for a project, even though you are not authorized to review the project's actual components (such as for security reasons).

Data can be entered to the reliability prediction table by 3 methods: manually, using import or as a "packed box".

9.5.4.1 Manual FR Table Data Entry

When you enter data manually into a failure rate table, you must specify the temperature and its associated known failure rate for each environment.

To manually create a new failure rate table:

1. Activate the Product tree view.

2. Open the GPRD Library.
3. Select Global or Project library in the View menu (project library is opened by default). If the Project library is selected, the component data you enter can only be used in the project where it is created.
4. Open an existing Part screen or create a new Part record.
5. In the General Part Data screen, click either Operating or Non-Operating; the field FR table appears.
6. Select FR or MTBF in the second list box under Part number.
7. Enter FR or MTBF according to the temperatures in the table for all temperature values that you have reliability data. The failure rates must be expressed in terms of 10^{-6} or FIT, depending on what is displayed in the list box under Part number. As you make new entries in the failure table, RAM Commander redraws the failure rate graph.
8. If you want to limit the extrapolation, enter a value larger than your minimum temperature in the Tmin field and a value smaller than your maximum temperature in the Tmax field.
9. Click to select the "Use for conversion" check box to define one of the environments as default. This table is now set as the default for a specified environment and for the specified Part number. If you try to perform calculation for this Part number and for other environments, which do not have FR Table data, the program will use the default environment for this Part number and convert it automatically to the required environment, using the Toolkit conversion coefficients.
10. Click Close.

You have built a table of field failure rate data that is now ready to be used in reliability calculations for the other product tree parts. Choose "GPRD" as a reliability prediction method for parts with GPRD FR table and RAM Commander will calculate the Failure Rate.

9.5.4.2 Pack to Box


You can use the **Pack to Box** option to calculate failure rates for a given environment and a wide range of ambient temperatures for specific assembly in the product tree and then "pack" the results into a single part of the GPRD library.

To pack an assembly into a failure rate table:

1. Set the current processor to the Operating or Non- Operating mode.
2. Highlight the source assembly in the Product tree view:


TUTORIAL	1	Communication System	1	184.3903
Communic	1	CN017000	1	99.8937
Main Switch	1	CN017004	2	8.7416
U1	1	8086A	1	0.2442
U9	2	80C88	1	0.2678
U10	3	80C31	1	0.0862
U12	4	LM299	1	0.0625
U13	5	74LS30	1	0.0367
R1-10	6	RLR	10	0.0890
R11-12	7	RN	2	0.0365
R30-34	8	RZ	5	0.0849
CC1	9	CK	1	0.0619
CC2	10	CK	1	0.0619
CC3	11	CK	1	0.0595
CC4	12	CK	1	0.0607
CC5	13	CK	1	0.0614
L0-4	14	HLMP-2450	4	0.0144
L5-6	15	HLMP-2400	2	0.0072
SW1-2	16	DP2	2	3.1361

3. Make sure that this assembly has defined unique Part Number.
4. From the Library menu, select Pack to box.
5. In the Pack to Box dialog box, select one or more environments and enter values for the Lowest Temperature and the Highest Temperature:



6. Click OK.
7. RAM Commander will recalculate the FR for the selected assembly by performing reliability prediction for underlying components for all the selected environments and temperatures and will insert the obtained results into the GPRD library.

To review the table, activate the Product tree view and select GPRD from the Library menu. In the GPRD parts list, select the required Part number (the Part number used in step 4 of the previous procedure), choose Edit from the pop-up menu, and then click either Operating or Non-Operating . You will get a FR table for this part:



9.5.4.3 Import

In addition to manually creating failure rate tables, you can import failure rates from an external file into the project's failure rate table.

There are two import approaches in GPRD:

- [Import from ASCII file](#)
- [Import Wizard](#) (customizable import from text, Access and Excel files)

9.5.4.3.1 Import from ASCII file

RAM Commander provides a facility to import failure rate table data from ASCII files. Each line in the ASCII file must have the following format:

Field name	Type	Width	Values
Part Number	String	User defined, maximum 31	User defined
Environment	S-text	3	See values in Top item definition paragraph
Temperature	Integer	User defined, default 4	numeric, from -273 to 1000 degrees centigrade

Field name	Type	Width	Values
FR or MTBF	Floating point	User defined, default 8	Any positive floating point number

The fields must appear in the order noted above. The ASCII file name can have any extension, but defaults to a *.dat extension.

To import a failure rate table:

1. From the Library menu, choose GPRD; the GPRD library opens.
2. Choose "Import from ASCII" from the Library menu..
3. The FR Table Import dialog box opens:

4. Enter values for field width and default values for environment and temperature, so that these values will be used as a default if no values are provided in the ASCII file that is being imported.
5. Select Failure Rate or MTBF, depending on the type of data in your import file.
6. Click OK.
7. In the Open dialog box, select the ASCII file containing the data to be imported.
8. Click OK.

RAM Commander imports the file directly into the GPRD library. Environment and Temperature fields without data are assigned the default values you set in step 4.

9.5.4.3.2 Import Wizard

Import Wizard is a convenient way to import files of different format (text, Access, Excel) into the GPRD library. It allows importing both General data (part number, catalog number, price, weight etc.) and FR tables.

To use the GPRD Import Wizard:

1. Activate the GPRD window.
2. Choose "Import Wizard" from the "Library" menu.
3. The next steps are very similar to the [Product Tree Import Wizard](#).

9.5.4.4 Copying and Deleting Failure Rate Tables

To copy a failure rate table to another environment, in the **GPRD-FR table** dialog box, select the Part number and Environment and click **Copy to Env**. The environment data is copied with the necessary adjustments. In the **Add/Copy Table** dialog box, select a target environment in the **Environment** list and click **OK**. Click to select the **Copy using Toolkit** checkbox if you wish to use the Reliability Analysis Center Reliability Tool Kit. RAM Commander makes a new copy of the failure rate table for the Part number/Environment combination.

To delete a failure rate table, select the **Part number** and **Environment** and choose **Delete**. A prompt appears asking if you want to delete the table. Click **Yes** and the table is deleted.

9.5.4.5 Using GPRD Library in Reliability Prediction

RAM Commander uses the Part number, environment and temperature values in the Item Data dialog box to extract an item's failure rates from an GPRD FR table and then performs interpolation/extrapolation/conversion between environments if required to calculate the actual failure rate.

To apply a failure rate table to a tree item:

1. Open the item's Item Data dialog box in the Operating tab (if the table was created in Operating mode) or the Item Data dialog box with the Non-operating tab (if the table was created in Non-Operating mode).
2. In the Part number field, enter the Part Number of the part you have in the GPRD Library.
3. In the "Method of FR(predicted) calculation" list, select "user defined". In the Methods list, select GPRD:

The screenshot shows the 'FR Prediction/Calculation Settings' dialog box. The 'Method selection' dropdown is set to 'user defined', 'Method' is 'GPRD', and 'Failure distribution' is 'Exponential'. A 'GPRD' button is highlighted with a green border. Below, the 'Failure Rate / Reliability Data' section shows 'FR Source' set to 'Predicted', '*Field factor' as 1, '*Duty cycle' as 1, and 'Item FR' as 11.4844.

4. Click the GPRD method button.
5. RAM Commander displays the GPRD FR Table dialog box. You can add or modify FR data or you can use the data already existing. You can toggle the data between MTBF and FR and view the resulting graph.
6. Click Close to close the GPRD FR table dialog box. RAM Commander should display the calculated FR for your part, ambient temperature and environment.
7. Click Ok; RAM Commander displays the Product tree view.

See also [Load from Library](#) paragraph earlier in this chapter.

9.5.4.6 Failure Rate Table Formulae

When using a failure rate table, enter the reliability data actually observed at specified temperatures. RAM Commander then extrapolates failure rates for temperatures outside the specified domain, and interpolates failure rates for temperatures within the specified domain.

The Interpolation and Extrapolation works differently for Electronic/Electro-Mechanical and for Mechanical parts. Pay attention to Family selection in the GPRD library General data screen:

General Part Reliability Data

General

Part Name: HDD002

Catalog number: CN00003

Manufacturer: IBM

Description: Hard Drive disk

Item Function: Data Storage

Family: **ELECTRONIC**

Item code: ...

Source of FR

Interpolation and Extrapolation for Electronic/Electro-Mechanical parts

Interpolation and Extrapolation is performed using RIAC Reliability Toolkit formulas for compound electronic equipment:

GPRD - Operating

Part Name: HDD002 Environment: GF Use for conversion

Project: MTBF 10e-6 Tmin: 0 Tmax: 150 Source: User Defined

#	Temperature	MTBF
1	0.0	
2	10.0	
3	20.0	
4	30.0	
5	35.0	81000.00
6	50.0	
7	60.0	
8	70.0	
9	80.0	
10	90.0	
11	100.0	
12	110.0	
13	120.0	
14	130.0	
15	140.0	
16	150.0	

MTBF * 10e5

Tmin

T (°C)

FR (or MTBF) interpolation/extrapolation is done according to provided FR(temperature) points.
For electronic family components or assemblies (Family="...") calculation is done according to RAC Reliability Toolkit formulas.
For mechanical and electro-mechanical family components linear interpolation/extrapolation is used.

Close
Add
Delete
Edit
Copy to Env
Redraw

Extrapolated failure rates are computed as follows (taken from RAC's Reliability Tool Kit):

$$\lambda = \lambda_0 \cdot 1.25^{\left[\frac{t-t_0}{10}\right]}$$

where

λ_0 known failure rate for temperature t_0

λ required failure rate for temperature $t > t_0$

Interpolated Failure Rates

Interpolated failure rates are computed as follows:

Case A:

$$x_1 = \lambda_1 \cdot 1.25^{\left[\frac{t-t_1}{10}\right]} ; x_2 = \lambda_2 \cdot 1.25^{\left[\frac{t-t_2}{10}\right]}$$

where

λ_1 and λ_2 known failure rate for temperature t_1 and t_2 , respectively


t temperature for which failure rate is to be evaluated.

Case B:

$$\log \lambda = \frac{\log [x_1 (t_2 - t)] + \log [x_2 (t - t_1)]}{t_2 - t_1}$$

Interpolation and Extrapolation for Mechanical parts

Interpolation and Extrapolation for mechanical parts is linear and is performed by any 2 closest points.



9.5.5 Copying GPRD Library between projects

You may copy GPRD library from one project to another to reuse the data. See [Copy libraries between projects](#) for instructions.

System manager may also transfer parts from the project to the global GPRD library. Use "Copy to global" option from the "Library" menu of GPRD library.

9.5.6 Reports

You can generate several types of reports for GPRD library parts.

In the Reports menu of GPRD Library window, select one of the following:

Field name	Type
Current part (FR data)	FR tables for the selected part
All Library (FR data)	FR tables for all parts
Selected environment (FR data)	FR table for the selected part and selected environment
General part data	List of all parts in the GPRD library with their general data (PN, family, Item type, description etc.)

Field name	Type
Failure Modes	Failure Modes for all parts in GPRD library (PN, Failure Mode, Alpha)

9.6 Calculation Defaults

RAM Commander provides defaults for all component information required for reliability prediction. RAM Commander uses these default values for reliability prediction in all places where the necessary data was not entered.

See below some sample resistor's MIL-STD-217 reliability prediction data screen:

The screenshot shows a software window titled "Resistor MIL-HDBK-217FN2". At the top, there are input fields for "Ref. des.:" (R1-10), "QTY:" (10), "ENV:" (GF), and "Temp:" (49. °C). Below these are fields for "Part name:", "Mil. num.:", and "Cat. num.:". A "Generic name:" field contains "RLR". A "Style:" dropdown menu is set to "RLR - Fixed, Film (Insulated), Est.Rel.". To the right of the style field are "Poper.:" (0.2) and "Prat.:" (1.) fields. Below these are several fields with "---" values, highlighted with red boxes: "PSR:", "Quality:", "Pl q:", "dT:", "T1:", "T2:", "S1:", "S2:", "Lead Configuration:", and "Distance: (mils)". There are "OK", "Cancel", and "Help" buttons on the right side. At the bottom, there is a toolbar with icons for help, a search icon, and a list of part numbers: 54HC00, 54HC08, 54HC36, 54F280, 68000, and 80386.

Note that only several parameters are defined, and other parameters have "---" undefined value (marked with red color). However reliability prediction method still needs values for these undefined parameters. These "undefined" parameters values will be taken from the calculation defaults library. It reduces prediction accuracy but allows to deal with situations when not all values are known and available.

You may review calculation defaults which will substitute "undefined" parameters values from the prediction method data screen by clicking the "View defaults" button:

Resistor MIL-HDBK-217FN2

Ref. des.: R1-10 QTY: 10 ENV: GF Temp: 49. °C

Part name:

Mil. num.:

Cat. num.:

Generic name: RLR

Style: RLR - Fixed, Film (Insulated), Est.Rel.

PSR: 0.2

Prat.: 0.125

Quality: M

Pl q: 1.

dT: 1.

T1: 70. S1: 100.

T2: 150. S2: 0.

Lead Configuration: Non SMT

Distance: 1. (mils)

Note the actual values (marked with yellow) which will be used instead undefined "---" values on the previous screen.

Click the same button again to return to the normal view.

Calculation defaults are stored per each project and are also stored in the global RAM Commander configuration. When you create a new project, global calculation defaults are copied to the newly created project.

Any user can review the defaults for any component type defined for a specific reliability prediction method. Users can also modify defaults for their own projects. Only the system manager can update global defaults.

The Default Manager list displays data for the reliability prediction method selected in the Project Configuration dialog box. For instance, if Telecordia (formerly Bellcore) Issue 6 was selected as the reliability prediction method, then the Default Manager list initially displays all the defaults for IC-Digital components specified by Telecordia (formerly Bellcore) Issue 6.

To open the Calculation Defaults manager:

1. Activate the Product tree view.
2. From the Project menu, choose Default Manager - the list will appear:

The screenshot shows the 'Default Manager' window with the following settings: MIL-217F-2 P. stress, ELECTRONIC, and IC-Memory. The table below represents the data shown in the window:

Techn	Type	Subtype	Correct. code	Memory
CMOS	ROM	—	—	16000
CMOS	PROM	—	—	16000
CMOS	UVEPROM	—	—	16000
CMOS	EEPROM	FLOTOX	No On-C	16000
CMOS	EAPROM	—	—	16000
CMOS	DRAM	—	—	16000
CMOS	SRAM	—	—	16000

3. Views displayed in the Default Manager list are keyed by reliability prediction method, family and Item type. Select the prediction method, family and Item type in the respective drop-down lists to see the desired information.

Note: **Do not add new records to or delete records from the global default listing.** Doing so will have an unpredictable impact on reliability calculations.

To change the defaults for the specific calculation method, component family, Item type and type/style, open the calculation defaults manager, select required filter, double-click the desired record and perform the changes.

Applying New Default Values

If a change is made to one of the values in the project's defaults and you want the defaults to be taken into account, then you must apply them by choosing Recalculate All from the "Calculation" menu of the Product Tree view.

Generating Calculation Defaults reports

To generate a listing of the defaults, do one of the following:

- For a report on the current family and Item type, from the Report menu, choose Current Item type.
- For a report on all family and Item type combinations, from the Report menu, choose All Defaults.

RAM Commander displays the report in a window.

Updating Global Defaults from a Project


The system manager can update global defaults library using project defaults library. It is useful if you've performed some changes in the default values for a particular project and now wish to have the same corrected values to be used in all newly created projects.

Caution: Be careful when updating global libraries. There is no undo facility to easily return your library to its original state.

To update global defaults library using the project defaults library:

1. Activate the Product tree view.
2. From the Project menu, choose Transfer.

3. Select the Project to Global option button.
4. Select the Calculation Defaults option:




5. Click OK.
6. RAM Commander updates the selected global library.

Refreshing project Defaults from the Global Defaults Library

The project's defaults may be refreshed from the global defaults. This may be necessary when there was a change to the global defaults you want to use in your project or when you feel that the project defaults you assigned are no longer required and you need to revert to the standard defaults.

To refresh project defaults from the global defaults:

1. Close any open Default Manager windows.
2. Activate the Product tree view.
3. From the Project menu, choose Transfer.
4. Select the Global to Project and Calculation Defaults option buttons:



5. Click OK.

RAM Commander updates the project defaults. When you reopen a Default Manager window, RAM Commander displays the new defaults. You have to run "Recalculate all" to get your calculation results updated using the updated default values.

9.7 Managing Libraries


You may copy between projects, backup, restore and create new project and global libraries.

9.7.1 Copy libraries between projects

You can copy libraries from one project to another. This feature saves you time when you have made changes to one project library and you want to make them available to other project libraries.

To copy project libraries:

1. Open the target Product tree view.
2. Activate the source Product tree view.
3. From the Library menu, choose Copy libraries.
4. In the Select Target Project for Copy dialog box, select the target Product tree view.
5. Select data you wish to copy from the source to destination project:



6. Choose OK.

RAM Commander updates the target project's libraries.

9.7.2 Global Library Files Location

Many reliability engineers perform a reliability analysis for various customers with the RAM Commander. In these projects, the same catalog number may be used for different items. Having just one component global library and cross-reference file can result in using the wrong data for the prediction. To avoid this and to allow the user to create alternative global library and cross-reference files for each customer, RAM Commander provides the user with access to all existing global library and cross-reference files.


Another reason to change global library files location is to place these files on a shared network folder to share it between multiple RAM Commander users. In client/server installation it is done by default - see and [Settings Management](#) also [Standalone Installation + Common Network Database](#) paragraphs for standalone installation.

9.7.3 Back Up and Restore of Global Libraries


As with all important data sources, RAM Commander's global libraries should be backed-up on any storage medium. This protects your information from computer crashes, allows data to be moved between computers, and provides a way to recover data if you need to reconstruct projects in the event of incorrect data entry.

To back-up global libraries:

1. Close (not minimize) all RAM Commander windows.
2. From the Library menu of the initial RAM Commander screen, choose Archive.



3. The Backup - Restore Data dialog box will appear:



4. Select the Backup option button.
5. In the drop-down list, select the libraries you want to back-up.
6. The Backup library path dialog box opens.
7. Select the destination file/path (GLOBAL.RMW by default).
8. Choose Save.

Enter your confirmations in the dialog boxes as the backup procedure progresses. Keep the back-up data in a safe place.

To restore archived global libraries, on a whole record basis, follow the previous procedure. In step 3, select the Restore option:

- Choose Restore with overwrite for RAM Commander to replace your current libraries with the version stored in the archive file.
- Choose Restore with merge to leave the original global library data intact only adding those records that do not already exist. Should the record already exist in the existing global library, you will be prompted to either overwrite or skip duplicate records.

Chapter

10

Reliability Analysis

10 Reliability Analysis

After the primary reliability prediction is done, it is possible to analyze different aspects of system reliability:

- Analyze system reliability under different environments and temperatures - [Temperature Curve](#).
- Analyze and find components with largest contribution to system MTBF - [Pareto](#).
- Calculate mission reliability when system is performing complex missions in different environment conditions - [Mission Profile](#).


10.1 Temperature Curve

Temperature curve reports show the influence of temperature on a project's reliability. You can view the temperature curve results for several environments simultaneously, in graph or text form.

RAM Commander's series of *temperature curve reports* provides many ways to look at failure rates with variation in temperature. You can review a project's failure rates for one or more environments, or generate a report for selected project items.

To view a Temperature Curve Report:


1. [Activate the Product Tree View](#).
2. Navigate to the desired level in the Product tree. Note: Like all reports, temperature curve reports are level-specific. Select the desired level in the product tree before running the report.
3. From the Reports menu, choose Temperature Curve; the Temperature Curve dialog box opens.



4. Enter an optional report description.
5. Select a report type in the Type list box.
 - If you selected Multi Environment in the Type list box, make one or more selections from the Environments list box.
 - If you selected Multi Item in the Type list box, choose the Delete button to remove items from the Item list, or choose the Add button; the Select Tree item dialog box opens. Select an item from the tree and choose OK. Repeat to add more items.

6. In the Result field, select F.R. for failure rate or MTBF for mean time between failures.
7. In the Output field, select Text or Graph.
8. In the Lowest Temperature and Highest Temperature fields, enter the lowest and highest temperatures to be included in the report.
9. Enter the number of temperature points in the # of points field. (The number of temperature intervals equals the number of points minus 1.)
10. Choose OK.

The text or graph versions of the Temperature curve report will appear - the example below shows Multi-Environment FR curves for GB, GF and GM environments between 0 and 100 degrees:




10.2 Pareto

Pareto reports display items in order of contribution to overall failure. For example, if an assembly contains two components: a diode failing at a rate of 5.0 and a capacitor failing at a rate of 0.5, then the assembly's overall failure rate is 5.5. The diode contributes $5/5.5 \times 100 = 91\%$, while the capacitor contributes $0.5/5.5 \times 100 = 9\%$. In a Pareto analysis, the diode is listed first and the capacitor second.

RAM Commander provides two types of *textual* Pareto reports. You can select a *detailed* report by part identifier (see Item ID Priority in Chapter 8 – Item Identifier (ID) Display Options), or a *summary* report by Item type. You can produce a Pareto report in *graph form* using Item type only.

To view a Pareto report:

1. [Activate the Product Tree View.](#)
2. Navigate to the desired level in the product tree.
3. From the Reports menu, choose Pareto; the Select type of Pareto Report dialog box opens.



4. In the Select type of Pareto dialog box, select the type of report you require.

5. Choose Prepare Report.

6. RAM Commander displays the selected Pareto analysis report.

If the selected report type is a table, after viewing the report, close it by double-clicking the window's control button:


Pareto analysis (by name)

Project name: TUTORIAL

Start from: TUTORIAL

PN	Qty	Total Failure rate	Item Failure rate contribution	Cumulative contribution
CL	33	76.749	41.025%	41.025%
CN017099	1	17.000	9.087%	50.113%
CD98AB1	1	14.430	7.713%	57.826%
F99	1	12.581	6.725%	64.551%
MB00887	1	12.000	6.414%	70.966%
HDD002	1	11.484	6.139%	77.104%
CN017201	1	8.350	4.463%	81.568%

When the Item type Graph - report is selected, the Graph View window opens.



The appearance of the Pareto graph may be customized by entering "Setup" (see more in the [Graphs](#) paragraph).

10.3 Mission Profile

RAM Commander provides a **Mission Profile analysis** module that simulates the product tree under varying conditions. Define a mission phase by specifying its operating mode, duration, temperature, alpha and number of cycles. A mission profile analysis report describes the product's reliability throughout the mission defined.



Complex mission profiles using many phases can be built. For example, you can design an airplane's mission profile starting at hangar storage, takeoff, various altitude climbs, and return to base. Each of these phases can be broken down into smaller phases, until you fine tune your mission so that it closely resembles the airplane's actual operational conditions.

10.3.1 Defining a Mission Profile

The first step in performing a mission profile analysis is to define the mission profile and its phases.

You must be in operating or non-operating mode to access the Mission profile module. For a review of project operating modes, "Reliability Calculation" chapter.

A mission profile is a progression of **phases**. Each phase is characterized by the following:

- * Operating or Non-operating mode
- * Environment
- * Temperature
- * Time
- * Test coverage (alpha)
- * Number of on/off cycles per 1,000 hours (non-operating mode only)


Complex mission profiles using many phases can be built. For example, you can design an airplane's mission profile starting at hangar storage, takeoff, various altitude climbs, and return to base. Each of these phases can be broken down into smaller phases, until you fine tune your mission so that it closely resembles the airplane's actual operational conditions.

10.3.1.1 To add a mission profile

- 1 Activate the Product tree view.
- 2 From the **Modules** menu, choose **Mission Profile**; the Mission Profile dialog box opens.



- 3 Choose **Add MP**; the Add Mission Profile dialog box opens.



- 4 In the Add Mission Profile dialog box, enter a mission profile name
- 5 Choose **OK**.

RAM Commander redisplay the Mission Profile dialog box. You can now access the new mission profile by choosing it from the MP Name list box. Then you may add multiple phases to this Mission Profile.

10.3.1.2 To add a mission profile phase

In the Mission Profile dialog box, select the mission profile to which you want to add a phase from the MP Name list box.

1. Choose **Add Phase**; the Add Mission Phase dialog box opens.

2. Enter values for the following fields:

Phase Description	Name of the mission phase
Mode	Operating or non-operating
Environment	One of the reliability environments
Temperature	Temperature during the phase
Time	Phase duration
Test Coverage	Coverage of failure detection/testing performed at the end of this phase. When 0, no test is performed; when 1, full test coverage is assumed. The which is "passed" from the current phase to the next phase is multiplied by (1-Alpha). Note: Alpha defined for the last phase in mission profile is ignored.
Nc	Number of on/off cycles per 1,000 hours (non-operating mode only)

3. Choose **OK**.

RAM Commander redisplay the Mission Profile dialog box with the new phase.

10.3.1.3 To delete a mission profile phase

Caution Use care when deleting mission profile phases. There is no undo facility to easily return the mission profile to its original state.

1. In the Mission Profile dialog box, select the phase by clicking on its number under the # column.

2. Choose **Delete Phase**.
 3. Enter your confirmation in the dialog box.
- RAM Commander displays the updated Mission Profile dialog box.

10.3.1.4 To copy a mission profile

1. In the Mission Profile dialog box, Choose **Save As...**
 2. Enter new Mission Profile name and press ok.
- Copy of your Mission Profile will be created under new name.

10.3.1.5 To delete a mission profile

Caution Use care when deleting mission profiles. There is no undo facility to easily restore the mission profile.

1. In the Mission Profile dialog box, Choose **Delete MP**.
 2. Enter your confirmation in the dialog box.
- RAM Commander displays the updated Mission Profile dialog box.

10.3.2 Mission Profile Calculation

After defining a mission profile, you can obtain reliability estimates for the product.

Note Recalculate the product tree before computing a mission profile. See Reliability Calculation chapter for reliability calculation techniques.

To compute mission profile reliability:

- 1 Activate the Product tree view.
- 2 From the **Modules** menu, choose **Mission Profile**; the Mission Profile dialog box opens.
- 3 Select the mission profile from the MP Name list box.
- 4 Choose **Analyze MP** button.

RAM Commander displays the mission profile report in a report window:

Mission Profile Report for Project TUTORIAL Drive C:

Mission Profile report

Project : TUTORIAL
Mission name : TEST
Start from : TUTORIAL

Mission Phase	OP/NOP	t(hours)	Env	T(°C)	Nc	Alpha	F.R.(E-6)	MTBF	F.R.*t	R(t)	1-R(t)
Storage	Nop	30.0000	GB	25.0	0.0	0.50	12.710304	78676.3	381.3091	0.99961876	0.000381
Transportation	Nop	4.0000	GM	35.0	0.0	0.00	25.883499	38634.7	103.5340	0.99989647	0.000104
Flight	Op	0.2000	AIC	55.0	0.0	---	267.217102	3742.3	53.4434	0.99994656	0.000053

Total Mission Reliability: 0.99965243

SUM[(1-a)*FR*t]	R=MULT[R(t)]	1-R
347.6320	0.99965243	0.000348

The report includes the following information:

- Description of all mission phases
- Failure rate during each phase
- MTBF during each phase
- Failure rate \square phase duration
- Reliability for each phase
- Unreliability for each phase
- Total mission reliability

Total Failure Rate Formula

The total failure rate for a mission containing $n + 1$ phases is calculated as follows:

$$\lambda_{\Sigma_{n+1}} = (1 - \alpha_{n+1})(\lambda_{n+1} \cdot t_{n+1} + \lambda_{\Sigma_n})$$

where

$\lambda_{\Sigma_{n+1}}$ - total mission failure rate over $n + 1$ phases

$\lambda_{\Sigma_1} = (1 - \alpha_1) \cdot \lambda_1 \cdot t_1$ - total mission failure rate for the first phase

α_1 - test coverage during transition from first phase to second phase; a fraction in the range [0; 1] where 0 means no testing, and 1 means complete fault isolation between phases

λ_1 - total failure rate of the system for the first phase

t_1 - duration in hours of the first phase

10.3.3 Summary

In this chapter, you learned about RAM Commander's **mission profile** analysis module. Using this module, you can build detailed models of a project's environmental conditions, compute the reliability values, and perform analysis. An important result of the mission profile module is the probability that the project will complete the mission.

10.4 Burn-In Report

Burn-in is the operation of a component under severe temperature and stress conditions to stabilize its performance. Burn-in reports may only be generated when using the Telecordia (formerly Bellcore), Bellcore Issue 5 or 6 reliability prediction methods. Before selecting the burn-in option from the Reports menu, define the burn-in time and burn-in temperature for the desired items, as follows:

To define global burn-in time and burn-in temperature

- 1 In the Product tree view, navigate to the top of the product tree.
- 2 From the **Tree** menu, choose **Edit**
 - OR -
 - right-click the mouse and select **Edit**.
- 3 In the Tree level item dialog box, enter values for:
 - Burn-in Temperature in °C; and
 - Burn-in Time in hours
- 4 Choose **OK**.

To define specific burn-in time and burn-in temperature

To define a burn-in time and burn-in temperature for a specific item (component or assembly):

- 1 In the Product tree view, navigate to the required item.
- 2 From the **Tree** menu, choose **Edit**
 - OR -
 - right-click the mouse and select **Edit**.
- 3 In the Item Data dialog box (Miscellaneous tab), enter values for:
 - Burn-in Temperature in °C; and
 - Burn-in Time in hours.
- 4 Choose **OK**.

To view a Burn-In Report

From the **Reports** menu, choose **Burn-in**; the Burn-in report window opens with a first year multiplier for each item. This multiplier is the ratio of the first year failure rate to the steady-state failure rate.

Chapter

11

Maintainability Prediction

11 Maintainability Prediction

Components that fail must either be discarded or repaired. RAM Commander provides you with a flexible module for developing and performing **maintainability prediction and analysis**.

Maintainability is a measure of how long a product is not available for use. When components are being maintained, they pass through a sequence of repair tasks that transform them from failure status to available status. Such tasks typically fall into the categories of disassembly, diagnosis, repair and reassembly.

RAM Commander allows you to build your own *time* and *task libraries*. *Standard times* are times you define for performing a particular activity. A *standard task* is a sequence of standard times. You can use standard time and task libraries to compute maintainability times for your system.

RAM Commander allows you to build libraries of skill types, equipment items and material types. You may use these libraries to specify skills, equipment and materials required to perform each maintenance task. From Maintenance Tasks Analysis report you may get a prediction of work load for each skill type and equipment, and usage of materials.

RAM Commander's maintainability prediction module is based on the recommendations in [MIL-HDBK-472, Procedure 5](#), Method A. The main definitions, models and assumptions presented in this chapter are taken from this document. Refer to MIL-HDBK-472 and [MIL-STD-721](#) for more information on RAM Commander's maintainability prediction module.

Method A, Procedure 5 of MIL-HDBK-472 is used to predict maintainability parameters for any type of system or equipment, including avionics, ground and shipboard electronics, or mechanical equipment, at organizational, intermediate, depot, supplier and manufacturer levels of maintenance.

See next paragraphs for a [theoretical discussion of maintainability prediction](#) , [philosophy and assumptions](#).


11.1 Philosophy and Assumptions

RAM Commander assumes that all corrective action consists of the following maintenance tasks:


- Preparation
- Fault isolation
- Disassembly
- Interchange (Remove/Replace)
- Reassembly
- Alignment (Calibration)
- Checkout (Verification)
- Start-up
- Other (all other tasks not in the above list)

In addition to the general assumptions listed in MIL-HDBK-472 Procedure 5, the RAM Commander maintainability prediction process includes an additional term: **level of replace**. Level of replace represents the specific maintenance level (location) where an item is to be removed and replaced. Therefore, the level of replace of an item corresponds to the level of repair of its parent. This assumes that an **assembly is repaired by replacing one or more of its lower level parts**.

The level of replace of the lower level parts must be equal to the level of repair of the assembly. MTTR can only be calculated for this situation:



When there are functional items in the product tree, then use “level of replace = unapplicable” so that these items will be transparent for MTTR calculation purposes. *Unapplicable* may be assigned to as many levels as required:



11.1.1 Information Required

You must provide the following data to perform maintainability prediction:

- The [Product Tree](#) (Bill of materials)
- The list of maintenance tasks or activities, including the number and description of all steps required to restore each replaceable item.
- For each task, the list of skills, equipment and materials required to perform the task (optional, for maintenance planning only)
- The failure rates associated with each replaceable item. These are taken automatically from the [reliability prediction](#) module.
- The estimated or required fault isolation resolution, expressed as a percentage of faults isolated to each of the ambiguity groups.

Note RAM Commander is able to take the ambiguity groups data from [FMECA](#) module.

11.2 Maintainability Prediction Modeling

This topic presents theoretical development for several maintainability modeling techniques:

- [Maintenance Corrective Time](#) (Mct)
- [Mean time to repair](#) (MTTR)

- [Ambiguity factor](#)
- [Maximum Corrective Maintenance Time](#)
- [Mean Maintenance Labor-Hours](#) per Maintenance Action (MLH/MA)
- [Maintainability Allocation](#)

11.2.1 Maintenance Corrective Time

The formula for computing Mct is

$$Mct_j = TPREP_j + TISO_j + TDIS_j + TR / R_j + TREAS_j + TCAL_j + TVER_j + TST_j$$

where:

Mct _j	average maintenance corrective or repair time for the jth replaceable item
TPREP _j	average preparation time for the jth replaceable item
TISO _j	average fault isolation time for the jth replaceable item
TDIS _j	average disassembly time for the jth replaceable item
TR/R _j	average time to remove/replace (interchange) the jth replaceable item
TREAS _j	average reassembly time for the jth replaceable item
TCAL _j	average calibration time for the jth replaceable item
TVER _j	average verification time for the jth replaceable item
TST _j	average time of start-up for the jth replaceable item

11.2.2 Mean Time to Repair

The formula for computing MTTR is

$$MTTR = \frac{\sum_{j=1}^N \lambda_j [TPREP_j + TISO_j + S(TDIS_j + TR/R_j + TREAS_j + TCAL_j + TVER_j) + TST_j]}{\sum_{j=1}^N \lambda_j}$$

where:

N	number of replaceable items on the next lower level of the product tree
λ_j	failure rate of the j^{th} replaceable item
S	Ambiguity factor, as explained in Ambiguity Factor paragraph

11.2.3 Ambiguity Factor

The ambiguity factor is the average number of iterations required to correct a fault, and is computed as

$$S = \frac{1}{100} \sum_{i=1}^K (X_i - X_{i-1}) \frac{(N_i + N_{i-1} + 1)}{2}$$

where

X_i	probability of fault isolation to N_i replaceable items. $X_1\% < X_2\% < X_3\% < X_4\% < 100\%$.
$0 < N_i$	Number of items in the i^{th} ambiguity group
$X_0 = N_0 = 0$	Ambiguity factor, as computed below

It is assumed that failure is isolated to an entire group of $0 < N_i < 99$ (for $i=1..5$) parts. The probability that the fault will be isolated for N_5 parts is $X_5 = 100\%$.

You can use up to 5 groups (i.e., $i=5$). The probability of the highest one must be equal to 100%. Furthermore, the inequality

$X_1\% < X_2\% < X_3\% < X_4\% < X_5\%$ must hold.

See also the [Fault Isolation and Ambiguity](#) paragraph.

11.2.4 Maximum Corrective Maintenance Time

The Maximum Corrective Maintenance Time (Mct max) for the f-th percentile $Mct_{max}(f)$ is the value of corrective maintenance time below which f percent of all maintenance actions are expected to be completed.

$$Mct_{max}(\phi) = \exp [\log MTTR + \phi\sigma_{Mct}]$$

where

$$\sigma_{Mct} = \sqrt{\frac{\sum_{i=1}^N (\log Mct_i)^2 - [(\sum_{i=1}^N \log Mct_i)^2 / N]}{N - 1}}$$

See also [Set Mct max Calculation Method](#) paragraph for more information.

11.2.5 Mean Maintenance Man-hours per Maintenance Action

Component Level:

$$MMH / MA = \sum_{i=1}^K MMH_i = \sum_{i=1}^K MP_i T_i$$

where:

MMH _i	Mean maintenance man-hours required for the <i>i</i> th maintenance task (preparation, fault isolation, disassembly, reassembly, etc.)
T _i	average time to perform the <i>i</i> th maintenance task (see Mct definition above)
MP _i	Manpower required for the <i>i</i> th maintenance task
K	number of maintenance tasks required (preparation, fault isolation, disassembly, reassembly, etc.)

Assembly Level:

$$\frac{MMH_{AS}}{MA} = \frac{\sum_{j=1}^N \lambda_j [MMH_{PREP} + MMH_{EO} + S(MMH_{DIR} + MMH_{R/R} + MMH_{CAL} + MMH_{VER}) + MMH_{SQ}]}{\sum_{j=1}^N \lambda_j}$$

where:

MMH_{PREPj}	average preparation MMH
MMH_{ISOj}	average fault isolation MMH.
$MMH_{D/Rj}$	average disassembly / reassembly MMH
$MMH_{R/Rj}$	average MMH of remove / replace (Interchange)
MMH_{CALj}	average calibration MMH.
MMH_{VERj}	average verification MMH
MMH_{STj}	average start-up MMH
N	number of replaceable items on the next lower level of the product tree.
λ_j	failure rate of the j 'th replaceable item
S	ambiguity factor

The value of the *ambiguity factor* S is used in calculating the MTTR for an assembly.

11.2.6 Maintainability Allocation

Maintainability allocation for each i^{th} child of the current item is computed according to the formula:

$$Mct(son_i) = MTTR_a(item) * W_M(son) \left(\frac{L(son_i) * Qty(son_i)}{\sum W_M(son_i) * L(son_i) * Qty(son_i)} \right)$$

where:

$Mct(son_i)$	allocated Mct of i^{th} child
W_M	weight factor for maintainability allocation
Qty	quantity of identical lower level items
$\lambda(son_i)$	failure rate of i^{th} child

11.3 Preliminary Steps

Before Maintainability Analysis stage you have to provide the following information using other RAM Commander modules:

- The [Product Tree](#) (Bill of materials)
- The failure rates associated with each replaceable item using the [reliability prediction](#) module

Then you may switch to **Maintainability** mode to start working with maintainability libraries and perform maintainability calculations.

To switch to the Maintainability Mode:

1. Activate the Product tree view.
2. From the **Project** menu, choose **Configuration**.
3. In the Project Configuration dialog box, select Maintainability as the current processor, and choose **OK**.

- or -

Select the Maintainability button in the Product tree view button bar.

4. RAM Commander product tree view, item data dialog, reports list and other menus and windows will change their appearance to accommodate maintainability mode.

Now you may set some initial configuration parameters and libraries in order to start the analysis:


1. [Set up/customize organizational level names](#)
2. [Set Mct max calculation method](#)
3. Set up [Maintainability libraries](#):
 - Standard Tasks Library
 - Standard Times Library
 - Skills/Equipment/Materials libraries

Then you may proceed to the [Maintainability Analysis](#).


11.3.1 Customize Organizational Levels

You may also set up maintenance levels (level of replace/repair) names:

1. Activate the Project tree view
2. Choose the Project Configuration from the Project menu; the Project Configuration dialog box is displayed:



3. Click "Maintainability" radio button to choose the type of Current Analysis.
4. Click the Repair/Replace Levels button; the dialog box with maintenance levels is displayed:




5. Change them as you wish and click OK. The level names appear in Maintainability Data Tab of Item Edit dialog box as well as in other related dialogs and reports, like Maintainability reports and [Spare Parts Calculation/Analysis](#).

11.3.2 Set Mct max Calculation Method

RAM Commander implements the advanced approach to the Mctmax calculation in the maintainability module.

1. Open the Product tree view.
2. From the **Project** menu, choose **Configuration**. The Project Configuration dialog box opens.
3. Select the Mctmax calculation method from the combo list:



4. Choose **OK**

The MIL-HDBK-472 applies the lognormal distribution to the repair times in the standard deviation calculation not taking in the account the item’s failure rates.

As many users have noticed however, the results were sometimes paradoxical. That’s why RAM Commander allows the user to perform Mct max calculation based on various repair times distribution assumptions. Users may now choose one of the following methods of the Mct max calculation:

1 MIL-HDBK-472 (Lognormal Distribution):

$$\sigma_{\ln T} = \sqrt{\frac{\sum_{i=1}^N Qty_i (\ln Mct_i)^2 - \frac{(\sum_{i=1}^N Qty_i \ln Mct_i)^2}{\sum_{i=1}^N Qty_i}}{\sum_{i=1}^N Qty_i - 1}}$$

$$Mct_{\max} = \exp(\ln MTTR + Z(p) * \sigma_{\ln T})$$

2 Weighted Lognormal Distribution

This is similar to the MIL-HDBK-472 based on lognormal distribution, but takes in the account the failure rates in the standard deviation calculation:

$$\sigma_{\ln T} = \sqrt{\frac{\sum_{i=1}^N \lambda_i (\ln Mct_i)^2}{\sum_{i=1}^N \lambda_i} - \frac{(\sum_{i=1}^N \lambda_i * \ln Mct_i)^2}{(\sum_{i=1}^N \lambda_i)^2}}$$

$$Mct_{\max} = \exp\left(\frac{\sum_{i=1}^N \lambda_i * \ln Mct_i}{\sum_{i=1}^N \lambda_i} + Z(p) * \sigma_{\ln T}\right)$$

3 Normal Distribution

The standard deviation calculation is based on the hypothesis of the repair times' normal distribution:

$$\sigma_T = \sqrt{\frac{\sum_{i=1}^N \lambda_i (Mct_i)^2}{\sum_{i=1}^N \lambda_i} - \frac{(\sum_{i=1}^N \lambda_i * Mct_i)^2}{(\sum_{i=1}^N \lambda_i)^2}}$$

4 Empirical Distribution

Does not use any distribution assumption and is based on the predicted repair times. The implementation algorithm consists of several steps:

$$Mct_{\max} = \frac{\sum_{i=1}^N \lambda_i * Mct_i}{\sum_{i=1}^N \lambda_i} + Z(p) * \sigma_T$$

A histogram of Mct_i and corresponding p_i is built, where

$$p_i = \frac{\lambda_i}{\sum_{i=1}^N \lambda_i}$$

cumulative (Mct_i in ascending order) distribution histogram is used to define the confidence level (CL) for each value of Mct :

$$\sum_{i=1}^k p_i * 100\% = CL_i$$

Mct_{max} is calculated by the linear interpolation of Mct_k . i.e. if the required value of CL (usually 90% or 95%) falls between CL_k and CL_{k+1} , then

$$Mct_{max} = \frac{Mct_k (CL_{k+1} - CL) + Mct_{k+1} (CL - CL_k)}{CL_{k+1} - CL_k}$$

11.4 Performing Maintainability Analysis

You may start performing the maintainability analysis only after the [Preliminary Steps](#) are done.

The primary goal of Maintainability Analysis in RAM Commander is MTTR and $Mct(max)$ calculation. Both parameters are calculated based on Mct of corresponding tree items. For Mct calculation of each item you should define a list of corrective maintenance (e.g. replacement) procedure tasks with their times.

When these procedures are defined, you may activate the calculation to get MTTR and $Mct(max)$ values for all the system and different sub-systems.

The paragraphs below explain the analysis procedure.

The calculated MTTR values may be used in other analyses like [Reliability Block Diagrams](#) , [Fault Tree Analysis](#) , [Markov Analysis](#) etc.

11.4.1 To enter Mct data

1. Select the required item in the Product tree view.
2. From the **Tree** menu, choose **Edit**; the Item Data dialog box opens:

The three fields grouped together in the upper left section of the dialog box contain information required to calculate maintainability parameters for the current item.

Define the following:

Method of Mct calculation	If you select default from the list box, then RAM Commander uses the maintainability method defined in the Project Configuration dialog box. If you select user defined, then you can select a maintainability method in the Method list box.
Method	Make a selection from this list box if you selected user defined in the Method of Mct calculation list box.
Level of Replace	Make a selection from this list box if you want to consider the item during maintainability prediction. See more on level selection in Philosophy and Assumptions paragraph.

In addition to these three fields, you must also make a selection for the source of Mct. In the list box, just under the maintainability parameter fields, you can select one of the following three values:

Predicted	The computation is made according to the selected maintainability prediction method. RAM Commander displays the result in the Mct(c) field.
User defined	You explicitly enter a value in the Mct(m) field.
Allocated	Select this value when you want to use the result of the maintainability allocation. See also Maintainability Allocation paragraph.

The lower part of the dialog box includes information required for the MTTR calculation of the current item as an assembly. Here you define the following parameters:

Level of Repair	Select Discard, Unapplicable, Organizational, Intermediate, Depot, Supplier or Manufacturer. See more on level selection in Philosophy and Assumptions paragraph.
Confidence level	Select a percentile used for calculating Mct max.

Define also the [Fault Isolation and Ambiguity](#) data - see the next paragraph.

11.4.2 MIL-HDBK-472 Procedure 5A

If you selected default for Method of Mct Calculation and MIL-472 Procedure 5 was selected as the default maintainability prediction method in the Project Configuration dialog box, then choosing OK in the Item Data - Maintainability dialog box displays the Maintainability MIL-472 Procedure 5 button in the right section of the Item data dialog box. Click on the button. The maintenance task list will appear.

Maintainability / RCM

Ref.Des.: Description:

Failure Mode:

Maintenance type: Maintenance procedure:

Preventive Maintenance procedure type:

Total maintenance times

Mct: [Hours]

MLH: [Hours]

Maintenance procedure frequency

User-defined: every [Hours]

Calculated: every [Hours]

#	Task Type	Task Description	Time [min]	LP
1	Preparation	UNIT DISCONNECTION	0.0	1.0
2	Fault Isolation	Diagnostic Procedure	4.0	1.0
3	Disassembly	Remove panel	0.8	1.0
4	Interchange	Replace switch	5.0	1.0
5	Reassembly	Replace panel	2.0	1.0
6	Start_up	Power On	5.0	1.0
*				

Note: The MIL-472 Procedure 5 button will not appear if levels of repair/replace are not defined properly according to the assumptions if the [Philosophy and Assumptions](#) paragraph.

11.4.2.1 To define MIL-472 Procedure 5A maintainability task information

- 1 If necessary, update the reference designator in the Ref. Des. field.
- 2 Do one of the following:

* To append a new task type to the end of the task list, choose **Append**. The Maintainability Task Description dialog box opens (see above). Follow the steps in the next procedure.

- OR -

Enter the task information directly into the last row marked with an *.

* **To insert a new task** type above the one currently highlighted, choose **Insert**. The Maintainability Task Data dialog box opens. Follow the steps in the next procedure.

* **To edit a highlighted task** type, choose **Edit**. The Maintainability Task Data dialog box opens. Follow the steps in the next procedure.

* **To copy a task**, select it and choose **Copy**. RAM Commander appends it at the end of the task list.

* **To delete a task**, select it and choose **Delete**. RAM Commander deletes the task and

redispays the task list.

- * **To set the tasks order** – use the move up and move down buttons to move that task accordingly.

3 Choose **Close**.

RAM Commander stores the maintenance task list for the current item.

Preventive Maintenance

In addition to Corrective Maintenance, Maintainability module supports Preventive Maintenance procedures.

Choose Preventive in Maintenance type list box of Maintainability/RCM dialog box. Click on Add button. Add/edit procedure name box appears. Enter required procedure and click on **OK**.

In Preventive Maintenance procedure type list box choose **Condition Monitoring, Failure Finding, or Restore or Discard**.

A number of different maintenance procedures may be defined, each procedure with its own frequency.

The frequency may be user-defined or optimized.

Choose Task type and enter Task description.

Your screen looks like below:

Maintainability / RCM

Ref.Des.: Description:

Failure Mode:

Maintenance type: Maintenance procedure:

Preventive Maintenance procedure type:

Total maintenance times

Mct: [Hours]

MLH: [Hours]

Maintenance procedure frequency

User-defined: every [Hours]

Calculated: every [Hours]

#	Task Type	Task Description	Time [min]	LP
1	Fault Isolation	Perform system tests	20.0	1.0
2	Fault Isolation	Check contacts	3.0	1.0
3	Other	Clean or replace the contacts	10.0	1.0
*				

You can edit or delete your defined maintenance procedures by clicking respectively on **Edit** or **Delete** buttons in the upper right hand part of the screen.

11.4.2.2 MIL-472 Procedure 5 Task Definition

Customize tasks by taking data from the standard task library, standard times library, or by creating your own user-defined tasks and times. All the procedures relate to the following dialog box.

Description	Qty	Time [min]
T01 Standard Screws	2	0.42
T03 Captive Screws	1	0.35
T06 Thumbscrews	3	0.14
T31 Slide Locking	1	0.21
...	0	0
...	0	0
...	0	0
...	0	0
...	0	0
...	0	0
...	0	0

You can use this dialog box to specify maintainability tasks using the standard tasks and times libraries supplied with RAM Commander.

11.4.2.2.1 To define a tasks using user-defined times

- 1 Select User Defined from the list box in the upper right hand corner of the dialog box.
- 2 Enter a task name in the Description field.
- 3 Enter the time in the User Defined Time field.
- 4 Enter a value for Mp (if different from 1).
- 5 Choose **OK**.

RAM Commander redisplay the Maintainability/RCM dialog box with the updated task.

11.4.2.2.2 To retrieve a standard time from the standard times library

- 1 Select Standard Times from the list box in the upper right hand corner of the dialog box.
- 2 In the Standard Times group box, select a standard time from the Description list box.
- 3 Enter a quantity for the standard time in the adjacent Qty field; the standard time is displayed in the adjacent Time field.
- 4 Repeat steps 2-3 for each additional standard time in the task.
- 5 Choose **OK**.

RAM Commander redisplay the Maintainability/RCM dialog box with the updated task.

11.4.2.2.3 To retrieve a standard task from the task library

- 1 Choose Tasks Library from the list box in the upper right hand corner of the dialog box.
- 2 In the Tasks Library list box, select a task. RAM Commander takes the task description and time displayed in the Total Time field from the Tasks Library.
- 3 Choose **OK**.

RAM Commander redisplay the Maintainability/RCM dialog box with the updated task.

11.4.2.2.4 To define a task's maintenance data

- 1 Switch to Skills tab
- 2 Choose from the Maintenance Library types of skills required to perform the task, enter number of workers for each skill:

Maintainability - Task Data

General Skills STE Materials

Task: Start_up Task #: 6

Description: Power On

#	Description	# of Persons
1	Electronics Engineer	1.0
2	Quality Engineer	2.0
*		

OK Cancel Apply Help

- 3 Switch to STE (Support and Test Equipment) and enter (by choosing from the Maintenance Library) all the equipment required to perform the task:

Maintainability - Task Data

General Skills STE Materials

Task: Start_up Task #: 6

Description: Power On

#	Description
1	Oscilloscope
2	Power Supply
*	

OK Cancel Apply Help

- 4 Switch to Materials tab and enter (by choosing from the Maintenance Library) all the materials required to perform the task:

#	Description	Qty	Units
1	Isolation Tape	1.000	m
2	Wire 2mm	0.500	m
3	Water	0.330	l
*			

11.4.3 Mean Time To Repair - MTTR

Before computing MTTR for an item, you must

- Enter all the maintainability information on the item's children.
- Perform reliability calculations. See Chapter 10 for reliability calculation procedures.

11.4.3.1 To compute MTTR

1. Activate the Product tree view.
2. From the **Calculation** menu, select the desired computation method.

RAM Commander redisplay the Product tree view with updated values for MTTR and Mct.

11.4.3.1.1 To calculate MTTR and Mct in Quick mode

1. Activate the Product tree view.
2. Change the Current Analysis, if necessary, using the corresponding icon on the Product tree view button bar.
3. Choose **OK**.
4. From the **Calculation** menu, choose **Quick**.

Note There is an option of automatic recalculation when defining the project properties to ensure that the RAM Commander output is based on the latest updated data (See – Adding a new project Chapter 8).

RAM Commander computes MTTR and Mct for the entire product tree. These results appear in the Product tree view.

11.4.3.2 Recalculate All

This function is the same as Quick Mode, but it also recalculates Mct for all items with the latest data from the maintainability library.

11.4.3.2.1 To calculate MTTR and Mct in Recalculate All mode

1. Activate the Product tree view.
2. Select the Current Analysis using the Product tree view button bar.
3. From the **Calculation** menu, choose **Recalculate All**.

RAM Commander computes MTTR and Mct using the items and libraries current data. These results appear in the Product tree view.

11.4.3.3 Fault Isolation and Ambiguity

In most products, a few components are responsible for most of the product failures, while the remaining components tend to function perfectly throughout the product's life. This behavior is similar to the Pareto principle discussed in [Reliability Analysis](#) chapter.

As a product undergoes the diagnostic phase of repair, the technician will first examine the problematic components in an attempt to locate the fault as quickly as possible. This effort can be modeled using *fault isolation*.

To define the fault isolation scenario, you first define up to five groups of parts N1, N2□N5. Each group is a subset of the next group that the technician examines. N1 includes the set of parts examined first, N2 includes the parts examined in N1 plus the next set of parts, and so on. If all sets of parts N1□N5 are examined, then in effect the technician has examined the entire product tree.

Associated with each part grouping is a *probability of fault isolation*. This is the probability that the faulty component is a member of any one of the examined sets. Suppose you group all the problematic components for the first set N1. Then the probability (X1) that the fault will be detected while examining the set of parts in group N1, will be high. If the fault is not detected while examining N1, then the probability (X2) of detecting the fault while examining the set N2 will be higher. This continues until the technician examines the last set of parts - N5, whereupon the probability of isolating the fault after examining *all* components is X5 = 100%.

For example, if a failure is always isolated to a single part in group N1, then

$$X1 = 1 = X5 = 100\%$$

and N1 = 1.

If in 80% of the cases a failure is isolated to a single part, and in the remaining 20% to two parts, then X1 = 80%, X2 = 100%, N1 = 1 and N2 = 2.

In the Fault Isolation group box, enter your values for N1□N5 and X1□X5.

The value of the *ambiguity factor* S is calculated based on fault isolation and is used to calculate the MTTR for an assembly (see [Ambiguity Factor](#) paragraph).

RAM Commander is able to take the ambiguity groups data from [FMECA](#) module.

11.4.4 Maintainability Allocation

You can use RAM Commander to perform top-to-bottom maintainability allocation. When allocating maintainability, use the following fields in the Tree Maintainability dialog box:

MTTRa	allocated (required) MTTR of an item
Complexity for Mct(a)	weighing factor for item's children intended for maintainability allocation

See [Maintainability Allocation](#) paragraph earlier in this chapter for a theoretical discussion of how RAM Commander allocates maintainability to each child of a parent.

11.4.4.1 To perform maintainability allocation

- 1 Activate the Product tree view.
 - 2 From the **Calculation** menu, choose **Allocation**.
 - 3 Choose **All Tree Down** to start the allocation from the current item downwards
 - OR -
 - choose **Current Level** to allocate the current item only one level down.
- RAM Commander calculates the allocated Mct values.

11.4.4.1.1 To copy maintainability tasks data to other items

1. Open the source and target Product tree views, or two views from the same product.
2. Activate the target Product tree view.
3. In the target window, select the items to which you want to copy maintainability data by highlighting it and using Windows conventions.
4. Activate the source Product tree view and select the item from which you want to copy maintainability data.
5. From the **Tree** menu, choose **Copy Processor Data**. Select the target project in the Select Target dialog box and choose **OK**.

RAM Commander copies the component data to the target window.

11.5 Maintainability Libraries

RAM Commander provides a library facility to store standard times, tasks, and Maintenance data (Skills, Support and Test Equipment, and Materials).

Standard Times Library contains typical times for typical simple operations like Screw remove, Screw replace etc.:

Code	Description	Interchange Time
1	T01 Standard Screws	0.42
78	T01 Standard Screws Remove	0.16
79	T01 Standard Screws Replace	0.26
2	T02 Hex or Allen Type Screws	0.60
85	T02 Hex/Allen Type Screws Remov	0.17
86	T02 Hex/Allen Type Screws Replc	0.43
3	T03 Captive Screws	0.35
58	T03 Captive Screws Remove	0.15
59	T03 Captive Screws Replace	0.20
4	T04 Dzus (1/4 Turnlock)	0.13
87	T04 Dzus (1/4 Turnlock) Remove	0.08
88	T04 Dzus (1/4 Turnlock) Replace	0.05
5	T05 Tridair Fasteners	0.12

Buttons: Edit, Add, Delete, Report, Close

It helps calculating more complex task times by composing them from multiple small operations taken from that library.

Standard Tasks Library is used to define typical tasks composed of multiple standard simple operations:


#	Action/Connection	Qty	Time	Total Time
1	T01 Standard Screws	4	0.42	1.68
2	T11 Spring Clip	1	0.07	0.07
3	T39 Cut Wire of Sleeving	1	0.04	0.04
*				

Task Description: EXAMPLE

Total Task Time: 1.79

Buttons: Edit Task Description, Add Task, Delete Task, Report, Edit, Append, Insert, Delete, Close

Maintenance Library contains maintenance staff skills definitions, equipment and materials definitions:



You may specify required skills, equipment and materials for each maintenance task and then RAM Commander will be able to predict estimated labour hours/usage hours/materials usage required for field maintenance of your system.

The information in all these libraries is open for editing and extension.

11.5.1 To access the Standard Times Library

1. Select maintainability mode.
2. From the **Library** menu, choose **Standard Times Library**.
3. The Standard Times Library window opens.

Only the system manager can edit, add or delete information in the Standard times library.

You can generate a report of the Standard times library by choosing Report from the Maintainability - Standard Times Library dialog box.

11.5.1.1 To add or edit a record in the Standard Times Library

- 1 From the Maintainability - Standard Times Library dialog box, choose **Edit** or **Add**.
- 2 In the Standard Times dialog box, enter the new time and description.
- 3 Choose **OK**.

RAM Commander updates the Standard Times Library list.

11.5.1.2 To delete a record in the Standard Times Library

1. Select the record you wish to delete.
2. Choose **Delete** from the Maintainability - Standard Times Library dialog box.

Caution Take care when updating the standard times library. There is no undo facility to easily return the library to its previous state.

11.5.2 To access the Standard Tasks Library

1. Activate the Product tree view.
2. Select Maintainability mode as the current processor.
3. From the **Library** menu, choose **Standard Tasks Library**.

The Tasks Library Manager window opens.

Only the system manager can edit, add or delete data in the Standard tasks library.

You can generate a report of the Standard tasks library by choosing Report from the Tasks Library Manager dialog box.

11.5.2.1 To add a new task to the Standard Tasks Library

1. From the Tasks Library Manager dialog box, choose Add Task.
2. Enter a description in the Task Description dialog box. Choose OK.
3. To add a new action or connection, choose Append or Insert.
4. In the Action/Connection dialog box, do the following:
5. Choose a connection from the Standard connections list box

- OR -

Enter a name in the Action/Connection field.

6. Enter a quantity.
7. To use a time different than the default, enter it in the Time field.
8. Choose OK.

RAM Commander redisplay the Tasks Library Manager dialog box with the new action or connection appearing at the end.

11.5.2.2 To delete a task from the Standard Tasks Library

Caution Take care when deleting tasks from the standard tasks library. There is no undo facility to easily return the library to its previous state.

1. From the Tasks Library Manager dialog box, select a task from the Task Description list box.
2. Choose **Delete Task**.

You can edit tasks within the Standard Tasks Library by creating new operations or deleting and

editing existing ones.

11.5.2.3 To edit a task in the Standard Tasks Library

1. In the Tasks Library Manager dialog box, select a task from the Task Description list box.
2. Do one of the following:
 - To add a new action/connection, choose **Append** or **Insert**. Enter information in the Action/Connection dialog box using steps 3-7 of the procedure on page 350.
 - To edit or replace an existing action/connection, select it and choose **Edit**. Enter information in the Action/Connection dialog box using steps 3-7 of the procedure on page 350.
 - To delete an existing action/connection, select it and choose **Delete**.

After each add, edit or delete, RAM Commander redisplay the Tasks Library Manager dialog box using the new data.

11.5.3 Standard Tasks/Times Library Reports

You can generate on-screen and hard copy reports of all standard tasks and standard times.

To generate a standard tasks/times library report


1. Activate the Product tree view.
2. Select **Maintainability** as the current processor.
3. From the **Library** menu, choose **Standard Tasks library** or **Standard Times library**.
4. In the dialog box, choose the **Report** button.

RAM Commander displays a window list containing a report of all the standard tasks or standard times. Use the report management utilities described in "[Reports](#)" paragraph to scroll, edit and print the report.

11.5.4 To access the Maintenance Library

1. Select maintainability mode.
2. From the **Library** menu, choose Maintenance **Library**.

The Standard Times Library window opens.



Use the tab sheets above to switch between tables.

To add a new line, just write the data into the empty table line with asterisk in the leftmost column.

To delete a line, right-click on the line and choose Delete from the pop-up menu.

11.6 Maintainability Reports

1. Select Maintainability mode.
2. Navigate to any level in the product tree.
3. From the **Reports** menu, choose **Standard Kit**; the Report Selection dialog box opens.
4. Select the report Type (see below) and the applicable Include items options. (Note how the fields in the Report Selection dialog box change accordingly.)

The table below explains the available report types:

Report Group	Description
Tree diagram	Tree structure
Maintainability information	ID, PN, RefDes, Qty, F.R.[FIT], Mct[hrs], MLH.
Level of replace information	ID, PN, RefDes, NHA, Qty, Mct[hrs].
Maintainability data	ID, PN, RefDes, Qty, maintenance tasks, F.R.[FIT], Mct[hrs], MLH.
MEA	(Maintenance Engineering Analysis): System, Next higher assembly, Part No., Part number, Freq*10 ⁻⁶ , Mnt.Lvl., Manual, Detect. Method, Maint. Method, Remark, Task No., Task Description, Task Code, Time[min], MP.
Configuration control	ID, reference designator, Qty, Mct, MLH

Report Group	Description
Maintenance tasks	Maint. Task, Task Description, Mp, Total Time, Task Source, Description, Qty, T[min].
Maintenance tasks analysis – Information	Item, Maint.Task, required skills, equipment and materials for each task
Maintenance tasks analysis – Skills summary	Calculation of Total Labour Hours per year for each skill type, according to system usage scenario.
Maintenance tasks analysis – STE summary	Calculation of Total Labour Hours per year for each equipment type, according to system usage scenario.
Maintenance tasks analysis – Materials summary	Calculation of material consumption for maintenance tasks per year for each material, according to system usage scenario.

5. To limit the report to a certain number of levels from the starting level, enter that number in the Depth from start item field.
6. Under 'Report items replaced in' select Organizational, Intermediate and/or Depot. (eg. If Depot is selected, then only those items whose level of replace is defined as 'Depot' will be included in the report table.)
7. Select 'Go under Hybrid' so that the sub-items of any hybrid in the tree will be displayed in the report.
8. Choose **OK**.

RAM Commander generates and displays the report in a report window.

You can print the report by selecting **Print** from the **Report** menu or click on the printer icon. The Windows print dialog box opens. Make the selections appropriate for your printer and choose **OK**.

To close a report window, double-click on its control button.

Use the report management techniques described in Chapter "[Fundamentals](#)" paragraph "[Reports](#)" to view and print the report.

11.7 RCM Module

RCM (Reliability-Centered Maintenance) utilizes a systematic approach to understand how equipment fails, and what maintenance tasks can be done to minimize failures and maximize reliability. RCM also provides the foundation for understanding why certain maintenance tasks are performed and the justification for eliminating unnecessary Preventive Maintenance (PM) activities. It is the optimal mix between the Corrective, Preventive, and Condition-Based maintenance. RCM is a function-oriented approach which considers mission importance, environment, safety, security, economics and regulation requirements.


The RCM analysis process involves 7 main steps, each one of the steps is supported by the RCM module of RAM Commander:

1. System definition (product tree, Functional blocks).


Item	Function	Description	FM	EE
Main Switch	Switching		No switching between channels	Communication Deg
Main Switch	Switching		Slow switching between channels	Communication Deg
Main Switch	Scrambling		No scrambling	Communication Deg
Main Switch	Scrambling		Wrong scrambling	Communication Loss

1. Determine Function Significance | 2. Categorize Failure Effect | 3. PM Decision | 4. Define PM tasks | Close


2. Significant Functions identification:



3. FMECA analysis, Failure Effects Categorization:



4. Preventive Maintenance strategy decision:



5. Preventive Maintenance definition and frequency optimization:

Maintainability / RCM

Ref.Des.: Description:

Failure Mode:

Maintenance type: Maintenance procedure:

Preventive Maintenance procedure type:

Total maintenance times: Mct: [Hours] MLH: [Hours]

Maintenance procedure frequency: User-defined: every [Hours] Calculated: every [Hours]

#	Task Type	Task Description	Time [min]	LP
1	Fault Isolation	Perform system tests	20.0	1.0
2	Fault Isolation	Check contacts	3.0	1.0
3	Other	Clean or replace the contacts	10.0	1.0
*				

6. Preventive Maintenance RCM report generation.

11.8 Summary

In this chapter you learned about RAM Commander's extensive maintainability prediction tools. Using these tools, you can conduct a detailed analysis on the length of time for repairing or replacing a system and calculating such parameters as **MTTR** and **Mct**.

Chapter

12

Derating/Stress Analysis

12 Derating/Stress Analysis

The Derating module is used to analyze the overstress of components under current temperature conditions.


Stress Derating Policy

The module provides a tool to define Derating Guidelines and identify overstressed components, i.e., those working under stress exceeding the specified rating value.

Rating, or maximum rated stress, is the specified value of temperature, power, voltage or current that define the absolute maximum stress limits. Exceeding these values creates a high probability of part damage/failure. The maximum rating is specified in the part specifications or in standard for this type of part. It is a well known practice in many companies to define limit values of stress for various components as a function of temperature. These limits, "Derating Guidelines", are part of the company policy of component usage.

In a derating study, in most cases, each type of component and stress must be specified using a **derating curve**.


Below is a conventional derating curve for capacitors. The derating VSR function is a constant s_1 in the range $0-t_1$, then drops to s_2 over the range t_1-t_2 :



For parameters that are not dependent on temperature, a maximum value may be defined. RAM Commander uses this information to generate exception reports for all components, and indicates which components are overstressed.

Features and Results

The user can define more than one set of Derating Guidelines, for general use and for particular applications. For each type (or style) of electronic component (e.g., RLR, RCR styles of resistor) its own Derating Guidelines can be defined.



A report created by the Derating module includes all components in the selected part of the system, or only overstressed ones. The overstressed components are appropriately marked in the report. The user can also run Spice software for automatic stress calculation and then import spice results for derating evaluation.

Derating Analysis in RAM Commander


There are three basic steps in a derating study using RAM Commander:

- [Defining one or more derating guidelines](#)
- [Entering derating values](#) for project components
- [Generating derating reports](#)

12.1 Defining Derating Guidelines

A derating *guideline* is a set of parameters and associated values applied to Item types. In addition, parameter values to individual types within an Item type. For example, a default derating curve may be specified for PSR for all IC-Digital components, and a different derating curve for IC-Digital components with CMOS technology.

Another way to customize derating guidelines is to disable the parameters for individual types. The Derating Value definition dialog box contains the "Enable" check box which indicates that the specified parameter values are compared with actual values. If the check box is cleared, RAM Commander ignores the specified derating parameter. In this way, individual types can be filtered out from consideration in the derating analysis. The figure below illustrates how the Derating list reflects the way in which various derating parameters apply to different Item type types.



"D" (Disabled) in the second column indicates that RAM Commander ignores the Tj and Fanout parameters for all components in the IC-Digital Item type.

"E" (Enabled) indicates that RAM Commander uses the VinSR stress parameter on all IC-Digital components except for the TTL technology.


A dash in the "Techn" column indicates the default parameter value applied to all component types within the Item type; if a specific technology appears in this column, its parameter value overrides the default.

12.1.1 To define Derating Guidelines


Use the following procedure to define derating guidelines.

To define derating guidelines

1. Activate the Product tree view.
2. From the **Modules** menu, select **Derating**; the Open Guidelines dialog box opens.



3. Select a guideline and choose **OK**; the Derating list opens:




4. In the Derating list, make selections for family and item code; the list displays all existing derating parameters for each type.

See the descriptions of available Derating parameters below:

Parameter	Description
VssSR (%)	Supply voltage stress ratio in Analog devices
VinSR (%)	Input voltage stress ratio
CoutSR (%)	Output current stress ratio
Fanout	Fanout is a measure of the ability of a logic gate output, implemented electronically, to drive a number of inputs of other logic gates of the same type. In most designs, logic gates are connected together to form more complex circuits, and it is common for one logic gate output to be connected to several logic gate inputs
Freq.(%)	Frequency stress
Tcase (°C)	Case temperature (for passive components)
CsrgSR(%)	Surge current stress ratio
VrevSR(%)	Reverse voltage stress ratio
PSR	Power Stress Ratio
VSR	Voltage Stress Ratio

5. To modify a type's parameter values, double-click on its row in the list; the Derating Value Definition dialog box opens.



6. To apply the parameter values to the specified type, check the Enable check box; to allow RAM Commander to ignore parameter values for the specified type, clear the Enable check box.
7. Enter values as required and choose **OK**.

RAM Commander updates the guidelines with the new parameter values.

You can set parameter values for specific item code types. This is useful for specifying different derating curves for various component types.

To define derating curves by item code type

- 1 Activate the Derating list.
- 2 From the **Item** menu, select **Create** or press F7; the Derating value definition dialog box opens.
- 3 Enter values as required and choose **OK**.

RAM Commander applies these values to the type instead of those defined for the entire item code. Select **Edit** or **Delete** from the **Item** menu to modify or delete any record in the Derating list.

Many guidelines may be defined for one project. Use the following table to manage multiple guidelines.


To	Select
Create a new guideline	New from the Guidelines menu
Open another project guideline	Open from the Guidelines menu
Delete a guideline	Delete from the Guidelines menu
Copy a guideline	Save As from the Guidelines menu

In the dialog box, enter the name of the requested guideline and choose **OK**; RAM Commander updates the guideline listing.

Use the following procedure to make the derating data available to other RAM Commander users on the network.

To transfer project guidelines to global guidelines

- 1 Close any open Derating lists, and activate the Product tree view.
- 2 From the **Project** menu, choose **Transfer**; the Transfer dialog box appears.



- 3 Select the **Project to Global** and **Derating Definitions** option buttons.
- 4 Choose **OK**.

RAM Commander transfers the project's derating data to the global library. All new projects will use this information.

A derating study may also be initialized or refreshed using the global settings. To do this, use the previous procedure, but switch Project and Global in step 3.

12.1.2 Print Derating Guidelines

There are two types of guideline reports: parameter listing and derating curve parameter.

Use the following procedure to generate a listing of parameters and their associated values.

To generate a parameter listing report

1. Activate the Derating list for the guideline you want to review.
2. From the **Reports** menu, select **List of Parameters**.

RAM Commander displays the report in a report window.

Another guideline report lists the derating curve parameters by item code.

To generate a derating curve parameter report

1. Activate the Derating list for the guideline you want to review.
2. From the **Reports** menu, select one of the following:
 - **Current Guidelines**, for a report on all the guideline's item codes.
 - **Current Item Code**, for a report on the displayed item code.

RAM Commander displays the report in a report window.

12.2 Entering Actual Stress Values

To enter actual stress values for a component, first configure the project for derating mode:

1. Activate Product Tree View window.
2. Choose "Derating" button in the left button bar.

The next step is to enter actual stress data for individual components.

To enter component stress data

1. If prediction data is available for components in Operating mode, they can be used for Derating as follows:
 - a. Activate the Product tree view.
 - b. Select Derating by clicking on the Derating button, OR choose **Configure** from the **Project** menu.
 - c. From the **Project** menu, select **Translate**; the Translate dialog box opens.
 - d. Select **Operating** in the **From** list box.
 - e. Choose **OK**. RAM Commander copies each component's operating data to derating data.

2. Activate the Product tree view, and navigate to a component derating data is to be entered for.
3. From the **Tree** menu, select **Edit**; the Item Data - Derating dialog box opens.

Item Data

General / Logistics Operating Nonoperating Maintainability

Derating Miscellaneous Functional Blocks

Family: **ELECTRONIC** Ref.Des.: U10

Item code: IC-Digital Part name:

Temperature

Delta Temp.: 3 °C Cur.: 48 °C **Stress Data**

Remark:

Description: M. Quantity: 1

4. Enter values in the fields as required, and press the **Stress Data** button; the Derating analysis dialog box opens.

Capacitor - Derating

Ref. des.: CC2 QTY: 1 ENV: GF Temp: 47 °C **OK**

Part name: **Cancel**

Mil. num.: **Help**

Cat. num.: **Help**

Generic name: CK

Style: CK

Vdc app.: 0.3 Vac app.: --- [V]

VSR: 0.9 or V. rated: 0.3 [V]

54HC00, 54HC08, 54HC36 54F280, 68000, 80386

5. Enter actual stress values, such as VSR. The stress parameters change depending on the item code.
6. When entering data for ICs, use the following additional procedure to compute power dissipation:
 - a. Press the Formula button.
 - b. The Power Dissipation Calculation dialog box opens.

The screenshot shows a dialog box titled "Power Dissipation Calculation". At the top left, there is a "Pd" field with a value of "0" and the unit "[W]". Below it is a "Formula:" dropdown menu. The dialog is divided into several sections: "# of Output Pins:" and "# of Input Pins:" both with "0" in the input boxes; "Icc:" and "Delta Icc:" both with "0" and "[A]"; "Duty Cycle:" with "0"; a "Capacitance" section with "Load:" and "Internal:" both with "0" and "[pF]"; "Vcc:" with "0" and "[V]"; and "Freq:" with "0" and "[MHz]". On the right side, there are three buttons: "OK", "Cancel", and "Pd Calculation".

- c. Enter values as required (Output Pins, Icc, capacitance, etc.).
 - d. Choose Pd Calculation; the power dissipation appears in the field.
 - e. Choose **OK**; the resulting power dissipation appears in the power dissipation (Pd) field.
7. Choosing **OK** returns to the Product tree view.

Repeat the above procedure to enter stress data for other components.

Some fields in the Derating analysis dialog box require *either* a quotient *or* a numerator and denominator. For example, in the figure to the left, enter either a value for the frequency stress ratio, or a value for both the applied frequency and rated frequency. If *applied frequency* and *rated frequency* are entered, RAM Commander computes the actual frequency stress ratio.

12.3 Derating Reports


When generating a derating report, RAM Commander compares the actual stress values for each component with those for the guideline's thresholds. A report can be displayed for all the project's components, or only for those components whose derating values exceed the corresponding threshold.

The following table describes the available derating reports:

Report	Description
Applied values	Actual stress parameter values
Applied values (+ defaults)	Actual stress parameter values; default values appear in fields not explicitly defined for each component.
All parts derating results	For each stress parameter for each component, displays derated value, applied value, and the ratio between the two.
Overstressed parts	Exception report of stress parameter for each component for which the applied value exceeds the derated value.

To generate a derating report

1. Activate the Product tree view
2. Switch to Derating mode using left button bar
3. From the **Reports** menu, select **Tree**; the Report Selection dialog box opens.



4. Select a report type in the Type list box.
5. If All parts derating results is selected, or Overstressed parts, in the Type list box, select a guideline from the list box.
6. Choose **OK**.

RAM Commander displays the derating report in a report window.

Applied Values (+Defaults) Report

Project name: TUTORIAL <Derating>
 Assembly Ref.Des.: Main Switch, IC-Digital

ID	Ref.des.	PN	Tech	Delta jc	Tetha jc	Vcc		Pd	Fanout	Vin	Freq
1.1.1.1	U1	8086A	NMOS	67.000	28.00	15.000	Stress	0.250	0.500	0.500	0.500
							Applied	0.250	1.000	1.000	1.000
							Rated	1.000	2.000	2.000	2.000
1.1.1.2	U9	80C88	CMOS	6.000	28.00	15.000	Stress	0.250	0.500	0.500	0.500
							Applied	0.250	1.000	1.000	1.000
							Rated	1.000	2.000	2.000	2.000
1.1.1.3	U10	80C31	CMOS	2.000	28.00	15.000	Stress	0.250	0.890	0.500	0.900
							Applied	0.250	1.000	1.000	1.000
							Rated	1.000	2.000	2.000	2.000
1.1.1.4	U12	LM299	CMOS	5.000	28.00	15.000	Stress	0.250	0.500	0.500	0.500
							Applied	0.250	1.000	1.000	1.000
							Rated	1.000	2.000	2.000	2.000
1.1.1.5	U13	74LS30	BIPOLA	5.000	39.00	15.000	Stress	0.250	0.500	0.500	0.500
							Applied	0.200	1.000	1.000	1.000
							Rated	1.000	2.000	2.000	2.000

(Segment of a derating report showing derated value, applied value, and the stress percentage.)

See also "[Reports](#)" paragraph in the [RAM_Commander_Fundamentals](#) chapter for more general information about reports.

12.4 Summary

This chapter described the RAM Commander derating module. The derating reports isolate those components that present possible reliability problems for your particular application.

Chapter

13

**Reliability Block
Diagrams**

13 Reliability Block Diagrams

RAM Commander's **Reliability Block Diagram** (RBD) module allows you to quickly and easily define and compute scenarios for *reliability*, *availability* and *mean time between critical failures* (MTBCF). You can use *analytic* or *simulation* techniques to evaluate RBDs. Analytical techniques are possible for most configurations. When such analyses are not possible, you can use RAM Commander's built-in Monte Carlo simulation engine to evaluate the RBD scenario.

RBD Module features:


- Graphical representaton of a block diagram
- Link to Reliability/Maintainability/FMECA modules
- Calculation of Availability, Reliability, R(t), MTBCF
- Monte-Carlo simulation
 - Series
 - Complex reliability configurations, including standby, partially loaded (warm) and active redundancy
 - Full or restricted repair with non-exponential distribution of time-to-repair
 - Non-exponential distribution of time-to-failure (Normal, Weibull, etc.)
 - Analysis under Non-steady, transient state
 - Analysis of periodical inspection policy
 - Splited K-out-of-N
 - K-out-of-N with non ideal switch
- Nested RBDs (Sub-RBD)
- All types of reliability configurations are supported by **RBD** module:
 - Series
 - Parallel
 - K out of N: * active redundancy (hot), stand-by (cold), partially loaded (warm);
 - with repair, without repair, with restricted repair.
- All common distributions of time to failure and time to repair are available:
 - Exponential
 - Normal
 - Log-Normal
 - Weibull
 - Erlang
 - Uniform and others
- Interactive graphic editor with "Drag and Drop" feature providing intuitive display and convenient manipulation tools for creating of any RBD configuration
- Simple and fast transfer of reliability and maintainability item data to the RBD module by selecting the target and source items on the graphic RBD screen.
- Flexible zoom, color palette, direct printing of any RBD configuration
- Database for each element includes:
 - identification parameters: ref. des., part number, description, etc.
 - type of time-to-failure distribution and corresponding parameters (e.g., MTBF, Sigma, etc.)
 - type of time-to-repair distribution and corresponding parameters

13.1 RBD Basics

RAM Commander displays each RBD in a separate window.

RBDs are graphically composed of the following elements:

Parallel section	A redundancy section containing n items. Parallel sections fail when all its items fail at the same time.
Parallel branch	A series of elements in parallel with other elements or a group of elements
SubRBD	A collapsed representation of an RBD.
Regular item	Any item with reliability data.
k-out-of-n section	A parallel section with n items. A k-out-of-n section is functional when k or more of the n elements are operational. The section fails when $n - k + 1$ items fail at the same time.
Insertion node	A place to insert new RBD elements



You add elements to the RBD diagram in a manner such that each element represents a reliability stage in the entire system. *The overall system fails when there is no path from the input node to the output node with all its elements operational.*

As you build the RBD, you must consider how true it is to the real system. For instance, an automobile stops functioning when one of its tires fails. The appropriate RBD for this situation is placing a k-out-of-n element, where $k=4$ and $n=4$. Using four parallel branches, one for each tire, is inappropriate, since the RBD would still be functional when one of the tires fails.

Each RBD element/block has time to failure parameters (for example MTBF) and may have time to repair parameters (for example Mct).

The same block ("identical" block with the same Ref.Des. value) may be repeated multiple times in the diagram. If "identical" calculation or simulation is specified, algorithm assumes that identical blocks represent the same physical system block and it is taken into account by calculation.

RBD diagram may contain another nested RBD diagrams (Sub-RBDs).

When RBD is built and time to failure/repair parameters for all elements are specified, RBD calculation may be performed to calculate Reliability, Availability and MTBCF.


13.2 Drawing the Diagram

You may create unlimited number of new RBD diagrams, open, rename, copy and delete existing diagrams, zoom in/out, export, change color and update diagrams. You may perform calculations and print out necessary reports. See next paragraphs for more information about these functions.


13.2.1 To create a new RBD diagram

1. Activate the Product tree view.
2. From the **Modules** menu, choose **RBD**.

The list of all available RBD diagrams in the current project will appear. From this list you may open, create new, delete, rename and copy RBD diagrams.



3. In the Name edit box enter the name of the new RBD diagram and press "Open".
4. RAM Commander will display an empty RBD diagram in a new window, like the one shown below:



The diagram contains only an input node, output node, and one insertion node. Insertion nodes are used to create new RBD diagram elements (blocks).

Now you may start adding nodes to your diagrams - see next paragraph for more information.

13.2.2 To change an RBD configuration

1. Activate the RBD window.
2. Choose **RBD Configuration** from the **RBD** menu; the Edit RBD Configuration dialog box opens.

3. In the Edit RBD Configuration dialog box, define the following fields:

RBD Title	Title of the RBD diagram
RBD Mission time	Mission time used in calculation
Display on upper line	Data item displayed in the upper section of each element
Upper font	Select upper font attributes
Display on lower line	Data item displayed in the lower section of each element
Lower font	Select lower font attributes
Grid	Toggles grid (Another way to toggle

the RBD grid is to choose **Grid** from the **View** menu.)

Print remarks Toggles remark printing


4. Choose **OK**.

RAM Commander redisplay the RBD using the new settings.


13.2.3 To add an element to an RBD

1 Right-Click on an insertion node.

2 From the popup menu, choose a required RBD element (see element descriptions in [RBD Basics](#) paragraph):



3 New element or elements will appear:



4 Enter new RBD element data by double-clicking the element to open its data dialog or Drag and Drop related item from the Product Tree window - see next paragraph for more information.

13.2.4 To enter data for an RBD element

Do one of the following:

- From the **Item** menu, choose **Edit**. In the Element Parameters Definition dialog box, enter the element's specifications. Choose **OK**.

or

- Activate the Product tree view. Drag and drop a tree item into the RBD element; RAM Commander displays the reliability data.

RAM Commander updates the reliability block diagram.

The Element parameters definition dialog box contains several fields, as shown below:

When you add elements to the RBD, you must specify their *characteristics* in the Element parameters definition dialog box's fields. These characteristics include:

FR distribution	A probability density function describing the part's failure rate.
FR distribution parameters	Parameters describing the FR distribution, such as μ and σ for the Normal distribution or MTBF for exponential distribution.
K-out-of-n	<p>K—the minimum number of units that must operate for the element to function</p> <p>N—the total number of units in the element</p> <p>Load defines the status of non-functional elements:</p> <p>Load = 0 - Element non-operating - standby redundancy</p> <p>0 < Load < 100 - Element partially stressed warm redundancy</p> <p>Load = 100 - Element with active redundancy</p>
Repair	<p>Specifies the repair policy for failed elements. If you select Restricted or Full repair, you must specify the distribution for the repair time as for the FR distribution.</p> <p>Without repair - Element is not repaired upon failure. (The repair distribution parameters are ignored.)</p> <p>Restricted repair - Only one element is repaired at a time (queuing for repair).</p>

	Full repair - Any number of elements can be simultaneously repaired (no queuing).
Inspection period	Applicable for Monte Carlo simulations only and if the element has either Restricted or Full repair. Inspection Period check box not checked - Element sent to repair upon RBD failure. Inspection Period check box checked and value = 0 - Element sent to repair upon component failure (default). Inspection Period check box checked and value > 0 - Element checked every [Inspection Period] hours. If failed, sent to repair.
Duty cycle	Amount of time the part is operational relative to mission time.
ID	Taken from the product tree; used for updating element data from the product tree.
FM Number	Taken from the FMECA analysis; used for updating element data from FMECA.
Description	For descriptive purposes only.
Part number	Taken from tree data; for descriptive purposes only.
Ref. Des.	Reference designator - element name. Taken from product tree data. If multiple elements have the same Reference designator, "Identical" calculation and simulation recognizes them as identical and then assumes that it is a single equipment block even if it appears in multiple places in the RBD.
Remark	For descriptive purposes only.


13.2.5 K/N Element Configuration

In addition to the general data you may define for all RBD elements described in the [To enter data for an RBD element](#) paragraph earlier, you may define additional parameters for K-out-of-N elements.

Switch

If your K-out-of-N element is switching between failed and redundant components and the switching mechanism is not 100% reliable, you may take into account the reliability of the switch.


To do that, open the K-out-of-N element and click the "Switch" button. Switch configuration screen appears - define the switch reliability distribution and parameters and press Ok:




Split elements

By default K-out-of-N element assumes that all N components inside are identical and have the same MTBF. If it is not your case, you may use "Split" function to define different reliability data for different components.


To do that, right-click your K/N element and choose "Split" option from the menu:



The dialog will appear – it allows assigning different reliability parameters to different ranges:




Using the "Change range" button, create new ranges and split your K/N elements into separate lines with different reliability values, like in the example below, where first element is different from the second and third:



13.2.6 To create a SubRBD

Note SubRBDs are in rectangles with rounded corners, which represent nested RBD diagrams.

1. To insert a SubRBD, highlight an insertion node.
2. Right click on the selected insertion node and from the **Item** menu or the pop-up menu, choose **Add SubRBD**.
3. A SubRBD element is inserted into the diagram.
4. Double-click on the SubRBD element.
5. The SubRBD Parameters Definition dialog box appears:




6. Select an RBD name.
7. Press Ok.
8. Sub-RBD block will be inserted into the current RBD diagram:



To open a SubRBD, select it and from the **RBD** menu, choose **Open Current SubRBD**.

An RBD diagram of the SubRBD opens in a separate window

Sub-RBDs nesting levels are not limited (main RBD may have multiple sub-RBDs, each of them may have its own nested RBDs etc.) To view the structure of nested Sub-RBDs Click the  icon on the menu bar.

13.2.7 To delete an RBD element

1. Click on an RBD element.
2. From the **Item** menu or the pop-up menu, choose **Delete**.

13.2.8 Saving and Opening Reliability Block Diagrams

You can create many RBDs for a project and save them under different names. To save an RBD, activate its window and choose **Save As** from the **RBD** menu. In the Save RBD with new name dialog box, enter a standard file name and press **OK**.

Once the RBD window is displayed, you can use it to display the project's other diagrams. From the **RBD** menu, choose **Open**. Select the name of an RBD and choose **OK**. RAM Commander displays the selected diagram in the RBD window.

13.2.9 Working with Diagrams

There are lot of additional convenient options and functions you may use while working with RBD diagrams - see next paragraphs for more information.

13.2.9.1 Elements Color

You can customize an RBD's appearance by changing the color of its elements to create even more beautiful and effective presentations.


- 1 From the **View** menu in RBD window, choose **Elements Color**; the Color selection dialog box opens.

2 Select desired color and press **OK**.


You can also create your own colors by choosing **Define Custom Colors** from the Elements Color dialog box. Enter settings and choose **Add to Custom Color**. RAM Commander adds the customized color to the palette which can then be used in the RBD display.

13.2.9.2 To fold a series of RBD elements to fit the screen


If the RBD diagram contains too many serially connected elements to fit the screen, it may be split into two or more rows.



1 Select by dragging a rectangular selection region around the RBD elements you wish to move.



2 Drag the selected elements to the desired position.




13.2.9.3 To zoom in or out of an RBD

You can zoom in or out of an RBD diagram to make the display larger or smaller. From the **View** menu, choose **Zoom in** or **Zoom out**.

13.2.9.4 To copy an RBD element

1. Drag a rectangular selection region around an RBD element (or group of elements) to select it:



2. Press Ctrl+C or choose **Copy** from the **Edit** menu.
3. Select an insertion node by clicking on it and press Ctrl + V or choose **Paste** from the **Edit** menu to paste in the copied element.

13.2.9.5 Update RBD Information

This function updates an RBD element's data from the Product Tree, using Reliability and Maintainability calculation results. Only those RBD elements that are associated with elements in the product tree will be updated. You can associate an RBD element with a tree element by dragging and dropping a tree element into the RBD element.

To update the RBD, choose **Update RAM information** from the **RBD** menu.

13.2.9.6 Export to MEADep

RAM Commander supports export to MEADep – Markov Chains software by SoHaR.

In RBD diagram, you can now create export files compatible with MEADep software and export RBD diagrams and corresponding calculations results to MEADep.

To export data:

1. Activate the RBD window.
2. Choose Export to MEADep from the RBD menu.
3. Choose file name for exported data; the new file with corresponding name is created. You may now use it with your MEADep software.

13.2.9.7 Export to MS Word, Excel etc.

You can export an RBD diagram to Windows standard format - Windows enhanced metafile (a file name with an .emf extension) - which is recognized by such Windows and MS Office applications as Word, Excel, etc.

- 1 From the **RBD** menu, choose **Export to metafile**.


The Save As... dialog box opens.

- 2 Enter a new file name, select a folder and click the **Save** button.
- 3 In the receiving MS Office application, from the **Insert** menu, choose **Insert Picture** or **Insert from file** option to import the saved metafile diagram into your file.

Tip We recommend folding long RBD diagrams (see above) before exporting them.

13.2.9.8 Global Changes

- 1 From the **RBD** menu, choose **Global change**. The Global Change dialog box opens.



- 2 In the Global Change dialog box, do one of the following:
 - * To make changes to RBD elements that satisfy the selection criteria, select the Use Condition check box.
 - * To make changes to all RBD elements, do not select the Use Condition check box.
- 3 Choose **OK**.

The Element parameters definition: Conditions dialog box only opens if the Use Condition check box in step 2 above was checked.

- 4 Enter search criteria.
- 5 Choose **OK**.

The Element parameters definition: New Values dialog box opens.

- 6 Enter new values for RBD elements.
- 7 Choose **OK**.

Note "****" appearing in a field in the Conditions dialog box means that each field changed from *** to another value will participate in the Global change conditions.

Note "****" appearing in a field in the New Values dialog box means that each field changed will result in a corresponding parameter change for all items (depending on the conditions in Conditions dialog box) during the Global Change.

13.3 RBD Calculations

RAM Commander computes the reliability and availability of an RBD using one of the following methods:

Analytical	RBD is computed using analytical techniques, when possible.
Identical	This calculation is necessary when the RBD has elements that appear more than once in the diagram (if multiple diagram blocks have the same Ref.Des. field value, identical calculation assumes that it is the same block).
Monte Carlo	RBD is computed using simulation techniques, employing the distributions specified for each element.
MTBCF and R(t)	Calculates the RBDs' mean time between critical failures and builds R(t) graph.

13.3.1 To calculate an RBD

- 1 Activate the RBD window.
 - 2 From the **Calculation** menu, choose the type of computation.
RAM Commander calculates the RBD.
- The Calculated Reliability and Steady State Availability are displayed in the status bar for analytical and identical calculations.

For Help, press F1

UA = 7.28049e-007

R = 0.999996

- Automatic analytical recalculation (if possible) occurs after an element's data has changed or after a mission time change (use "RBD Configuration" option from "RBD" menu to change mission time).
- MTBCF and Monte-Carlo calculation results are displayed on separate additional windows which will be explained later in this chapter.

13.3.2 Formulas

The next paragraphs provides details on RBD calculation formulas.

You may find the information about reliability and availability calculations of individual blocks:

[Reliability Distributions](#) , [Availability Distributions](#).

Calculation of basic configurations like serial and parallel connection between blocks is described in the [Basic calculations](#) paragraph.

K-out-of-N blocks calculation is explained separately by paragraphs [K-out-of-N With Repair](#) and [K-out-of-N Without Repair](#).

Equivalent Lambda/FR/MTBF according to RIAC Reliability Toolkit is explained in paragraph [Equivalent Lambda/MTBF](#).

13.3.2.1 Reliability Distributions

The following table lists the probability distributions and associated reliability functions used in computing reliability of a single RBD block.

Distribution	Reliability Function $R(t) = 1 - F(t)$	Probability Density Function $f(t)$	Parameters
Exponential	$e^{-\lambda t}$	$\lambda e^{-\lambda t}$	$\lambda = \frac{1}{MTBF} > 0$
Weibull	$e^{-\left(\frac{t}{a}\right)^b}$	$b a^b t^{b-1} e^{-\left(\frac{t}{a}\right)^b}$	$a > 0; b > 0$
Normal	$\int_t^{\infty} f(\tau) d\tau$	$\frac{1}{\sigma\sqrt{2\pi}} e^{-\frac{(t-\mu)^2}{2\sigma^2}}$	$-\infty < \mu < \infty;$ $\sigma > 0$
Log normal	$\int_t^{\infty} f(\tau) d\tau$	$\frac{1}{\sigma t\sqrt{2\pi}} e^{-\frac{(\log t - \mu)^2}{2\sigma^2}}$	$-\infty < \mu < \infty;$ $\sigma > 0$
Erlang	$e^{-\lambda t} \left[\sum_{i=0}^{\kappa-1} \frac{(\lambda t)^i}{i!} \right]$	$\frac{\lambda^\kappa t^{\kappa-1} e^{-\lambda t}}{(\kappa - 1)!}$	$\lambda > 0;$ κ - positive integer
Time-independent	1-Ur		$0 \leq U_r \leq 1$
Constant	0 for $t \geq T_0$ 1 for $t < T_0$		$T_0 > 0$
Uniform	$\frac{b-t}{b-a}$	$\frac{1}{b-a}$ for $a \leq t \leq b$	$0 \leq a < b$

13.3.2.2 Availability Distributions

This paragraph provides formulas used in calculation of an availability of a single RBD block.

In general, unavailability UA is calculated using the following equation:

$$UA = MCT_{eq} / (MTBF_{eq} + MCT_{eq}),$$

where MCT_{eq} is equivalent maintenance corrective time and

$MTBF_{eq}$ is equivalent MTBF.

$MTBF_{eq}$ and MCT_{eq} are calculated differently for each failure and repair times distribution type - see tables below.

Equivalent MTBF calculation for different failure time distributions:

Distribution	Equivalent MTBF	Parameters
Exponential	MTBF	$\lambda = \frac{1}{MTBF} > 0$
Weibull	$a \cdot \Gamma((b+1)/2)$, where Γ is gamma function	$a > 0$; (scale) $b > 0$ (shape)
Normal	μ	$-\infty < \mu < \infty$; $\sigma > 0$
Log normal	$e^{(\mu + \sigma^2/2)}$	$-\infty < \mu < \infty$; $\sigma > 0$
Erlang	$\lambda \cdot \kappa$	$\lambda > 0$; κ - positive integer
Time-independent	0	$0 \leq U_r \leq 1$
Constant	T_0	$T_0 > 0$
Uniform	$(a+b)/2$	$0 \leq a < b$



Equivalent MCT calculation for different repair time distributions:

Distribution	Equivalent MCT	Parameters
Exponential	MCT	MCT
Weibull	$a \cdot \Gamma((b+1)/2)$,	$a > 0$; $b > 0$

Distribution	Equivalent MCT	Parameters
	where Γ is gamma function	
Normal	μ	- $-\infty < \mu < \infty$; $\sigma > 0$
Log normal	$e^{(\mu + \sigma^2/2)}$	- $-\infty < \mu < \infty$; $\sigma > 0$
Erlang	$\lambda * \kappa$	$\lambda > 0$; κ - positive integer
Time-independent	0	$0 \leq U_r \leq 1$
Constant	T_0	$T_0 > 0$
Uniform	$(a+b)/2$	$0 \leq a < b$


13.3.2.3 Basic calculations

The following formulas are used to calculate reliability and availability of basic RBD models:

Configuration	Reliability R, Unreliability UR	Availability A, Unavailability UA
<p>Serial configuration</p> 	$R = R_a * R_b$ $UR = UR_a + UR_b - UR_a * UR_b$	$A = A_a * A_b$ $UA = UA_a + UA_b - UA_a * UA_b$
<p>Parallel configuration</p> 	$R = 1 - (1 - R_a) * (1 - R_b)$ $UR = UR_a * UR_b$	$A = 1 - (1 - A_a) * (1 - A_b)$ $UA = UA_a * UA_b$

Reliability and Availability calculation of individual blocks is explained in previous paragraphs - [Reliability Distributions](#).

For complex model RBD diagrams, diagram breakdown to basic models described above is performed and calculation is done using the same principles and formulas. Consider for example the following diagram:



First, the serial segment containing blocks A and C is calculated, resulting in $R_{ac} = R_a * R_c$.

Then serial segment is considered a single block AC which is parallel to block B, and reliability of the whole system R is calculated as reliability of two parallel blocks AC and B, so $R = 1 - (1 - R_{ac}) * (1 - R_b)$.

13.3.2.4 K-out-of-N With Repair

The formulas in the following table are used to compute MTBF and reliability for various redundant item loads with item repair.

$$\gamma = \frac{\lambda}{\mu} = \frac{MTTR}{MTBF}$$

MTBF (exact value)

Source Data		Equations
Repair	Load of redundant items	MTBF (exact value)
Unrestricted	100%	$\frac{1}{N\lambda} \sum_{s=0}^{N-K} \frac{\sum_{i=0}^s \binom{N}{i} \gamma^i}{\binom{N-1}{s} \gamma^s}$
Restricted	100%	$\frac{1}{\lambda} \sum_{s=0}^{N-K} \sum_{i=0}^s \frac{1}{(i+1)! \binom{N-S+i}{i+1} \gamma^i}$

Unrestricted	0%	$\frac{1}{K\lambda} \sum_{i=0}^{N-K} \binom{N-K+1}{i+1} \frac{i!}{(K\gamma)^i}$
Restricted	0%	$\frac{1}{K\lambda} \frac{1 - (K\lambda)^{N-K+1} [1 + (N-K+1)(1-K\gamma)]}{(K\gamma)^{N-K} (1-K\gamma)^2}$
Unrestricted	0 < v < 100% □ 100%	$\frac{1}{\lambda} \sum_{s=0}^{N-K} \frac{s! \sum_{i=0}^s \frac{\gamma^i}{i!} \prod_{r=1}^i [K + (N-K+1-r)v]}{\gamma^s \prod_{r=1}^{s+1} [K + (N-K+1-r)v]}$
Restricted	0 < v < 100% □ 100%	$\frac{1}{\lambda} \sum_{s=0}^{N-K} \frac{\sum_{i=0}^s \gamma^i \prod_{r=1}^i [K + (N-K+1-r)v]}{\gamma^s \prod_{r=1}^{s+1} [K + (N-K+1-r)v]}$

Mission Reliability over time t_0 (approximate value)

Source Data		Equations
Repair	Load of redundant items	Mission Reliability over time t_0 (approximate value)
Unrestricted	100%	$\exp - \left\{ N\lambda t_0 / \sum_{S=0}^{N-K} \frac{\sum_{i=0}^S \binom{N}{i} \gamma^i}{\binom{N-1}{S} \gamma^S} \right\}$
Restricted	100%	$\exp - \left\{ \lambda t_0 / \sum_{S=0}^{N-K} \sum_{i=0}^S \frac{1}{(i+1)! \binom{N-S+i}{i+1} \gamma^i} \right\}$
Unrestricted	0%	$\exp - \left\{ K\lambda t_0 / \sum_{i=0}^{N-K} \binom{N-K+1}{i+1} \frac{i!}{(K\gamma)^i} \right\}$

Restricted	0%	$\exp - \left\{ \frac{(K\gamma)^{N-K} (1 - K\gamma)^2 K\lambda t_0}{1 - (K\gamma)^{N-K+1} [1 + (N - K + 1)(1 - K\gamma)]} \right\}$
Unrestricted	0% <input type="checkbox"/> 100% <input type="checkbox"/> 100%	$\exp - \left\{ \lambda t_0 / \sum_{S=0}^{N-K} \frac{S! \sum_{i=0}^S \frac{\gamma^i}{i!} \prod_{r=1}^i [K + (N - K + 1 - r)\nu]}{\gamma^S \prod_{r=1}^{S+1} [K + N - K + 1 - r)\nu]} \right\}$
Restricted	0% <input type="checkbox"/> 100% <input type="checkbox"/> 100%	$\exp - \left\{ \lambda t_0 / \sum_{S=0}^{N-K} \frac{\sum_{i=0}^S \gamma^i \prod_{r=1}^i [K + (N - K + 1 - r)\nu]}{\gamma^S \prod_{r=1}^{S+1} [K + (N - K + 1 - r)\nu]} \right\}$

Steady State Availability (approximate value)

Source Data		Equations
Repair	Load of redundant items	Steady State Availability (approximate value)
Unrestricted	100%	$1 - \binom{N}{N - K + 1} \gamma^{N - K + 1}$
Restricted	100%	$1 - (N - K + 1)! \binom{N}{N - K + 1} \gamma^{N - K + 1}$
Unrestricted	0%	$1 - \frac{(K\gamma)^{N - K + 1}}{(N - K + 1)!}$
Restricted	0%	$1 - (K\gamma)^{N - K + 1}$
Unrestricted	0% <input type="checkbox"/> 100% <input type="checkbox"/> 100%	$1 - \frac{\gamma^{N - K + 1}}{(N - K + 1)!} \prod_{r=1}^{N - K + 1} [K + (N - K + 1 - r)\nu]$
Restricted	0% <input type="checkbox"/> 100% <input type="checkbox"/> 100%	$1 - \gamma^{N - K + 1} \prod_{r=1}^{N - K + 1} [K + (N - K + 1 - r)\nu]$

Note: description of repair types like restricted / unrestricted may be found in the [To enter data for an](#)

[RBD element](#) paragraph earlier in this chapter.

The source of the formulas is "Reliability Handbook" by B. A. Kozlov, I. A. Ushakov.

13.3.2.5 K-out-of-N Without Repair

The formulas in the following table are used to compute MTTF and reliability for various redundant item loads and without item repair.

Source Data	Models	
Load of redundant items	MTTF	Reliability
100%	$\frac{1}{\lambda} \sum_{i=0}^{N-K} \frac{1}{K+i}$	$(N-K+1) \binom{N}{K-1} \sum_{i=0}^{N-K} \frac{(-1)^i \binom{N-K}{i}}{K+i} e^{-(K+i)\lambda t_0}$
0%	$\frac{N-K+1}{\lambda K}$	$e^{-K\lambda t_0} \sum_{i=0}^{N-K} \frac{(K\lambda t_0)^i}{i!}$
$0 < v \leq 100\%$	$\frac{1}{\lambda} \sum_{i=0}^{N-K} \frac{1}{K+vi}$	$\frac{\prod_{i=0}^{N-K} (K+vi)}{v^{N-K} (N-K)!} \sum_{i=0}^{N-K} \frac{(-1)^i \binom{N-K}{i}}{K+vi} e^{-(K+vi)\lambda t_0}$

The source of the formulas is "Reliability Handbook" by B. A. Kozlov, I. A. Ushakov.


13.3.2.6 Equivalent Lambda/MTBF



Equivalent (Effective) Lambda or **Effective MTBF** is calculated according to formulas and assumptions described below.

Calculation is allowed only with following limitations:

- Repairable Configuration (all elements with repair)
- Failure Rate distribution - only "Exponential"
- Repair Rate distribution – only "Exponential"
- K-out-of-N elements:
 - Load = 100 (active redundancy)
 - No Switch
 - No Split

Effective λ (FR) equations approximations:

Configuration	λ	μ
	$\lambda = \lambda_a + \lambda_b$	$\mu = (\lambda_a * \mu_a + \lambda_b * \mu_b) / (\lambda_a + \lambda_b)$

Configuration	λ	μ
	$\lambda_{1/2} = \frac{\lambda_A \lambda_B [(\mu_A + \mu_B) + (\lambda_A + \lambda_B)]}{(\mu_A)(\mu_B) + (\mu_A + \mu_B)(\lambda_A + \lambda_B)}$ (1)	$\mu = (\lambda_a * \mu_a + \lambda_b * \mu_b) / (\lambda_a + \lambda_b)$
	$\lambda_{(n-q)/n} = \frac{n!(\lambda)^{q+1}}{(n-q-1)(\mu)^q}$ (2)	μ

References (1) and (2) refer to [RIAC System Reliability Toolkit](#), page 394.

To calculate the effective MTBF, execute the RBD report generation and select the corresponding checkbox on the report settings screen:




13.3.3 MTBCF and R(t)

Mean time between critical failures (**MTBCF**) is the mean time until the function defined by the RBD diagram fails. RAM Commander uses numeric integration of the reliability function $R(t)$:

$$MTBCF = \int_0^{\text{Max Time}} R(t) dt$$

where Max Time is an upper limit of integration.

After computation, RAM Commander displays a graph of the function $R(t)$ which describes the system's reliability over time:




With the help of changing the Max. Time you reach the result – when you reach a certain Max. time when the function almost reaches 0 and MTBCF stops changing. This means that you can ignore the “tail” of the graph.

The general rule is to start with the Max. time which is about 10 times of the expected MTBF and the Step 100 times less than the Max. time. You just match the Max. time and Step. When after some tries you get necessary Max. Time, you may reduce the Step to get more accuracy.


If you choose Epsilon option, set Epsilon to the minimal MTBCF value where you want to stop the R (t) integration – on the graph the Epsilon is a distance between T axe and graph, where you are satisfied with the preciseness of the result and want to stop calculations.

Larger Max Time, smaller epsilon, and smaller integration steps lead to better results yet longer computation times:

if you choose short Max Time and large step, the function integration may be presented as squares area calculation:




if you choose large Max Time and small steps, the function integration may be presented as squares area calculation:



So you may see how the parameters you enter influence the calculation process.

13.3.3.1 To calculate MTBCF and $R(t)$

1. Activate the RBD window.
2. Choose **MTBCF** from the **Calculation** menu; the MTBCF For RBD dialog box opens:



3. In the list box, select one of the following:


- **Max Time** and enter the time after which the tail of function $R(t)$ is cut off.
- **Epsilon** and enter the cutoff value for the function $R(t)$ where δ becomes less than epsilon ($R(T_n) - R(t_{n-1}) < \epsilon$).
- **Mission time**

to calculate MTBCF for a non-continuous mission, and enter the mission time. MTBCF in this

$$MTBCF = \frac{\int_0^{T_0} R(t) dt}{1 - R(T_0)}$$

case is calculated by formula , where T_0 is Mission Time.

4. In the **Step** field, enter the integration step. (Start with 10% of the Max Time and then reduce it after each calculation to the point where MTBCF shows no significant change.) Larger Max Time, smaller epsilon, and smaller integration steps lead to better results yet longer computation times.
5. Choose **Calculate**. RAM Commander displays the MTBCF and $R(t)$ graph:



6. Choose **Print** to print out the graph generated, choose "Export" to save graph as Windows Metafile. You may open it from the MS Word later.
7. Repeat steps 3–5 to review different graphs for different field settings.

The general rule is to start with the Max. time which is about 10 times of the expected MTBF and the Step 100 times less than the Max .time. Then you just match the Max. time and Step. When after some tries you get necessary Max.Time, you may reduce the Step to get more accuracy.

8. Choose **Close** to exit.

To generate RBD reports, follow the procedure in the next section.

13.3.4 Monte Carlo Simulations

RAM Commander employs a **Monte Carlo** event-driven *simulator* to evaluate RBDs. You can customize the simulator parameters and report output to generate the report you need.

Use the Monte Carlo when there is no analytical solution for the RBD you have defined. This

includes the following cases:

- Complicated reliability structures, including complex redundancy.
- For a k-out-of-n block when the failure distribution of an item is not exponentially distributed or K-out-of-n from different elements.
- Derivation of availability curves in a non-steady, transient state.
- RBD contains identical elements.
- Studying the impact of periodical inspection strategy on reliability and availability.

Set up Monte-Carlo parameters using "Monte Carlo Configuration" dialog and then run the simulation from "Calculation" menu - see next paragraph "[To initiate Monte-Carlo simulation](#)" for more information.

13.3.4.1 To initiate a Monte Carlo simulation

1. Activate the RBD diagram window.
2. From the **RBD** menu, choose **Monte Carlo configuration**:


3. In the Monte Carlo Configuration dialog box, enter the configuration values:

Start time	Starting time for collection of results. (The simulator always starts at time $t = 0$.)
Max Time	Elapsed time for collecting results
# of points	Number of intervals in output graph
Report	Text, graph or both
Identical	If selected, simulation assumes that if multiple blocks are identical (have the same Ref.Des. value) it is actually the same single block even if it appears multiple times on the diagram.

Conf. Level	Confidence level of the output	
Simulation	Fast (least number of iterations = 100), Intermediate (medium number of iterations = 1000), Accurate (most number of iterations = 10000), Custom - number of iterations defined by user	
Seed	Seed for random number generator	
Inspection period	Inspection Period value = 0	Element sent to repair upon component failure (default).
	Inspection Period value > 0	Element checked every [Inspection Period] hours. If failed, sent to repair.

RAM Commander applies the value in the Inspection period field to all RBD elements that do not have a defined inspection time (marked as ---) in the Element parameters definition dialog box.

4. Choose **OK**.
5. From the **Calculation** menu, choose **Monte Carlo**.
6. RAM Commander conducts the simulation and displays resulting report and graph:



The report contains **Reliability** (reliability is a probability of failure at time t) and **Availability** (probability that the system is operating at time t) figures for each selected time point (according to Monte-Carlo settings, max.time and number of points). For Reliability and Availability, upper and

lower limit estimation according to Confidence level selected on Monte-Carlo configuration screen. **MTBCF** (mean time between critical failures) is also calculated.

You may view, print, save, customize and export the generated report and graph (see Fundamentals - [Reports](#) and [Graphs](#)).

13.4 RBD Reports

To review the results of RBD calculations, choose Report from the Calculation menu.



In the Report for RBD dialog box, select the items you want to include and choose **Report**. You can select from the following options:

Reliability	To include reliability calculations.
Availability	To include availability calculations.
Equivalent Lambda	To include equivalent lambda/effective MTBF calculation (Equivalent Lambda/MTBF).
MTBCF	To include the MTBCF calculation. If you select this option, you must include a value for Max Time or Epsilon and the step value (see previous section).
Max Time	Choose Max Time or Epsilon and enter a number.
Step	Select a step value. (See Chapter 3 regarding Reliability function and MTBCF computations.)

MTBCF calculation and Monte-Carlo simulation have their own reports.

Use the report management techniques described in Chapter "[Fundamentals](#)" paragraph "[Reports](#)" to view and print the report.

13.5 Summary

In this section, you learned about RAM Commander's versatile reliability block diagram module. Using this module, you can model complex systems and perform reliability computations. You can use analytical, identical or simulation techniques to compute reliability/availability values.

See more about automatic RBD diagram building from Product Tree elements in "System Configuration" chapter - [RBD diagram building](#).

Chapter

14

System Configuration


14 System Configuration

"**System Configurations**" module is unique and innovative RAM Commander function that allows producers of several blocks of a product that can be combined in various configurations, to compare the reliability of the different configurations using the existing product tree, without needing to descend to the component level.

Utilizing the already created product tree with reliability and maintainability calculations performed, user can easily create an unlimited number of configurations where system blocks appear in different quantities and in various combinations of reliability models.

The system configuration function allows the comparison of reliability data of an unlimited number of different configurations built from new or existing blocks in the product tree. The function allows the creation of new configurations, inserting new or existing blocks, changing values and then transforming it into an RBD.

Each configurations contains a sequence of system elements, with quantity and redundancy model (serial, parallel, K-out-of-N) for each element. Example below shows to different product configurations:




Name	MTBF	Mct	Qty(N)	K	Reliability Model
Switching base configuration	7640.8	4.173E-002			
Main Switch	1198136.3	0.125	2		Parallel
Receiver	1694118.6	0.154	10	6	K-out-of-N
Transmitter	445099.4	0.127	1		Serial
PS	119760.5	0.118	3		Parallel
Control	12693.9	1.667E-002	1		Serial
Pedestal	88288.5	0.125	1		Serial
Receiver	1694118.6	0.154	10	6	K-out-of-N
Non-switching base configuration	8699.2	4.039E-002			
Receiver	1694118.6	0.154	10	4	K-out-of-N
Transmitter	445099.4	0.127	1		Serial
PS	119760.5	0.118	2		Parallel
Control	12693.9	1.667E-002	1		Serial
Pedestal	88288.5	0.125	1		Serial

RAM Commander may build RBD diagram automatically and calculate MTBF, Mct and MTBCF. Then engineers may compare different configurations.


14.1 To open the configuration system list


- 1 Activate the project's Product tree view.
- 2 From the **Modules** menu, select **System Configuration**.


The System Configuration list opens.



The tree above shows system configurations and their elements. The elements have different Reliability models (their connection types). The icons in the tree depend on the item's Reliability model:

Serial 

Parallel 

K-out-of-N 

Now you may create new configurations, edit existing, add new configuration elements from scratch or insert new configuration elements dragging them from the Product Tree.

14.2 To create a new configuration

1. Right click in the blank area of the list, and in the pop-up menu, choose **New Configuration**.
- or -

From the **Configuration** menu choose **New**.

2. The System Configuration dialog box opens:

The screenshot shows a 'System configuration' dialog box with the following fields and controls:

- Name: [Text input field]
- Mct [Hrs]: [Text input field]
- MTBF [Hrs]: [Text input field]
- Mission time [Hrs]: [Text input field with value 1.0]
- Repair: [Dropdown menu with 'Without repair' selected]
- RBD file name: [Text input field]
- MTBCF Max.time: [Text input field with value 10]
- Step: [Text input field with value 1]
- MTBCF: [Text input field with value 0.0]
- Calculate... [Button]
- OK [Button]
- Cancel [Button]

3. The calculate button is only activated when an RBD has been created.
 4. Input a new configuration name and relevant data into the other fields.
- Now you may add blocks to the newly created configuration.

14.3 Adding Blocks to Configuration

When the configuration is created, you may **add existing Product Tree elements/blocks to the configuration**:

- Drag and drop an existing block from the Product tree view into your new configuration
- or -
- Right click the configuration record and select **Insert from tree**. Tree browser dialog appears - select the desired element and press Ok.

You may also **add new blocks from scratch**:

1. Right click on a configuration or an item and in the pop-up menu, choose **Insert blank item**.

- or -

From the **Item** menu, choose **Insert blank item**.

- or -

Select configuration record and press F7.

2. The System Configuration – Item dialog box opens.

3. Input the relevant data and click **OK**.

4. The new item is appended at the end of the item list.

Repeat the procedure to add all required configuration blocks. When the configuration is built you may build RBD diagram automatically, calculate MTBCF and generate reports.

14.4 Working with existing configurations

You may edit existing configurations and their blocks, delete blocks and configurations, reorder blocks, update blocks information by updated information in the Product Tree (MTBF, Mct) and more - next paragraphs will provide more information about these operations.

14.4.1 To update RAM info

Each configuration block which was created by drag and drop operation or selection from the Product tree stays linked with the related product tree element, but block's MTBF and Mct data are not updated automatically if reliability/maintainability calculation of related Product Tree element are changed.

"Update RAM info" function synchronizes the entire configuration with a product tree that has been updated.

1 Right click on a configuration or item and in the pop-up menu, choose **Update RAM info**.

- OR -

From the **Configuration** menu choose **Update RAM info**.

2 RAM Commander automatically updates the entire configuration.

Note Those items for which the 'Do not update from tree' check box is checked, will not be updated.

14.4.2 To delete an item

Right click on an item, or select a group of items using the usual MS Windows conventions, and in the pop-up menu, choose **Delete**.

- OR -

From the **Configuration** or **Item** menus, choose **Delete**.

- OR -

Press the **Del** key.

RAM Commander prompts for confirmation prior to deleting the item.

Caution Use care when deleting an item. There is no undo facility to easily return the configuration to its original state.

14.4.3 To locate an item in a tree

Right click on an item, and in the pop-up menu, choose **Locate in tree**.

- OR -

From the **Item** menu, choose **Locate in tree**.

RAM Commander jumps to the relevant item in the Product tree view.

Note Copy and Paste are used as with MS Windows conventions.

14.4.4 To reorder items inside the Configuration

New blocks are always added to the end of the list. Order is important for RBD creation – RBD elements will be positioned accordingly to their order in System Configuration. To change items order, use Drag & Drop inside the configuration:

- 1 Click an item you wish to relocate
- 2 While holding the left mouse button, point the mouse to the item which should go after the first selected item
- 3 Release the mouse button. The first item will be placed before the second selected item.

14.4.5 To edit an item

1. Right click on an item (one level lower than a configuration), select **Edit** from the pop-up menu

- OR -

From the **Configuration** menu, choose **Edit**.

- OR -

Press Alt+Enter.

2. The System Configuration - Item dialog box opens:

3. Input the relevant data and click **OK**.

14.5 RBD diagram building

System Configurations module may build an RBD diagram automatically for the selected configuration.

To build an RBD:

1. Right click on a configuration, select **RBD** from the pop-up menu
- OR -

From the **Configuration** menu, choose **RBD**.

2. The Open RBD dialog box opens the first time the RBD module is run:

3. Define the RBD diagram name. After the RBD name has been entered once, all future RBDs for this configuration will be created with this name.

4. Press **Ok**. RAM Commander will initiate RBD module and build a new RBD diagram corresponding to the selected configuration.

Note Each time you enter an RBD from Sys. Conf., the RBD is recreated. If you want to use the RBD diagram in the future and change it without changing the configuration, choose **Save as** from the **RBD** menu, and save it under a new file name.

14.6 MTBCF Calculation

1. Select a configuration by clicking on it.
2. Choose **Edit** from the pop-up menu

- OR -

From the **Configuration** menu, choose **Edit**.

3. The System Configuration dialog box opens.
4. Click the **Calculate** button.
5. The MTBCF for RBD graph appears. See "[RBD_module](#)" chapter, "[MTBCF_calculation](#)" for information about this calculation type.
6. Choose **Close** to save the calculation data (Max. time, Step and MTBCF) to configuration.

14.7 Reports

Two report options are provided: Summary and Details.

Summary report is useful to compare reliability of several configurations:

System configuration

Project name: TUTORIAL

Configuration name	MTBF [hrs]	MTBCF [hrs]	Mct [hrs]	Max.time [hrs]	Step [hrs]
Switching base configurat	7640.8	10758.8	4.173E-002	60000.0	100.0
Non-switching base config	8699.2	93897.3	4.039E-002	500000.0	100.0

Detailed report provides all the available information about the selected configuration and its blocks:

System configuration

Project name: TUTORIAL

Configuration: Switching base configuration

MTBF [hrs]	MTBCF [hrs]	Mct [hrs]	Max.time [hrs]	Step [hrs]
7640.8	10758.8	4.173E-002	60000.0	100.0

Item name	MTBF [hrs]	Mct [hrs]	Quantity (N)	K	Reliability Model
Main Switch	1198136.3	0.125	2		Parallel
Receiver	1694118.6	0.154	10	6	K-out-of-N
Transmitter	445099.4	0.127	1		Serial
PS	119760.5	0.118	3		Parallel
Control	12693.9	1.667E-002	1		Serial
Pedestal	88288.5	0.125	1		Serial
Receiver	1694118.6	0.154	10	6	K-out-of-N

Each report may contain one selected configuration data or data for all existing configurations.

Use Reports menu or popup menu (right-click the configuration record) to initiate the selected report generation.

See also "[Reports](#)" paragraph in the [RAM Commander Fundamentals](#) chapter for more general information about reports.

14.8 Summary

In this chapter you saw how several blocks of a product can be combined in various configurations, to compare the reliability of the different configurations using the existing product tree, without needing to descend to the component level.

Chapter

15

Reliability Growth

15 Reliability Growth


RAM Commander's **reliability growth module** is based on the Duane method described in MIL-STD-1635. Reliability growth analysis is appropriate when you have limited reliability data on your project. In such cases, you can use the limited data to extrapolate what the reliability data would be if the testing were conducted over long periods of time.

The **Duane model** is the most widely used method for reliability growth planning, testing and tracking. In this model, as long as the effort to improve the reliability of electronic equipment continues, the tested system *MTBF* is proportional to T^α , where T is the cumulative operating time and α is the rate of growth. The cumulative mean time between failures $MTBF_c$ is measured during testing and then divided by $(1-\alpha)$ to convert it to the current instantaneous $MTBF_i$, i.e., the instantaneous *MTBF* ($MTBF_i$) is calculated as follows:

$$MTBF_i = \frac{MTBF_c}{1 - \alpha}$$

$MTBF_c$ is plotted versus cumulative test time on Log-Log paper, where the growth regression is a straight line with slope coefficient α . The test time at which the growth line reaches the required *MTBF* ($MTBF_R$) is the expected duration of the Reliability growth test:

Duane plot



The graph above is created using the following sample failure data set:

Point #	Time, hours	Cumulative MTBF, hours
1	33	33
2	76	38
3	145	48.3
4	347	86.8
5	555	111
6	811	135.2
7	1212	173.1
8	1499	187.3

Module Features:

- The default values of MTBF_i and Initial test time for Reliability Growth Planning are defined in accordance with MIL-STD-1635.
- The default MTBF/R values for each project item are those predicted by the RAM Commander.
- Reliability Growth calculation can be performed for the whole system, for any subsystem, or even for an external item that doesn't belong to the current project.
- Reliability Growth Test plan and expected remaining time to test accomplishment are presented.
- Calculation of a Confidence Interval for a selected Confidence Level using the new Bootstrap technology. (A new statistical technology named "Bootstrap" reproduces the origin sample as many times as necessary, and all new samples have absolutely identical statistical properties).
- Reports for all failures available or only for the last N reported failures.
- Tabular or graphic report presentation.

See next paragraph for a [theoretical discussion of reliability growth](#).

15.1 Reliability Growth Modeling

Reliability Growth Modeling

RAM Commander's reliability growth module is the Duane method as described in MIL-STD-1635. In this model, the tested mean time between failure (MTBF) is proportional to T^α where T is the cumulative operating test time and α is the growth rate index. On a log-log plot, the growth regression line is linear with slope α .

The **cumulative mean time before failure** (MTBF_c) is normally measured during testing and then divided by $(1 - \alpha)$ to convert it to the current instantaneous mean time before failure MTBF_i. MTBF_i is then plotted parallel to the MTBF_c at an offset of $1/(1 - \alpha)$. The test time at which this line reaches the required MTBF is the expected duration of the reliability growth test.

RAM Commander uses Bootstrap, a new statistical technology that enables the user to calculate accurate confidence intervals for the main parameters of the Duane model by obtaining a large number of samples. Details of this method have been published in the paper "*Bootstrap Technology for RAM Analysis*", Z. Bluvband and L. Peshes, *Proceedings of the Symposium on New Directions in Military Reliability, Availability and Maintainability (RAM) Analysis*, Maryland, USA, 1993.

Derivation of Model Equations

According to the Duane formulation:

$$\lambda_{\Sigma} = \frac{F}{E} KH^{-\alpha}$$

where:

- λ_{Σ} cumulative failure rate
- H total test hours
- F failure during H hours
- K condition-dependent coefficient
- α growth rate

The original mathematical model was expressed in terms of cumulative failure rate. However, since equipment reliability is generally expressed in terms of MTBF, the following expression is more frequently used:

$$MTBF_R = MTBF_I \left(\frac{T_I}{t_i} \right)$$

where:

- MTBFR required MTBF
- MTBFI initial MTBF
- t_i time at which initial data point is plotted (preconditioning time)
- T_i time at which the instantaneous MTBF of the equipment under test will reach the required MTBF

Differentiating the equation with respect to time, we receive

$$\lambda(t) = \frac{\partial F}{\partial H} = (1 - \alpha)KH^{-\alpha} = (1 - \alpha)\lambda_{\Sigma}$$

Thus, the current instantaneous failure rate is $(1 - \alpha)$ times the cumulative failure. That is, the instantaneous MTBF is $1/(1 - \alpha)$ times the cumulative MTBF.


The instantaneous MTBF may be interpreted as the MTBF that the equipment under test would exhibit if we stopped the reliability growth and continued testing. Thus, on a logarithmic plot, instantaneous or current-status curves are straight lines displaced a fixed distance from the cumulative plot by a factor of $(1 - \alpha)$.

The cumulative MTBF (MTBFC) is normally measured during testing and then converted to the instantaneous (or current) MTBF (MTBFI) by dividing by $(1 - \alpha)$, that is:

$$MTBF_i = \frac{MTBF_c}{1 - \alpha}$$

15.2 To view reliability growth data

1. Activate the Product tree view.
2. From the **Modules** menu, choose **Reliability growth - Duane**; RAM Commander displays the Reliability growth list, containing list of failures with information about system and cumulative time since start of system testing for each failure:




	F.R. #	Ref. Des.	Cumulative Test Time	Source	Cumulative MTBF
	T 1	TUTORIAL	1000.00	Tree	1000.00
	T 2	TUTORIAL	1100.00	Tree	550.00
	T 3	TUTORIAL	1200.00	Tree	400.00
	T 4	TUTORIAL	2000.00	Tree	500.00
	T 5	TUTORIAL	2900.00	Tree	580.00
	T 6	TUTORIAL	3300.00	Tree	550.00
	T 7	TUTORIAL	4500.00	Tree	642.86
	T 8	TUTORIAL	8000.00	Tree	1000.00
	T 9	TUTORIAL	9000.00	Tree	1000.00
	T 10	TUTORIAL	29000.00	Tree	2900.00
	T 11	TUTORIAL	33000.00	Tree	3000.00
	T 12	TUTORIAL	34000.00	Tree	2833.33
	T 13	TUTORIAL	67000.00	Tree	5153.85

To view individual subsystems of the Reliability growth list, from the **View** menu choose **Subsystem**. Select an item from the reference designator dialog box, and then choose **OK**. RAM Commander displays the Reliability growth list with only those records that have the selected reference designator. To view all records, from the **View** menu, select **System**.

15.3 To enter reliability growth data

1. Activate the Reliability growth list.
2. Provide information about all failures (you may specify system failures and failures of particular system items/assemblies) - perform the procedure below for each failure:

- From the **Item** menu, choose **Create**; the Reliability Growth Entry dialog box opens:



The screenshot shows a dialog box titled "Reliability Growth Entry". It contains the following fields and controls:

- Ref. Des.:** A text box containing "TUTORIAL".
- Source:** A dropdown menu with "Tree" selected.
- Cumulative Test Time:** A text box containing "0".
- Remark:** An empty text box.
- Date:** An empty text box.
- Tree Location:** A button.
- OK:** A button.
- Cancel:** A button.

- In the Reliability Growth Entry dialog box, do the following:
 - Open the product tree navigator by choosing **Tree Location**. Navigate through the product tree and select the item you want to perform the reliability growth analysis on. Choose **OK**.
 - or-
 - Manually enter a reference designator in the Ref. Des. field (the project name is default).
- Enter a value for Cumulative Test Time (time since the testing was started and till the specific failure occurred) and optionally remarks about the failure and failure date.
- Choose **OK**.

RAM Commander updates the reliability growth list with the new values.

The next step is to [compute the reliability growth planning parameters](#).

15.4 To compute reliability growth planning parameters

After failures are inserted into Reliability Growth table, you may specify the required MTBF and calculate:

- Required Test Time by known Growth Rate (α)
- or
- Growth Rate (α) by known Test Time.

To perform the calculation:

- From the Reliability Growth menu, choose RG Planning; the RG Planning dialog box opens:




The RG Planning dialog box contains the following fields and buttons:

Initial Time :	100	OK	Cancel
Initial MTBF:	1500		
Required MTBF:	3000		
Req. Test Time :	215443		
Growth Rate:	0.090309		

2. Enter a value for the required MTBF.
3. Enter value for one of the two following fields:
 - Required Test Time
 - Growth Rate (see formula in the [next paragraph](#))
4. Move the cursor to another field; RAM Commander computes and displays the second parameter.
5. Choose **OK**.

You can review and edit the required mean time between failure values for each item in the Reliability growth list:

1. From the **Reliability Growth** menu, choose the MTBF required:



The MTBF Required dialog box contains the following fields and buttons:

Ref. Des. :	TUTORIAL	OK	Cancel
MTBF Required :	3000		

2. In the MTBF required dialog box, select the reference designator whose required MTBF you want to set.
3. RAM Commander displays the current value in the MTBF required dialog box.
4. To modify, enter a new value and choose OK to close.

15.5 Reliability Growth Formula

Growth Rate is calculated as follows:

$$\alpha = \frac{\log MTBF_R - \log MTBF_I}{\log T_C - \log T_I}$$

where

α	growth rate
$MTBF_R$	required MTBF
$MTBF_I$	initial MTBF
T_C	cumulative test hours
T_I	initial test time

Assumptions:

$$T_I = 100h$$

$$M_I = \begin{cases} 0.1MTBF_R & \text{for } MTBF_R \leq 200h \\ 0.5MTBF_R & \text{for } MTBF_R > 200h \end{cases}$$

15.6 Reliability Growth Reports


RAM Commander directs reliability growth reports to the regular text window and graph viewer.

Two reports are available:

- Reliability Growth Information Report (or graph)
- Reliability Growth Planning Information

15.6.1 To generate reliability growth reports

1. Activate the Reliability Growth list.
2. From the **Reports** menu, choose **RG Info**; the Reliability Growth Report dialog box opens.



3. In the Items group box, select one of the following:

All Report generated for all available entered failures.

N-last Report generated for only the last N entered failures. If you select this option, enter a value for N in the adjacent field.

Bootstrap Report generated with a confidence level. Select the desired confidence level from the list box.

4. If required, select the View planning information check box.
5. Select either Text or Graph from the Type list box.
6. Choose **OK**.

RAM Commander displays the selected report:

Reliability Growth Information Report

System : TUTORIAL # Failures : 14


Cumulative Test Time : 67000 Hours

Failure number	Ref.Des.	Cumulative Test Time	Source	Cumulative MTBF	Current MTBF	Time Between FR's	Alpha	Date	Remark
1	TUTORIAL	1000.00	Tree	1000.00	0.00	0.00	0.00		
2	TUTORIAL	1100.00	Tree	550.00	75.63	100.00	-6.27		
3	TUTORIAL	1200.00	Tree	400.00	66.17	100.00	-5.04		
4	TUTORIAL	2000.00	Tree	500.00	314.90	800.00	-0.58		
5	TUTORIAL	2900.00	Tree	580.00	484.02	900.00	-0.19		
6	TUTORIAL	3300.00	Tree	550.00	480.22	400.00	-0.14		
7	TUTORIAL	4500.00	Tree	642.86	614.52	1200.00	-0.04		
8	TUTORIAL	8000.00	Tree	1000.00	1171.60	3500.00	0.14		
9	TUTORIAL	9000.00	Tree	1000.00	1260.95	1000.00	0.20		
10	TUTORIAL	29000.00	Tree	2900.00	4904.77	20000.00	0.40		
11	TUTORIAL	33000.00	Tree	3000.00	5654.60	4000.00	0.46		
12	TUTORIAL	34000.00	Tree	2833.33	5561.75	1000.00	0.49		
13	TUTORIAL	40000.00	Tree	3076.92	6197.38	6000.00	0.50		
14	TUTORIAL	67000.00	Tree	4785.71	10124.41	27000.00	0.52		

Expected termination time : 42247.96 Hours

MTBF required : 6331.22 Hours

or graph:



where:

Time axis scale is $\text{Log}_{10}(\text{time})$,

MTBF axis scale is $\text{log}_{10}(\text{MTBF})$,

MTBF current is Instantaneous MTBF,

Scatter is a line connecting actual times of failures provided.

Another reliability growth report is the *reliability growth planning* report. This report displays the values displayed in the RG Planning dialog box. To generate this report, choose Planning from the Reports menu.

See also "[Reports](#)" paragraph in the [RAM_Commander_Fundamentals](#) chapter for more general information about reports.

15.7 Summary

In this chapter you learned how to use the reliability growth module. With this module, you can produce reliability estimates for products that have undergone limited field testing.

Chapter

16

Spare Parts Analysis

16 Spare Parts Analysis

RAM Commander's **Spare Parts Analysis** module provides an analysis of the required quantity levels of spare parts for all project items.

Two types of optimization are available:

- optimization of spare parts for the required Non-Shortage Probability (NSP)
- optimization using two criteria - cost function (price, weight, volume) and Availability/Non Shortage probability.

The first type is used for stock computations for normal system support, and the second used to get optimized stock quantities when you face a budget constraint.

Spare parts module uses data from other RAM Commander modules - Product tree, reliability prediction and maintainability data. Both repairable and non-repairable parts from the Product Tree are taken into consideration, spare parts recommendation is given for all organizational levels (levels of replace - O, I, D etc.).

To perform spare parts calculation/optimization user should define a Scenario (containing information about number of systems in the field, prediction period, operation hours/day, operation days/year, required Non-Shortage probability and more). Multiple scenarios may be created and stored in the database.

16.1 Operation Modes

The spare parts module performs evaluation in two modes: *regular operation* and *unsupported mission*.

Regular operation During a regular operation, normal spare part replace and repair activities are permitted.

The module takes into account each part's failure rate and level of repair. The number of systems in the field, operation hours per day, operation days per year, prediction period, and repair turnaround time for Intermediate and Depot levels are taken into account for spare parts evaluation.

Unsupported mission During an unsupported mission, no repair or supply of spare parts is permitted. The only way to restore a system to operating condition is to replace failed parts from existing stock at the operational site. Examples of unsupported missions include submarines at sea, aircraft in the sky, or space shuttles in orbit.

The number of days during which replacement of spare parts is impossible, and the number of systems participating in the mission, are taken into account for spare parts evaluation.

16.2 Product Tree Data

Spare parts calculation/optimization module uses **product tree** information during the calculation. Product tree supplies data about replaceable parts, their part numbers, their failure rates, replace level and other information.

You should build the product tree and define the following information for each product tree item before you may use Spare parts module:

1. **Part Number** (or other identifies like Catalog Number, Generic name etc.)
2. **Quantity**
3. Operating reliability data - **Failure Rate** (using prediction, FR/temperature curve in GPRD library or just specifying fixed user-defined or field failure rate).
4. Maintainability data - **Level of Repair** and Level of **Replace**.
5. Item minimal and maximal spare parts quantity, condemnation rate and turnaround time, if necessary and if part values differ from general settings in spare parts scenario - see "General" tab of "Item data" screen::

Repair turnaround time [days]:	5
SMR:	
Condemnation Rate [%]:	0.
Spare Parts Min:	1
Spare Parts Max:	---

Field name	Definition
Spare parts Min.	Minimum number of spare parts to be on hand at all times ("---" means to take value from Scenario)
Spare parts Max.	Maximum number of spare parts ("---" means no limitation)
Condemnation rate %	Condemnation rate is the proportion of items needing repair that it is uneconomical to repair
Repair turnaround time (days)	Time required to send part for repair and get it back (0 - take TAT from Scenario)

6. **Price** ("Miscellaneous" tab of the "Item data" screen) if Spares optimization by budget will be used. Enter also Weight and Volume is optimization will be done by these parameters too.

16.3 Spare Parts Calculation

Spare parts calculation performs the evaluation of unrestricted spare parts stock is based on the required No Shortage Probability (NSP) criterion for up to five maintenance levels:

- Organizational – replacement made at customer site (in line, in the field)
- Intermediate – replacement made at service center (repair base, repair hangar)
- Depot, Supplier, Manufacturer – replacement made at higher levels like factory site

With this information, together with the reliability data, RAM Commander computes the required spares stocks at each maintenance level.

You define an *operational spares parts scenario* using regular operation mode parameters, required No Shortage Probability, and the minimum number of spare parts you want to keep on-hand.

16.3.1 To add an operation scenario

- 1 Activate the Product tree view.
- 2 From the **Modules** menu, select **Spare Parts**, then **Quick Calculation**; the Quick Spare Calculation dialog box opens.

- 3 Choose **Add**.
- 4 In the Scenario Name dialog box, enter a name for the scenario. Use a string of up to eight characters.
- 5 Choose **OK**.
- 6 In the Quick Spare Calculation dialog box, enter the necessary changes to scenario's parameters in the Scenario and Calculation request group boxes.

Field name	Definition
No. of systems in the field	Number of actual systems in operation
Operation hours per day	Hours per day each system operates at the customer site

Field name	Definition
Operation days per year	Days per year the systems operate at the customer site
Prediction period	Elapsed scenario years
Repair turnaround time - Intermediate	Number of days required to repair a failed item at the intermediate maintenance level
Repair turnaround time - Depot	Number of days required to repair a failed item at the service depot
Unsupported Mission Time	Length of time during which no repair or supply of spare parts is permitted (required only for unsupported mission mode)
Required No Shortage Probability	Probability that there will be no shortage of the spare part
Minimum spare parts	Minimum initial number of spare parts
Mode	Regular operation or Unsupported mission

7 Choose **Save**.

16.3.2 Working with existing Scenarios

You may add new scenarios and edit, delete and copy the existing scenarios.

16.3.2.1 To copy a spare parts operation scenario

1. In the Quick Spare Calculation dialog box, select the source scenario from the Scenario list box.
2. Choose **Copy**.
3. In the Scenario Name dialog box, enter a name for the target scenario. Use a string of up to eight characters.
4. Choose **OK**.
5. Edit the new scenario's parameters.
6. Choose **Save**.

RAM Commander saves the new scenario.

16.3.2.2 To delete a scenario

Select the scenario from the Scenario list box; then choose **Delete** and enter your confirmation.

You can easily generate new operation scenarios by copying existing scenarios and editing individual fields.

16.3.2.3 To edit a scenario

Select the scenario from the Scenario list box, enter your changes, and choose **Save**.


16.3.3 Generating Spare Parts Reports

After defining scenario, you can generate a report detailing the following data for each spare part:

- Recommended stock that provides the required No Shortage Probability
- Achieved No Shortage Probability

To generate a spare parts report:

1. Compute reliabilities in Operating mode (see Chapter 10).
2. In the Quick Spare Calculation dialog box, select a scenario from the Scenario list box.
3. Choose Calculate; the Spare parts - Report Options dialog box opens.



4. Set the Organizational, Intermediate and Depot check boxes to include parts replaced at these levels in the report.
5. In the Report depth field, enter the number of product tree levels to be included in the report
6. Choose **Prepare Report**.

RAM Commander displays the spare parts report in a window. You can manage the spare parts report using the techniques described in Chapter "RAM Commander Fundamentals" - [Reports](#).

16.4 Spare Parts Optimization

Rarely can you purchase or ship spare parts in unlimited quantities. Budget constraints require the *optimization* of spare part quantities so that a maximum NSP or availability is achieved. In addition to the parameters discussed in the previous section, spare parts optimization requires the following information:

- Optimization criteria
- Constraints

16.4.1 Optimization Criteria

The spare parts module supports the computation of two optimization criteria:

The spare parts module supports the computation of two optimization criteria:

- Total No Shortage Probability - applicable for unsupported missions.
- Availability - applicable for regular operation and unsupported missions.

During computation, the module maximizes the selected criterion subject to a cost constraint described below.

16.4.2 Constraint

The cost for each spare part is computed as follows:

$$\text{Cost} = (k1 \square \text{price}) + (k2 \square \text{weight}) + (k3 \square \text{volume}) + k4$$

This approach makes it possible to solve spare parts optimization problems for a variety of mission applications. When the only consideration is the actual price of the spare part, and weight and volume have no cost impact, then the cost coefficients are defined as follows:

$$k1 = 1; k2 = k3 = k4 = 0$$

These are the module's default settings.

If the primary restriction is weight, such as for fly-away kits, then the coefficients would be

$$k1 = 0; k2 = 1; k3 = k4 = 0$$

In early stages of analysis, when pricing data are not available, rough calculations can be obtained by defining a fixed cost for all spare parts as follows:

$$k1 = k2 = k3 = 0; k4 = \text{constant}$$

For example, it is generally supposed that the cost to send 1 kilogram into space is \$10,000. A 1 kilogram reel of wire, which may normally cost \$5 in a retail store, becomes extraordinarily expensive when orbiting the earth.


Take a look at the values in the Item Data - Miscellaneous tab dialog box on page 413 and the ISLE - Spare Optimization dialog box on page 415. The total cost for taking the particular item on the mission as a spare part is as follows:

$$\begin{aligned} \text{Cost} &= (k1 \square \text{price}) + (k2 \square \text{weight}) + (k3 \square \text{volume}) + k4 \\ &= (1 \times 100,000) + (100 \times 1) + (500 \times 0.3) + 1,000 \\ &= 101,250 \end{aligned}$$

When computing optimal quantities, RAM Commander makes sure that the total cost does not exceed a budget you specify.

16.4.3 Optimization Algorithm

The optimization algorithm is based on convex programming as outlined in the flow chart below.



16.4.4 Optimization Parameters

Two sets of input parameters are required to define an optimization problem:

- item data
- operation scenario data

You may create a scenario with spare parts optimization scenario data in the Spare parts module (see [To add an operation scenario](#) paragraph earlier in this chapter).

You specify item data in the Product Tree item data dialog - General, Maintainability and Miscellaneous pages - see [Product tree data paragraph](#) earlier in this chapter.

16.4.4.1 To set operation scenario parameters

1. From the **Modules** menu, select **Spare Parts**, then select **Optimization** from the submenu; the Spare Optimization dialog box opens. See also [To add an operation scenario](#) paragraph earlier in this chapter.

ISLE - Spare Optimization

Scenario name: Test.spr

Scenario

No. of systems in the field	N	10
Operation hours per day	Hd	24.
Operation days per year	Dy	365
Prediction period (years)	Y	10.
Repair turnaround time - Intermediate (days)	TI	30.
Repair turnaround time - Depot (days)	TD	60.
Repair turnaround time - Supplier (days)	TS	60.
Repair turnaround time - Manufacturer (days)	TM	90.
Unsupported Mission Time (days)	Md	365.

Calculation request

Required No Shortage Probability NSPREQ 0.9

Minimum spare parts quantity MINQTY 1

Mode Unsupported mission

Optimization

Criterion: NSP Budget: 900000 # of points: 10

Cost = 1 * price + 0 * weight + 0 * volume + 0

Select point by

Cost

0

Quantities

- In the **Mode** list box, select Regular operation or Unsupported mission.
- From the **Criteria** list box, select NSP or Availability.

Criteria serves as an objective function for the optimization. RAM Commander can optimize two criteria: availability and No Shortage Probability. If you select Availability for the objective function, RAM Commander determines the combination of spare parts that gives the highest availability within the given budget constraint. If you select NSP as the objective function, RAM Commander determines the combination of spare parts that gives the highest NSP within the given budget constraint.

When selecting availability as the objective function, RAM Commander makes computations at the *end* of the mission period - not at any instantaneous time during the mission. Therefore, as your mission gets longer, its availability declines (everything else being equal). However, for steady state situations (common in regular operation mode) when all parts are repairable, availability approaches a constant level.

- In the **Budget** field, enter the maximum amount of money you can allocate to spares purchases.

Specify a *budget constraint* - a limit on the amount of money you can invest in spare parts during a particular mission. Generally, the value of a spare part is its cost multiplied by its quantity. In specific circumstances, you can also specify costs associated with the part's weight and volume

5. Enter the number of evaluation points in the **# of points** field.
6. Enter coefficients for price, weight, volume and a fixed cost.
7. When all the required data for product tree items and scenario are defined, you may proceed to optimization and reports.

16.4.5 Generating Optimization Reports

RAM Commander provides two types of optimization reports:

- summary, which gives the objective function value at various monetary values, and
- detailed, which gives the quantities of spare parts at various points within the optimization.


16.4.5.1 To generate an optimization report

1. Make sure that all data relevant to calculation (scenario, product tree, prices, failure rates etc.) are provided and calculated.
2. Open Spare Parts Optimization module (Modules menu, "Spare parts" option, "Optimization" item).
3. Select the required scenario.
4. Choose **Optimize**; the Spare parts - Report Options dialog box opens.
5. Select which parts to include in the report from those replaced at any combination of Organizational, Intermediate or Depot levels.
6. Enter a value for report depth (if different from default).
7. Choose **Prepare Report**.

RAM Commander displays both a tabular spares report and graph.

Note The optimization algorithm computes spare stocks satisfying the criteria established in steps 5–6 in the previous procedure. The report starts the optimization at the current product tree level - parts appearing in higher levels of the product tree are ignored.

Example of Availability optimization graph and report:



SPARE PARTS OPTIMIZATION report

No. of systems in the field - 10
 Operation hours per day - 24.00
 Budget - 5000000.0
 Unsupported Mission Time (days) - 365.0

Items replaced in -Organizational Intermediate Depot
 Report depth - 9

Cost - Availability optimization results for project TUTORIAL
 Start from: 1 - TUTORIAL Scenario: Test.spr

##	Cost	Avail.
1	0.0	0.2337729
2	293800.0	0.5259672
3	578800.0	0.6231985
4	768800.0	0.7023172
5	1049900.0	0.8302997
6	1258700.0	0.9049402
7	1539000.0	0.9652671
8	1824500.0	0.9901330
9	2055400.0	0.9969657
10	2338700.0	0.9993178
11	2526600.0	0.9997314
12	2761000.0	0.9998867
13	3061100.0	0.9999243
14	3259600.0	0.9999285
15	3531600.0	0.9999295
16	3842600.0	0.9999296
17	3842600.0	0.9999296

The optimization report gives an overall availability or NSP for a particular monetary amount. You can review the exact quantities of each spare part to take on the mission.

16.4.5.2 To review optimal spare part quantities

1. From the **Modules** menu, select **Spare Parts, Optimization**; the Spare Optimization dialog box opens.
2. Select the required scenario.
3. In the **Select point** by group box, do one of the following:
 - Select **Cost**, and enter a cost value in the field below.
 - Select **Criterion**, and enter a value for NSP or Availability in the field below.
 - Select **Point #**, and enter a value for one of the evaluation points in the field below.

4. Choose **Quantities**.

RAM Commander displays the quantity report in a window.

The output below, taken from the Spare Part quantities report, provides the exact number of spare parts providing the optimum availability for the selected point:

SPARE PARTS OPTIMIZATION report

No. of systems in the field - 10
 Operation hours per day - 24.00
 Budget - 5000000.0
 Unsupported Mission Time (days) - 365.0

Items replaced in -Organizational Intermediate Depot
 Report depth - 9

Recommended SPARE PART quantities for project TUTORIAL

Item Name	Level of Replace	TAT [days]	Level of Repair	Cond.rate [%]	Sum of F.R[xE-6]	Cost	Qty in system	Min Qty	Max Qty	Recom. stock	Achieved EBO
CN017000	Organiz	30	Interme	0	100.2550	1140000.0	1	0	---	12	0.2415900
CN017004	Interme	60	Depot	0	8.7416	126000.0	2	0	---	2	0.0517900
CN017009	Interme	60	Depot	0	0.3419	13000.0	1	0	---	1	0.0004440
CN017012	Interme	60	Depot	0	8.0000	1500.0	1	0	---	5	0.0001000
CN017016	Interme	60	Depot	0	82.8215	169000.0	10	0	---	13	0.0302500
CN017045	Interme	60	Depot	0	50.4954	12000.0	1	0	---	12	0.0009900
CN017099	Interme	60	Depot	0	17.0000	700.0	1	0	---	7	0.0001920
CN017201	Interme	N/A	Discard	0	8.3500	5200.0	1	0	---	4	0.0010800
CN017334	Organiz	30	Interme	0	75.4954	28000.0	1	0	---	14	0.0056400
CN017880	Organiz	30	Interme	0	11.3265	30000.0	1	0	---	3	0.0227200
CN023190	Interme	N/A	Discard	0	6.6583	9000.0	1	0	---	3	0.0034200
CN023770	Interme	N/A	Discard	0	4.5000	4500.0	1	0	---	3	0.0008000
CN055550	Interme	N/A	Discard	0	0.1682	100.0	1	0	---	1	0.0001080

Total cost: 1539000.0, Achieved availability: 0.965267

The detailed report displays results computed during the optimization. The following table describes the lookup logic.

Select point by	Result used
Point #	Entered point
Cost	Highest cost less than or equal to the entered value
Criteria	Lowest NSP/availability greater than or equal to the entered value

16.5 Spare Parts Analysis Formulae

Recommended spare stock is calculated interactively (using Poisson distribution) by finding the smallest n for which the following inequality is true:

$$\sum_{i=0}^n P_i = \sum_{i=0}^n \left[e^{-\lambda t} \cdot \frac{(\lambda t)^i}{i!} \right] \geq \text{NSP}$$

where t is a repair turnaround time (TAT) for *repairable* items, or total expected operating hours during prediction period for *discardable* items.

For very large stocks ($\lambda t > 720$), the following formula based on normal approximation is used:

$$n = \frac{\left(Z_R + \sqrt{Z_R^2 + 4\lambda T} \right)^2}{4}$$

where Z_R is a fractile of the cumulative normal distribution corresponding to the required NSP.

Achieved NSP is calculated as the probability corresponding to the fractile Z_A of the cumulative normal distribution:

$$Z_A = \frac{n - \lambda T}{\sqrt{n}}$$

16.6 Possible Important Applications

The RAM Commander spares module can be used to analyze a variety of mission scenarios. Two possible applications are described below: [compound operation modes](#) and [level of repair decision](#).

16.6.1 Compound Operation Modes

In many practical applications, a system operates under a combination of regular operation *and* unsupported mission modes. It is usually difficult to formulate one analytical criterion for spare parts calculations in such situations. Instead, the usual practice is to perform several calculations for each operation mode, and then combine the results in the appropriate manner.

Example 1 An oceangoing vessel has a total mission time of 10 years. During this time, it sails for periods of two months, during which no spares supply is possible. In this case, the spares stocks computation is done in three steps:

1. Calculate sail-away kits for two months' unsupported mission.
2. Calculate base spare parts stocks for 10 years' regular operation.

3. Overall spares stock is the sum of the quantities computed in steps (a) and (b).

Example 2 During wartime, a weapon system is used frequently and enjoys short repair turnaround times. The same weapon system, during peacetime, is used only occasionally and experiences long repair turnaround times. Spare parts planning for such a system can be accomplished as follows:

1. Calculate spare parts quantities for peacetime operation.
2. Calculate spare parts quantities for wartime operation.
3. Total spares stock is the maximum of the quantities computed in steps (a) and (b).

16.6.2 Spares and Level of Repair Decisions

The quantities of spare parts required have a major impact on the level of repair decisions. In cases where several alternatives are technically feasible, the decision is based mostly on economic factors: the alternative with the lowest life cycle cost is preferred. To incorporate life cycle costing into spare parts analysis, results from the RAM Commander spares module can be exported to ALD's DLCC life cycle costing software.

The optimization module supports the calculation of spare parts for various maintenance concepts. One example is stocking whole units (such as entire computers) versus stocking modules (printed circuit boards). This approach facilitates Level of Replace Analysis.

16.7 Summary

In this chapter, you learned how to define operation scenarios to calculate quantities of spare parts. You also learned about RAM Commander's capability to optimize spare parts stocks in the face of budget constraints. Using the results of these analyses, you can determine the stock levels required to support a desired No Shortage Probability or availability.


Chapter

17

Markov Analysis

17 Markov Analysis

The **Markov chain analysis** technique and its mathematical model have been demonstrated over years to be a powerful tool to analyze the evolution, performance and reliability of physical systems.




RAM Commander Markov is a powerful tool with the following features:


- Up-to-date, intuitive and powerful Markov Chain diagram interface with possibilities of full control over the diagram: elements location, colors, styles, zooms etc.
- Convenient ways of diagram printing and simple **Copy & Paste transfer to other applications**
- Calculation of **Steady-State Mode**
- Calculation of **Time-Dependency Mode**
- **Calculation** of Availability, Unavailability, Failure and Repair rate and frequency, MTBF, MTTF, MTTR, Reliability/ Unreliability, Downtime, Performance Ratio and other system parameters.
- Results output:
 - System parameters for selected times as table or graph
 - Steady-State results report
 - Transition Matrix report
 - States and Transitions data report
 - Results export to **Excel, Word, HTML** formats

17.1 Initiating Markov module

1. Run RAM Commander
2. Open project
3. Go to Modules menu, choose "Markov Chains".
4. Each project may contain multiple Markov Diagrams. The list of all diagrams in the current project will appear. Choose existing diagram or enter name of a new diagram and press "Open" button:



5. Selected or new Markov Diagram will appear.



For new or existing diagram you may use diagram properties dialog to set up diagram calculation time, visual display details and other information - see "[Diagram data](#)" paragraph.

17.2 Drawing the diagram

Each Markov diagram contains number of states and transitions between states. Diagram may contain any number of states and transition between them. Below you will find procedures for creating or editing states and transitions. Once the diagram is created, you can freely move and resize state nodes, change elements shapes, colors and other properties:

[Draw a state](#)

[Draw a transition](#)

17.2.1 Draw a state

To draw a state, bring the mouse cursor into the diagram, press the left button, move the mouse and release the left button. You have created a state node. This node is selected: that's why 9 handles (little squares) are displayed.

The handle at the center of the node is used to draw a link. The 8 others allow resizing the node. If you want to move the node you bring the mouse cursor into the node, press the left button, move the mouse and release the left button.


State data screen will appear immediately for the new state.

To edit existing state data, double-click on it, or select from menu Item → Edit.... On edit dialog,

you can choose state node background color, shape and assign bitmap picture. See the "[State data](#)" topic.

17.2.2 Draw a Transition

Bring the mouse cursor into the handle at the center of the selected node, press the left button, move the mouse towards the other node.



When the mouse cursor is into the other node, release the left button. The transition has been created. And it is selected since a handle is displayed at the center of this transition link.

Transition data screen will appear immediately for the new transition.

To edit existing transition data, double-click on it, or select from menu Item → Edit. See "[Transition data](#)" topic.

17.2.3 State Data

When you create a new state or double-click an existing state, the following state data screen appears:

Below is the explanation of state data fields:

Field	Description
Code	Unique state code
Name	State name
Description	State description (appears as a tooltip when mouse pointer is over state node on diagram)
State type	State type: define if the state is Failure state or Operational state.
Performance	Value describing whole system performance or capacity, when the system is in the current state. Performance measurement units are user-defined – you may define percent of maximal performance or absolute measurement, like power station power produced while it is in current state. Performance unit is defined on Diagram Properties screen.
Initial state prob.	Probability that the system is in the current state when it starts working. Total initial probability for all states should be 1.

Field	Description
Visual representation	Possibility to select shape, color, border, background picture and text alignment for diagram element

17.2.4 Transition Data

When you create a new transition or double-click an existing transition, the following data screen appears:

Below is the explanation of transition data fields:

Field	Description
Code	Unique transition code
Name	Transition name
Description	Transition description (appears as a tooltip when mouse pointer is over transition on diagram)

Field	Description
Transition type	Transition type: define if the transition is Failure (usually from good to bad state), Repair (usually from bad back to good state) or custom transition.
Transition rate	Number of transitions per hour between states connected by current transition link
Visual representation	Possibility to select line style, direction, color and width
Connection with Product Tree / FMECA	Under development

17.2.5 Diagram data

To define general Markov Chain diagram properties, choose “Properties” from Diagram menu, or just double click empty blank space on the diagram.

The following screen appears:

Markov Chain properties

Name: Test_1

Description:

Author: ALD

Created: 02/19/07 Updated: 04/15/07

Calculation settings

Start time: 0 hours Probability calculation precision: 0.0001

End time: 10 hours Number of points in results output: 101

Visual representation

Show state code Show transition code

Show state name Show transition name

Show state performance Show transition rate

Show state initial probability

Performance unit: %

OK Cancel

Below is the explanation of diagram properties:

Field	Description
Name	Diagram file name
Description	Description of the diagram
Author	Author name, by default RAM Commander user login name
Created, Updated	Date when the diagram was updated or created
Start time	Starting time for results output
End time	Finish time for diagram results output
Precision	Calculation precision. Used in time-dependent analysis calculation
Number of points	Number of points in time-dependent analysis results output. For example, if start time is 0 hours and end time is 10 hours and number of points = 11, then resulting report will contain points for 0,1,2,...10 hours.
Visual representation	Allows defining appearance of states and transitions – what is printed and what is hidden.
Performance unit	User-customizable performance unit (may be % of maximal performance or absolute value)

17.2.6 Working with diagram

Markov module provides the following convenient options while working with Markov diagrams:

Print the diagram - Choose "Print" option from the "Diagram" menu to print the diagram

Zoom in/Zoom Out - Choose different zooming options from "Diagram" menu, "Zoom" submenu; or use +/- numeric keypad keys.

You can **export**/insert the diagram as a picture to another application (Word, Excel, PowerPoint etc.) - choose menu item Diagram – Export to Clipboard. The diagram will be placed to Clipboard. Then switch to another application, choose where to paste the diagram and press Ctrl+V (or choose menu item Edit – Paste). The diagram picture will be copied.

Delete, Rename, Copy diagrams - choose "Manage diagrams" option from the "Diagram" menu. Diagrams list will appear. Use Save as, Delete, Rename, Create buttons for corresponding operations.

17.3 Calculation

Two calculation modes are available: Steady-state and Time-dependency.

Steady-state calculation mode

This mode calculates and displays system parameters (state probabilities, system availability, reliability etc.) for a Steady State.

Steady State is state where time t is approaching infinity and state probabilities are approaching final probabilities. It is assumed that final probabilities exist and that they do not depend on initial state probabilities.

Calculation is based on linear equations solving.

To run this calculation mode, choose "Steady-State Calculation" from Calculation menu.

Time-dependency calculation mode

This mode calculates and displays system parameters (state probabilities, system availability, reliability etc.) for time points from Start time to End time (see Diagram properties).

Calculation is based on fourth-order Runge-Kutta method for differential equations.

To run this calculation mode, choose "Time Dependency Calculation" from Calculation menu.

17.4 Reports

There are a number of different reports and graphs available to output diagram data and calculation results. Open "Reports" menu to see the list of available reports:

Diagram data report:

Diagram Details for Project TUTORIAL Drive C:

Markov Chain Information

Project name: TUTORIAL
Markov diagram: Relex1

States information

#	Code	Name	Description	State Type	Init.Prob.	Performance
1	State1	A ok, B ok		Operational	1	20
2	State2	A failed, B ok		Operational	0	10
3	State3	A ok, B failed		Operational	0	10
4	State4	A and B failed		Failure	0	0

Transitions information

#	Code	Name	Description	Type	Rate trans/hour	Source State	Destination State
1	Unit A Failure Rate			Failure	0.0001	State1 - A ok, B ok, Init.prob.=1, Performance=20	State2 - A failed, B ok, Init.prob.=0, Performance=10
2	Unit A Repair Rate			Repair	0.01	State2 - A failed, B ok, Init.prob.=0, Performance=10	State1 - A ok, B ok, Init.prob.=1, Performance=20
3	Unit B			Failure	0.0002	State2 - A failed,	State4 - A and B

Transition Matrix Report:

Diagram Details for Project TUTORIAL...

Markov - Transition Matrix

Project name: TUTORIAL
Markov diagram: Relex1

Transition matrix
(transition matrix q ; $q[i,j]$ is transition rate from state i to state j , in transitions/hour)

State j i	1	2	3	4
1		0.0001	0.0002	0
2	0.01		0	0.0002
3	0.02	0		0.0001
4	0	0	0	

Steady-State Calculation Results:

Steady-State Mode Results for Project TUTORIAL Drive C:

Markov - Steady-State Mode Calculation Results

Project name: TUTORIAL
Markov diagram: Test_1

State probabilities for steady-state

#	Name	State Type	Probability
1	State 1	Operational	0.04166666667
2	State 2	Failure	0.5
3	State 3	Operational	0.20833333333
4	State 4	Operational	0.25

System calculation results

Parameter	Value	Unit
Availability	0.5	
Unavailability	0.5	
Performance	45.416666667	%
Failure Frequency	0.5	failures/hour
Repair Frequency	0.5	recoveries/hour
MTBF	2	hours
MTTF	1	hours
MTTR	1	hours

Time-Dependency Calculation Results:

Steady-State Mode Results for Project TUTORIAL Drive C:

Markov - Time-Dependency Mode Calculation Results

Project name: TUTORIAL
Markov diagram: Relex1
Time: 100000 hours


State probabilities for specified time

#	Name	State Type	Probability
1	State1 - A ok, B ok	Operational	0.7340995269
2	State2 - A failed, B ok	Operational	0.007199100442
3	State3 - A ok, B failed	Operational	0.007305526655
4	State4 - A and B failed	Failure	0.251395846


System calculation results

Parameter	Value	Unit
Availability	0.748604154	
Unavailability	0.251395846	
Performance	14.82703681	
Failure Frequency	2.170372754e-006	failures/hour
Repair Frequency	0	recoveries/hour

Time-Dependency Calculation Results for time interval – table and graph:



Markov Calculation Results



Time-Dependency State Probabilities for time interval – table and graph:

State Probabilities for Specified Time Interval for Project TUTORIAL Driv...


Markov - Time-Dependency Mode State Probabilities

Project name: TUTORIAL
Markov diagram: Test_1

Start Time: 0 hours
End Time: 10 hours
Number of points: 101

#	Time [hours]	State 1	State 2	State 3	State 4
1	0	0.5	0	0.5	0
2	0.1	0.5	0	0.5	0
3	0.2	0.3461576198	0.1671870347	0.4787122284	0.007943117107
4	0.3	0.2504640697	0.2873011838	0.4357234333	0.0265113132
5	0.4	0.1882131432	0.3728461328	0.3887668483	0.05017387574
6	0.5	0.1441157673	0.4357773121	0.343073375	0.07703354563
7	0.6	0.1132728714	0.4789206773	0.3036925063	0.1041139449
8	0.7	0.08229916661	0.5057600970	0.2722920424	0.1294669021

Markov State Probabilities



See also "[Reports](#)" and "[Graphs](#)" paragraphs in the [RAM Commander Fundamentals](#) chapter for more general information about reports.

Chapter

18

FMECA

18 FMECA

Failure Mode, Effects and Criticality Analysis (FMECA) is a systematic set of activities intended to identify and help eliminate failure modes. Modern standards and regulations require designers and manufacturers to formally prove that all potential malfunctions have been eliminated or put under control.

RAM Commander FMECA is a module that has been designed for reliability professionals and design engineers, and is suitable for both hardware and functional approaches. The module, fully compliant with MIL-STD-1629A and other standards, is a powerful tool with the following features:

- FMECA data management
- Calculation of criticality numbers
- Report generation
- FMECA utilizes the RAM Commander product tree and associated failure modes. You can actually view each level of your project, giving an overview of how all items interact with each other.
- Library driven FMECA is equipped with an extensive set of libraries for managing components, failure modes, test methods, etc.

FMECA features:

- Fully integrated within RAM Commander. The FMECA module utilizes the RAM Commander product tree and its reliability information.
- Library driven FMECA is equipped with an extensive set of customizable libraries for managing components, failure modes, test methods, etc. - like FMD-97, CENELEC EN50129 etc.
- Multiple phases, different EE severity in different phases
- Fully visible failure mode => NHE => EE chain input with unlimited number of NHE (Next Higher Effect)
- Functional Blocks, analysis on components or on functional level
- Customizable additional fields, customizable field names
- Reports: FMEA, Criticality Matrix, Criticality Analysis and more
- Graphical Fault Isolation Tree
- Fault Tree Report, automatic fault tree creation in FTA Software Module
- Import/Export to and from Excel
- Report Generator
- Testability analysis. Comprehensive testability analysis and reports are integrated within the FMECA module.

FMECA Standard Reports:

- FMEA - MIL-STD-1629
- FMEA - GJB 1391-92
- FMECA
- FMEDA (Failure Mode, Effects and Diagnostics Analysis)
- Criticality Analysis - MIL-STD-1629
- Criticality Analysis - GJB 1391-92
- End Effects Criticality Numbers
- Criticality Matrix
- Fault Tree
- NHE Criticality
- Test methods
- BIT/Detection Coverage
- Fault Isolation Resolution

What you need to know:

To effectively operate the FMECA, as well as to understand the concepts presented in this manual, you need to know the following:

- Basic knowledge of Microsoft Windows.
- Fundamentals of Failure Mode and Effects Analysis
- Probability concepts, such as frequency and conditional probability
- Reliability module of RAM Commander

With this background, you can start using FMECA in a quick and efficient manner.

18.1 Initiating FMECA module

To initiate the FMECA module:

- 1 Activate the Product tree view.
- 2 Click on **Current Analysis** in the button bar in the RAM Commander project list.
- 3 Click the **FMECA** icon.

The FMEA grid is displayed in the lower part of the product tree view:

Ref.Des.	ID	Name	Qty	Opr. FR [10 ⁻⁶]	Status	MTBF	Temp.
TUTORIAL	1	Communication System	1	187.0768		5345.398	35.0
Communic	1	COMM001	1	100.2550		9974.567	35.0
Control	2	Control Unit	1	75.4953		1.3E+004	25.0
Monitor	1	MON001	1	8.0000		1.3E+005	25.0
Keyboard	2	KB003	1	17.0000		5.9E+004	25.0
SystemBlock	3	MB665	1	50.4953		2.0E+004	25.0
HardDrive	1	HDD002	1	11.4844		8.7E+004	25.0
CD-ROM	2	CD98AB1	1	14.4300		6.9E+004	25.0
Floppy	3	F99	1	12.5810		7.9E+004	25.0
MotherBrd	4	MB00887	1	12.0000		8.3E+004	25.0
Pedestal	3	PD001	1	11.3265		8.8E+004	35.0
Antenna	1	ANT555	1	6.6583		1.5E+005	35.0
Motor	2	MOT978	1	4.5000		2.2E+005	35.0
Bearing	3	B0896	1	0.1682		5.9E+006	35.0

#	FM			NHE		EE			Detection	Con p
	Description	Alpha	Cause	IDN	Description	Beta	Description	Beta		
1	Bearing Failure	0.280		1.1	No movement	1.000	Communication Loss	1.000	II	Visual Inspection
2	Fail Run,After Strt	0.230		1.1	No movement	1.000	Communication Loss	1.000	II	Visual Inspection
3	Fails to Start	0.180		1.1	No movement	1.000	Communication Loss	1.000	II	Noise receive test -->>
4	Winding Failure	0.310		1.1	Wrong movement	1.000	Communication Degradation	1.000	III	

FMECA module is based on the RAM Commander product tree and uses data of reliability calculation/prediction module.

You can now [configure the FMECA module](#) (if required) and [enter the FMECA](#) data for relevant product tree items.

18.2 FMECA Module Basics


FMECA grid in the lower part of the screen appears after the [FMECA module activation](#).

It displays Failure Modes and its consequences for the currently selected product tree element. To perform the FMECA analysis, you should define **Failure Modes** for each product tree element.

Then for each Failure Mode its conditional probability (**Alpha**) and possible consequences chain should be defined: **Next Higher Effects**, their Next Higher Effects and **End Effects**.

Each item may have multiple Failure Modes, each Failure Mode may have multiple Next Higher Effects, each Next Higher Effect may have multiple End Effects.

On the illustration below, Failure Mode of Hard Drive (*Single sector data error*) cause NHE (Next Higher Effects) of System block (*Error in data processing*), which in turn lead to NHE of Control unit (*Wrong system control*) which in turn lead to several EE (End Effects) of the whole system level:



The RAM Commander FMECA module screenshot below displays **FM-NHE-EE** chains for the same situation explained above (TUTORIAL project):

Ref.Des.	ID	Name	Qty	Opr. FR [10 ⁻⁶]	Status
TUTORIAL	1	Communication System	1	187.0769	
Communic	1	CN017000	1	100.2550	
Control	2	CN017334	1	75.4954	
Monitor	1	CN017012	1	8.0000	
Keyboard	2	CN017099	1	17.0000	
SystemBlock	3	CN017045	1	50.4954	
HardDrive	1	HDD002	1	11.4844	
CD-ROM	2	CD98AB1	1	14.4300	
Floppy	3	F99	1	12.5810	

#	FM			NHE			NHE 2			EE		
	Description	Alpha	Cause	IDN	Description	Beta	IDN	Description	Beta	Description	Beta	Severity
1	Total drive fail	0.30		1.2.3	No data processing	1.000	1.2	Communication System Control Loss	1.000	Communication Loss	1.000	II
2	Single sector data error	0.70		1.2.3	Error in Data processing	1.000	1.2	Wrong System Control	1.000	Communication Degradation	0.800	III
										Maintainance Degradation	0.200	IV

Each failure mode may have multiple **detection methods** (selected from FMECA Tests library). Each detection method may have Efficiency factor (probability of failure detection) from 0 to 1:

Selected Test Data

Code	Name	Subtest	Efficiency
7	Noise receive test	▼	1.00
10	Visual Inspection	▼	1.00

Failures without detection methods considered to be undetectable (latent) failures.

Additional information (remarks, compensating provisions, corrective actions, user-defined fields etc.) may also be defined for each Failure Mode.

See below descriptions of standard FMECA data table fields:

Field	Description (MIL-STD-1629)
Failure Mode	The manner by which a failure is observed. Generally describes the way the failure occurs and its impact on equipment operation.
Failure Cause	The physical or chemical processes, design defects, quality defects, part misapplication, or other processes which are the basic reason for failure or which initiate the physical process by which deterioration proceeds to failure.
Alpha, Failure Mode Ratio	Failure mode conditional probability. The fraction of the part failure rate (FR) related to the particular failure mode under consideration shall be evaluated by the analyst and recorded. The failure mode ratio is the probability expressed as a decimal fraction that the part or item will fail in the identified mode. If all potential failure modes of a particular part or item are listed, the sum of the Alpha values for that part or item will equal one.
Next Higher Assembly (NHA)	Assembly/product tree item related to the Next Higher Effect
Next Higher Effect (NHE)	The consequence(s) a failure mode has on the operation, functions, or status of the items in the next higher indenture level above the indenture level under consideration.
Beta	Failure Effect probability Beta - conditional probability that the failure effect will result in the identified criticality classification, given that the failure mode

Field	Description (MIL-STD-1629)
	occurs
End Effect	The consequence(s) a failure mode has on the operation, function, or status of the highest indenture level.
Detection	The means or methods by which a failure can be discovered by an operator under normal system operation or can be discovered by the maintenance crew by some diagnostic action.
Severity	The consequences of a failure mode. Severity considers the worst potential consequence of a failure, determined by the degree of injury, property damage, or system damage that could ultimately occur.
Corrective Action	A documented design, process, procedure, or materials change implemented and validated to correct the cause of failure or design deficiency.
Compensating Provisions	Actions that are available or can be taken by an operator to negate or mitigate the effect of a failure on a system.

18.3 Configuring FMECA module

FMECA module should be properly configured before you may start entering failure modes and their consequences.

Several configuration types may be performed:

1. [FMEA or FMECA](#) analysis selection
2. [FMECA Library](#) - Definition of Phases, Severities, End Effects and more.
3. [FMECA grid customizable fields](#)
4. [Phase selection](#)


18.3.1 FMEA or FMECA

RAM Commander FMEA/FMECA has two modes:

- **FMEA** – performs failure mode and effects analysis without criticality numbers. FMEA mode is useful and time saving at the initial stages of the failure mode analysis when the user does not have enough information or needs a criticality numbers calculation.
- **FMECA** – failure mode and effects *criticality* analysis. In addition to processing all FMEA data, FMECA mode displays: **failure mode ratio** (commonly known as *alpha*) and **failure effect probability** (*beta*). FMECA mode utilizes Failure Rates calculated/entered in the Operating reliability prediction stage, alpha, beta and phase duration time for criticality numbers calculation.

To select the desired mode:

1. From the **Project** menu, choose **Configuration**.
2. Check the **FMEA** radio button.
3. Check or uncheck the **Criticality Analysis** check box.



4. Press Ok.

The FMECA grid is displayed in the lower part of the product tree view, containing **alpha & beta**. You can now enter the FMECA data.

By checking and un-checking the Criticality Analysis check box in the Project Configuration dialog box, the user can control the **alpha & beta** display. **Alpha & beta** values are normalized for the entire project every time the user switches between FMEA and FMECA.

18.3.2 FMECA Library

FMECA module contains comprehensive library allowing customization of the module and saving time during FMECA grid data entry. In the FMECA library you may enter and customize Phases, Severities, Criticality groups, test types and other information specific to your particular FMECA standard, language or product. See [FMECA Libraries](#) paragraph later in this chapter for more information.

FMECA analysis may be performed for several product life cycle/mission phases separately. You may define required phases and their durations in the FMECA Library. Then you may choose the current FMECA analysis phase and switch between phases:

1. From the **Project** menu, choose **Configuration**.
2. Check the **FMEA** radio button.
3. Select the required phase from the drop down list next to the FMEA section.

4. Press Ok.

18.3.3 FMECA Grid Customization

FMECA supports user-defined fields for failure modes. User may also change existing field names and sizes to adjust FMECA grid to particular standard, language or requirements.

To change the FMECA grid appearance:

1. From the **Project** menu, choose **Configuration**.
2. Check the **FMEA** radio button.
3. Click the "Table Setup" button near "FMEA" section. List of FMECA fields will appear:

#		Field Name	Show	Width
1	FM	Description	<input checked="" type="checkbox"/>	150
2	FM	Alpha	<input checked="" type="checkbox"/>	40
3	FM	Relev.	<input type="checkbox"/>	40
4	FM	Class	<input type="checkbox"/>	40
5	FM	Cause	<input checked="" type="checkbox"/>	100
6	NHE	IDN	<input checked="" type="checkbox"/>	60
7	NHE	Description	<input checked="" type="checkbox"/>	150
8	NHE	Beta	<input checked="" type="checkbox"/>	35
9	EE	Description	<input checked="" type="checkbox"/>	150
10	EE	Beta	<input checked="" type="checkbox"/>	35
11	EE	Severity	<input checked="" type="checkbox"/>	40
12	FM	Detection	<input checked="" type="checkbox"/>	100
13	FM	Compensating provisions	<input checked="" type="checkbox"/>	100
14	FM	Remarks	<input checked="" type="checkbox"/>	100
15	FM	FM Code	<input checked="" type="checkbox"/>	20
16	FM	User2	<input type="checkbox"/>	100
17	FM	User3	<input type="checkbox"/>	100
18	FM	User4	<input type="checkbox"/>	100
19	FM	User5	<input type="checkbox"/>	100

4. Change the names of existing or new fields, switch the "Show" checkbox on or off to show/hide each field, change field size (in characters).
5. Press Close, then Ok.


FMECA grid will change its appearance.

These definitions are stored per each specific RAM Commander project.


18.3.4 Phase selection

FMECA Analysis may be performed differently for different mission phases/profiles. For example, some device may have different failure modes and their effects between ground operation and airborne operation - so you should create two different FMECA data sets, one for each phase.

You may define multiple phases on the "Phases" page of FMECA Library (see [FMECA Libraries](#) paragraph) - for each phase you should define its name, description and duration in hours:



Then you may select phase of current analysis and switch between phases on the Project Configuration screen:



When you start a new project, there is one default phase called "Default" with duration of 1 hour - change the phase definition, duration and add additional phases if required into FMECA Library.

18.4 FMECA Libraries

After the first time initialization of an FMECA project, you should define the settings of the **FMECA Libraries**. The RAM Commander FMECA module comes with a number of predefined libraries. The purpose of the libraries is to simplify and standardize the FMEA data input.

You can enter data in the following fields with the help of these libraries:

- **Phase** – at least one Phase should be in the library at the moment of FMEA initialization
- **Severity** – at least one Severity category with its rank should be in the library at the moment of FMEA initialization
- **Criticality Groups (A,B,C,D,E groups for Criticality Matix)**
- **End Effect** - at least one End Effect with its rank should be in the library at the moment of FMEA initialization
- **Failure Mode**
- **Cause**
- **Component** (FMD-97 by default)
- **Test**
- **Subtest**
- **Test Type** - at least one test type should be present in the library before you may create tests

18.4.1 To access FMECA libraries

From the **Library** menu, choose **FMECA Library**.

The **FMECA Library data** window opens with **Phase library** displayed.

The screenshot shows a window titled "Safety/FMECA Library Data" with a tabbed interface. The active tab is "End Effect". The table below is a representation of the data shown in the window.

#	End Effect Description	FMECA Severity	Safety Severity	S/R Objective	Design Objective
1	Mission Degredation	Marginal	Catastrophic	0.000	0.000
2	Mission Loss	Critical	Catastrophic	0.000	0.000
3	Communication Loss	Critical	Catastrophic	0.000	0.000
4	Communication Degradation	Marginal	Catastrophic	0.000	0.000
5	Maintainance Degradation	Minor	Catastrophic	0.000	0.000
6	Performance Degradation	Minor	Catastrophic	0.000	0.000
*					

At the bottom of the window, there is a "Phase:" dropdown menu set to "Operation" and a "Change Severity" button. At the very bottom, there are buttons for "Close", "Report", "Apply", and "Help".

You may switch between library pages and insert/edit/delete records in tables on each page.

18.4.2 FMECA Libraries Definition

You can access and change the FMECA libraries at any stage of working with a project. However, when working with your project for the first time, the following three libraries must have at least one value defined for: **Phase**, **Severity** and **End Effect**. The rest of the libraries are optional.

First Time Definition of the FMECA Libraries

1. Define / add additional phases and duration time for each phase.
2. Define / enter at least one **Severity** category.
3. You can define any number of Severity Categories later on in the project.

Important note: The order in which the Severity categories appear in the Severity library is important. The severity category appearing in the *first line of the severity library* is considered the *most critical* in the FMECA reports.

4. Define / enter at least one **End Effect** with the Severity rank.

Each End Effect must have a Severity Rank specified.

Optional FMECA Libraries

The **Failure Mode, Cause** and **Component Libraries** are optional. These three libraries may be very useful during the FMECA information input.

The **Failure Mode and Cause libraries** may contain user's definitions of the Failure Modes that may be selected from the list. This saves time for typing and allows you to achieve consistency of spelling.

The **Component library** serves for recording of the failure modes data for different components/parts based on the component's Family, Item Code and Type. The data is based on the FMD 97 publication from the RAC, USA.

Testability Analysis Libraries

Test Type, Test and **Indication Libraries** are used for the Testability Analysis.

At least one Test Type and Test must be defined when you start performing the Testability Analysis.

Subtest library contain different subtests for the user to select during Testability Analysis information input.

18.4.3 Generating a Library Report

You may generate a report of any library that displays its contents.

To generate a specific library report:

1. Open the FMECA library
2. Select a page with the name of the library you wish to display / print.
3. Choose the **Report** button.

18.4.4 Global Change of the End Effect Library


To make a global change of the Severity category for all End Effects with a certain severity category, choose the **Change Severity** button.

18.4.5 Copy FMECA Libraries Between Projects

Each RAM Commander project has its own FMECA library. You may reuse FMECA library data by copying libraries from one project to another.

To copy FMECA libraries from one project to another:

1. Open two projects and activate the product tree view for the source project.
2. From the **Library** menu, choose select **Copy Library**.
3. Select the target project and choose **OK**; the **Copy FMECA Library** dialog box opens.



4. From the **Copy FMECA Library** dialog box, select which parts of the library are to be copied and how they are to be copied: **Overwrite** or **Merge**.
5. Click **OK**.

18.5 Entering FMECA data for Item

RAM Commander FMECA grid displays FMECA data for the currently selected product tree item.

To provide FMECA data for the product tree item:

1. **Select the desired item** in the product tree.
2. **Specify the Failure Mode** - in the FMECA grid beneath the product tree:
 - a. type directly a Failure Mode in the "FM description" column and press Enter or Tab key.

#	FM			NHE			EE		
	Description	Alpha	Cause	IDN	Description	Beta	Description	Beta	Severity
	The failure								

or

- b. right-click the Failure Mode Description field and choose "Get from FM Library" to pick the description from the FMECA library

or

- c. right-click the Failure Mode Description field and choose "Get from Component Library" to get a list of standard Failure Modes from FMD-97 library (FMECA library, Component Library page) according to current item's Family and Item Code.

or

d. right-click the Failure Mode Description field and choose "Get from GPRD Library" to get a list of Failure Modes from GPRD library according to current item's Part Number.

3. Alpha, Cause and other fields will become editable and Next Higher Effect (NHE) column opens with its default display of "No effects" description:

#	FM			NHE			EE		
	Description	Alpha	Cause	IDN	Description	Beta	Description	Beta	Severity
1	The failure description	1.000		1.3	No effect	1.000			

4. **Provide Alpha value** (for Criticality mode). Use Alpha calculator (right click on Alpha cell, choose "Calculator for Alpha") if you have Lambda of failure mode and need to calculate its ratio (alpha). **Note that sum of failure mode alphas for specific product tree item should be equal to 1.**

5. Provide Cause description (if required):

a. type directly a Cause in the "Cause" column and press Enter or Tab key.

or

b. right-click the Failure Mode Description field and choose "Get from Cause Library" to pick the description from the FMECA library.

6. **Select Next Higher Assembly** and **specify the Next Higher Effect(s)** and it's conditional probability Beta. The NHE IDN field points to specific item in the product tree, which is affected by the Failure Mode. By default an FM affects the direct parent assembly, which is why the parent assembly ID will appear in the NHE IDN column. The NHE Description field should describe the effect of the Failure Mode on the affected assembly (IDN). See more about specifying Next Higher Effects in the [Entering NHE](#) paragraph later in this chapter.

7. **Specify the End Effect(s)** and it's conditional probability Beta:

a. Press the "..." button right to the End Effect field in the desired row . The popup window with list of all End Effects in the library will appear - choose the desired End Effect and double-click it.

or

b. right-click the EE Description field and choose "EE List" to pick the description from the FMECA library.

or

c. right-click the EE Description field and choose "Add to EE List" to add a new End Effect which is not located in the library. New EE dialog will appear - provide EE description and severity level and press Ok.

The severity rank of the EE is displayed. Note that the Severity of each specific End Effect is defined in the library and is always the same, no matter what is the reason of this End Effect (FM, NHE).

To enter **more than one End Effect** for a single NHE: enter the first EE as described above, then right-click the first EE, choose "Add EE" from the popup menu. New End Effect line will appear in the grid. Edit this line using the same procedure that was used for the first EE creation.

If more than one EE for a single FM/NHE is specified, **conditional probability Beta should be specified** for each EE. Sum of Betas for End Effects coming from single cause (FM-NHE) should not exceed 1 (and usually is equal to 1).

8. Specify **Detection** methods (if required) - see [Testability Analysis](#) Module paragraph later in this

chapter.

9. Provide additional information (Remarks, Compensating Provisions, Actions etc.) directly typing the data into corresponding cells of the FMECA data table:

FM			NHE			EE			Detection
Description	Alpha	Cause	IDN	Description	Beta	Description	Beta	Severity	
Bearing Failure	0.280		1.3	No movement	1.000	Communicatic Loss	1.000	II	Visual Inspection
Fail Run,After Strt	0.230		1.3	No movement	1.000	Communicatic Loss	1.000	II	Visual Inspection
Fails to Start	0.180		1.3	No movement	1.000	Communicatic Loss	1.000	II	Noise receive test -->>
Winding Failure	0.310		1.3	Wrong movement	1.000	Communicatic Degradation	1.000	III	

10. If you need to enter additional information and FMECA grid does not contain relevant fields for it, see "[FMECA Grid Customization](#)" paragraph earlier in this chapter.

Repeat the procedure above to enter all Failure Modes of all relevant Product Tree items.

18.5.1 Entering Next Higher Effects

During the FMECA analysis failure modes of product tree items should be specified. For each failure mode it's consequences should be specified - Next Higher Effects and End Effects. See [FMECA Basics](#) paragraph for more explanations and examples.

For one failure mode multiple NHE may be specified, for each NHE the affecting assembly should be specified.

RAM Commander FMECA allows very high flexibility of FM-NHE-EE chain definition and supports the following cases:

A. simplest case - Failure Mode has a single effect (NHE) on a single higher level assembly, which in turn has single effect on the whole system level (EE) - for example FM "A" causes NHE "B" which causes EE "C":

FM			NHE			EE		
Description	Alpha	Cause	IDN	Description	Beta	Description	Beta	Severity
A	1.000		1.3	B	1.000	C	1.000	II

B. Failure Mode affects an assembly other than the parent assembly (for example some failure of hydraulic system affects some assembly power engine system, or for example you wish to specify that component failure affects the whole system without specifying all the effects on the block/assembly/subsystem etc. of that component).

C. a single Failure Mode has multiple consequences (NHE) - for example failure mode "A" may

cause NHE "B" or NHE "C" or NHE "D", each with its own conditional probability:

FM			NHE		
Description	Alpha	Cause	IDN	Description	Beta
A	1.000		1.3	B	0.3
			...	C	0.7
			1.3		
			...		

D. Failure Mode consequences are described by a long FM-NHE-EE chain - for example Failure Mode "A" causes NHE "B" which in turn causes NHE "C" which in turn causes EE "D":

FM			NHE			NHE 2			EE		
Description	Alpha	Cause	IDN	Description	Beta	IDN	Description	Beta	Description	Beta	Severity
A	1.000		1.2.3	B	1.000	1.2	C	1.000	D	1.000	I
							

It is up to the user to take a decision about the product tree level where Failure Modes are specified and how (on which tree level and with which level detalization) their consequences (Next Higher Effects) are defined.

The next paragraphs will explain how to define all the mentioned FM-NHE-EE definition cases ([A](#), [B](#), [C](#), [D](#)).

18.5.1.1 To define a single NHE

1. After the failure mode input, NHE group of fields will become editable:

FM			NHE		
Description	Alpha	Cause	IDN	Description	Beta
failure mode	1.000		1.2.3	No effect	1.000
			...		

2. The NHE IDN field will point to the direct parent item of the selected item.

3. Enter the NHE description:

Select NHE Description cell and type in the text (removing the default "No effect" text).

or

Right-click the NHE Description cell, select "Get from FM Library" - the list of failures from the FMECA Library ("Failure Mode" page) will appear. Select one and press Ok.

or

Right-click the NHE Description cell, select "NHE List" - the list of Next Higher Effects already defined in the project (and not in the library) will appear. Select one and press Ok.

4. Now the End Effect group of fields will become editable - you may proceed filling other fields for this failure Mode:

FM			NHE			EE		
Description	Alpha	Cause	IDN	Description	Beta	Description	Beta	Severity
failure mode	1.000		1.2.3	effect of the failure mode	1.000	No effect	1.000	
			...					

18.5.1.2 To select affected assembly

1. Click on the IDN selection button <...> to the right of the FM; the NHA selection window opens.

#	FM			NHE		
	Description	Alpha	Cause	IDN	Description	Beta
1	A	1.000		1.2.3	No effect	1.000

- From the NHA Selection window, select the affected assembly.
- Choose OK.

Note There are some limitations in IDN selection: any item with already defined/inherent failure modes cannot be selected; also any IDN that may cause a loop in the FM-NHE-EE chain, cannot be selected.

18.5.1.3 To define multiple NHEs for a single FM

1. After the failure mode input, NHE group of fields will become editable:

FM			NHE		
Description	Alpha	Cause	IDN	Description	Beta
failure mode	1.000		1.2.3	No effect	1.000

2. Create the first NHE as described in paragraph [To define a single NHE](#) earlier in this chapter. The first NHE ("B" in this example) will appear:

#	FM			NHE			EE		
	Description	Alpha	Cause	IDN	Description	Beta	Description	Beta	Severity
1	A	1.000		1.2.3	B	1.000	No effect	1.000	

3. Right-click the related failure mode description cell ("A" in this case) and choose "Add NHE" from the popup menu. A new NHE line (related to the same FM "A") will appear:

#	FM			NHE			EE		
	Description	Alpha	Cause	IDN	Description	Beta	Description	Beta	Severity
1	A	1.000		1.2.3	B	1.000	No effect	1.000	
				1.2.3	No effect	1.000			

- Edit the NHE description as described in earlier in the [To define a single NHE](#) paragraph and change the IDN if required as described in the [To select affected assembly](#) paragraph.
- Enter conditional probability Beta for the new NHE. Total sum of Betas of effects of a single failure mode is usually equal to one:

#	FM			NHE			EE		
	Description	Alpha	Cause	IDN	Description	Beta	Description	Beta	Severity
1	A	1.000		1.2.3	B	0.300	D	1.000	I
				1.2.3	C	0.700	E	1.000	II

You may use the "Normalize Beta" function (right-click the FM description and select "Normalize Beta" from the popup menu) to change all Betas so that their sum is equal to 1.

6. Enter End Effect information of this new NHE, as described in [Entering FMECA data for Item](#) paragraph.

7. Proceed with steps 3-4 to enter all possible consequences of this Failure Mode, with conditional probability of each one of them.

18.5.1.4 To define NHE for NHE

When the product tree depth is more than 3 levels, the FM-NHE-EE consequences chain may be longer.

See the following example:

Ref.Des.	ID	Name	Qty
<input checked="" type="checkbox"/> Aircraft	1 ...		1
<input checked="" type="checkbox"/> System	1 ...		1
<input checked="" type="checkbox"/> Subsystem	1 ...		1
<input checked="" type="checkbox"/> Assembly	1 ...		1
<input checked="" type="checkbox"/> Block	1 ...		1
<input type="checkbox"/> Component	1 ...		1

#	FM		NHE	
	Description	Alpha	IDN	Description
1	failure 1	0.500	1.1.1.1.1	No effect
2	failure 2	0.500	1.1.1.1.1	No effect

You may specify how failures of Component affect Block, then how these effects affect Assembly, then how these effects affect Subsystem, etc. till the End Effect on Aircraft level.

You may also omit some product tree levels and for example specify the effect of Component failures on Block, then jump over some levels and specify directly the influence of block failures to the whole System level. It will reduce a number of work required but will not allow generation of FMECA reports on skipped levels (Assembly, Subsystem in this example).

To define NHE for NHE:

1. After the failure mode input, NHE group of fields will become editable:

FM		NHE		
Description	Alpha	IDN	Description	Beta
A	0.500	1.1.1.1.1	No effect	1.000

2. Create the first NHE as described in paragraph [To define a single NHE](#) earlier in this chapter. The

first NHE ("B" in this example) will appear:

FM		NHE			EE
Description	Alpha	IDN	Description	Beta	Description
A	0.500	1.1.1.1.1	B	1.000	No effect

3. To enter the first NHE ("B") consequences and effect on next higher assembly, right-click the NHE description cell ("B") and select "Add NHE" from the popup menu. The second NHE will appear:

#	FM		NHE			NHE 2			EE
	Description	Alpha	IDN	Description	Beta	IDN	Description	Beta	Description
1	A	0.500	1.1.1.1.1	B	1.000	1.1.1.1	No effect	1.000	

4. Edit the NHE description as described in earlier in the [To define a single NHE](#) paragraph and change the IDN if required as described in the [To select affected assembly](#) paragraph:

FM		NHE			NHE 2			EE		
Description	Alpha	IDN	Description	Beta	IDN	Description	Beta	Description	Beta	Severity
A	0.500	1.1.1.1.1	B	1.000	1.1.1.1	C	1.000	No effect	1.000	

For this example, if you wish to omit the "Assembly" level and specify the effect of NHE "B" on "System" level, click the "..." button in the IDN cell of "NHE 2" group and select "System" item from the product tree:

#	FM		NHE			NHE 2			EE		
	Description	Alpha	IDN	Description	Beta	IDN	Description	Beta	Description	Beta	Severity
1	A	0.500	1.1.1.1.1	B	1.000	1.1	C	1.000	D	1.000	II

7. Proceed with steps 3-4 to enter all the NHE chain.

8. Enter End Effect information for the last NHE, as described in [Entering FMECA data for Item](#) paragraph.

18.5.2 Additional operations in FMECA grid

Spelling Checker

You may use spelling checker in FMECA grid - see [Spelling checker](#) paragraph in [RAM Commander Fundamentals](#) chapter.

Copy/Delete Items

You may copy and delete items in the product tree (see the [Product Tree Building](#) chapter for more information) . These operations affect FMECA data too:

- *Copy inside project:* When copying inside the project, the item copied will include all FMECA and TAM information. The item is copied with information for **all** existing phases.
- *Copy between projects:* When copying between projects, the item copied will include all FMECA and TAM information. Any necessary/related data from the FMECA library will also be copied. Items are copied with information from the current phase from the source project to the current phase into the destination project.
- *Item Delete:* When an item is deleted, everything related to the item's FMECA and TAM information is deleted including all **unshared chains** up to the EE.

Copy FMECA processor data between items

You may copy FMECA data from one item to another in the same project or in different projects. To copy FMECA data,

1. Open two product tree windows:
 - a. To copy between items of the same project, choose "New window" from the "Window" menu to open another product tree view window of the same project
 - b. To copy between items of different projects, go to the projects list and open the product tree view window of another project.
2. Select items in both windows
3. Choose FMECA mode in both windows
4. Select window with the source information
5. From the Tree menu, choose "Copy processor data".

Copy FMECA data between Phases

- If you are performing FMECA analysis for several phases and wish to copy all FMECA data from the existing phase to a new empty phase, use <Copy all FMECA data> option of the Phases library.



Copy all FMECA data

- If you are performing FMECA analysis for several phases and wish to copy FMECA data from the existing phase to a new empty phase for specific item only, perform the following actions:
 1. Open project window, choose phase you wish to use as FMECA data source
 2. select the required item
 3. choose "Copy processor data" from the tree menu
 4. choose target phase where you wish to copy data to
 5. press ok


Popup menus

The FMECA grid is manipulated by invoking pop-up menus with a right mouse click. Each field/column in the FMECA grid has a different pop-up menu displaying the available options.

The next paragraphs provide explanation to these options.

18.5.2.1 FM Column Pop-up Menu Options

Right-click the Failure mode description cell to get options menu:





The table below explains these options:

Option	Action
Get from FM Library	Opens the Failure Modes Library for viewing. Select an FM from the Failure Modes Library to be inserted into the current FM cell.
Add to FM Library	Adds the current FM to the Failure Modes Library.
Get from Component Library	Retrieves all FMs corresponding to the current product tree item in the FMECA Component Library. Note The FMECA Component Library consists of the standard failure

Option	Action
	modes defined for the specific Family, Item Code and Type of product tree item (by default FMD-97). If one or more of the standard FMs in the FM list already appears in the FMECA grid, it will be ignored.
Get from GPRD Library	Retrieves all FMs corresponding to the current product tree item's Part Number in the GPRD Library.
Add NHE	Adds an additional NHE for the current FM. Note A new "No effect" NHE is added by default. If the FM already has a "No effect" NHE, you may not add a new NHE until "No effect" is changed to the "real" effect. In another words, each FM can have only one effect defined as "No effect".
Failure Cause	For lowest level FMECA items (LFI), opens the "Cause" window for typing in required data. For higher level FMECA Items (HFI), opens the list of causes from the lowest levels.
Delete FM	Deletes the current FM and corresponding unshared chains up to the EE.
Delete all FMs	Deletes all Failure Modes of the selected product tree item and corresponding unshared chains up to the EE.
Maintenance/RCM	Open corrective and preventive maintenance procedures related to the selected Failure Mode (see Maintainability Module for more information)
Show connected Fault Trees	Displays a list of fault trees containing Basic Events linked to the selected product tree item and Failure Mode.
Normalize Alpha	Normalizes alpha for all item FMs to a total of 1. The normalization works proportionally according to the current alpha's values.
Equalize Alpha	Puts the same Alpha value for all Failure Modes so that their total sum is 1.
Normalize Beta	Normalizes beta for all NHE of current FM to a total of 1. The normalization works proportionally according to the current beta's values.

18.5.2.2 Alpha Column Pop-up Menu Options

Option	Action
Calculator for Alpha	Allows alpha calculation using known item FR and failure specific FR: 
Sum Alpha	Displays total sum of Alphas for all FMs of the current product tree item:

Option	Action
	

18.5.2.3 NHE Column Pop-up Menu Options

Option	Action
Get from FM Library	Opens the Failure Modes Library. Select an FM from the Failure Modes Library to be inserted into the current NHE cell.
Add to FM Library	Adds the current NHE to the Failure Modes Library.
NHE List	Opens the NHE list corresponding to the current IDN i.e. lists all FMs of the Next Higher Assembly (NHA) only for this NHA.
Add NHE	When the current NHE is the last before the EE, adds an additional column to the FM-NHE-EE chain. If the NHA corresponds to the first level in the product tree, then the NHA Selection window opens. When the current NHE has its own NHEs (more than one NHE column), adds the additional NHE to the current NHE. The new NHE will always be defined as "No effect". Note When the NHE already has an NHE defined as "No effect", you cannot add a new NHE until "No effect" has been changed to the "real" effect. In another words, each NHE can have only one effect defined as "No effect".
Delete NHE	Deletes the current NHE and corresponding unshared chains up to the EE.

18.5.2.4 End Effect Column Pop-up Menu Options

Option	Action
EE List	Displays End Effects library. Select EE from the list to be inserted into the current EE cell
Add EE	Adds an additional End Effect to the NHE. Note A new End Effect is always defined as "No effect". When an NHE already has an End Effect defined as "No effect", you may not add a new End Effect until "No effect" has been changed to a "real" end effect. In other words, each NHE can have only one end effect defined as "No effect".

Option	Action
Add to EE List	Adds a new End Effect to the End Effect list. Note The new End Effect will be copied into the EE Description column.
Delete EE	Deletes the current End Effect.

18.6 Testability Analysis Module (TAM)

Testability Analysis Module (TAM) allows definition of detection methods (tests) for each failure mode. Test indications and efficiency may also be specified.


With this information RAM Commander may provide the following:

- list of Undetectable (Latent or Dormant) events, their probabilities and MTBF
- calculate test coverage for system and system parts
- generate ambiguity groups report
- generate optimal fault isolation procedure with replace recommendations
- and more.

The starting condition for this analysis is that there must be at least one test defined in the FMECA library. Test types (e.g. Visual, BIT etc.) should be also defined before you start working with tests. TAM information is always entered per failure mode.

18.6.1 To define tests for FM

1. Select the desired FM.
2. In the **Detection** column, press the <...> button; the **Testability** dialog box opens. Left part of the screen displays tests library, the right part of the screen displays tests selected for the specific Failure Mode:



3. In the **Testability** dialog box, you individually select a test from the list of tests (the left part of the screen) by clicking on them or select or deselect them as a group by right-clicking. All tests thus selected will be marked with a "V" and will be linked as a group to the FM when you click the -> button. This selection will remain for all TAM analyses and can be used for other FMs with the same tests list.

4. For each linked test, you can define **Indication** by choosing an item from the drop-down list and **Efficiency** by entering the data directly to the grid.


5. Press Close button to return to the FMECA grid. The first selected test will be displayed in the "Detection" field. If there is more than one test, the first name will be followed by "-->>" symbol to indicate multiple tests available but not shown.

To remove a test from the current FM

1. Select the desired test on the right part of the **Testability** dialog box and click the <- button.
2. To remove all tests from the FM, click the <<- button.
3. Click **Close**.

18.6.2 Testability Analysis Reports

Testability module provides multiple reports located in the "Testability" group of FMECA report:



Report types are described in the table below:

Report subtype	Description
Testability Information	Item, Failure Mode, EE, Severity, Tests information
Testability Information (Quantitative)	Item, Failure Mode, EE, Severity, FM Ratio, FM Criticality, Tests information
Testability Data	Failure Modes/Tests matrix with indication and efficiency on each intersection
Undetectable FM	List of undetectable FMs, with Expected number of failures, contribution to severity and MTBF for each FM
Detectable FM	List of tests, for each test - list of detectable Failure modes with test information for each, including test type, test level, efficiency etc.
Detectable FM - Quantitative	List of tests, for each test - list of detectable Failure modes with test information for each, including test type, test level, efficiency, failure effect probability etc.
Coverage	Coverage calculated for the whole system and all system blocks, with total and detectable Failure Rates etc.
Fault Isolation	Fault Isolation Resolution report with ambiguity groups
Fault Isolation with Replace Recommendations	Fault Isolation Resolution report with ambiguity groups and replace recommendations for each test
Fault Isolation with Replace Recommendations including End Effect	Fault Isolation Resolution report with ambiguity groups and replace recommendations for each test, including EE information
Isolation Tree	Optimal isolation tree (troubleshooting diagram) with optimized sequence of tests and replace recommendations:

Report subtype	Description
	<pre> graph TD Start([Start]) --> LBR1[Loop-back transmitter-receiver] LBR1 --> D9{9_*} D9 -- Not OK --> NR1[Noise receive test] NR1 --> D7{7_*} D7 -- Not OK --> Receiver([Receiver]) D7 -- Ok --> LBR2[Loop-back transmitter-receiver] LBR2 --> D8{8_*} D8 -- Not OK --> MS([Main Switch]) D8 -- Ok --> PS([PS]) PS --> Transmitter([Transmitter]) D9 -- Ok --> NR2[Noise receive test] NR2 --> D7b{7_*} D7b -- Not OK --> Motor([Motor]) </pre>
Isolation Tree per End Effect	Optimal isolation tree (troubleshooting diagram) for specific End Effect

To generate a Testability report:

From the **Reports** menu, choose **Tree**.


When the Criticality Analysis check box is not checked, you may choose only a non-quantitative report. The list of reports in this case is: Testability Information and Testability Data.

When the Criticality Analysis check box is checked, you can choose any of the existing reports.

Different TAM reports can be defined by selecting the Testability report subtype. These parameters delineate which information will be included in the report.

A desired set of tests may be selected for all reports. This selection will be the superposition of the Tests, Test Levels and Test Types. In addition, EE under analysis may be selected through Severity.

For a **Coverage** report:




Level of Replace: all items with the *Level of Replace* selected will be displayed in the report.

One level down: all items one level under the items selected by *Level of Replace* will be displayed in the report.

Lowest: all items from the lowest level will be displayed in the report.

For a **Fault Isolation** report:



Level of Replace: those items with the selected *Level of Replace* will be under analysis.

For System Level: when selected, the results will be displayed at the system level; otherwise the results will be displayed according to the *level of replace* selected above.

Note Both *Level of Repair* and *Level of Replace* must be defined in order for product tree items to produce Coverage and Fault Isolation reports.

18.7 Functional Blocks

According to the explanations and examples in the previous paragraphs, FMECA analysis is done on components/assemblies level. In addition, the analysis can be performed on the **functional blocks level**.

Inside one assembly, components can be grouped by functional blocks. In a functional block, functions are defined for a group of components. You can enter more than one functional block (FB)

for each component. In this way you can hide components and work (enter FM->NHE->EE chains etc.) with functional blocks. This significantly reduces the work required to enter Failure Modes for an assembly with a large number of small and insignificant components.


The Failure Rate of the functional block is equal to a total FR of all components included into the block.

18.7.1 To create functional blocks

1. Select an assembly.

<input type="checkbox"/>	Receiver	2 CN017016
<input checked="" type="checkbox"/>	C1-2	1 CKR
<input checked="" type="checkbox"/>	C3-5	2 CL
<input checked="" type="checkbox"/>	UR1	3 RZ
<input checked="" type="checkbox"/>	UR2	4 RZ
<input checked="" type="checkbox"/>	U1	5 74HC04
<input checked="" type="checkbox"/>	U4	6 74AS1035
<input checked="" type="checkbox"/>	U2	7 26LS32
<input checked="" type="checkbox"/>	U5	8 74LS123
<input checked="" type="checkbox"/>	U3	9 Z8001

2. Right-click on the assembly and choose **Edit** from the pop-up menu.
3. From the **Item Data** dialog box, choose to the **FMECA** tab. The **Functional Blocks** table is displayed.



4. Right-click on the table header and choose the **Add functional block** option from the pop-up menu.
5. In the **Item Function** dialog box, enter a name and a description of the function.

6. Click **OK**.

7. Repeat steps 3 - 5 to enter all the required functional blocks.
8. To group components by functional blocks, click on the corresponding check boxes which are the intersection of the specific component and functional block (FB):

Component	Function		
	Receive	Transmit	Signal
C1-2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
C3-5	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
UR1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
UR2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
U1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
U4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
U2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
U5	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
U3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
LD1	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

Each component may be attached to more than one functional block.

Failure rates of all components are distributed equally to all functions to which this component belongs (according to the selection). If component does not belong to any function, its failure rate is distributed equally to all functions. You need to perform the recalculation of a product tree to see failure rates of all functions.

In addition to default function failure rate calculation described above, there are two additional options for function FR calculation - the selection of desired option is performed by "Functional block FR source" selection on Item Data screen:


The available options are:

- **Underlying components - proportional FR ratios:** default option, illustrated above. Component FR is distributed equally to selected functions it belongs to.
- **Underlying components - custom FR ratios:** Component FR is distributed to functions according to specified ratio. Total ratio for each component should be equal to 1. Option allows to specify for example that FR of some component is distributed to functions as $0.3*FR$ for the first function and $0.7*FR$ for the second function.
- **Current item - custom FR ratios:** Used when the item under analysis has functions but does not have underlying components. So the FR of the item itself is distributed to functions with specified ratios.

9. Click **OK** to store the data.

18.7.2 Working with Functional Blocks

There are two product tree view modes for FMECA module – Normal View (with components) and Functional Blocks View (with FB displayed instead of assemblies). To switch from one mode to another, use **View** menu – **Normal/Functional Block View** mode. The example below shows the same assembly in two different view modes:



Normal View



Functional Blocks View

After choosing Functional Tree View, select the functional block and enter FMECA data in the same way as for components (as it was described above in the [Entering FMECA data](#) paragraph).

NOTE For a specific assembly, only one mode of FMECA analysis is allowed – either per components or per Functional Blocks. For different assemblies within the same project, both modes are allowed simultaneously.

18.8 FMECA Reports

FMECA module provides more than 30 different reports, divided into several groups:


Report Group	Description
FMEA	Item information, FM description, Next higher effect, End effect,

Report Group	Description
	Severity, Detection method, Compensating provisions, Remarks, Failure cause, Caused by item.
Criticality analysis	Item information, FM description, FM ratio (alpha), End Effect, Severity, Fail effect probability (beta), FM criticality (Cm), Remark.
End effect criticality numbers	IDN, Name, FR(FIT), Oper. Time, FM description, FM ratio (alpha), Severity, Point Criticality, Cumulative Criticality, End Effect, Fail effect probability (beta).
Criticality matrix	List and count of FM/items by severity and criticality.
Fault tree	Presentation of EE-NHE_FM chains in different forms (EE, all its causes (NHE), for each NHE all its causes (other NHE or FMs) etc.
NHE criticality	IDN, Name, FM Description, Max Severity, Failure Rate Data Source, Fail effect probability (beta), FM ratio (alpha), FR(FIT), Oper. Time, NHE criticality.
Testability	See Testability Analysis Reports earlier in this chapter.
Configuration control	Report for checking the consistency of FMECA data (total Alpha=1, total Beta=1, etc.)

In addition to these predefined reports, [Report Generator](#) may be also used to create very customizable reports.

18.8.1 To Generate an FMECA Report

From the **Reports** menu, choose **Tree**.
The Report Selection dialog box opens:



Note The fields displayed change according to the report type selected.

Several reports may be produced in FMECA.

When the Criticality Analysis check box in the Project Configuration dialog box is not checked, you can only choose non-quantitative reports. The list of reports in this case is FMEA and the Fault Tree.

When the Criticality Analysis check box is checked, you can choose any of the existing reports.

There are different parameters for each report that define which information will be included in the report.

See also "[Reports](#)" paragraph in the [RAM_Commander_Fundamentals](#) chapter for more general information about reports.

18.9 Import/Export

RAM Commander allows FMECA data import and export to and from fixed MS Excel file format.

Export and Import file contains product tree items, Failure modes with FM-NHE-EE chains, Testability data and FMECA libraries.

To Export data:

1. Select tree root (to export all tree) or specific branch (to export only this branch's FMECA data),
2. Select "FMECA Export" from Tools menu and choose file name for export.
3. Excel workbook will be created with multiple sheets in it:

- "FMECA" sheet - failure modes and effects

This sheet has the following structure:

- ItemID – string, hierarchical ID of tree element.
- Depth – numeric, depth of tree element in tree or in branch
- RefDes – string, Reference Designator of tree element
- Qty – numeric, Quantity
- FROper – numeric, Operating Failure Rate
- DutyCycle – numeric, Duty Cycle
- FM_name – string, failure mode name. Each item may have more than 1 failure mode, in this case each failure mode is a separate line in worksheet.
- Sev_rank – string, severity rank of the End Effect
- FM_Alpha – numeric, failure mode ratio
- FM_Cause – string, cause of the failure mode
- FM_compens – string, compensating provisions of the failure mode
- FM_remarks – string, remark for the failure mode
- NHE_ID – string, hierarchical ID of tree element for Next Higher Effect
- NHE_name – string, Name of the Next Higher Effect. Each Failure Mode may have more than 1 NHE, in this case each NHE is a separate line in a worksheet.
- NHE_Beta – numeric, NHE conditional probability

Failure Modes of highest level tree elements are End Effects. Please see example for project TUTORIAL:

	A	B	C	D	E	F	G	H
1	ItemID	Depth	RefDes	Qty	FROper	DutyCycle	FM_name	Sev_rank
2	1	0	TUTORIA	1	45.677	1	Maintainance Degradation	IV
3		0		0	0	0	Communication Degradation	III
4		0		0	0	0	Communication Loss	III
5	1.1	1	Pedestal	1	7.3083	1	Wrong movement	
6		0		0	0	0	No movement	
7		0		0	0	0	No Transmission	
8		0		0	0	0	Transmision with errors	
9	1.1.1	2	Antenna	1	6.6583	1	No Transmission	
10		0		0	0	0	Signal Leakage	
11		0		0	0	0	Spurious Transmis.	
12	1.1.2	2	Motor	1	0	1	Bearing Failure	
13		0		0	0	0	Fail Run,After Strt	
14		0		0	0	0	Fails to Start	
15		0		0	0	0	Winding Failure	
16	1.1.3	2	Bearing	1	0.65	1	Binding/Sticking	

- "TAM" sheet - Testability data

This sheet has the following structure:

- ItemID – string, Item hierarchical ID in tree
- FM_name – string, Failure Mode
- TestCode – numeric, code of the test (from test library) for current Item and Failure Mode
- Efficiency – numeric, test efficiency
- Indication – string, test indication

Here is an example for project TUTORIAL:

	A	B	C	D	E
1	ItemID	FM_name	TestCode	Efficiency	Indication
2	1.1.1	No Transmission	10	1	
3	1.1.2	Bearing Failure	10	1	
4		Fail Run,After Strt	10	1	
5		Fails to Start	10	1	
6	1.1.3	Binding/Sticking	10	1	
7		Excessive Play	10	1	
8	1.2.2.1	Total drive fail	4	1	Indication 1
9		Single sector data error	4	1	Indication 2
10	1.2.2.2	No Data reading	5	1	Indication 3
11	1.2.2.3	No Data reading	6	1	Indication 3
12		No Data writing	6	1	Indication 3

- **"Tests"** sheet - Test library

This sheet has the following structure:

- TestCode – numeric, code of the test in tests library
- TestName – string, test name
- TestLevel – string, test level first letter (O-Organizational, D-Depot, I-Intermediate, S-Supplier, M- Manufacturer)
- TestTypes – string, test types

Here is an example for project TUTORIAL:

	A	B	C	D
1	TestCode	TestName	TestLevel	TestTypes
2	4	Test 4	O	BIT
3	5	Test 5	O	BIT
4	6	Test 6	O	BIT
5	7	Test 7	O	BIT
6	8	Test 8	O	BIT
7	9	Test 9	O	BIT
8	10	Test 10	O	Visual


- **"FB"** sheet - List Functional Blocks
- **"FM sheet"** - Failure Modes list from FMECA library
- **"EE sheet"** - End Effects list from FMECA library
- **"Class sheet"** - Classifications list from FMECA library
- **"Phase sheet"** - Phases list from FMECA library
- **"Sever"** - Severities list from FMECA library
- **"SAF_SEV"** - Safety Severities list from FMECA library
- **"EE SAF"** - Safety Severities for ENd Effects, per phase - from FMECA library

This data may be used to export FMECA data to another software or to change the data in Excel and import it back to RAM Commander with function "FMECA Import". Please note that data format for import should be exactly as export format described above.

To Import data:

1. Perform data export at least once to get a file of required structure.
2. Change the received file or add information to that file or convert your existing Excel file format to the required format.
3. Activate RAM Commander product tree view, FMECA mode.
4. Select tree root or specific branch related to the FMECA data being imported
5. Select "FMECA Export" from the Tools menu.

6. Import setup dialog will appear:



Select what do you wish to import: Full FMECA data table or libraries only. For the libraries option, select which libraries you wish to import from the file.

7. Press Ok. Import process will be initiated.

There is also another FMECA data Export method using the [Report Generator](#) : Create customized report of required format with needed product tree and FMECA fields. Then you may generate the report and use "Publish in MS Excel" option of the report viewer to export the report to MS Excel.

18.9.1 Functional Blocks Import

In addition to exporting and importing the FMECA data, there is also an option to import the functional blocks of a specific single assembly together with mapping of components by functional blocks.

The file should have the following structure:

	A	B
1	ItemFBRefDes	ItemRefDes
2	Switching	U1
3	Switching	U9
4	Switching	U10
5	Switching	U13
6	Switching	L0-4
7	Switching	L5-6
8	Switching	SW1-2
9	Scrambling	U10
10	Scrambling	U12
11	Scrambling	U13

It should have a worksheet called "FB" with two columns: ItemFBRefDes with function name and ItemRefDes with component reference designator. All the referenced components should be present under the selected assembly, and assembly should not have underlying functions with names which are present in the Excel file.

To import this file:

1. Select the desired assembly.

2. Prepare the Excel file.
3. Remove the existing functions of the assembly.
4. Use the the Tools->"Import functional blocks" option to import the file.

Then you will be able to open the assembly and see the functional blocks with their relationships with components:

Component	Function		
	Receive	Transmit	Signal
C1-2	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
C3-5	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
UR1	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
UR2	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
U1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
U4	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
U2	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
U5	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
U3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
LD1	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>

18.10 Summary

The **FMECA** module is an advanced software tool for failure mode, effects, and criticality analysis. It includes many specialized features not found in any other failure mode and effects analysis software. The FMECA module provides you with powerful and convenient analysis techniques to identify failure modes during development. A thorough use of FMECA results in better products and more satisfied customers.


Chapter

19

Fault Tree Analysis

19 Fault Tree Analysis

RAM Commander's FTA module is the one of the unique features of the RAM Commander. It implements and summarizes the first-hand experience gained by the **A.L.D.** FTA experts in hundreds of projects using RAM Commander and other FTA software.



RAM Commander FTA is a powerful tool with the following features:

- Up-to-date, intuitive and powerful fault tree diagram interface allowing full control over the diagram: elements location, colors, styles, zooms, etc.
- Handy methods for diagram printing and simple Copy & Paste transfer to other applications
- Easy to use **Events Library**
- Calculation of **Unavailability at time t**, **Mean (Steady state) Unavailability** and **Minimal Cut Sets** generation
- Highly intelligent MCS **Cut-off** (truncation) for large fault trees calculation
- Calculation of **Importance and Sensitivity**
- Calculation of [Frequency](#), Intensity, [PFH/PFD](#) (IEC 61508) , [Lambda Equivalent](#) (EN 50129)
- BDD (Binary Decision Diagram) Calculation and visualization
- Customizable reports – FTA diagram, MCS, events library etc.
- Visualization of MCS on the fault tree
- Visual **True/False Propagation** of event states
- **Repeated Events Indication**
- Common Cause Failures (**CCF**) Support
- Link between **FTA** , **Reliability**, **Maintainability** and **FMECA** modules

- **Automatic creation of the fault tree from FMECA , FMEA and RBD**

19.1 FTA basics

Fault Trees are one of the most widely used methods in system reliability and failure probability analysis. A Fault Tree is a graphical representation of events in a hierarchical, tree-like structure. It is used to determine various combinations of hardware, software, and human error failures that could result in a specified risk or system failure. System failures are often referred to as top events. A deductive analysis using a Fault Tree begins with a general conclusion or hazard, which is displayed at the top of a hierarchical tree. This deductive analysis is the final event in a sequence of events for which the Fault Tree is used to determine if a failure will occur or, alternatively, can be used to stop the failure from occurring. The remainder of the Fault Tree represents parallel and sequential events that potentially could cause the conclusion or hazard to occur and the probability of this conclusion.

A **fault tree** is a graphical representation of a logical structure representing undesired events ("failures") and their causes. You create the logical structure by using gates and represent undesired events by using basic events. Reliability parameters are assigned to the basic events. Widely used in system reliability studies, fault tree analysis offers the ability to focus on an event of importance, such as a highly critical safety issue, and work to minimize its occurrence or consequence. The probability of the top-level event can then be determined by using mathematical techniques. The resulting fault tree diagram is a graphical representation of the chain of events in your system or process, built using events and logical gate configurations.

The main purpose of Fault Tree Analysis is to evaluate the probability of the top event using state-of-the-art analytical and/or statistical methods. These calculations involve system quantitative reliability and maintainability data, such as failure probability, failure rate, expected failure, down time, repair rate, etc.

Two types of analysis can be conducted using Fault Trees:








- **Qualitative Analysis:** performed by means of Minimal Cut Sets (MCS) building
- **Quantitative Analysis:** calculating the Absolute probabilities, i.e. the probabilities of system failures






Definition: A Cut Set is a collection of basic events that if all its events occur, the fault trees top event is guaranteed to occur.

A Minimal Cut Set is such **Cut Set** that, if any basic event is removed from the set, the remaining events collectively are no longer a cut set. A cut set that includes some other sets is not a minimal cut set.

For large trees, with a large number of identical events, the number of MCS may be very large increasing the calculation time immensely. In this case, **MCS Cut-off** is used. During the Cut-Off, some minimal cut sets, which barely affect the final result, can be deleted. Three Cut-Off parameters are the Max. MCS number for Cut-Off, Relative cut-off value and Relative Cut-Off order (see Building FTA diagrams, [Define FTA properties](#) paragraph). When the MCS count in calculated tree increases the Max. MCS number, the Cut Off process is performed. If the relative affect on the calculation result for the MCS is less than the Relative cut-off value, the MCS is deleted.

The following **FTA elements** are used and supported in the RAM Commander software:


	<p>OR gate - output event occurs if any of the input events occurs.</p>
	<p>AND gate - output event occurs only when all the input events occurs simultaneously.</p>
	<p>NAND gate – NOT AND operation</p>
	<p>NOR gate – NOT OR operation</p>
	<p>XOR gate – Exclusive OR operation</p>
	<p>K-out-of-N gate - output event occurs if K or more of the input events occurs</p>
	<p>Transfer gate – transfer to another tree (sub-tree)</p>

	<p>Basic event - represents a basic equipment fault or failure that requires no further development into more basic faults or failures.</p>
	<p>Latent (Dormant) event - similar to basic events but indicates the latent failure which is discovered by periodical tests.</p>
	<p>Undeveloped event - represents a fault event that is not examined further because information is unavailable or because its consequence is insignificant.</p>
	<p>House event – represents a condition or an event which is TRUE (ON) or FALSE (OFF) (false).</p>
	<p>Priority AND gate - output event occurs only when all the input events occurs in the specified order.</p>

Notes:

- In addition, NOT operation can be performed on gates and events.
- A diagram may contain unlimited number of free-positioned remark boxes with descriptive text and pictures.

FTA module is integrated with other RAM Commander modules - Reliability, FMECA and Safety. The picture below illustrates linkage between Product tree, FMECA, FTA and Safety (FHA) modules - FTA uses Reliability and FMECA data for basic events probabilities calculation, Safety module in turn uses FTA for failure probability calculation:




19.2 FTA module initiation

To enter the RAM Commander FTA module, do one of the following:

- In the list of projects, select a project, right-click and choose **FTA** from the pop-up menu.
- Open a project and choose **FTA** from the **Modules** menu.
- Open a project, click **Modules** at the left button-bar, and click the **FTA** button.

The FTA module screen is displayed with a list of existing FTA diagrams:



To edit an existing diagram, select it in the list and click **OK**.

To create a new diagram, enter its name in the edit box and click **OK**.

The FTA diagram screen will be displayed.

Then you may review or edit an existing diagram, build a new diagram, calculate, analyze the fault tree and print required reports.

You may also delete, rename and copy FT diagrams from the same screen with fault tree diagrams list.


19.3 Building FTA Diagrams

Please note several important facts about RAM Commander FTA module:

- Each RAM Commander project may contain multiple (unlimited number) of diagrams.
- Diagrams may be connected to each other using Transfer gates (each tree may contain Sub-Trees, which are referenced in the main tree using "Transfer" gates).
- All diagrams in the same project use the same basic events library.

After initiation of FTA module, list of FTA diagrams appear. Select an existing diagram or choose to create a new diagram and press **Ok**. Then FTA diagram window will appear.

Each FTA diagram window displays single Fault Tree. You may open several FTA windows simultaneously and switch between them.



A diagram consists of gates, events and remark items - you may create, edit, delete, copy&paste these diagram elements. Use the available options (scrolling, zooming, opening sub-trees, etc.) to obtain the best possible view of the diagram. A more in-depth explanation of each option is provided later in this chapter.

19.3.1 Creating a new Fault Tree

1. [Initiate the FTA module](#)
2. List of exiting diagrams will appear
3. Enter new diagram name and press Ok.
4. New diagram screen will appear, with only FTA top gate on the diagram.
5. [Define diagram properties.](#)
6. [Build the diagram](#) by adding gates, events, sub-diagrams etc.

19.3.2 Define FTA properties

To define the diagram properties:

- 1 From the **FTA diagram** menu, choose **Properties**.
Or
Double-click an empty (white) space on the diagram.
- 2 Define the following properties:

Field	Field description
Description	Enter the FTA Tree description in this text box.
Author	Enter the Author name or names in this text box.
Time	Enter the Mission time (hours) for Q(t) calculation in this text box.
Automatically rearrange the tree	Select this check box if you wish the diagram elements to be automatically rearranged after create/delete operations.
Automatically adjust node font	Select this check box if you wish the diagram element font to be automatically adjusted after creation or editing according to the size of displayed text.
Alignment	Click either Central or Left balanced to define the tree alignment (To select these options, the Automatic Arrangement check box should be selected.)
Show event details	Select this check box if you want to view basic event details (probability model, FR, MTTR etc.) for each basic/undeveloped event
Show codes	Select this check box if you want the element code to be displayed in the element box.
Show Q(mean)	Select this check box if you want the Qmean (mean unavailability, or steady state unavailability) to be calculated and displayed under the element box and in reports.
Show Q(t)	Select this check box if you want the Q(t) (unavailability at time t, or instantaneous, or point availability - probability that a system (or component) will be operational (up and running) at a specific time, t) to be calculated and displayed under the element box and in reports.
Max. MCS number for Cut-Off	Cut-off will be performed only if number of MCS is more than the value entered in this text box. The setting is global for current workstation.
Relative cut-off value	MCS will be deleted if the Q / Total Q (i.e. relative unavailability) is less than the value entered in this text box. The setting is global for current workstation.
Relative cut-off order	MCS will be deleted if its order is greater than the shortest MCS order + specified value. The setting is global for current workstation.
Sensitivity factor	Sensitivity Factor is used for high and low unavailability values for Sensitivity calculation; the default value is 10. The setting is global for current workstation.
Width	Default diagram node box width
Height	Default diagram node box height

19.3.3 FTA diagram building

When a new diagram is opened, the tree top event is created. You can now start the tree building by adding successors (child items) to the top event.

To add a successor (child) to the tree element:

1. Select the tree element and then right-click. Choose **Add Element** from the pop-up menu.

or

Select the tree element and press the **F7** key.

The FTA element data screen is displayed.

2. Select FTA Gate/Event type. Relevant fields on the data screen will be enabled.
3. Specify gate/event code, name and description. For Event (basic, undeveloped or house) specify event probability calculation type and parameters. See the list of parameters in the table below:

Field	Field description
Code	<p>Enter the element code in this text box. This should be unique for the diagram.</p> <p>Events with the same code are considered as identical during the calculation.</p> <p>For a gate, enter its code.</p> <p>For an event, enter the code for the new event or choose it from the list, if</p>

Field	Field description
	the event is already in the library. New node automatically receives the Code equal to the predecessor's node code plus the number of successors. For example, if top event's code is "AAA", the predecessors receive codes "AAA-1", "AAA-2", etc. This is only a default value and can be changed by user.
Name	Enter the element name in this text box.
Description	Enter a description for the element in this text box.
Negated	Select this check box if you want the gate or event to be negated (NOT operation applied).
K	Enter a value for K-out-of-N gate - K argument.
N	Enter a value for the N for K-out-of-N gate (calculated automatically by the number of gate's children)
Border style	Select a border style of the gate/event box (Solid, Dot, etc.) from the drop down list.
Background color	Select a background color of the element from the color palette.
Font	Select a font for the element code and name.
Foreground color	Select a foreground color of the element from the color palette.
Event type	Select an Event reliability model from the list (Probability, Frequency, Repaired, Unrepaired, etc.). See the detailed description of available models in the Basic Event Types paragraph.
Logical state	Select a Logical state for House events from the drop-down list.
FR	Select a Failure rate from the drop-down list (failures per million or billion of hours, depending on project settings).
FR multiplier	Enter a value for Failure Rate multiplier. (FR used in unavailability calculation is item FR * FR Multiplier.)
Probability q	Enter a value for Probability q.
Frequency f	Enter a value for Frequency F.
MTTR	Enter a value in hours for MTTR (Mean Time To Repair).
Test interval	Enter a value in hours for the Test interval (time between periodical tests).
Time to first test	Enter a value in hours for Time to first test.
Mission time	Enter a value in hours for the Mission time.
Q(t)	Calculated value for the Unavailability Q(t) - probability of failure at a given time point.
Q mean	Calculated value for the Probability or long-term steady-state average unavailability, Q.
Tree ID	For events, ID of linked element in Product Tree. Press the "Select" button next to the field to pick up product tree item from the product tree.

Field	Field description
FM number	For events, number of FMECA Failure Mode of linked element in Product Tree. Press the "Select" button next to the field to pick up specific failure mode from the list of linked product tree item's failure modes.
CCF Group	Code of Common Cause Failure Group the basic event belongs to. Use "Select" and "Clear" buttons near this field to add/remove it from the CCF Group.

4. Press Ok. Newly created event or gate will appear on the diagram.

To edit tree element, double-click on it, or right-click on it and choose **Edit** from the pop-up menu. Data screen described above is displayed.

19.3.4 Transfers

Transfer gates are used to connect diagrams and create nesting inside FTA diagrams.

With Transfer gates, a large diagram may be divided into smaller trees or a sub-tree can be inserted into the same or different tree multiple times.

You can perform the following actions with Transfer gates:

- **To add sub-tree to the current tree**, select the predecessor gate, right-click and choose "Add transfer to sub-tree". Then select the desired tree from the list.
- **To open the sub-diagram**, double-click the transfer gate in the diagram.
- **To change the sub-tree under the transfer**, select the transfer gate, right-click and choose **Edit** from the pop-up menu. In the **Edit** dialog box, click **Select** and choose the desired sub-tree from the list.
- To delete the transfer and insert the whole sub-tree into the current tree, select the transfer gate, right-click and choose **Expand sub-tree** from pop-up menu.
- To divide a part of a large tree into sub-tree, select tree element you wish to be a top gate of the sub-tree, right-click and choose **Transfer branch to sub-tree** from the pop-up menu. The Transfer gate and a new sub-tree are created.

19.3.5 Events library

All basic, undeveloped and house events that you assigned to the tree are added to the event library. In tree element item data screen, you may choose an event from the library by opening Code combo box or by clicking the ">" button to the right of it.

If you want to edit or view the Events Library, choose **Events** from the **Library** menu.

Code	Name	Description
Alternative transmitter failure		Alternative mobile radio station failure
Antenna failure		Communication antenna
Database failure-3	Motor - Fails to Start	Failure of item Motor ID 1.3.2 - Fails to Start
DB engine files absent		
DB engine registry record is bad		
HardDrive	Total drive fail	Failure of item HardDrive ID 1.2.2.1 - Total drive fail
Installation files bad		Installation files are absent, bad or damaged
Keyboard	Total keyboard fail	Failure of item Keyboard ID 1.2.1 - Total keyboard ...
License	License file absent	
Main Switch		Main Switch
Mother Board - CPU Fail		Failure of item MotherBrd ID 1.2.2.4 - CPU Fail
Mother Board - Memory Fail		Failure of item MotherBrd ID 1.2.3.4 - Data bit loss
Plug	Plug system failure	
Plug absent		Plug absent - plug is stolen or temporarily removed...
Plug driver failure		Plug driver failure - wrong driver, Windows service...
Port failure	Printer port or USB port failure	Printer port or USB port failure
PS	Power Supply	Power Supply
PS-1	PS	Power Supply
PS-2	PS	Power Supply
PS-3	PS	Power Supply
Receiver failure		Receiver Type 1
Receiver-1	Receiver	Receiver Type 1

Use the **Add**, **Edit** and **Delete** buttons to change library items. Use the **Print** button to print reports with events data.

NOTES:

- Data of events in the tree is not be immediately updated in the library, but only after the tree recalculation has been performed.
- All events in the tree with the same code correspond to the same event in the library. If you change one of them in the tree, all the events with the same code are updated in the tree and in the library. Such events are regarded as identical during the calculation.
- Basic events, linked to the tree product tree or/and FMECA by the Tree element ID or Failure Mode number, get their parameters (FR, MTTR) from corresponding product tree / FMECAelement during the linking. To update the basic event data later on, choose **Update events from RAM & FMECA** from the **Library** menu.

19.3.6 Delete elements

The following options are available for deleting tree elements:

- To delete only the selected element, select the element, right-click, choose **Delete element** from the pop-up menu. (If the gate element has its children deleted, all its children are then reconnected to the element's predecessor).
- To delete the whole branch, select the branch gate, right-click, and choose **Delete branch** from the pop-up menu, or simply press the **Delete** key.
- To delete all child elements of a specific gate, choose the gate, right-click, choose **Delete sub-levels** from the pop-up menu.

19.3.7 Copy & Paste

You can copy/paste selected element or elements inside the tree or between different Trees.

To copy and paste elements:

1. Select the items and then

Choose **Copy** from the **Item** menu

Or

Press **Ctrl+C**

Or

Right-click and select **Copy** from the pop-up menu.

2. Choose a tree to insert the items.
3. Select the tree element (gate) which will be the predecessor of the copied elements and then
4. Choose **Paste** from the **Item** menu

Or

Press **Ctrl+V**

Or


Right-click and choose **Paste** from the pop-up menu.

5. Copied items will appear at the target location.

Another Paste option (Special Paste) allows you to paste tree elements automatically by changing their codes. To use this option, perform steps 1 and 2 as described above. In step 3, choose **Paste Special...** instead of **Paste**. The dialog allowing for automatic changes of events and gates codes appears. Select the required options and press **OK**.


19.3.8 Remarks

Remarks clarify the fault tree diagram by allowing you to add descriptive text and pictures:



To create a remark:

1. Select any tree element (gate or event), right-click.
2. Choose **Add remark** from the pop-up menu. The **Remark** dialog box appears.



3. Enter the remark text in the textbox; choose the background and foreground colors, font and a picture (BMP format graphics file).
4. Click **OK**. The **Remark** box is placed on the diagram. You can select it and then resize it and/or change its location.

19.3.9 Automatic FTA building

RAM Commander allows you to automatically build FTA diagrams from other modules – FMECA , FMEA and RBD.

Choose **Build Fault Tree** from the **Tools** menu in both of these modules. Then you will need to provide the name of the new fault tree and this new fault tree will be created.

19.3.10 Print preview, Print, Zoom

Use the **FTA** menu options to view print preview, print the tree, or zoom the diagram on the screen.

'-' and '+' keys on Numeric keyboard also act as **Zoom in/Zoom out** keys.

The following is a list of the **FTA printing options** in RAM Commander:

- **Print:** The whole tree is printed on a single piece of paper. Use this option when you have a normal size tree with no sub-trees.
- **Print tree + sub-trees:** The whole tree is printed as well as all of its sub- diagrams. Each tree is printed on a separate piece of paper. Use this option when you have a normal size tree with average size sub-trees.
- **Print the selected branch only:** Use this option to print only the selected branch without the rest of the tree. Branch parent gate should be selected.
- **Print + automatic separation to pages:** Use this option when you have a large tree which doesn't fit on a single page. RAM Commander automatically divides this large tree to smaller sub-trees in the most optimal way and prints them separately.

To adjust the **Page Orientation** for tree printing, select one of the following options from the **FTA** menu:

- Landscape
- Portrait
- Automatic: This is the default setting and allows RAM Commander to choose the most suitable page orientation for each diagram according to its layout.

Print FTA and all it's sub-trees – do not print the same sub-tree multiple times

The automatic hierarchical printing is improved – now the same sub tree is printed only once, even if it is used several times in different transfer gates.

19.3.11 Export Diagram as Picture

Export to Clipboard

You can insert the FTA tree as a picture into another application (Word, Excel, PowerPoint, etc.).

To insert the FTA tree into another application:

- 1 Choose **Export to Clipboard** from the **FTA** menu. The diagram is moved to the Clipboard.
- 2 Open another application.
- 3 Select where you want to paste the diagram and press Ctrl + V or choose **Paste** from the **Edit** menu. The diagram is copied into the application.

Export FTA + all its sub trees to MS Word

Use this option to create an MS Word report with the current Fault Tree and all its sub-trees, including page numbering, links between pages etc.

Choose "Export to file..." - "Export tree + subtrees to MS Word" from the "FTA Diagram" menu. Then choose MS Word template (you may customize or create your own template) and press "Select" button. MS Word document will be automatically generated by RAM Commander.

Export FTA + all its sub trees to WMF (Windows Meta File)

Use this option to export currently open Fault Tree (alone or with all its sub trees) to the Windows Metafile. You may later insert this file/files into another software – MS Word, Excel, Visio etc. The picture you get is not static but is a vector graphics set, which may be freely resized without quality loss and may be edited in MS Word, MS Excel, Visio etc.

Use FTA menu, "Export to File ..." option to use this feature.

19.3.12 Using Common Cause Failures

Fault Tree may contain multiple failures (basic events) which has common cause failure (like parts manufactured by the same manufacturer, or parts receiving power from the same power supply, or installed at the same zone of aircraft etc.). To take that into consideration we should include the "Common Cause Failure" for these failures into calculation. It is done using Common Cause Failure approach: for each group of basic events with common cause the "CCF Group" should be created, and corresponding basic events should be connected to that group.

Then "Beta factor" for the CCF Group should be set. Beta factor is what fraction of basic event probability would represent a common cause threat. Or in other words, when you define Beta = 0.05 for some CCF Group and maximal probability of basic event in this CCF Group is 0.1 you mean that $0.1 * 0.05 = 0.005$ is the probability that the common cause failure will occur and will cause all basic events in that CCF Group to occur as well.

During the FTA calculation each basic event belonging to some CCF Group will be connected through "OR" gate with its CCF Group, which means that or basic event alone will occur or CCF will occur (in other words, basic event A belonging to CCF group X will be replaced with "A OR X" expression).

Probability of each basic event in CCF group will be $Q_i = (q - \text{Beta}) * Q_i$, where Beta is beta factor and Q_i is event i total original unavailability.

Probability of CCF Group will be $Q_{ccf} = \text{Beta} * Q_{\max}$, where Q_{\max} is highest unavailability between unavailability values of events in this CCF group.

Project may have multiple CCF Groups. Each basic event may belong to a single CCF Group.

To define a CCF Group:

- Select "CCF Groups" from the "Library" menu – list of groups will appear.
- Press "Add" button – new CCF Group screen will appear:

CCF group

Code: Pwer Supplies

Name:

Description:

Model: Beta

Model Parameters: Beta 0.05

Event List

Code	Name	Description
PS-1	PS	Power Supply
PS-2	PS	Power Supply
PS-3	PS	Power Supply

Define group code (unique), name, description and Beta Factor.

- Use Add and Delete buttons to link basic events from basic events library to the group.
- Press Ok button to save your changes.

Repeat the procedure to add more CCF Groups. You may also edit and delete groups.

Basic Event data dialog has "CCF Group" field with "Select" and "Clear" button next to it – use these buttons to add/remove specific basic event to CCF Group from basic events data dialog.

19.3.13 Gobal Change

"Global change - Special functions" option allows to perform a number of predefined specific operations which may affect all fault trees, all gates or basic events.

"Global change - Special functions" dialog is divided to a number of blocks, each one performs some specific operation:

Copy event/gate name to description

FTA Global Change - Special Functions

Copy Name to Description (events, gates)

Only If Description is empty

Copy

This option goes through the list of all basic events and all fault tree gates and copies information from the Name field to the Description field. Contents of description field are overwritten by the contents of the Name field. If you choose the "Only if description is empty" checkbox, the existing descriptions will not be overwritten.

Change description using Code and Name (events, gates)

Change Description using Code and Name (events, gates)

Pattern:

Use <Description>, <Name>, <Code> in pattern

This option allows you to re-write all descriptions of all events and gates by using some user-defined pattern. Pattern may contain 3 placeholders - <Description>, <Name> and <Code>. For example, if you specify the pattern like "Code: <Code>; Name: <Name>", then RAM Commander will apply this pattern to each gate and event and replace the placeholders with actual values of code and name. For example, if you have an event where Code field value "U12DBL" and Name field value is "U12 Data Bit Loss", and you run a global change using template "Code: <Code>; Name: <Name>" then its description will be replaced with "Code: U12DBL; Name: U12 Data Bit Loss". Set up the template and press the Change button.

Change basic event codes

Change Basic Event Codes

Pattern:

Use <ID> in pattern

This option gives you possibility to recodify all the basic events in your database, using template. The template may contain any symbols and also an <ID> placeholder which will be replaced by event's unique number by order in event's list. For example, with the default template shown above, all the events in your database will get codes like BE1, BE2 etc. Set up the template and press the Change button.

Change gate codes

Change Gate Codes

Pattern:

Use <SequentialID>, <HierarchicalID>, <ID>, <RootCode>, <TreeName>, <TreeID>, <TreeSequentialID> in pattern

Similar to previous option, but lets you change the codes of all gates in all your fault trees. You also need to specify the template, which in this case may contain multiple different placeholders to compose the code:

<RootCode> is replaced with the code of a root gate of your tree.

<SequentialID> is replaced by number by order of your gate in tree, like 1,2,3,4 etc.

<HierarchicalID> is replaced by hierarchical ID of your gate in tree, for root it is 1, for root's first child it is 1.1, for root's second child it is 1.2, for the third child of root's second child it is 1.2.3 etc.


<ID> is internal system ID for the gate

<TreeName> is the name of the fault tree

<TreeID> is internal unique Id of the fault tree

<TreeSequentialID> is number by order of the fault tree in the list of fault trees.

You may see an example of a fault tree after this function execution using the template "**<RootCode>-<HierarchicalID>**" :



(pay attention to yellow logical gate codes).
Compose the pattern and press Change.

Change Fault Tree Parameters

Change tree parameters

Box Height: *	Start cut-off if number of MCS more than: *
Box Width: *	Relative Cut-off value (default value 1e-6): *
Time: *	Relative Cut-off order: *


Put * to leave current value

Change

This options allows changing fault tree parameters like box sizes, time, cut-off. Set value in desired field, leave asterisk in fields you do not wish to change. Then press Change button. The update will affect all fault trees.

Replace one basic event to another

There are cases when it is required to replace all occurrences of some basic event in all fault trees to another basic event. For example, you have many fault trees with inclusion of basic event "A". At some stage you understand that you need to replace this basic event A with another event A1, while leaving the event A unchanged in the library. Is is possible using this option:



Replace one basic event with another in all trees
Scan all trees, replace all inclusions of event with code
to event with code

First field should contain the code of the event you wish to be removed (like "A" in example above), second field should contain the code of the event you wish to be inserted (like "B" in the example above). Then press Change button.

Note: This Global change option should be used by advanced users only and with caution. Changes may affect all the events/gates/fault trees and are not undoable.

19.3.14 Importing Fault Trees

RAM Commander supports Fault Tree import from other FTA software tools - RiskSpectrum, Isograph Fault Tree +, CAFTA and Aralia Simtree. Import options may be found in the Tools menu of FTA module.

19.3.14.1 Import FT from RiskSpectrum

RAM Commander may import single fault trees from RiskSpectrum.

Import is performed from "RSA" file which should be prepared using RiskSpectrum software before importing in to RAM Commander.

To import RiskSpectrum fault tree into the RAM Commander:

1. Open the desired project and database.
2. Open the list of fault trees, create new or open any FT.
3. Choose "Import from RiskSpectrum" option from the Tools menu.
4. Select the RSA file exported from the RiskSpectrum.
5. Fault tree will be imported and you will get message about import result.


19.3.14.2 Import FT from Isograph FT+

RAM Commander may import single fault trees from Isograph FaultTree +.

Import is performed from Excel file which should be previously prepared inside the Isograph Fault Tree+ software, using the "Export" feature.

To perform the export of the fault tree from Isograph Fault Tree+ software:


1. Open Fault tree
2. Choose File->Export option
3. Create Excel template with FT Events, FT Gates and other application tables:



The tables you need to include are:

- For Isograph FaultTree+ version 10 - FT Events, FT Generic Models, FT Gates, FT Common Cause Failures.
- For Isograph FaultTree+ version 11 - (RBDFTETProjectOptions, FailureModels, PrimaryEvents, Gates) or (FT Events, FT Generic Models, FT Gates, FT Common Cause Failures).

For each table, you should select all the available columns to be exported:



4. Perform the export using this template, creating Excel (XLS) file.

To import Isograph FT+ fault tree into the RAM Commander:

1. Open the desired project and database.

2. Open the list of fault trees, create new or open any FT.
3. Choose "Import from Isograph Fault Tree+" option from the Tools menu.
4. Select the previously created Excel file.
5. Fault tree will be imported and you will get message about import result.

19.3.14.3 Import FT from CAFTA

RAM Commander may import single fault trees from CAFTA.

It needs two CAFTA files to import data:


- CAFTA Database file (*.rr file) containing basic events and gates data
It is native CAFTA file, you do not need to prepare it for import.
- Fault tree file (*.FRE file) containing fault tree structure.
It is not native CAFTA file. CAFTA stores fault trees in *.CAF files and provides export of CAF files to FRE files. You need to perform this export before trying to import the fault tree into ISA Tool.

To prepare CAFTA fault tree for import into ISA Tool:

1. Open Fault Tree in CAFTA
2. Select File->Save as...
3. Choose FRE format
4. Specify FT file name.
5. FRE file will be created.

To import CAFTA fault tree into RAM Commander:

1. Open the desired project.
2. Open the list of fault trees, create a new or open any FT
3. Choose "Import from CAFTA" option from the Tools menu.
4. Input parameters screen will appear:



5. Select the required RR and FRE files and press Ok.
6. Fault tree will be imported and you will get message about import result.

Note that the imported fault tree is not exactly the same as it was in CAFTA. Events types are changed and tree may be composed of multiple sub-trees in case that the original CAFTA tree had repeated gates.

19.3.14.4 Import FT from Aralia Simtree

RAM Commander may import single fault trees from Aralia Simtree.

Import is performed from "DAG" file (SimTree compatibility file V2.1000) which should be prepared using Aralia software before importing in to RAM Commander.

To import Aralia Simtree fault tree into the RAM Commander:

1. Open the desired project and database.
2. Open the list of fault trees, create new or open any FT.
3. Choose "Import from Aralia Simtree" option from the Tools menu.
4. Select the DAG file exported from the Aralia.
5. Fault tree will be imported and you will get message about import result.

19.4 Analysis & Calculation

RAM Commander provides different ways of Fault Tree top gate probability calculation:

Calculation type	Description	How to start
Minimal Cut Sets Calculation	Default calculation mode. Quick, deals with large trees, but approximate. Allows qualitative MCS analysis, Importance/Sensitivity analysis and more.	" MCS Calculation " from the calculation menu - see the related paragraph later.
Monte-Carlo simulation	Suitable for trees with dynamic gates (Priority AND gate).	Calculation menu->Explore->Monte-Carlo Simulation
Simple calculation	Arithmetical calculation of the tree according to the logical laws, without considering identical events.	Calculation menu->Explore->Simple calculation
Bayes formula	Exact calculation of the tree using Bayes formula, suitable for small trees with low number of identical events (less than 15).	Calculation menu->Explore->Exact calculation-Bayes formula
BDD Calculation	Calculation with the help of Binary Decision Diagram Generation. Suitable for trees with only OR/AND logical gates (without K/N and NOT). More precise than MCS Calculation, but does not generate the MCS list.	Calculation menu->Explore->BDD Calculation

For all calculation types, basic event probabilities should be defined and calculated, using several event probability models (constant probability, unrepairable, repairable, latent etc.). See the "[Basic Event Types](#)" paragraph for more information about basic event probability models.

In addition to calculation of FTA top gate probability, you may calculate intermediary gate

probabilities, perform [Importance / Sensitivity Analysis](#) , perform [FALSE/TRUE Propagation](#), get Unavailability Curve and a lot of different FTA reports and graphs.

19.4.1 Basic Event Types

RAM Commander allows several types of Basic Event reliability model. The description of each model and calculation formulas is given below.

#	Basic Event Type	Input Parameters	Description	Unavailability Q (t)	Mean Unavailability Q mean	Frequency (unconditional failure intensity) w (t)
1.	Probability	Probability (q)	Constant probability, not depends on mission time. Failure probability on demand.	q	q	0
2.	Frequency	Frequency (f)	Frequency. Events occur with a constant frequency (rate).	0	0	f
3.	Constant mission time	FR (λ) Probability (q) Mission time (T_m)	Probability of event linked to element which works during some constant mission time, not depends on mission time	$1 - (1-q) \cdot \exp(-\lambda T_m)$	$1 - (1-q) \cdot \exp(-\lambda T_m)$	0
4.	Repairable	FR (λ) Probability (q) MTTR ($\mu=1/\text{MTTR}$)	Repairable element with known FR and MTTR. Failures are detected immediately.	$q \cdot \exp(-(\lambda+\mu)t) + (\lambda/(\lambda+\mu)) \cdot [1 - \exp(-(\lambda+\mu)t)]$	$\lambda / (\lambda + \mu)$	$\lambda \cdot (1-Q(t))$
5.	Unrepairable	FR (λ) Probability (q)	Unrepairable element with known FR	$1 - (1-q) \cdot \exp(-\lambda t)$ (if $\lambda < 1e-15$, simplified formula $P=\lambda t$ is used)	1	$\lambda \cdot (1-Q(t))$
6.	Periodical tests	FR (λ) Probability (q) MTTR ($\mu=1/\text{MTTR}$)	Latent event linked to repairable element being inspected periodically, with	For Formula see Table 2	For Formula see Table 3	$\lambda \cdot (1-Q(t))$

#	Basic Event Type	Input Parameters	Description	Unavailability Q (t)	Mean Unavailability Q mean	Frequency (unconditional failure intensity) w (t)
		Test interval (Ti) Time to first test (Tf)	known FR, MTTR and test interval.			
7	Latent	FR (λ) Probability (q) Test interval (Ti)	Latent event with known FR and inspection time. Element is not repairable during the mission.	$1 - (1-q)*\exp(-\lambda Ti)$	$1 - (1-q)*\exp(-\lambda Ti)$	$\lambda*(1-Q(t))$
8	Average probability per mission hour	Average probability/hour (q)	Average probability of event during average mission (flight) hour. Linked element is unrepairable during the mission.	$1 - (1-q)^t$	1	0
9	Periodical Tests #2	FR (λ) Probability (q) MTTR ($\mu=1/MTTR$) Test interval (Ti) Time to first test (Tf)	Extends the "Periodical tests" model, suits wider range of cases. Recommended instead of "Periodical tests".	Algorithm with different formulas for different cases.	Algorithm with different formulas for different cases.	Algorithm with different formulas for different cases.

Table 1: Basic Events Calculation

Formula #	Condition	Unavailability Q(t)
1.	$t < Tf$	$1 - (1-q)*\exp(-\lambda t)$
2.	$t = Tf + nTi$	$1 - (1-q)*\exp(-\lambda Ti)$
3.	$Tf + nTi < t \leq Tf + nTi + MTTR$	$1 - (1-q)*\exp(-\lambda Ti) + [(1-q)*\exp(-\lambda Ti)] * [1 - (1-q)*\exp(-\lambda(t1))]$ (t1-time since the last test)
4.	$Tf + nTi + MTTR < t < Tf + nTi + Ti$	$1 - (1-q)*\exp(-\lambda(t1))$ (t1-time since the last test)

Table 2: Unavailability Calculation for Periodical Tests

Formula #	Mean Unavailability Qmean
1.	$q + (1 - q) * (1 - (1 / \lambda T_i) * (1 - \exp(-\lambda T_i))) + (q + (1 - q) * (1 - \exp(-\lambda T_i))) * (MTTR / T_i)$

Table 3: Mean Unavailability Calculation for Periodical Tests

19.4.2 MCS Calculation

MCS Calculation is the default Fault Tree calculation method in RAM Commander.

To calculate the tree:

1. Choose **MCS calculation** from the **Calculation** menu.
2. Calculation parameters dialog will appear. See the table below for information about possible calculation options and parameters:

[Easary-Proschan Formula](#)

FTA Calculation parameters explanation:

Parameter name	Description
Calculation type	Quick calculation uses previous calculation results if possible,

Parameter name	Description
	Recalculation ignores previous calculation results
Approximation type	Type of MCS sum calculation and approximation: <ul style="list-style-type: none"> • Easary-Prochan formula - default selection, see Easary-Prochan Formula paragraph for more information. • F1:F2 - more exact (and slow) F1:F2 approximation. • Automatic - this approximation type will select the most appropriate approximation type for the current fault tree • Simple sum - will just calculate top gate probability as a sum of probabilities of all MCS. Recommended for fault trees with very low probabilities of MCS (lower than 1e-10). • Independent probabilities formula - top gate probability $P_{top} = 1 - (1 - P_{mcs1}) * (1 - P_{mcs2}) * \dots * (1 - P_{mcsN})$, where P_{mcsN} is probability of minimal cut set #N. Does not take into consideration common events between all MCS, in contrary to Easary-Prochan formula.
Probability Calculation Level	The difference between the two calculation options (only top and top and intermediary gates) is that the first option calculates unavailability for top tree event only while the second option calculates the unavailability for the top tree event AND each intermediary gate.
Ignore CCF Groups	CCF Groups will be ignored during the calculation, if this option is selected.
Time t	Time for Q(t) calculation
Cut-off parameters	See FTA Properties for more information.
Calculation cancel conditions	Option to set up calculation interruption conditions may be useful when dealing with large trees with long calculation times. Set up cancel conditions to stop calculation in case that calculation time or number of generated MCS will be too large.

3. Set the calculation parameters and pres Ok. FTA Calculation will be started. Minimal Cut Sets calculation will be performed ([basic event probabilities calculated](#), Minimal Cut Sets list generated and diagram Mean Unavailability (or Unavailability(t)) calculated - see "[Tree Unavailability Calculation](#)" paragraph for more information).
4. When the calculation is finished, results dialog appears:

FTA - Minimal Cut Sets

Result for top event: FTA Name:

Minimal Cut Sets: Number of MCS: / Order of MCS: Min Max

N	Q(t)	%	Order	Event 1	Event 2	Event 3	Event 4
1	9.82518e-007	100.0	1	PS			
2	1.33523e-013	0.0	2	Main Switch	Mother Board - Memory Fail		
3	1.15122e-013	0.0	2	HardDrive	Main Switch		
4	1.0061e-013	0.0	2	Mother Board - Memory Fail	Receiver failure		
5	8.67452e-014	0.0	2	HardDrive	Receiver failure		
6	8.39584e-014	0.0	2	Antenna failure	Mother Board - Memory Fail		
7	7.23881e-014	0.0	2	Antenna failure	HardDrive		
8	4.00029e-014	0.0	2	Keyboard	Main Switch		
9	3.01424e-014	0.0	2	Keyboard	Receiver failure		
10	2.51535e-014	0.0	2	Antenna failure	Keyboard		
11	9.6233e-015	0.0	2	Main Switch	Mother Board - CPU Fail		
12	7.2512e-015	0.0	2	Mother Board - CPU Fail	Receiver failure		
13	6.05106e-015	0.0	2	Antenna failure	Mother Board - CPU Fail		
14	1.41889e-015	0.0	3	Alternative transmitter failure	Mother Board - Memory Fail	Transmitter failure	
15	1.22335e-015	0.0	3	Alternative transmitter failure	HardDrive	Transmitter failure	
16	4.25091e-016	0.0	3	Alternative transmitter failure	Keyboard	Transmitter failure	
17	1.02262e-016	0.0	3	Alternative transmitter failure	Mother Board - CPU Fail	Transmitter failure	
18	3.58794e-025	0.0	4	Mother Board - Memory Fail	PS-1	PS-2	PS-3
19	3.09348e-025	0.0	4	HardDrive	PS-1	PS-2	PS-3
20	1.07493e-025	0.0	4	Keyboard	PS-1	PS-2	PS-3
21	2.5859e-026	0.0	4	Mother Board - CPU Fail	PS-1	PS-2	PS-3

Settings

Order by: Probability Cut Set Order Limit: None By order By probability

Event Data: Element type Event type Print MCS by: Row Column

Only top MCS will be shown on the screen. Only top MCS will be shown printed in report.

The tree diagram will be also updated with the new probabilities.

You may view, filter, sort and print out MCS list using the FTA calculation results dialog. Calculation results are stored in the database so that you may get the same results again without recalculation using "View MCS" option from the Calculation menu. However if the changes were applied to the tree (new gates, events, changed probabilities, times, failure rates etc.) you have to run the tree calculation again.

Press "Close" to close the results dialog and return to the FTA diagram screen.

After the calculation is performed, you may do also [Importance&Sensitivity analysis](#), use Unavailability curve, print calculation results for all phases and use other available FTA [Reports](#) .

NOTES:

- The tree recalculation process should be started again manually as explained above to get correct results if the tree was changed (if the basic events parameters were changed, the tree structure was changed, or the tree time was changed).
- If the current tree consists of sub-trees, these sub-trees are recalculated too.
- If the Q(t) calculation is performed and tree contains sub-trees, the tree time for sub-trees

calculation is taken from the current tree.

19.4.2.1 Tree Unavailability calculation

Basic method for Fault Tree unavailability calculation is Minimal Cut Sets generation and then unavailability calculation using [Esary-Proschan formula](#).

Two main types of tree result can be calculated:

- **Mean Unavailability Q** (long-term steady-state average unavailability) or
- **Unavailability Q(t)** (probability of failure at a given time point). To choose which result to calculate and display on the diagram, see paragraph "Using FTA module", FTA properties.

RAM Commander also supports Frequency (unconditional failure intensity) at time t $W(t)$ calculation - see [Frequency W\(t\) Calculation](#) paragraph for more information.

In order to perform the MCS Calculation, algorithm performs bottom-up fault tree analysis, building set of Minimal Cut Sets and performing Boolean transformations of the cut sets according to Boolean algebra laws. Then probability of each cut set is calculated, and then the top gate probability is calculated.

For large fault trees, with a large number of identical events, the number of MCS may be very large increasing the calculation time immensely. In this case, **MCS Cut-off** is used. During the Cut-Off, some minimal cut sets, which barely affect the final result, can be deleted. Three Cut-Off parameters are the Max. MCS number for Cut-Off, Relative cut-off value and Relative Cut-Off order (see [FTA properties](#)). When the MCS count in calculated tree increases the Max. MCS number, the Cut Off process is performed. If the relative affect on the calculation result for the MCS is less than the Relative cut-off value, the MCS is deleted.

19.4.2.2 Esary-Proschan Formula

Esary-Proschan formula is an approximation formula used for FTA top event probability calculation after Minimal Cut Sets generation. It is able to take into account common basic events and calculate the result in reasonable time.

The calculation procedure using this formula consists of several steps:

1. Minimal Cut Sets Generation

2. Common basic events factor calculation

Common basic events are basic events which appear in all Minimal Cut Sets. We need to calculate the common basic events factor using the following formula:

$$f_{common} = \sum Q(e(x))$$

where $e(x)$ is common basic event appearing in all MCS and $Q(e(x))$ is its probability.

3. Top event probability calculation

$$f_easaryproshan = f_common * (1 - \sum (1 - Q(MCS(y))))$$

where MCS(y) is Minimal Cut Set number y and Q(MCS(y)) is its probability.

19.4.2.3 Frequency W(t) Calculation

RAM Commander supports Frequency (unconditional failure intensity) at time t W(t) calculation.

The frequency w(t) for each particular basic event is calculated based on formulas specified in events list table in paragraph [Basic Event Types](#) earlier in this chapter.

To calculate the W(t) for top gate we need to generate Minimal Cut-Sets list first.

Then the following formulas are implemented:

Unconditional failure intensity of the specific MCS with number j is:

$$W_MCS[j](t) = \sum_{i=1}^{n[j]} \{w[i_j](t) * \prod_{\substack{k=1 \\ k \neq i}}^{n[j]} f[i_j](t)\}$$

where

MCS[1],...,MCS[j],...,MCS[m] – minimal cut set
 n[j] – amount of Basic Events of the MCS number j;
 f[i_j](t) – unavailability Q(t) of the BE with number i_j at the time t;
 w[i_j](t) – frequency of the BE with number i_j at the time t;

Unconditional failure intensity of the top gate of the fault tree:

$$W_TOP(t) = \sum_{j=1}^m \{W_MCS[j](t) * \prod_{\substack{j=1 \\ j \neq i}}^m \{1 - F_MCS[j](t)\}\}$$

where

MCS[1],...,MCS[j],...,MCS[m] – minimal cut set;
 W_MCS[j] - Unconditional failure intensity of the specific MCS with number j;
 F_MCS[j] - unavailability Q(t) of the specific MCS with number j.

19.4.2.4 PFH and PFD Calculation

RAM Commander may also calculate the PFH and PFD parameters as required by the IEC 61508 functional safety standard. You may get this calculation from the reports menu.

PFD (Probability of failure on demand) is calculated by the following formula:

$$PFD_{avg}(T) = \frac{1}{T} MDT(T) = \frac{1}{T} \int_0^T U_{sf}(t) dt$$

where U is instantaneous unavailability at time t (Q(t) - see the [Tree Unavailability calculation](#) paragraph).

PFH (Probability of Failure per Hour) is calculated by the following formula:

$$PFH(T) = \frac{1}{T} \int_0^T w(t) dt$$

where W(t) is frequency at time t (see the [Frequency W\(t\) Calculation](#) paragraph).

19.4.2.5 Lambda Equivalent

RAM Commander may also calculate the "Lambda Equivalent" parameter according to the EN 50129 standard (CENELEC) requirements - Use the "Equivalent Lambda" report from the "Reports" menu of FTA module.

Lambda-equivalent of the system S is an indicator of the ability of the system to fail. It is evaluated using the following equation:

$$EF(S) = \frac{\sum_{e \in \text{var}(S)} MIF(S, e) \cdot w(e)}{1 - p(S)}$$

where: w (e) is unconditional failure rate of the BE e,
MIF is Marginal importance factor - the rate at which the TOP unavailability S increases when the unavailability of component e increases,

$$MIF(S, e) = \frac{\partial p(S)}{\partial p(e)}$$

19.4.3 House Event Profiles

House events are often used in "what-if" situations when user wishes to check what is the top event probability if some event definitely occurs or does not occur. The House event profiling option brings that "what-if" analysis to the new level. Multiple house event profiles may be created with specific states (True/False) of house events. Then each profile may be activated and calculated:

FTA House Event Profiles				
Current tree	Tutorial			
House Event Code	Current	aaaa	bbb	
Antenna failure	Normal	True	False	False
Transmitter failure	Normal	True	True	True
HardDrive	Normal	False	False	False

To create house event profile and perform its calculation:

1. Open Fault Tree module
2. Choose "House event profiles" from the "Library" menu.
3. The profiles dialog will appear – with the list of house events in rows and list of profiles in columns. The "Current" column shows the current state of house events in events library.
4. Right-click the grid, choose "Add profile". Profile dialog will appear – provide the profile code, description etc. Press Ok.
5. New column in the profiles grid will appear, corresponding to the newly created profile.
6. Intersection of profile column and house event row corresponds to event state in this profile. Select the desired states for each profile.
7. Select desired profile cell, right-click, choose "Select profile" from the popup menu. Profile column will change its color.
8. Click the "Calculate" button in the lower part of the dialog – the current fault tree will be calculated according to the selected profile and its house event states and calculation results dialog (MCS results) will appear.

Repeat steps 1-6 to create additional profiles. Repeat 6-8 steps to switch between profiles, perform calculations and work with the calculation results.

19.4.4 Importance / Sensitivity Analysis

Importance & Sensitivity Analysis can only be performed after MCS analysis, because it uses generated Minimal Cut Sets. Importance analysis results help to select those fault tree events, which contribute most to the system's unavailability. Sensitivity analysis helps to choose those events, where a relatively small change will lead to relatively large system unavailability changes.

Calculated values for each event are:

- *Fussell-Vesely importance (FV Imp)*
Fussell - Vesely importance for basic event i $FV(i) = \text{Sum of all MCS containing the event } i / \text{sum of all MCS}$
- *Risk Decrease Factor (RDF)*
Risk Decrease Factor for a basic event i $RDF(i) = \text{Sum of all MCS} / \text{sum of all MCS taking into account that event } i \text{ probability is } 0$.
- *Fractional Contribution (FC)*
Fractional Contribution for a basic event i $FC(i) = 1 - 1/RDF(i)$
- *Risk Increase Factor (RIF)*
Risk Increase Factor for a basic event i $RIF(i) = \text{sum of all MCS taking into account that event } i \text{ probability is } 1 / \text{sum of all MCS}$.
- *Sensitivity*

Example of the analysis results report:

FTA - Importance & Sensitivity Analysis

Project name: FTA

FTA: RAMC

Top event: RAMC

Q mean=0.807138


N	Code	Occurrence	Q mean	FV Imp.	FC	RDF	RIF	Sens. high	Sens. low	Sensitivity
1	ActiveX not registered	1	0.3	0.371684	0.102405	1.11409	1.23895	1	0.732748	1.36472

N	Code	Occurrence	Q mean	FV Imp.	FC	RDF	RIF	Sens. high	Sens. low	Sensitivity
2	Btrieve files absent	1	0.3	0.371684	0.102405	1.11409	1.23895	1	0.732748	1.36472
3	Btrieve registry record is bad	1	0.03	0.0371683	0.007394	1.00745	1.23895	0.860821	0.80177	1.07365
4	License	2	0.3	0.212975	0.0496012	1.05219	1.09756	0.88588	0.771276	1.14859
5	Plug absent	1	0.3	0.111505	0.023632	1.0242	1.05514	0.851645	0.789971	1.07807
6	Plug driver failure	1	0.3	0.111505	0.023632	1.0242	1.05514	0.851645	0.789971	1.07807
7	RAMC files bad	1	0.3	0.371684	0.102405	1.11409	1.23895	1	0.732748	1.36472
8	RAMC registry records bad	1	0.3	0.371684	0.102405	1.11409	1.23895	1	0.732748	1.36472

19.4.5 FALSE/TRUE Propagation

RAM Commander allows visualizing consequences of any of the fault tree events (and event combinations) upwards the tree structure. Any combination of the fault tree events may be selected, for each event you may specify its logical state to propagate (TRUE – indicating that the event occurs, FALSE – indicating that this event does not occur).

Then the propagation statuses are visualized on the diagram using red color for TRUE and green color for FALSE logical states. For example, the diagram below displays propagation of several events – "Antenna failure", "Receiver failure" and "Motherboard-CPU Fail" TRUE and "Transmitter failure" as FALSE:



This function allows exploration of influence of different combination of basic events on higher – level events and on the top event of the fault tree.

To use this function, open the fault tree, choose "TRUE/FALSE Propagation" from the "Calculation" menu. List of propagated events will appear:

Code	Logical State	Name	Description
Antenna failure	TRUE		Communication antenna
Transmitter failure	FALSE		Transmitter type 2
Mother Board - CPU Fail	TRUE		Failure of item MotherBrd ID 1.2.2.4 - CPU Fail
Receiver failure	TRUE		Receiver Type 1

Buttons: Add, Delete, True, False, Normal, Propagation, Clear, Close, Cancel

Choose any number of events, set TRUE or FALSE logical state for each of them and press "Propagate" button to run the analysis and see updated fault tree diagram.

In addition to this TRUE/FALSE Propagation feature, RAM Commander may visually display the paths of all events in the selected cutset in the list of Minimal Cut Sets (MCS), from the event level upwards to the top gate level of the fault tree.

When working with the list of MCS, you may select any cut-set and click the "MCS Propagation" button:

FTA - Minimal Cut Sets

Result for top event: $Q(5)=6.55934e-020$ FTA Name: Tutorial

Minimal Cut Sets: Number of MCS: 8 / 8 Order of MCS: Min 3 Max 5

N	Q(t)	%	Order	Event 1	Event 2	Event 3	Event 4
1	5.79966e-020	88.4	3	Antenna failure	PS	Receiver failure	
2	6.68989e-021	10.2	3	Antenna failure	Keyboard	Receiver failure	
3	8.17913e-022	1.2	4	Alternative transmitter failure	Antenna failure	PS	Transmitter f
4	9.4346e-023	0.1	4	Alternative transmitter failure	Antenna failure	Keyboard	Transmitter f
5	7.28299e-027	0.0	4	Antenna failure	HardDrive	Mother Board - Memory Fail	Receiver fai
6	5.249e-028	0.0	4	Antenna failure	HardDrive	Mother Board - CPU Fail	Receiver fai
7	1.0271e-028	0.0	5	Alternative transmitter failure	Antenna failure	HardDrive	Mother Boar
8	7.40255e-030	0.0	5	Alternative transmitter failure	Antenna failure	HardDrive	Mother Boar

Settings


Order by: Probability Cut Set Order Limit: None By order By probability

Event Data: Element type Event type Print MCS by: Row Column

Only top 100 MCS will be shown on the screen. Only top 1000 MCS will be shown printed in report.

MCSs Propagation Filter Refresh Report Log Close

Then close the list of MCS and note the red paths of all MCS events leading to the top gate:




Note that propagation will remove all custom background colors of fault tree events and gates, if such colors were specified by users.

19.4.6 Repeated Events Indication

The "Repeated events indication" analysis allows to find and visually mark all the repeated (identical) events and transfer gates in your currently selected master fault tree. It is important information which helps to track common causes and understand calculation results of logical gates.

To perform the analysis, open Analysis menu, expand the "Repeated items", choose "Indicate". Analysis will be executed and the fault tree display will be refreshed, as shown below:



To remove the repeated events and transfer gates indications, open Analysis menu, expand the "Repeated items", choose "Clear".

19.5 Reports

Reports

The FTA module offers the following reports:

<u>Minimal Cut Sets</u>	MCS Calculation results report. Available from the Reports menu of from MCS calculation results window.
<u>Tree diagram</u>	Plain tree diagram. Available from the Reports menu.
<u>Basic events</u>	List of all basic events with their data. Available from the Reports menu.
<u>Tree gates list</u>	List of all tree gates. Available from the Reports menu.

<u>Tree output</u>	Graphical tree output. Choose Print from the FTA Diagram menu. There are different options available: Tree may be printed as is, tree may be printed with all its sub-trees, tree may be printed on multiple pages (suitable for large trees)
<u>Importance / Sensitivity Analysis</u>	List of all basic events from the selected tree with their sensitivity and importance ratings. Available from the Reports menu.
<u>Unavailability Curve</u>	Graph or table for: Unreliability $F(t)$, Frequency $W(t)$, Intensity $L(t)$, Number of Failures $E(0,t)$. Available from the Reports menu.
<u>FTA Summary Report</u>	List of all Fault Trees in the project, with their calculation parameters and results
<u>FTA Calculation Results for All Phases</u>	Current fault tree top gate probability calculated for all mission phases (phases are taken from Safety/FMECA phases library, each phase has its own duration and $Q(t)$ of the tree is calculated for that specified duration).

There is also a number of additional advanced reports.

See also "[Reports](#)" paragraph in the [RAM Commander Fundamentals](#) chapter for more general information about reports.

19.6 Summary

Fault Tree Analysis is acknowledged as a key tool for increasing safety. It is unique and indispensable in analyzing risks and determining various combinations of hardware, software, and human error failures that result in a specified risk or system failure. Fault tree analysis is useful both in designing new products/services and in dealing with identified problems in existing products/services. In the quality planning process, the analysis can be used to optimize process features and goals and to design for critical factors and human error. As part of process improvement, it can be used to help identify root causes of trouble and to design remedies and countermeasures.

The Fault Tree Analysis module is an advanced software tool with very convenient user interface and many of its useful features are not available in other FTA programs.

Chapter


20

Event Tree Analysis

20 Event Tree Analysis

Event Trees are one of the most widely used methods in system risk analysis. It is an inductive failure analysis performed to determine the consequences of single failure for the overall system risk or reliability. Event Tree Analysis uses similar logic and mathematics as Fault Tree Analysis, but the approach is different – FTA uses deductive approach (from system failure to it's reasons) and ETA uses the inductive approach (from basic failure to it's consequences).

An event tree itself is a visual representation of single failure sequences, it's influence on other events and on the whole system:



RAM Commander's ETA module features:

- User-friendly and convenient tree building interface (zoom, export to clipboard as metafile, print, etc.)
- Customizable graphical representation (diagram elements colors, styles etc.)
- Events Library
- Event Probability assessment models:
 - user-defined
 - calculated (repairable/unrepairable/constant mission time/periodical tests)
 - linked to product tree element
 - linked to FMECA Failure Mode, NHE or End Effect
 - linked to Fault Tree basic event
 - linked to Fault Tree gate or tree top event
- Different Event logic types:
 - Binary logic
 - True/False
 - Success/Failure
 - Multiple alternatives (for events where not only True/False or Success/Failure outcomes are

- considered)
- Different Event probability types
 - Equal event probabilities in all sequences
 - Different event probabilities in different sequences (conditional probabilities)

20.1 ETA module initiation

You may use different ways to enter the RAM Commander ETA module:

- In the list of projects, select project, right-click on it and choose “ETA” option from the pop-up menu.
- Open project, from the Modules menu choose ETA.
- Open project, click Modules at the left button-bar, press ETA button.

In the ETA module, you get the list of existing ETA diagrams.

About diagrams:

- There can be an unlimited number of diagrams in the project.
- All diagrams in the same project use the same events library.

To edit an existing diagram, select it in the list and click OK.

To create a new diagram, enter it's name in the edit box and click OK.

You will get an ETA diagram screen:




Diagram consists of events (vertical columns) and gates. The first event is initial event (the event which consequences should be analyzed). The last (rightmost) vertical column is consequences column which contains all possible outcomes. Between them regular events are situated.

A variety of available options: scrolling, zooming, etc. help you to view the diagram in the best possible way. See each option description for better understanding.

When creating a new diagram, diagram properties should be set up:

- from the ETA menu, choose Properties.
 - or -
- double-click an empty (white) space on the diagram


The following properties may be defined:

Field	Field description
Description	Tree description
Author	Author name or names
Time	Mission time (hours) for Q(t) calculation
Alignment	Central - or Top - balanced tree alignment (automatic arrangement should be checked)
Show code	If checked, element code will be displayed on the element box
Show name	If checked, element name will be displayed on the element box
Show probability	If checked, element probability will be displayed on the element box
Results display	Choose Q mean (steady-state probability) or Q(t) (probability at time t) calculation

Having defined your ETA diagram properties, you can now start [creating the ETA diagram](#).

20.2 ETA diagram building

When a new diagram is opened, Initial event and outcome event are created, so the tree building can be started immediately by adding regular events among the initial and outcome columns.



To add an event, select another event and

- right-click on it and choose “Append event” from the pop-up menu to add a new event to the end of the diagram (before Outcome)

- or -

- right-click on it and choose “Insert event” from the pop-up menu to insert a new event before the selected event

You will get an ETA element data screen:

The following data may be entered:

Field	Field description
Code	Element code. Should be unique inside the diagram.
Name	Element name
Description	Element description
Event logic	Success/Failure – choose if the event’s outcome is described in Success or Failure True/False – choose if the event is a failure which may occur or may not Custom – choose if event’s logic is not binary, for example “North wind”, “South wind”, “West wind” etc.
Probabilities in different branches	The same probabilities – choose if event probability in different sequences is the same Different probabilities – choose if event probability differs and depends on previous events (for example if event #2 probability is different if event #1 is true and if event #1 is false)
Probability source	Set up probability calculation method: User-defined Calculated Calculated using Product Tree/FMECA data


Field	Field description
	<p>Using FTA Basic Event – pick "Linked to FTA Basic Event" button and click on arrow in FTA Basic Event. In the opened FTA Events Library select FTA Basic Event.</p> <p>Using FTA top event/gate – pick "Linked to FTA Gate/Top Event" button, click on arrow in FTA tree and select required tree. Click on arrow in FTA Gate/Top event and select the gate or event from tree selected before.</p>
Background color	Background color of the element
Foreground color	Foreground color of the element
Font	Font of the element
Load from Library	Press the button to update event's data from the library (library should contain event with the same Code)
Load to library	Press the button to save event's data in the Library
Automatically update from Library	Check the checkbox if you wish to update event's data from the event's library automatically when library record with the same Event Code is changed.

To edit event, double-click on it, or right – click on it and choose "Edit" from the pop-up menu. Data screen described above will be displayed.

If you choose to use calculated probability, you have to press "Calculate" button and enter calculation parameters:

Field	Field description
FR	Failure rate (failures per million or billion of hours, depends on project settings)
Probability q	Probability q
Frequency f	Frequency F
MTTR	MTTR (Mean Time To Repair), hours
Test interval	Test interval - time between periodical tests, hours
Time to first test	Time to first test, hours
Mission time	Mission time, hours
Q(t)	Unavailability Q(t) - probability of failure at a given time point
Q mean	Probability or long-term steady-state average unavailability, Q
Tree ID	For events, ID of linked element in Product Tree
FM number	For events, number of FMECA Failure Mode of linked element in Product Tree

New event will be created with its gates for each sequence:




Any number of events may be added to the diagram. Then you may define all outcomes (Code, Name, and Description) and calculate the probabilities of consequences.

20.2.1 Events library

Events data may be stored in the events library. To store event's data in the library, press "Load to Library" button on event's data screen.

To open the library, select "Events" item from the Library menu.



Use Add, Edit and delete buttons to change library items. Use Print button to print report with events data.

Note that data of events in the tree will not be updated from the library immediately, but only after the tree recalculation.

Only events which are set to be automatically updated from the library will be updated.

20.2.2 Delete

To delete specific gate in the event tree, select the gate, right-click on it, choose "Delete" from the popup menu. The gate and all its outcomes will be deleted.

To delete specific sequence in the event tree without deleting the gate, select the gate, right-click on it, choose "Clear sequence" from the popup menu. The gate will not be deleted but all its outcomes will be deleted.

To delete the whole event you should first remove all gates from it. Then click on the event rectangle, right-click on it, choose "Delete" from the popup menu. The event will be deleted.

20.2.3 Export Diagram as Picture

You can insert the ETA tree as a picture to another application (Word, Excel, PowerPoint, etc.). Choose **Export to Clipboard** from the **ETA** menu. The diagram will be placed in the Clipboard.

Enter another application, choose where to paste the diagram and press Ctrl+V (or choose **Paste** from the **Edit** menu). The diagram picture will be copied.

20.2.4 Print preview, Print, Zoom

From the **ETA** menu you can also view print preview, Print the tree, Zoom it on the screen.

For the best printing, we recommend to perform "**Fit to printer**" operation before the printing, then print the diagram, and then after printing return the diagram to the normal size by "Zoom 100%" option.

20.3 Analysis & Calculation

To calculate the tree, select "Recalculate sequences" from the calculation menu. Updated probability values will be displayed on the Outcomes.

20.4 Reports

The ETA module offers the following reports (see Reports menu):

- **ETA sequences** report displays summary on all tree outcomes

RAM Commander for Windows - [ETA sequences for Project TUTORIAL Drive C:]

Report Edit View Window Help

ETA - Sequences Report

Project name: TUTORIAL
ETA: Explosion
Initiating event: Explosion

#	Event 1	Event 2	Event 3	Event 4	Outcome	Probability P
1	Explosion	Start of fire - True	Sprinkler system does not function - True	Fire alarm is not activated - True	Critical damage	8e-008
2	Explosion	Start of fire - True	Sprinkler system does not function - False	Fire alarm is not activated - True	Damage	7.92e-006
3	Explosion	Start of fire - False			Minor damage	0.002
4	Explosion	Start of fire - True	Sprinkler system does not function - True	Fire alarm is not activated - False	Major damage	7.992e-005
5	Explosion	Start of fire - True	Sprinkler system does not function - False	Fire alarm is not activated - False	Damage	0.00791208

Done

- **ETA sequences-detailed** report displays detailed information for each tree sequence

RAM Commander for Windows - [ETA sequences - detailed for Project TUTORIAL Drive C:]

Report Edit View Window Help

ETA - Sequences Detailed Report

Project name: TUTORIAL
ETA: Explosion
Initiating event: Explosion

Outcome: Critical damage Probability P=8e-008


N	Event Code	Event Name	Event Description	Logical State	Event Probability	Probability Source	Reliability model	Calculation parameters
1	Explosion				0.01	User-defined	Probability	q=0.01
2	Start of fire			True	0.8	User-defined	Probability	q=0.8
3	Sprinkler system does not function			True	0.01	User-defined	Probability	q=0.01
4	Fire alarm is not activated			True	0.001	User-defined	Probability	q=0.001

Outcome: Damage Probability P=7.92e-006

N	Event Code	Event Name	Event Description	Logical State	Event Probability	Probability Source	Reliability model	Calculation parameters
1	Explosion				0.01	User-defined	Probability	q=0.01
2	Start of fire			True	0.8	User-	Probability	q=0.8

NUM

- **Tree diagram** displays the tree structure



- **Events** report is available from the Library screen.
- **Tree output** to the printer is available from the ETA Diagram menu: select Print.

See also "[Reports](#)" paragraph in the [RAM Commander Fundamentals](#) chapter for more general information about reports.

20.5 Summary

Event Tree Analysis is acknowledged to be one of the key tools for increasing safety. It is ultimate and indispensable to analyze risks, determine various combinations of hardware, software, and human error failures that could result in a specified risk or system failure. Event tree analysis is useful both in designing new products/services or in dealing with identified problems in existing products/services. In the quality planning process, the analysis can be used to optimize process features and goals and to design for critical factors and human error. As part of process improvement, it can be used to help identify root causes of trouble and to design remedies and countermeasures.

The **Event Tree Analysis module** is an advanced software tool with very convenient user interface and a lot of useful features not found in many other ETA programs.

Chapter

21

Process/Design FMEA

21 Process/Design FMEA

RAM Commander's Process and Design FMEA module is the latest addition to the unique scope of the RAM Commander features. It implements and summarizes the first-hand experience gained by the A.L.D. FMEA experts in hundreds of projects where they used the old version of the A.L.D. FMEA software.

The screenshot displays the RAM Commander software interface. The top part shows a diagram of a computer system with components: Display (green), Keyboard (cyan), Mouse (grey), System block (red cylinder), and Printer (purple). Arrows indicate connections between these components. A group of people labeled 'Users' is shown on the right, with arrows pointing towards the System block. Below the diagram is a table with the following data:

#	Potential FM	End Effect of Failure	Severity	Cause	Occurrence	Controls	Detection	RPN	
1	Users report often system crashes	Impossible to work	9	Hardware is not stable	3		10	270	> Test
				Operating system is not stable	4		10	360	> Choo
				OS configuration is invalid	7		10	630	> Defi
2	Users report often physical damages	Equipment is not reliable	10	The equipment is not armored	7	Check armor	1	70	> Arm

RAM Commander's Process/Design FMEA is an interactive module for Process/Design potential Failure Mode and Effects Analysis. It has been designed for reliability professionals and design engineers, and is suitable for both Design and Process FMEA. The software, fully complying with QS-9000 PFMEA requirements, is a powerful tool with the following features:

- Process flow or design elements diagram - easily built and easily exported to MS Word, PowerPoint, etc.
- Fully visible Failure Mode → Cause → Effects sequence
- FMEA data management
- Automatic calculation of Risk Priority Numbers
- Automatic FMEA report generation
- Full support of the FMEA-based decision making with multiple criterias
- Extensive set of FMEA libraries
- Fully documented process establishes an organizational procedure for process/design FMEA.
- Team collaboration in decision making and Severity, Occurrence and Detection ranking.

21.1 FMEA Basics

“Up front time spent in doing a comprehensive FMEA well, when product/process changes can be most easily and inexpensively implemented, will alleviate late change crises. An FMEA can reduce or eliminate the chance of implementing a corrective change which could create an even larger concern.” (AIAG, *Potential Failure Mode and Effects Analysis*, Third Edition, 2001, p. 1)

To compete in today’s marketplace, manufacturers must eliminate all severe malfunctions and possible failures from their products and manufacturing processes. Failure Mode and Effects Analysis (FMEA) is a systematic set of activities intended to identify and help eliminate potential concern.

To yield the most valuable results, an FMEA must be performed before a design or process failure has been unknowingly incorporated into the product. Moreover, modern standards and regulations require designers and manufacturers to formally prove that all potential malfunctions have been eliminated or put under control.

Up-front time spent in doing a comprehensive FMEA, at the stage when products/processes changes can be easily and inexpensively implemented, will obviate late change crises.

An FMEA can be described as a systematic group of activities intended to: (a) recognize and evaluate the potential failure of a product/process and the effects of that failure; (b) identify actions that could eliminate or reduce the chance of the potential failure occurring; and (c) document the entire process. FMEA is an integral part of any QS 9000 compliant quality system.

FMEA Process

The FMEA process involves the following activities:

- Identification of functions/elements of your process/product;
- Identification of possible Failures for a function/element;
- Identification of possible Effects of the Failure;
- Determination of Severity of the Failure;
- Identification of possible Causes of the Failure;
- Determination of Occurrence of the Cause;
- Identification of control methods used to inspect function/element for failures;
- Determination of Detection;
- Calculation of RPN - Risk Priority Number;
- Prioritization of failures, selection of Critical and Important failures as candidates for Corrective Actions;
- Identification of corrective actions to reduce the Risk. (Corrective Actions (CA) are actions aimed at the process/product improvement by reducing risk and increasing responsibility);
- Determination of improved rates of Occurrence, Detection and calculation of the resulting RPN;
- Process repetition to achieve better results.

At every step, results should be documented in a standard tabular FMEA Form.

The fundamental purpose of the FMEA is to recommend and take actions that reduce risk. Actions taken should result in a lower Occurrence or Detection rating. Adding validation or verification controls can reduce Detection. Design or process revision may result in lower Severity and

Occurrence ratings. The revised ratings are documented with the originals on the tabular FMEA form. If no action is recommended, the decision not to act should also be noted.

21.2 FMEA module initiation

1. Enter the RAM Commander Product tree view.
2. On the Product tree view toolbar, click Modules. Click the icon corresponding to Process FMEA or Design FMEA

- or -

From the Modules menu, select Process FMEA or Design FMEA

The FMEA window will appear.

The FMEA window consists of two parts – the process/design flow diagram in the upper part and the failure modes data grid in the lower part.

Every diagram item presents a step of a process (in process FMEA) or product elements (in design FMEA). Links between items show relations between process steps or design elements.

The lower part of the screen presents FMEA data for the currently selected diagram item.

RAM Commander allows multiple users to edit the same FMEA analysis case. Only one (first) of the users has exclusive access to diagram itself (picture elements, their position, colors etc.), but all users have a free access to FMEA data (analysis table in the lower part of the screen).

Now you may:

1. [Define the basic properties](#) of your FMEA project,
2. [Draw the diagram](#) (process flowchart or design schema)
3. [Define FMEA data](#) (failure modes, their effects, detection methods, causes etc.) for each process step or design element.
4. [Take a decision on critical failures](#).
5. Take a decision on required [corrective actions](#).
6. Print all the necessary [reports and charts](#).

See next paragraphs for more information about each of these tasks.

21.3 Defining FMEA Properties

1. From the **Diagram** menu, select **Properties**.
2. FMEA properties dialog will appear:

Name	Report header 1	Report
Process name	Process	name
Potential FM	Potential	Failure
End Effect of Failure	Potential	Effect
Severity	SEV	
Cause	Potential	Cause
Occurrence	OCC	
Controls	Current	Control:
Detection	DET	
RPN	RPN	
Recommended Actions	Recommended	Actions

3. Enter the FMEA properties:

Author:	Author of the FMEA.
FMEA Number:	FMEA document number, to be used for tracking.
Description:	Description of the FMEA document and its purposes.

You may change also FMEA grid column captions and enable recommended actions efficiency calculation.

4. Press Ok.

Having defined your FMEA project, you can now start creating the process/design flow diagram.

21.4 Drawing the Diagram


During the process flow diagram building phase, create the diagram of the main blocks of your process. Process/design FMEA should begin with a block diagram representing the system, subsystem, and/or components being analyzed for design FMEA, and the sequence of the process stages for the process FMEA. The diagram should indicate the functional relationships to the appropriate level of analysis.

For each item of the diagram, define all required parameters, such as name and item function.

The next section describes the basics of creating and manipulating the diagrams used to present a process for Process FMEA and a product for Design FMEA.

21.4.1 Drawing a Node

Bring the mouse cursor into the diagram, press the left button (indicating the first corner of diagram block), move the mouse to another position (to the opposite block corner desired position) and then release the left button. You have created a node:



The newly created node will be selected - 9 handles (little squares) are displayed.

The handle at the center of the node is used to draw a link. The 8 others allow resizing the node.

To move the node, bring the mouse cursor into the node, depress the left button, move the mouse and release the left button.

To resize the node, click and move any one of node handles located on the node perimeter.

You may align multiple nodes by their left or top edges, set the same size for multiple nodes, bring to front/to back overlapping nodes etc. you will find all these functions in the "Item" menu.

To edit the node data:

- double-click on it
 - or -
- select Edit on the Item menu,
 - or -
- press ALT+ENTER
 - or -
- right-click the mouse and select **Edit** from the pop-up window.

The FMEA item data dialog box opens. Here you can define FMEA information and also can choose the diagram node background color, shape and assign a bitmap picture.

For each diagram node, the following data may be entered:

Name	Process name or design element name.
Comments	Description (visible as a “tool tip” while the cursor is over the diagram node).
Shape	Select the shape you find most suitable for the node you wish to create from the combo list.
Color	Choose the node’s color
Responsibility	Department, group or person responsible for the FMEA.
Prepared by	Name, phone number and company of the engineer responsible for preparing FMEA.
Core Team	List the names of the individuals and departments with authority to identify and/or perform tasks.
Key Date	The initial FMEA due date, which should not exceed scheduled production design release date.
FMEA Date	The date the original FMEA was compiled and the latest revision date.
Latest revision	The latest FMEA revision date.

21.4.2 Drawing a Link

Bring the mouse cursor into the handle at the center of the selected node, press the left button, move the mouse towards the other node.

When the mouse cursor is inside the other node, release the left button.

The link has been created and selected since a handle is displayed at the center of this link:




You may double-click the link to open link properties dialog where you may change link text, style, width and color.

21.4.3 Multiselection

You can select several nodes by clicking them with the mouse while holding the Shift or Ctrl keys. You can also select nodes only or nodes together with links.


21.4.4 Stretching a Link

Bring the mouse cursor into the link handle, press the left button, move the mouse and release the left button. You have created a new link segment. It has 3 handles allowing you to add or remove segments. (The handle at the intersection of two segments allows you to remove a segment: move it with the mouse so that the two segments are aligned and when these two segments are approximately aligned, release the left button):



21.4.5 Drawing a Reflexive Link

Select a node by clicking on it. Bring the mouse cursor into the handle at the center of the selected node. Press the left button, move the mouse and release the left button when the mouse is still inside the selected node. You have created a reflexive link, i.e. a link whose origin and destination are the same.



21.4.6 Delete

You can delete selected diagram element (for elements – see Multiselection above):

Select **Delete** on the **Item** menu

- or -

Right-click the mouse and select **Edit** from the pop-up window.

21.4.7 Copy & Paste

You can copy/paste a selected diagram element (for elements – see Multiselection above) inside the diagram or between different diagrams. Simply select items (links and nodes), then:

select **Copy** from the **Item** menu,

- OR -

press Ctrl+C,

- OR -

right-click the mouse and select Copy from the pop-up window.

Then choose a diagram to insert items into,

select **Paste** from the **Item** menu,

- OR -

press Ctrl+V,

- OR -


right-click the mouse and select Paste from the pop-up window.

Note that diagram items are copied with all the corresponding data in the data table (FM's, Causes etc.).


21.4.8 Sub-diagrams

FMEA sub-diagrams are similar to sub-RBDs; an unlimited number of nested sub-processes or sub-parts may be created for each diagram element (part or process).

Open FMEA diagram. Right-click a diagram item. Choose **Sub-FMEA** from the pop-up menu.



The item's sub-diagram is displayed on the screen or if a sub-diagram was not created previously for the item, a new empty sub-diagram is displayed. You can work with it the same way as with the basic diagram. The number of nested diagrams is unlimited.

For better orientation between nested diagrams, click the **Locate**  button on the toolbar for a hierarchical view of all the nested FMEA diagrams.

21.4.9 Print, Zoom, Undo

From the **Diagram** menu you can print the diagram, view the print preview, zoom in or out on the screen, and undo changes made to a diagram since opening the FMEA window.

- To display how the diagram will look when printed, choose **Print Preview** from the **Diagram** menu.
- To fit the entire diagram on the printed page, choose **Zoom – Fit to Printer** from the **Diagram** menu before the printing.
- To revert the diagram to normal scale, choose **Zoom 100%** from the **Diagram** menu.

21.4.10 Export Diagram as Picture

You can insert the FMEA diagram as a picture to another application (Word, Excel, PowerPoint, etc.).

There are two options - export to clipboard or to file:

- Choose **Export to Clipboard** from the **Diagram** menu. The diagram will be placed in the Clipboard. Enter another application, choose where to paste the diagram and press Ctrl+V (or choose **Paste** from the **Edit** menu). The diagram picture will be copied.\
- Choose **Export to File** from the **Diagram** menu. Then provide the file name and the diagram will be saved directly to file. Windows Enhanced Metafile format is used, which is compatible with Microsoft Office applications such as Visio, Word, Excel etc. It contains vector components and diagram remains editable and scalable when imported to Visio or Word.

21.4.11 Inserting nodes from Product Tree

You can “drag and drop” elements from Product tree into Design FMEA. RAM Commander copies their failure modes and causes from FMECA data or from FMECA Library (if there is no FMECA data entered for the element).

To copy a Tree element into Design FMEA:

1. Activate the Product tree view and FMEA Diagram windows.
2. Select a tree item, “drag” it to the FMEA diagram and “drop” on a free place of the diagram.

21.5 Failure Modes, Causes and Effects

When a diagram node (representing a Design element or Process) is selected, the table in the lower part of the screen displays corresponding Failure Modes and Causes.

The lower FMEA table shows the following:

Potential Failure Mode: Failure Modes are sometimes described as categories of failure. A potential Failure Mode describes the way in which a product or process could fail to perform its desired function (design intent or performance requirements) as described by the needs, wants, and expectations of internal and external Customers. Each process/element may have an unlimited number of failure modes, and each failure mode may have an unlimited number of corresponding causes of the failure.

As noted in the *AIAG Potential FMEA Reference Manual*, a potential failure mode is defined as the manner in which a component, subsystem, or system could potentially fail to meet the design intent. The potential failure mode could also be the cause of a potential failure mode in a higher-level subsystem or system, or be the effect of a potential failure mode in a lower level component. A recommended starting point is a review of past items that have “gone wrong”, concern reports and group “brainstorming”. Potential failure modes that could only occur under certain operating conditions, such as hot, cold, dry or dusty weather should also be considered.

Effect of Failure: An Effect is an adverse consequence that the Customer might experience. The Customer could be the next operation, subsequent operations, or the end user. State clearly if the failure mode could impact safety or non-compliance to regulations. The effect should always be stated in terms of the specific system, subsystem, or component being analyzed. *Potential effects of failure* are defined as the effects of the failure mode on function as perceived by the customer.

Severity: Severity is an assessment of how serious the Effect of the potential Failure Mode is on the Customer (value of the most serious effect). Explanation of Severity values can be found in the library (press the <...> button near the Severity field).

Enter the following Cause of Failure data:

Potential Cause of Failure: A Cause is the means by which a particular element of the design or process results in a Failure Mode. Enter every Potential Cause for Failure Mode. *Potential cause of failure* is defined as an indication of design weakness, the consequence of which is the failure mode. The designer should assess the occurrence and detection of each cause, as well as the severity of each end effect.

Occurrence: Occurrence is an assessment of the likelihood that a particular Cause will happen and result in the Failure Mode during the intended life and use of the product. An explanation of Occurrence values may be found in the library (press the <...> button near the Occurrence field).

Controls: Controls (Design and Process) are the mechanisms that prevent the Cause of the Failure Mode from occurring, or which detect the failure before it reaches the Customer.

Detection: Detection is an assessment of the likelihood that the Current Controls (Design and Process) will detect the Failure Mode, thus preventing it from reaching the Customer. An explanation of Detection values may be found in the library (press the <...> button near the Detection field).

RPN: (Automatically calculated, you do not have to enter it.) The Risk Priority Number is a mathematical product of the numerical Severity, Occurrence and Detection ratings. $RPN = (S) * (O) * (D)$. This number is used to place priority on items than require additional quality planning. FMEA automatically calculates risk priority numbers.

Actions Taken: Data about the corrective actions, implemented to improve RPN.

Occurrence (resulting): Improved Occurrence value after the implementation of “Taken Actions”.

Detection (resulting): Improved Detection value after the implementation of “Taken Actions”.

RPN (resulting): Improved RPN value after the implementation of “Taken Actions”. FMEA automatically calculates resulting risk priority numbers.

21.5.1 To create a new Failure Mode

There are three ways to create a new Failure Mode (FM) for the selected item:

1. From the **Item** menu, choose **Failure Modes** and select **Add Failure Mode**. The Insert/Update Potential Failure Mode dialog box opens.

- or -

2. Right-click on the table, and select **Add FM** from the pop-up menu. The Insert/Update Potential Failure Mode dialog box opens.

- or -

3. Insert data directly into the table - double-click on the left-most cell in the blank line after the last table entry and enter Failure Mode data.

The number of Failure Modes for every diagram element is unlimited.

21.5.2 To create a new Failure Cause

There are three ways to create a new Failure Cause for the selected Failure Mode:

1. From the **Item** menu, choose **Failure Modes** and select the **Add FM cause** menu item.

- or -

2. Right-click on the table at required Failure Mode row and choose **Add Cause** from the pop-up menu.

The Insert/Update Potential Cause of Failure dialog box opens:

Insert/Update Potential Cause of Failure

Name: Prepare laminate

Potential Failure Mode: Board not usable

End Effect of Failure: Product is unstable

Severity: 7

Initial Potential Cause of Failure: Bad materials

Occurrence: 6

or Probability: 0.000000

Detection: 6

Risk Priority Number (RPN): 252

Control methods: Visual inspection, X-rays analysis

Importance: Critical

Action Results: Decision making

Actions Taken: Mark different sizes with differ colors, Always clean surfaces before welding

Severity: 7

Occurrence: 2

or Probability: 0.300000

Detection: 3

Risk Priority Number (RPN): 42

Document Link: Browse Open OK Cancel

Fill in the necessary fields and press Ok.

- or -

3. To insert data directly into the table, double-click on the “Cause” column of the blank row with only a Failure Mode entered in the table, and then enter Cause data as required.

The number of Causes modes for every Failure Mode is unlimited.

21.5.3 To edit or delete Failure Modes

Failure Modes and Causes may be edited and deleted.

Right-click the mouse and choose **Edit/Delete FM** or **Edit/Delete FM Cause** in the pop-up menu.

- or -

From the **Item** menu, choose **Failure Modes** and select **Edit/Delete Failure Mode** or **Edit/Delete FM Cause**.

21.5.4 To copy failure mode

Use this option to copy a Failure Mode with all its hierarchy from one element to another inside the project or between different projects.

1. Right-click on required FM.
2. Choose **Copy FM** from the pop-up menu.
3. Select another diagram element, right-click on the lower grid and choose **Past FM** from the pop-up menu.

21.5.5 Spelling checker

RAM Commander FMECA has a built-in Spelling Checker with 16 dictionaries in the following languages:

SpellUS.lex - US English	SpellLAT.lex – Latin
SpellUK.lex - British English	SpellNL.lex – Dutch
SpellGER.lex – German	SpellPL.lex – Polish
SpellESP.lex – Spanish	SpellCRO.lex – Croatian
SpellFRA.lex – French	SpellSLO.lex – Slovenian
SpellDAN.lex – Danish	SpellSVE.lex – Swedish
SpellITA.lex – Italian	SpellCZ.lex – Czech
SpellHE.lex – Hebrew	SpellRU.lex – Russian

English UK and US, German and French dictionaries are included with the standard installation; other dictionaries are available by request from our support service.


To set up Spelling Checker:

1. Open your project.
2. From the **Tools** menu, choose **Spell checker dictionary**.
3. Select a dictionary from RAMC32/BIN folder (see the above explanation for a list of dictionary file names).

You can now initiate the spell checker in any cell of FMEA or FMECA table or field of the data dialogs.

To use Spelling Checker:

1. From the **Tools** menu, choose **Check spelling** or press **Ctrl+S**.
2. The standard **Spelling** dialog box is displayed with options for replacing the misspelled word.



21.5.6 To work with cumulative list of failures

FMEA module screen displays failure modes, causes and Effects table for selected process step or design element only.

You may work with the cumulative list of all failures in your FMEA diagram using the following procedure:

1. Select "FMEA Data Table" from the "Item" menu.
2. Choose failure modes filtering conditions
3. List of all failure causes according th selected conditions will appear:

Process	FM	EE	S	Cause	O	Controls	D	RPN
Prepare laminate	Board not usable	Product is unstable	7	Designers error	4	Visual inspection	6	168
Prepare laminate	Board not usable	Product is unstable	7	Bad materials	6	Visual inspection, X...	6	252
Prepare laminate	Bad assembly	Product is unusable	3	Designers error	3	Visual inspection	1	9
Prepare laminate	Undefined failure	Product is unstable	7	Bad materials	5		4	140
Prepare laminate	Wrong component - uncompatible	Product is unusable	4	Designers error	4		1	16
Prepare laminate	Wrong component - uncompatible	Product is unusable	4	Unqualified worker	4		1	16
Prepare laminate	Bad air	Users avoid to use ...	7					
Print board	Bad assembly	Product is unusable	4	Lack of material	8	Computerized stock...	9	288
Print board	Excessive heating	Product is unstable	7	Climat disaster	3	Switch off the AC	10	210
Print board	Excessive heating	Product is unstable	7	Design error	2	Voltage measurement	3	42
Print board	Power loss	Product is unstable	7	Design error	3	Obligate inspection ...	6	126
Print board	Power loss	Product is unstable	7	Poor cleaning	2	Visual inspection	8	112
Print board	Power loss	Product is unstable	7	Bad materials	8	Quality control befor...	6	336
Print board	Short circuit	Unstable	5	Design error	5	X-Rays expectation	7	175
Print board	Wrong component	Product is unstable	7	Bad materials	3	Visual inspection	6	126
Drill holes	Bad assembly	Unusable	8					
Drill holes	Short circuit	Unusable	3	Designers error	4	Visual inspection	6	72
Drill holes	Board not usable	Not functional	1	Designers error	4			
Drill holes	Holes are unable to drill	Increased time of pr...	1	Old equipment	5	Visual inspection	6	30

4. You may sort the list by clicking table headers, export it to Excel, edit and change failure cause importance - use popup menu (appears when you right-click on specific failure cause).

21.6 Selecting Critical Failure Causes

One of the most important FMEA tasks is selecting critical/important Failures and deciding which causes are the most important for the improvement of the system (priority tasks). Causes are ranked in importance according to their RPN.

You can mark these failure causes as **Critical Causes** or **Important Causes** on the **Failure Cause** screen (right-click the required cause, choose "Edit Cause" from the pop-up menu and change the cause importance).


These causes appear as red (Critical) or yellow (Important) in FMEA table:

#	Potential FM	End Effect of Failure	Severity	Cause	Occurrence
1	Board not usable	Product is unstable	7	Designers error	4
				Bad materials	6
2	Bad assembly	Product is unusable	3	Designers error	3
3	Undefined failure	Product is unstable	7	Bad materials	5
4	Wrong component - uncompatible	Product is unusable	4	Designers error	4
				Unqualified worker	4


You may use the Pareto report to get a list of causes with the largest RPN values and perform prioritization using this report.

However, if you use the **Scree Plot graph** or **Severity/Likelihood matrix**, you will receive a more intuitive and visual presentation of the relative importance of each cause.

The Scree Plot graph displays the Pareto report data for the RPN, sorted in ascending order. The **Y** axis represents the **RPN** value and the **X** axis represents the Cause Sequential number:




The Severity/Likelihood matrix displays points on 2-dimensional space where Y axis represents the Severity and X axis represent Likelihood=Detection*Occurrence:



After generating the graph, the user has the option of selecting the Failure Causes in a specific range as Critical/Important and then marking them as priority tasks for improvement.

For example, to select and mark the Failure causes for improvement using the Scree plot:

1. Close the graph.
2. Click **Yes** when prompted to select critical causes.
3. In the **Select Critical Causes** dialog box, enter the values for the range of selected causes in the **From** and **To** boxes. (For example in the following graph, the "Select causes in range" option is selected and the Values 22 – 27 are entered in the boxes. This is the range where RPN value growth is exponential).



4. The selected causes appear in red in the FMEA grid.
5. For a list of all the critical causes, run the **Pareto** report and select the **Only Critical Failure**

Causes check box, or open Item->"FMEA Data Table" and set filter to "Critical" causes only.

21.7 Team Collaboration

Severity, Occurrence and Detection ranks are given by experts as their subjective evaluation of the situation. This expert ranking gives much better results when multiple expert opinions are obtained and processed. RAM Commander provides option to perform Severity, Occurrence and Detection evaluation by team of experts, storing opinion of each expert and calculating resulting mean/media value:

Team Evaluation
X

Name:

Potential Failure Mode:

End Effect of Failure:

Potential Cause of Failure:

Controls:

#	Member	Severity	Occurrence	Detection
1	Expert 1	4	7	3
2	Expert 2	5	8	3
3	Expert 3	6	9	2

Mean:

Median:

Expert opinions may be collected manually (by entering expert opinion in the table above using the keyboard) and automatically (when all experts are using special electronic wireless voting devices):

**To use the team collaboration:**

1. Define the experts team
2. Start entering the FMEA data, for each cause enter "Team Evaluation" mode and collect expert opinions manually or automatically.

21.7.1 To define the expert team

1. From the Diagram menu, Choose "Team Definition" - team members list will appear.
2. Enter team members names and other details.
3. If you plan to use automatic data collection using voting devices, enter also voting device ID for each team member and give them the corresponding voting device with the specified ID. Keypad ID for each participant may be set manually or automatically. If keypad Id is known, FMEA facilitator may ust enter it into the Keypad ID field near the corresponding person name. If keypad Id is unknown, facilitator should select specific person in the list, press "Assign selected keypad ID" button and ask the selected person to press any button on his/her keypad. Its ID will be stored in the table.
4. Press Ok.

21.7.2 To collect rankings manually

1. While working with FMEA grid on the main FMEA module screen, Right-click on FMEA table line with Failure Mode and Cause data and choose Team Evaluation form the pop-up menu.
2. Team evaluation data screen for the specific Failure/Cause will appear.
3. Let each team member evaluate the criteria and enter the ranking into the corresponding column and row of the table. If a team member is absent or doesn't have a value, leave "-" symbol.
4. After all members values are obtained, you may choose mean or median method of averaging and press Ok to place the resulting data into the FMEA table.

21.7.3 To collect rankings automatically

1. Right-click on FMEA table line with Failure Mode and Cause data and choose Team Evaluation from the pop-up menu.
2. Team evaluation data screen for the specific Failure/Cause will appear. The screen contains 3 "Start Voting" buttons for each parameter (Severity, Occurrence and Detection):

#	Member	Severity	Occurrence	Detection
1	Expert 1	4	7	3
2	Expert 2	5	8	3
3	Expert 3	6	9	2

3. Team facilitator should press "Start Voting" button for each parameter and wait while participants are voting using their keypads. Voting results appear immediately on the data screen.
4. To stop voting for the specific parameter, team facilitator press "Stop voting" button of currently processed parameter or "Start voting" button of the next parameter.
5. When all parameters are processed, team facilitator presses the "OK" button and continues working with FMEA.

Notes:

- Each keypad may vote multiple times during one parameter voting, only last vote will be accepted.
- Votes from keypads which are not identified (not linked to specific team member) will not be considered.
- Voting for the same parameter may be initiated multiple times, new values override the old values.

21.7.4 Voting System Installation

Process/Design FMEA module allows Team Work using audience response system since RAM Commander 7.7 version. Team members use keypads to provide their Severity, Occurrence and Detection rankings:



Team facilitator starts voting and team members provide rankings, which are stored in the database.

		Stop Voting	Start Voting	Start Voting
#	Member	Severity	Occurrence	Detection
1	Expert 1	3	8	3
2	Expert 2	2	5	6
3	Expert 3	3	6	4
4	Expert 4	2	7	5

<input type="radio"/> Mean:	3	7	5
<input checked="" type="radio"/> Median:	3	7	5

SunVote company hardware is used for that purpose. The required set of hardware consists of USB receiver and a number of voting keypads with 10 voting keys:



Voting system hardware is not supplied with standard RAM Commander delivery and should be ordered separately. Voting system software components are not installed with the standard RAM Commander installation too - see the next paragraph for detailed installation instructions.


21.7.4.1 To install and configure the Voting System


Pre-installation requirements:


- RAM Commander 8.1 (or later version) installation CD
- 1 SunVote USB Receiver PVS 3000
- Number of SunVote W50 or W52 keypads with active CR2032 batteries
- PC with CDROM and free USB 2.0 port.

Installation procedure:

1. Install RAM Commander. During the installation, select "FMEA Voting API" checkbox on the "Select Components" screen:



2. Insert SunVote Receiver into the USB port of your computer.
3. During the driver installation, select specified location for drivers - *Ramc\Tools\SunARS_USB_Driver* folder on RAM Commander installation CD.
4. When the driver installation is finished, check COM Port number assigned to SunVote device:
 - a. Right-click on My Computer, choose properties.
 - b. Select "Hardware" tab, press "Device Manager" button, find "Ports" section, locate "USB Serial Port" device:
 
 - c. Double-click the device, select "Port settings" tab, press "Advanced" button. Port settings screen will appear:



- d. Remember the port (you may also change it if required) and close the open system dialogs.
 - e. Open RAMC.ini file in RAM Commander installation folder, BIN subfolder using Notepad.
5. Edit " VotingSysCOMPort", set port number found earlier in above steps. For example, if port is COM3 then RAMC.INI file should contain the following lines:

```
[FMEA]
VotingSysCOMPort=COM3
```
 6. Save RAMC.ini
 7. Installation is finished.

21.8 Making Decisions on Corrective Action

Decision Making is a tool for the assessment of preventive/corrective actions which should be implemented to reduce risks and increase customer satisfaction by improving the design of a product or the process features.

There are two ways to enter Decision Making:

1. In the **Failure Mode/Cause** table, click on the <....> button in "Recommended Actions" column.

- or -

2. In the Insert/Update Potential Cause of Failure dialog box, press the Decision Making button.

The Corrective Action – Decision Making dialog box opens:

Recommended Actions - Decision Making

Item name: Prepare laminate Failure Mode: Board not usable
 End Effect: Product is unstable Cause: Bad materials
 Controls: Visual inspection, X-rays analysis

RPN
 Initial: Severity: 7, Occurrence: 6, or Probability: 0.000000, Detection: 6, Risk Priority Number (RPN): 252
 Resulting: Severity: 7, Occurrence: 2, or Probability: 0.300000, Detection: 3, Risk Priority Number (RPN): 42

Suggested and Selected Actions: (Potential solutions of a problem)

Action Name	Action Description	Advantages	Disadvantages	Sev.	Occ.	Det.	RPN	dRPN	Feasibility
different size-differ color	Mark different sizes with differ colors	Will let to decrease mistakes and increase speed	Error during color marking - fatal	7	5	3	105	147	1
installing air conditioning	Increase concentration in work area by installing air conditioning in production area			7	4	5	140	112	3
surfaces clean before welding	Always clean surfaces before welding			7	2	3	42	210	1
Maintain-6 mnths, blades-25 o	1. Maintain machine every 6 months. 2. Set blades at 25 degrees.			7	3	5	105	147	4
Cover printed circuit	Cover printed circuit with soldering resist			7	4	6	168	84	5

Buttons: New, Edit, Delete, Select, Deselect, Reject, Done, Calculate Res.RPN, Report, OK, Cancel

Actions Taken: Mark different sizes with differ colors, Always clean surfaces before welding

Document Link: _____ Browse Open

In the Decision Making functions, you can enter an unlimited number of possible corrective actions with its advantages/disadvantages, comments, person responsible, etc. You can then evaluate the possible actions and select some of them for implementation (Selected actions) with the help of the "Select" button. On the basis of selected actions, you can fill in the "Actions Taken" field and the fields for the resulting "Occurrence" and "Detection".

Use the following criteria to evaluate a suggested action:

- * Severity (S), Occurrence (O), Detection (D) and RPN for every action in addition to S, O, D and RPN parameters per each Failure Cause, and also $\Delta RPN = RPN_{initial} - RPN_{resulting}$
- * Cost, Duration, Risk, Additional criteria with their **Efficiency**, which is calculated as:

$$\text{Efficiency} = \frac{\Delta RPN}{RPN_{initial} \cdot \sqrt[4]{(\text{Cost} \cdot \text{Duration} \cdot \text{Risk} \cdot \text{Additional})}}$$

where: $\Delta RPN = RPN_{initial} - RPN_{resulting}$
 $RPN = \text{Severity} \square \text{Occurrence} \square \text{Detection}$

- * **Feasibility** criteria (F) and ΔRPN :

$$dRPN / F = \frac{\Delta RPN}{\text{Feasibility}}$$

Set the Feasibility value for each potential corrective action. Values range from 1 to 10. 1 indicates


that there are all the required resources to perform the action and the probability of success is high. 10 indicates that there are no available resources and/or the probability of success for this action is low. A more detailed explanation of Feasibility values is described in the section on Libraries.

After the feasibility for each action is entered, normalized RPN improvement value dRPN/F is calculated and used for actions evaluation. The higher the value of dRPN/F for the action, the more preferable this action is. Entered actions appear in the **Failure Modes and Causes** table in the **Recommended actions** column; selected actions are marked with ">".

You may get a full list of all recommended actions for the whole FMEA diagram using "Actions data table" function from "Item" menu, or list of all selected corrective actions using "Corrective actions checklist" report.

21.9 Libraries

Process/Design FMEA has an extensive set of *libraries* containing all necessary supporting information. The set of libraries provides a convenient facility to quickly and efficiently build and update projects. You can add or modify data in each library before and during project creation.



The Process/Design FMEA provides libraries for:


- Failure Modes,
- Failure Causes,
- End Effects,
- Process Controls,
- Corrective Actions,
- Feasibility,
- Severity,
- Occurrence and
- Detection.

While building the project, you can revise all of the libraries. The libraries: Severity, Occurrence and Detection are provided with data that complies with the AIAG FMEA document, and can also be changed as required.

You can fill your libraries automatically using data from your FMEA table using "[Load to library](#)" function.

21.9.1 To view and update FMEA libraries

- 1 Run the FMEA module.
- 2 From the **Libraries** menu, select the required library.
- 3 The Library window opens (e.g. Occurrence).



Rank	Probability	Description	Possible FR (1 in)	Probab.From	Probab. To
10	Very High	Failure is almost inevitable.	2	0.9	1
9	Very High	Failure is almost inevitable.	3	0.8	0.9
8	High	Repeated failures.	8	0.7	0.8
7	High	Repeated failures.	20	0.6	0.7
6	Moderate	Occasional failures.	80	0.5	0.6
5	Moderate	Occasional failures.	400	0.4	0.5
4	Moderate	Occasional failures.	2000	0.3	0.4
3	Low	Relatively few failures.	15000	0.2	0.3
2	Low	Relatively few failures.	150000	0.1	0.2
1	Remote	Failure is unlikely.	1500000	0	0.1

Buttons: Add, Edit, Delete, Print, Close

- 4 The following buttons are available on the library window:

Add – To add a library item.

Edit – To edit the highlighted item.

Delete – To delete the highlighted item.

Print – To print out the library item list.

Close – To close the window.

21.9.2 To update a library during FMEA data input

1. Run the FMEA module and select a diagram in the FMEA upper window.
2. To revise an entry in the lower FMEA table and update the associated library, click on the button with the three dots <...> next to the relevant comment to open the appropriate selection box.
3. The Select box opens offering 6 buttons:

- **Select** – To insert the highlighted item into the lower FMEA window.
 - **Cancel** – To close the Select box.
 - **Add** – To add a library item.
 - **Edit** – To edit the highlighted item.
 - **Delete** – To delete the highlighted item.
 - **Print** – To print out the library item list.
4. Click on the **Add** or **Edit** button to update the library as required.

21.9.3 To select a field value from a library


During FMEA data input/edit, values can be chosen for most of the fields from the libraries:

1. Press the <...> button in the lower FMEA table beside the relevant table entry.
2. The Select box opens.
3. Choose the item and press the **Select** button.

21.9.4 To copy libraries between projects

Libraries may be copied from one open project to another:

1. Open two projects in FMEA mode – source and destination.
2. Select source project FMEA diagram.
3. Select **Copy Libraries** from the **Library** menu. The **Open Project Lists** dialog box is displayed.
4. Select which project you want to copy to libraries to.
5. Select which libraries you want to copy the project to (multiple selection is possible).



6. Click OK.

21.9.5 Load to Library

RAM Commander allows data input directly to FMEA table without filling the libraries of Failure Modes, Causes etc.

Using libraries significantly speeds data input but sometimes FMEA worksheet is just filled in with data without using the libraries, but at some stage user may wish to put the repeating failure modes causes etc. to the library to speed up the work.

The "Load to Library" option scans FMEA table for selected diagram elements and adds their data (Failure Modes, Causes, Detection Methods, Corrective Actions) into a corresponding library, enabling data reusability.

To execute the "Load to Library" function, select "Load to library" from "Libraries" menu.


21.10 Reports

FMEA displays analytical results in a wide variety of tables or graphs. You can export these reports to other programs such as MS-Word or Excel for customized analysis.

Before generating reports, you should use FMEA's built-in facility to report and automatically correct errors.

- 1 From the **Report** menu, choose **FMEA Analysis**.

The FMEA Report generation dialog box opens showing the different reports that can be generated and some radio buttons for sorting and filtering.



Sorting by: Sort the report by RPN, by Resulting RPN, or unsorted

Elements: Contents of the report will display either all the Process/Design elements or selected diagram elements only (see Diagram Basics – Multiselection on page 460).

Type: Contents of the report will display either all the Process/Design elements or elements of selected type only.

Only Critical: Contents of the report will display either all the failure causes or only causes marked as Critical Causes.

2 Choose **OK** to finish.

The report will be shown in a report window for preview. See [Reports](#) paragraph in "RAM Commander Fundamentals" chapter for more information about report options.

21.10.1 To print the report

From the **Report** menu, choose **Print**.

See also "[Reports](#)" paragraph in the [RAM Commander Fundamentals](#) chapter for more general information about reports.

21.11 Summary

FMEA is an advanced software tool for potential failure mode and effects analysis. It includes many specialized features not found in any other FMEA programs. FMEA provides you with powerful analysis techniques to identify potential failure modes *before* you start manufacturing through to shipping, and also allows you to find better corrective actions after encountering a failure. Using FMEA results in better products and more satisfied customers.

Chapter



Safety Analysis

22 Safety Analysis

RAM Commander Safety Module is a safety toolkit implementing safety tasks defined in the various safety assessment standards/recommendations. RAM Commander Safety module implements the requirements and tasks of:

- **SAE APR 4761**,
- recommendations from **MOC-2 (Russia)**,
- **SHA** and O&SHA according to **MIL-STD-882E** and more.

The safety assessment process has fundamental importance in establishing appropriate safety objectives for the System under Analysis (SUA) and determining that the implementation satisfies these objectives. The safety assessment process is iterative by nature; using RAM Commander to support all necessary iterations and to produce all required outputs is the easy, accurate and timesaving way to perform the safety assessment. RAM Commander Safety Module implements tasks of qualitative and quantitative safety assessment required during system development:


- Generation and verification of safety requirements;
- Identification of all relevant failure conditions;
- Consideration of all significant combinations of failures leading to failure conditions;
- Calculation of expected probabilities for all failure conditions;
- Generation of output reports starting from the stage of Functional Hazard Analysis (FHA/ PHA) and ending with the System Safety Assessment (SSA) verifying that the design meets safety requirements;

RAM Commander's easy-to-use modules: Reliability Prediction, [RBD](#), [FMECA](#), [Markov](#) and [FTA](#) are the basis and the heart of the Safety Module.


22.1 Safety Module Basics

Safety Analysis requires to build a functional tree of the product and to provide information about potential failures for each product function.

There multiple Safety/Hazard analysis standards/approaches available (FHA, SHA, SSA, PSA etc.) - the required standard may be selected in the "View" menu of Safety module:



Safety Module screen contains two parts: the functional tree in the upper part of the screen and the failure data in the lower part of the screen:



Functional tree may have unlimited hierarchy depth. For each function user may enter unlimited number of potential failures. For each failure, user should provide information about relevant phases, end effect on the whole product, end effect classification (severity) and other details (depending on selected standard/approach).

System Safety Assessment or **Probabilistic Safety Assessment** requires quantitative evaluation of failure probability for each failure condition. Evaluation can be performed using RBD, FTA or Markov chain. User should select at least one safety assessment mean ([RBD](#), [FTA](#), [Markov](#) diagram) to each failure condition. RBD calculation result (unreliability), FTA calculation result (probability of tree root occurrence) or Markov chain calculation result (unreliability) will be taken as failure probability. During the SSA (System Safety Assessment), these calculated probabilities will be compared to the Safety/Reliability (S/R) objectives and Design objectives to make sure that the designed system meets the requirements.

Now you may:

1. [Setup Safety Libraries](#) (Phases, End Effects)
2. [Build the functional tree](#) and
3. Provide [information about possible failures and their consequences](#), reasons etc. for all system functions.

Then (for SSA/AFO) you may:

1. [Define objective probabilities](#) for failure severities and failure effects,
2. Build [Fault Trees](#) for each failure condition,
3. [Calculate expected probability](#) for each failure and compare it to objective probability.

22.3 Safety Libraries

Safety module uses common libraries with FMECA module.

Libraries which are relevant for the Safety module are:

- **Phases**

Define your product mission (or life cycle) phases on the Phases tab of the library screen. Define duration for each phase. Put the total mission (e.g. "whole flight") phase to be the first phase in the list.

- **Safety Severities**

Classification of End Effect Severities from the point of view of Safety (each EE has two severities - FMECA Severity and Safety Severity; in the Safety module we need Safety Severity).

On Safety Severities page you may also set objective maximal probability of failure per average mission hour for each severity level (for SSA/AFO).


- **End Effects**

List of failure effects / hazard effects. Each effect should have Safety Severity defined for each phase (switch phases using the drop-down list above the End Effects list). You may set two objective probabilities (according to Safety Requirements and according to design requirements) for each EE and each phase separately. End Effects may be added later while working with failure conditions data grid.

22.3.1 Working with Libraries

To open the libraries from Safety Module, choose "Safety/FMECA Library" from the "Libraries" group of the main menu.

Libraries screen will appear:



The screen contains all libraries; each library is located on its own page. Select the page title with library name in the upper part of the screen to switch to the required page.

Three libraries in Safety/FMECA common library are relevant for Safety module: Phases, Safety Severities and End Effects.

Working with Phases

Switch to the first page of the screen called "Phase". Phases library is a list of product life cycle phases like "Flight", "Landing" etc. Each project should have at least one default phase in the library. Each phase has a name, description and phase duration in hours.

To create a new phase just find the last empty table line, select the first cell (Phase Name) and type in the phase name. Press enter, switch to the next field and type phase description. Press enter and type phase duration in the last field.

To edit any phase parameter, double-click the corresponding cell, type the information and press enter.

Working with Severities

Switch to the page named "Safety Severity" to get a list of severities. The list contains possible categories of failure severity on the whole system operation level. By default, there are 6 severity categories – from Catastrophic to "No effect".

To create a new category just find the last empty table line, select the first cell (Category) and type in the name. Press enter, switch to the next field and type description. Press enter and type rank (one or two-symbol code like IV or B) in the last field.

Working with End Effects

Switch to the page of the screen called "End Effect".

End Effects (EE) library contains the list of all possible consequences of different failures on an overall system operation.

To create a new EE just find the last empty table line, select the first cell (EE Description) and type in the phase name. Press enter, select the next table field (FMEA Severity) and choose a severity for FMECA calculations. Select "Safety Severity" cell and choose a severity for Safety module.

Then enter S/R objective and Design objective. S/R objective is a maximal allowed probability of specified End Effect, defined by safety authorities; Design objective is a maximal allowed probability of specified End Effect, defined by internal safety/reliability department. Design objective is lower than S/R objective.

Please note that End Effects may have different safety severities (and different objective probabilities) for different phases.


22.4 Building the Functional Tree

When the Safety Module in specific project is opened for the first time, the functional tree is empty – only the tree root element exists. User should build a hierarchical functional tree.

Tree building is started by adding successors (child items) to the tree root. Then successors could be added to the root successors etc.

To add a successor (child) to the tree element:

- Select the tree element and then right-click. Choose **Create** from the pop-up menu:



Or

- Select the tree element and press the **F7** key.


The function data screen is displayed:

A screenshot of a dialog box titled "Function data". It has a close button (X) in the top right corner. The dialog contains two text input fields: "Function:" with the value "Control Aircraft Direction on the Ground" and "Function description:" with the same value. To the right of the "Function:" field is an "OK" button, and to the right of the "Function description:" field is a "Cancel" button. Below these fields is a section titled "Product Tree Dependency" containing a table with two columns: "ID" and "Reference Designator". The table is currently empty. At the bottom of the dialog are two buttons: "Add" and "Delete".

It contains the following information:


Field	Field Description
Function	Function Name
Function Description	Function Description
Product Tree Dependency	List of product tree items, which affect the specified function. Use Add and Delete buttons below to edit this list of linked items.

Fill in the data and press Ok button. New function will appear in the tree:




Continue the tree building procedure by selecting tree element and creating its successors as described above.

Sometimes there is a need to insert tree element to the specific position between two other existing elements, as shown on the example below:



To insert a function between two existing functions:

1. Select the function, which shall become the next function after the new one will be inserted.
2. Right-click on it and choose "Insert" from the popup menu.
3. Fill in the function data and press Ok.
4. The new function will be inserted into the tree before the selected existing function:



To edit a specific function:

- Select it and then right-click. Choose **Edit** from the pop-up menu.
Or
- Double-click on it (if it is a lowest level function and it has no successors)
Or
- Select it and then press Alt+Enter keys.

Function data screen will appear – change the data and press Ok to save you changes or cancel to discard the changes.


To delete a specific function:

- Select the function, right-click on it, choose "Delete" from the popup menu
Or
- Select the function and press "Del" button on the keyboard
Or
- Select the function and choose "Delete" option from the "Tree" section of main application menu

22.5 Working with different standards/recommendations

RAM Commander Safety Module suits different standards and safety/hazard analysis types (SAE APR 4761, MIL-STD-882 etc.). It can be customized and used for other recommendations and standards. Some recommendations give different names to the same data and require additional information to be provided. One of such supported recommendations is AFO defined by MOC-2 (Russia). It requires additional fields in the Failure Conditions table and gives different names to failure data.

To switch between standards select the desired standard/recommendation name from the "View" section of the main application menu:



The failure conditions table contents will be refreshed and will display columns relevant to the

selected mode.

You may also customize the failure conditions table column names and define your own names to columns.

To change the failure conditions table column name:

1. Right - click the desired column header.
2. Popup menu will appear - Choose the "Change column title" option
3. Title dialog box will appear - write down the new title and press ok.
4. The failure conditions table contents will be refreshed and will display the new name.


22.6 Working with Failure Conditions

You may define unlimited number of failure conditions for each function of the functional tree. The table in the lower part of the screen displays all failure conditions of specific function currently selected in the functional tree.

To work (create, edit, delete etc.) with failure conditions of the specific function, at first select this function in the functional tree.

To create a new failure condition (FHA mode):

1. Select specific function.
2. Select the first field in the table below and start writing the failure condition description:



3. Press enter.
4. Select relevant phases in the next field:
 - a. Press the "..." button, phases list will appear
 - b. Select relevant phases from the list (you may select multiple phases)
 - c. If required Phase is not found in the list, add it to the library – see "Working with Safety/ FMECA Library" later in this document.
 - d. Press Ok.
5. Select failure condition end effect in the next field:

- a. Press the "..." button in the "End Effect" column, End Effects list will appear.
 - b. Select relevant EE from the list (you may select only one EE).
 - c. If required EE is not found in the list, add it to the library – see "Working with Safety/FMECA Library" later in this document.
 - d. Press Ok.
6. Fill in other fields in the same table line – Verification, Remarks, Detection, Action etc.
 7. Specify or create a safety assessment method for this failure condition:
 - a. Right-click the failure condition, pop menu will appear:

#	Failure Condition	Phases	
1	Loss of Deceleration Capability	Taxi; Landing Roll; Rejected Takeoff (RTO)	...
2	a. Unannounced loss of deceleration capability	Landing Roll;	<div style="border: 1px solid black; padding: 2px;"> Safety Assessment Definitions Delete Failure </div>

- b. select "Safety Assessment Definition" from the popup menu, assessment definition screen will appear:

Safety Assessment Definitions ✕

Function: OK

Failure Condition: Cancel

Phase:

Effect:

Safety Assessment Means

Type	Name	Description
FTA	Unannounced_Loss_of_All_Whell_Br...	Unannounced_Loss_of_All_Whell_Breaking


- c. Add or create any number of probability assessment means using "Add RBD", "Add FTA" and "Add Markov" buttons below.

- d. Select one of linked methods as "final" by selecting it and pressing "Select/Deselect" button. The "final" method will be used in SSA reports. Selected "final" method will appear in green color in the methods list. This "final" method will be used to calculate a probability of the currently selected failure condition.
- e. To delete Safety Assessment means from the list, select the corresponding record and press "Delete" button.
- f. To open and edit Safety Assessment means directly from the "Safety Assessment Definition" screen, select the corresponding record and press "Open" button.
- g. Press "Ok" button to save the selected assessment methods and return to the failure conditions list.

There is possibility to group failure conditions with common behavior. Failure condition group will appear on a gray background and specific failure conditions will appear below the group, as shown on the picture below:

To create a new failure condition inside the group:

1. Select the group cell in the failure conditions table
2. Right-click on it and choose "Add failure sublevel" from the popup menu:



1. Enter name of the new failure condition to be added to the selected group.
2. The new failure condition appears inside the group:

#	Failure Condition
1	Loss of Deceleration Capability
2	New failure
3	Partial loss of Deceleration Capability

3. Fill in the information in all other fields of the new failure condition.

To edit an existing failure condition data:


You always can change any failure condition data by clicking the required table cell and writing the

new data (or clicking the "..." button and selecting different phases or End Effects).

To delete a specific failure condition, right-click the failure condition in the failure conditions table and select "Delete" from the popup menu.

To create a new failure condition (AFO mode):

1. Select specific function.
2. Make sure to switch to the "AFO" mode in "View" menu.
3. Select the first field in the table below and enter the failure condition number:



1. Press Enter.
2. Fill Failure condition name in the next field.
3. Specify Safety Assessment Method (FTA) as described in **"To create a new failure condition (FHA mode)"** section earlier in this document, paragraph 7.


4. Switch to the next field and

- a. write down the logical expression explaining failure condition cause


Or

- b. Let RAM Commander build the logical expression explaining failure condition cause automatically:

- i. Press "..." button.
- ii. FTA earlier selected as "Safety Assessment Method" for this failure condition, will be displayed in a plane format:



- iii. Expand the tree branches to the desired level of logical expression detalization;
- iv. Press "Ok" button. Logical expression will be build according to the FTA state on the previous screen:



2. Select relevant phases in the next field:
 - a. Press the "..." button, phases list will appear
 - b. Select relevant phases from the list (multiple phases can be selected)
 - c. If required Phase is not found in the list, add it to the library – see "Working with Safety/FMECA Library" later in this document.
 - d. Press Ok.
3. Select failure condition end effect in the next field:
 - a. Press the "..." button in the "End Effect" column, End Effects list will appear.
 - b. Select relevant EE from the list (you may select only one EE).
 - c. If required EE is not found in the list, add it to the library – see "Working with Safety/FMECA Library" later in this document.

- d. Press Ok.
4. Fill in other fields in the same table line – Indication, Actions etc.

22.7 Probability Calculation

When the FHA analysis is performed and each failure condition is linked to Fault Tree in order to get expected failure probability, you may initiate the calculation.

To calculate probability for selected failure condition (SSA/AFO mode):

1. Select specific function.
2. Select failure condition.
3. Choose **Calculate selected FTA** from the pop-up menu. Result of the calculation will be displayed in SSA/AFO report and in failure conditions table on the screen.

To calculate probability for multiple failure conditions (SSA/AFO mode):

1. Select specific function (top function to calculate all, specific function to calculate only FTAs linked to failure conditions of this function and nested child functions).
2. Choose **Recalculate Assessment Means** from "Calculation" menu. Result of the calculation will be displayed in SSA/AFO report and in failure conditions table on the screen.

Probabilities comparison

Both screen and report will show **expected probability per average mission hour** (calculated using Fault Trees as described above) and also **objective probability** (some reports may show both "Safety Requirements Objective" and "Design Objective" probabilities) per average mission hour. If expected calculated probability is greater than objective probability RAM Commander will provide red color indication in that grid/report line.

The objective probabilities ("Safety Requirements Objective" and "Design Objective") are defined in Safety/FMECA libraries - "Safety Severity" library and "End Effects" library. See the next paragraphs for more information about the libraries.

22.8 Reports

Reports

The Safety Module has a number of customizable reports.

Below is the list of available reports with their explanations:

#	Name	Description
1	Functional Tree Diagram	Functional tree with all branches expanded

#	Name	Description
2	Functional Breakdown	All functional tree items represented in a tabulated form
3	Functional Hazard Analysis	FHA – Failures information for all functions
4	Safety System Assessment	SSA – failures information including selected assessment means for each function
5	Safety Assessment Results Summary	SSA summary – all failures with S/R objective, Design objective and calculated probability for each failure.
6	AFO	Special report for AFO Safety Assessment analysis
7	Dormant (Latent) Failure Assessment	List of all latent events leading to failure conditions with specified severity and information about these events and failure conditions.
8	Safety Reports by MS Word template	FHA, SSA, AFO documents generated using MS Word templates
9	SHA Reports by MS Word template	SHA, O&SHA, MIL-STD-882 documents generated using MS Word templates


Reports view could be customized – colors, fonts, column sizes. See RAM Commander Fundamentals Chapter - "[Reports](#)" for more information.

Almost all reports in the Safety Module take only the currently selected functional tree item or branch into consideration. For example, if specific branch is selected before executing the report then only this branch will appear in the report.

Several reports in Safety module are generated directly to MS Word as final documents using customizable MS Word templates. See RAM Commander Fundamentals Chapter - "[Reports by MS Word template](#)" for more information.

To get a simple report:

1. Select required functional tree element (function, tree branch, or tree root)
2. Open "Reports" group of the main menu:




3. Select the required report from the list.
4. Generated report will appear.
5. Generated report can be printed, saved, exported to MS Word or Excel etc.

6. Close the report window to return to the Safety Module.

To get a report based on MS Word template:

1. Select required functional tree element (function, tree branch, or tree root)
2. Open "Reports" group of the main menu.
3. Select the required reports group (Safety or SHA).
4. Select the required template report from the list of templates:



5. Press Page setup button to set document header/footer properties.
6. Press "Select" button.
7. Generated report will appear in MS Word:

ALD_SAFETYReport.doc - Microsoft Word

File Edit View Insert Format Tools AutoTag Table Window Help

Normal + Arial, Arial 12 RU B I U

Safety Assessment Process Example Safety Assessment Results Summary

Safety Assessment Results Summary

Safety Assessment Process Example

Failure Condition	Effect of Failure Condition	Phase	Severity Class	Safety Requirements Objective probability of failure for 1 hour	Design Objective probability of failure for 1 hour	Expected probability of failure for 1 hour	Expected probability for phase/flight time	Reference to RBD/FTA
1.5.2.2 Stopping Wheel Rotation on the Ground								
Unannunciated loss of wheel braking	The crew detects the failure when the brakes are operated. The crew uses spoilers and thrust reversers maximum extent possible. This may result in a runway overrun	Landing/ RT O/TA XI	Catastrophic	1.00e-009	1.00e-009	3.11e-026	1.55e-025	Unannunciated_loss_of_wheel_braking
		Landing/ RTO	Critical	1.00e-007	1.00e-007	1.31e-026	6.55e-026	
Annunciated loss of wheel braking	Crew selects a more suitable airport, notifies emergency ground support, and prepares occupants for landing overrun. Crew uses spoilers and thrust reversers to the maximum extent possible.	Landing	Critical	1.00e-007	1.00e-007	3.88e-027	1.94e-026	Unannunciated_loss_of_wheel_braking
Partial Symmetrical loss of wheel braking	The crew detects the failure when the brakes are used. Crew uses available wheel	Landing/ RTO		0	0	0	0	Preliminary_Aircraft_FTA
Unannunciated partial symmetrical loss of wheel braking		Landing/ RTO	Major	1.00e-005	1.00e-005	1.43e-007	7.13e-007	WBULOSS5

Generated by RAM Commander Software

Author:		Date:	2010-08-04
Group:		Document Nr:	92837498234923
Project:	S18_AIRCRAFT	Page:	1 / 4

Page 1 Sec 1 1/4 At 5.1cm Ln 4 Col 1 REC TRK EXT OVR Russian (Ru)

Chapter

23

MMEL

23 MMEL

The **Master Minimum Equipment List** (MMEL) is a document which lists the equipment that may temporarily be inoperative, subject to certain conditions, whilst maintaining an acceptable level of safety as intended in the applicable documents. Each MMEL is specific to an aircraft type.

RAM Commander's MMEL module main features:

1. Compliance with MMEL requirements (JAA, RRJ)
2. Interconnectivity with aircraft Reliability and Safety analyses
3. Candidate Item selection
4. Calculation(s) of Expected Probability before and after failure
5. Automatic identification of the next (first in flight) and second worst failures
6. Reports generation:
 - Standard MMEL : "Five Column Format" – presents the standard MMEL report
 - Detailed Quantitative Analysis – presents results of analysis on which MMEL selection has been made


23.1 Prerequisites for MMEL generation using RAM Commander MMEL Module

In order to generate an adequate MMEL you need to perform Reliability/FMECA and Safety analyses prior to initiating the MMEL Module.

Performance of MMEL quantitative analysis utilizes the following information which is the results of Reliability/FMECA and Safety analyses:

1. Product tree Items data:
 - a) Item Name (Ref.Des.)
 - b) Item ATA Number
 - c) Item operating Failure Rate
2. FHA – Functional Hazard Analysis ([Safety module](#))
3. [FMECA](#) – Failure Mode End Effect Criticality Analysis
4. [FTA](#) – Fault Tree Analysis
5. Failure modes defined in the FMECA must be used as Basic Events in FTA.
6. Each Basic Event must be connected to a corresponding Failure Mode through Product Tree ID and Failure Mode Number.
7. Each Fault Tree in FTA must be connected to a corresponding Failure Condition in FHA. This connection is established done at the Safety Assessment Definition screen.

The picture below illustrates linkage between Product tree, FMECA, FTA and Safety (FHA) modules which is used by MMEL module:



23.2 MMEL Analysis process

MMEL Analysis contains two steps which should be performed for each product tree item:

1. Qualitative MMEL Analysis - selection of MMEL list candidates using RAM Commander calculations of quantitative analysis
2. MMEL “Five Column Format” report preparation, with information about rectification periods and inoperative equipment operational and maintenance implications.

23.3 To perform MMEL analysis

To perform MMEL analysis

1. Activate the Product tree view.
2. Select FMECA as current analysis.
3. Navigate to desired candidate item in the product tree.
4. Activate pop-up menu and select **MMEL** option; the MMEL dialog box opens.

MMEEL

ATA Number: 36-11-01 Standard: JAA OK

Ref.Des.: HIGH PRESSURE VALVE L Status: Candidate Cancel

Five Column

#	Rect. Period	Period for A	Installed Qty	Required Qty	Remarks
1	TBD		2	1	(O) Switch the affected air conditioning pack off. Maximum flight altitude – 25000 ft (7600 m). Refer to AFM for additional limitations. Avoid icing conditions.
2	TBD		2	0	(M) Secure failed valve in closed position. May be inoperative provided: 1. APU works normally AND 2. LCV works normally. AND 3. Ram air ventilation works normally

Calculation

Reports

Five Column

Detailed

Print Code

Print Name

Failure Details

#	Failure Mode	Failure Condition	O & M	Next Worst Failure
1	External bleed air leakage	Loss of bleed air supply to engine starter.(I)	no yes	PRSOV 8 L

Set Worst Failure Reset

The dialog include following fields:

Field	Field description
ATA Number	Item ATA number
Ref.Des.	Item Name
Status	MMEL status, Candidate or N/A
	"Five Column" Table
Rect. Period	Rectification Interval, A, B (3 days), C (10 days), D (120 days) or TBD
Period for A	Rectification Interval for Category A
Installed Qty	Number Installed
Required Qty	Number required for dispatch
Remarks	Remarks or Exceptions
	"Failure Details" Table
Failure Mode	Item Failure Mode
Failure Condition	Failure Condition connected to current Failure Mode
O&M	No – without O&M, Yes – with O&M
Next Worst Failure	Code of the Basic Event selected as Next Worst Failure
Second Worst Failure	Code of the Basic Event selected as Second Worst Failure

There are also several buttons

Button	Button description
Calculation	Activate quantitative analysis for current item
Parameters	Set Cut-off parameters for quantitative analysis
Five Column (report)	Generate "five column format" report for current item
Detailed (report)	Generate detailed report with results of the quantitative analysis
	Print Code Print Basic Event Code in the detailed report

Button	Button description	
	Print Name	Print Basic Event Name in the detailed report
Set Worst Failure	Manually select Next / Second Worst Failure	
Reset	Reset manually selected Next / Second Worst Failure	

The analysis is divided into two steps:

1. Quantitative MMEL analysis
2. "Five Column Format" report preparation

23.4 1st step: MMEL Quantitative Analysis

Each candidate to MMEL list affects system safety if the candidate is inoperative.

RAM Commander may help in candidate element failure safety effect evaluation and prove this candidate element inclusion into MMEL list.

RAM Commander has all the necessary data for such a quantitative analysis and may generate report to support the decision making about each candidate inclusion into the MMEL list.

See the decision making/algorithm explanation in the [MMEL Module Quantitative Analysis Algorithm](#) paragraph.

See the decision making quantitative report example in the [To activate quantitative analysis](#) paragraph.


The results quantitative analysis results for each element should be manually compared to the safety requirements (maximal allowed failure probability per each severity classification) and expert takes a decision about element inclusion into MMEL. If the decision is positive, the element should be selected as "Candidate" and the 2nd analysis step ([5-column report](#)) should be performed.

23.4.1 MMEL Module Quantitative Analysis Algorithm


MMEL Module Quantitative Analysis Algorithm

In order to cover all MMEL generation requirements RAM Commander MMEL module implements two algorithms:

1. Algorithm based on JAA MMEL development guidelines:




2. Algorithm implementing RRJ – 95/75 guidelines - Decision making algorithm for inclusion of assemblies (equipment) in MMEL:



Choosing of the needed MMEL algorithm is the first step of operating the MMEL Module.

23.4.2 To select a required algorithm

1. From the Project menu, choose Configuration.
2. The Project Configuration dialog box opens.
3. Select required MMEL calculation algorithm from the MMEL list box:



Your selection will be applied to MMEL Quantitative Analysis and Detailed Report.

23.4.3 To activate quantitative analysis

1. Press "Calculation" button on the MMEL dialog box.

RAM Commander will perform quantitative analysis according to selected algorithm. When calculation is finished, a "Detailed" report for the quantitative analysis will be displayed in a report window and in the grid in the lower MMEL screen part:

MMEL - Quantitative analysis results (JAA)

Project name: TUTORIAL_MMEL

ATA: 36-11-05

Item Name: BLEED TEMPERATURE SENSOR L


Failure Mode	Fault Indication	Failure Condition	Failure Cond. Classification	Probability (per FH)	O & M	Prob. after cand. failure (per FH)	Next Worst Failure in flight	Prob. after next worst (per FH)
Signal low in error, one channel	no	Annunciated total absence of air supply to: - air conditioning system. - wing anti-icing system.	Major					
		Unannunciated total absence of air supply to: - air conditioning system. - wing anti-icing system	Catastrophic	2.112E-012	no	3.597E-009	Single Failure	
					yes	1.843E-012	EXT-AV-1 -	5.316E-008
Annunciated loss of wing anti-ice on one side	Major							

See report columns explanation in the [MMEL Module Reports](#) chapter.

2. Manually select the Next/Second Worst Failure (if required).

When performing quantitative analysis, RAM Commander automatically selects Next/Second Worst Failure using Fussell-Vesely importance factor. In order to overwrite automatic selection, do the following:

1. Select appropriate cell in the "Failure Details" Table (columns "Next Worst Failure" or "Second Worst Failure").
2. Press "Set Worst Failure" button – "Set Worst Failure" screen will be opened.



3. In the “Set Worst Failure” screen select new Worst Failure and press OK. Cell with manually selected failure will be marked with grey background.

In order to return to the automatic selection: Select required cell and press “Reset” button.

To perform quantitative analysis for entire project select “Recalculate MMEL” from “Calculation” menu.

23.5 2nd step: MMEL Five Column Format Report Preparation

Note: This step is performed only if after the quantitative analysis it has been decided that an Item is considered as a MMEL candidate.

Prior to generation of "Five Column Format" Report you have to do the following:

1. Set Item MMEL status to “Candidate”
2. Select Rectification Period from the list
3. Enter rectification interval for category A, if such category selected
4. Enter number (quantity) of items normally installed in the aircraft
5. Enter minimum number (quantity) of items required for operation
6. Enter Remarks or Exceptions (usually they contain Operational (O) and Maintenance (M) limitations and requirements which arise when the selected item is not operational).

To generate “Five Column Format” for the current item report press MMEL button.


To view “Detailed Quantitative Analysis” for the current item report press the Detailed button.

Note: The view is available only if a quantitative analysis has been already performed.

23.6 MMEL Module Reports

To create MMEL reports:

1. Activate the Product tree view.
2. Select FMECA as current analysis
3. Navigate to a desired level in the Product Tree.
4. From the **Reports** menu, choose **Standard Kit**; the Report Selection dialog box opens.



5. Select the report Type: "MMEL".
6. Select the report Subtype: "Candidate List", "Five Column", "Five Column (MS Word)" or "Detailed".
7. Choose OK.

RAM Commander generates and displays the report in a report window. Only items with the MMEL status equal to "Candidate" will be included in the report.

The MMEL module provides the following reports:

1. MMEL Candidate List – shows all MMEL candidates in the project:

Candidates List Report
 Project name: AIRC

ATA	Name
21-50-07	PACK TEMPERATURE SENSOR
21-50-16	PACK INLET TEMPERATURE SENSOR L
21-51-76	FLOW CONTROL VALVE
21-52-12	PACK DISCHARGE TEMPERATURE SENSOR L
21-52-48	PACK DISCHARGE PRESSURE SENSOR L

2. MMEL (“five column format”) report:

Master Minimum Equipment List
 System / ATA Chapter: Sample project with MMEL analysis

System & Sequence No		Rectification Interval			Remarks or Exceptions
			Number Installed		
				Number required for dispatch	
(1)	(2)	(3)	(4)	(5)	
36-11-01	HIGH PRESSURE VALVE L	T	2	1	(O) Switch the affected air conditioning pack off. Maximum flight altitude – 25000 ft (7600 m). Refer to AFM for additional limitations. Avoid icing conditions. (M) Secure failed valve in closed position.
		T	2	0	May be inoperative provided: 1. APU works normally AND 2. LCV works normally. AND 3. Ram air ventilation works normally (O) Switch both air conditioning packs off. Maximum flight altitude – 10000 ft (3000 m). Refer to AFM for additional limitations. Avoid icing conditions. (M) Secure both failed valves in closed position.
36-11-03	PRESSURE REGULATING VALVE L	T	2	1	(O) Switch the affected air conditioning pack off. Maximum flight altitude – 25000 ft (7600 m). Avoid icing conditions.

Explanation of the report columns:

Column	Column description
System & Sequence Numbers	(Column 1) Systems numbers are based on the Air Transport Association (ATA) Specification Number 100 or 2200 and items are

Column	Column description
	numbered sequentially.
Rectification Interval	(Column 2) - Rectification Interval, A, B (3 days), C (10 days), D (120 days) or TBD.
Number Installed	(Column 3) is the number (quantity) of items normally installed in the aircraft. This number represents the aircraft configuration considered in developing this MMEL. Should the number be a variable (e.g., passenger cabin items) a number is not required; a "-" is then inserted in column.
Number required for dispatch	(Column 4) is the minimum number (quantity) of items required for operation provided the conditions specified in Column 5 are met. Should the number be a variable (e.g., passenger cabin items) a number is not required; a "-" is then inserted in column 4.
Remarks or Exceptions	(Column 5) in this column includes a statement either prohibiting or permitting operation with a specific number of items inoperative, provisos (conditions and limitations) for such operation, and appropriate notes.

3. MMEL Detailed Report displays quantitative analysis detailed information for each MMEL candidate:

MMEL - Quantitative analysis results (JAA)

Project name: AIRC_EN_11

ATA: 21-52-48

Item Name: PACK DISCHARGE PRESSURE SENSOR L

Failure Mode	Fault Indication	Failure Condition	Failure Condition Classification	Probability (per FH)	O & M	Prob. after cand. failure (per FH)	Next Worst Failure in flight	Prob. after next worst (per FH)
Leak	yes	n/a						
Out of range (high)	yes	Un-anniated total loss of air supply to crew and passengers.	Catastrophic	2.571E-010	no	3.734E-009	EXT-EIU-2 L - EIU: Loss	8.923E-005
					yes	2.571E-010	EXT-CP-2 - Control Panel: Loss of RAV opening command	3.102E-008
Out of range (low)	yes	n/a						
In range (high)	no	n/a						
In range (low)	yes	n/a						

Explanation of the report columns:

Above the report table two data fields appear:

ATA – Candidate Item ATA Number

Item Name - Candidate Item Name

Column	Column description
Failure Mode	Item Failure Mode
Fault Indication	Indication/Detection for current Failure Mode
Failure Condition	Failure Condition from the FHA
Failure Cond. Classification	Failure Condition Classification according to FHA (Catastrophic, Hazardous, Major, Minor).
Probability (per FH)	Expected probability of the Failure Condition according with FTA calculation.
O & M	No – results without O&M. Yes – results after O&M
Prob. after cand. failure (per FH)	Expected probability of the Failure Condition after the candidate failed according with FTA calculation.
Next Worst Failure in Flight	Next Worst Failure (1st failure in flight) according with Fussell-Vesely Importance criterion.
Prob. after next worst (per FH)	Expected probability of the Failure Condition after the next worst failure according with FTA calculation.
Second Worst Failure in Flight	Second Worst Failure (2nd failure in flight) according with Fussell-Vesely Importance criterion.
Prob. after second (per FH)	Expected probability of the Failure Condition after the second worst failure according with FTA calculation.

See also "[Reports](#)" paragraph in the [RAM Commander Fundamentals](#) chapter for more general information about reports.

23.7 Summary

In this section, you learned about RAM Commander's **Master Minimum Equipment List (MMEL)** module. Using this module, you can perform quantitative MMEL analysis and generate standard "five column format" report.

See more about relevant to MMEL RAM Commander modules: [FMECA](#) and [FTA](#).

Chapter

24

MSG-3

24 MSG-3

MSG-3 Scheduled Maintenance Development Analysis is divided into 4 main sections:

- [Systems and Power Plant Analysis](#)
- [Structural Analysis](#)
- [Zonal Analysis](#)
- [L/HIRF Analysis](#) (Lightning and High Intensity Radiated Field Analysis)

RAM Commander supports all 4 analysis methods and provides computerized multi-user way of performing the analysis, while all input data is stored in the database and printed out using customizable MS Word reports.

All 4 types of analyses use the same database, share common information and supplement each other; however, any type of analysis may be performed separately.

Next paragraphs of this document will provide more detailed explanation of each type of analysis.


24.1 Systems and Power Plant Analysis

The **MSG-3** module is used by aircraft manufacturers or aircraft operators (airlines) to perform aircraft Scheduled Maintenance Development analysis according to Air Transport Association (ATA) MSG-3 document.

The **MSG-3 "Systems and Power Plant Analysis"** module is integrated with RAM Commander **Basic, Reliability** and **FMECA** modules. It divides the procedure into 7 steps:

- System Definition,
- Maintenance Significant Items (MSI) Selection,
- [FMECA](#) ,
- Failure Effect Categorization,
- Task Selection and Development,
- Task Interval Definition/Optimization,
- MSG-3 Report Generation.

These steps are explained later in this document.



It brings user through the decision-making process using interactive decision diagrams taken from the standard.

Prerequisites:

To successfully perform MSG-3 analysis in RAM Commander, you must be familiar with Basic, Reliability, Maintainability and FMECA (including Functional Blocks issue) modules of RAM

Commander.

24.1.1 Initiating MSG-3 Module

1. Run RAM Commander
2. Open project
3. Click on "MSG-3" section in the button bar on the left side of the product tree window.
4. MSG-3 seven steps menu buttons will appear. Go through the MSG-3 procedure selecting one step after another, performing required actions on each step. If required, previous steps may be activated to edit/add required information.

24.1.2 MSG-3 Procedure Steps

The following paragraphs will explain each step of the seven MSG-3 procedure steps.

24.1.2.1 Step 1 – System Definition

During this step user has to create a system definition in RAM Commander – build/import system product tree and provide additional information required for MSG-3 reports (MTTR, supplier/manufacturer name, failure rate, item functions, part numbers, ATA numbers etc). See chapter "Project Building" for more information on system definition.

The screenshot shows the RAM Commander software interface. On the left, there is a sidebar with four steps: 1. System Definition (selected), 2. MSI Selection, 3. FMECA (Default Phase), and 4. Failure Effect Categorization. The main window displays a tree view of the system definition and a table of items.

Ref.Des.	ID	Name	Qty	Opr. FR [10...	Status	ATA Number
Aircraft	1	---	1	0.0000	++	
Fuel System	1	---	1	0.0000	++	28-00-00
Fuel Storage System	1	---	1	0.0000	++	28-10-00
Fuselage tank	1	XXXXZZXXZZ	1	0.0000	++	28-10-01
Refueling pilot valve	2	XXXXZZXXZZ	1	0.0000	++	28-10-03
Drain valve-Center tank/collec...	3	XXXXZZXXZZ	1	0.0000	++	28-10-04
Pressure refueling adapter	4	XXXXZZXXZZ	1	0.0000	++	28-10-05
Check valve-flapper	5	XXXXZZXXZZ	1	0.0000	++	28-10-06
Interconnect valves	6	XXXXZZXXZZ	1	0.0000	++	28-10-07
Wing drain valve	7	XXXXZZXXZZ	1	0.0000	++	28-10-08
Wing float vent valve	8	XXXXZZXXZZ	1	0.0000	++	28-10-09
Center tank transfer jet pump	9	XXXXZZXXZZ	1	0.0000	++	28-10-10
Wing tank transfer jet pump	10	XXXXZZXXZZ	1	0.0000	++	28-10-11
Transfer inline check valve	11	XXXXZZXXZZ	1	0.0000	++	28-10-12
Fuel Distribution System	2	---	1	0.0000	++	28-20-00
Boos Jet Pump	1	---	1	0.0000	++	28-20-01
Electric Standby Pump	2	---	1	0.0000	++	28-20-02
Feed Inline Check Valve	3	---	1	0.0000	++	28-20-03
Engine Fire Shutoff Valve	4	---	1	0.0000	++	28-20-04
APU Fire Shutoff Valve	5	---	1	0.0000	++	28-20-05
Fuel Pressure Switch	6	---	1	0.0000	++	28-20-06
Fuel Dump System	3	---	1	0.0000	++	28-30-00

In addition to system hardware breakdown definition, system element functions should be provided. If system element has single function, it may be specified in "Item Function" field on the Item Data screen, "General" tab:

Item Data

Derating Miscellaneous Functional Blocks

General / Logistics Operating Nonoperating Maintainability

Family: ... Ref.Des.: Fuselage tank
Item code: ... Part name: XXXXZZXX-ZZ

Military number: Quantity: 1
Catalog number: Manufacturer:
Generic name:
Remark:
Description:
Item Function: Fuel storage
LCN:
ATA number: 28-10-01 Get ATA Number

Background color:
Automatic
Change

If system element has several functions, these functions should be specified as underlying functional blocks:

Ref.Des.	ID
[-] Aircraft	1
[-] Fuel System	1
[-] Fuel Storage System	1
[-] Fuel storage	1
[-] Enable fuel flow in tank from outboard wing inboard	2
[-] Vent wing tank in flight and during refueling	3
[-] Allow interconnection of wing tanks from both sides	4
[-] Fuel Distribution System	2

See Chapter "[FMECA](#)", "[Functional_Blocks](#)" paragraph for more information on working with functional blocks.

24.1.2.2 Step 2 – MSI Selection

The purpose of this step is decision making and selection of system items which are significant from the maintenance point of view and which will be analyzed in the next steps of MSG-3 procedure as candidates to preventive scheduled maintenance.

1. Choose "2-MSI Selection" MSG-3 step.
2. List of system items will appear (only items which have function/functions defined and have ATA number defined will appear).

ATA Number	Part Number	Ref.Des.	Description	MSI?	Highest Manageable MSI	Remarks
28-10-00		Fuel Storage System				
28-10-01	XXXXXXXXZZ	Fuselage tank				
28-10-03	XXXXXXXXZZ	Refueling pilot valve				
28-10-04	XXXXXXXXZZ	Drain valve-Center tank/collector box				
28-10-05	XXXXXXXXZZ	Pressure refueling adapter				
28-10-06	XXXXXXXXZZ	Check valve-flapper				
28-10-07	XXXXXXXXZZ	Interconnect valves				
28-10-08	XXXXXXXXZZ	Wing drain valve				
28-10-09	XXXXXXXXZZ	Wing float vent valve				
28-10-10	XXXXXXXXZZ	Center tank transfer jet pump				
28-10-11	XXXXXXXXZZ	Wing tank transfer jet pump				
28-10-12	XXXXXXXXZZ	Transfer inline check valve				

Determine Item Maintenance Significance Set Remarks and Highest Manageable MSI Close

3. For each item in the list, perform the following steps:
 - a. Press "Determine Item Maintenance Significance" button (or double-click on the item).
 - b. Decision diagram will appear. Select appropriate "Yes" or "No" answers for each of 4 questions by clicking yellow boxes with answers:

MSG-3 - MSI Selection -

MAINTENANCE SIGNIFICANT ITEM SELECTION (MSI)

a) Could failure be undetectable or not likely to be detected by the operating crew during normal duties?

Yes No

b) Could failure affect safety (on ground or in flight), including safety/emergency systems or equipment?

Yes No

c) Could failure have significant operational impact?

Yes No

d) Could failure have significant economic impact?


Yes No

Please provide answers to all four questions, clicking the relevant Yes or No boxes.

Ok Cancel

Selected answers are marked by green background color.

- c. Press Ok when done.
- d. Press "Set remarks and Highest Manageable MSI" button.
- e. Remarks dialog will appear – provide remarks on your decision and select highest manageable MSI item for the current item (it is subsystem/system for which separate MSG-3 report will be generated):



MSG-3 - MSI Selection - MSI Data

Part Number: XXXYZZXXZZ

ATA Number: 28-10-09

Ref.Des.: Wing float vent valve

Description:


MAINTENANCE SIGNIFICANT ITEM (MSI)? Yes

Remarks:

Highest Manageable MSI Level: 28-10-00

Buttons: Browse... Clear OK Cancel

4. After decision for all items is taken, the items list will display the results:




ATA Number	Part Number	Ref.Des.	Description	MSI?	Highest Manageable MSI	Remarks	...
28-10-00	XXXXXX	Fuel Storage Syst...		Yes	28-10-00		1
28-10-01	XXXXXX	Fuselage tank		Yes	28-10-00		2
28-10-03	XXXXXX	Refueling pilot valve		No			3
28-10-04	XXXXXX	Drain valve-Cente...		Yes	28-10-00		4
28-10-05	XXXXXX	Pressure refueling ...		No			5
28-10-06	XXXXXX	Check valve-flapper		Yes	28-10-00		6
28-10-07	XXXXXX	Interconnect valves		Yes	28-10-00		7
28-10-08	XXXXXX	Wing drain valve		No			8
28-10-09	XXXXXX	Wing float vent va...		Yes	28-10-00		9
28-10-10	XXXXXX	Center tank transf...		Yes	28-10-00		10
28-10-11	XXXXXX	Wing tank transfer...		Yes	28-10-00		11
28-10-12	XXXXXX	Transfer inline che...		No			12

5. Close the items list.

24.1.2.3 Step 3 – FMECA

The purpose of this step is Functional Failure Mode and Effects Analysis for MSI (maintenance significant items).

For items with single function regular FMECA analysis should be performed. For items with multiple functions defined as functional blocks the FMECA analysis should be performed for the functional blocks:



See chapter 18 "FMECA" for information about FMECA analysis module.

Additional possibility in FMECA analysis required for MSG-3 is specification of multiple causes of Failure Mode. All possible causes of a single failure mode should be specified in the "Cause" column. Put double backslash delimiter between different causes to perform MSG-3 analysis step 5 separately for each of the causes. If "Cause" column does not appear in FMECA grid switch it on using the [FMECA Grid Customization](#) options.

24.1.2.4 Step 4 – Failure Effect Categorization

The purpose of this step is categorization of failures. MSG-3 document lists 5 failure effect categories:


- 5 – Evident Safety
- 6 – Evident Operational
- 7 – Evident Economic
- 8 – Hidden Safety
- 9 – Hidden Economic

The current MSG-3 step provides decision-making diagrams for selecting appropriate category for each failure effect.

1. Select top element or highest manageable MSI item in the product tree.
2. Choose "4-Failure Effect Categorization" MSG-3 step in the button bar.
3. List of failure effects will appear (only maintenance-significant items effects will appear):

ATA Number	Item	Function	Functional failure	Failure Effect	FEC	FEC Name	#
28-10-00	Fuel Storage Syst...	Fuel storage	Fails to store fuel	Fuel leakage	6	Evident Operational	1
28-10-00	Fuel Storage Syst...	Enable fuel flow in...	Fails to allow flow inboard	Loss of redundancy of fuel flow from ou...	9	Hidden Economic	2
28-10-00	Fuel Storage Syst...	Enable fuel flow in...	Fails to prevent flow outboard (during m...	Possible shift in fuel distribution in wing...	9	Hidden Economic	3
28-10-00	Fuel Storage Syst...	Vent wing tank in...	Fails to vent wing tanks during flight an...	Loss of wing tank venting redundancy	9	Hidden Economic	4
28-10-00	Fuel Storage Syst...	Vent wing tank in...	Fails to prevent fuel entering into vent li...	Fuel may be spilled from vents during m...	9	Hidden Economic	5
28-10-00	Fuel Storage Syst...	Allow interconnect...	Fails to interconnect left and right fuel t...	Inability to balance fuel load	6	Evident Operational	6
28-10-00	Fuel Storage Syst...	Allow interconnect...	Loss of redundant interconnect between...	Fuel transfer is slower from one side to th...	6	Evident Operational	7
28-10-00	Fuel Storage Syst...	Allow interconnect...	Fails to indicate interconnect valves in-t...	Crew unaware of interconnect valve fu...	6	Evident Operational	8

4. For each failure effect in the list, perform the following steps:
 - a. Press "Determine Failure Effect Category" button (or double-click on the effect).
 - b. Decision diagram will appear. Click the appropriate answer in the lower part of the diagram:



Selected answers are marked by green background color.

- c. Press Ok when done.
- d. Press "Provide remarks and explanations" button.
- e. Remarks dialog will appear – provide remarks on your decision:

The dialog box contains the following information:

- Item Data:** Ref. Des.: Fuel Storage System; ATA Number: 28-10-00; Description: ; Part Number: ; MAINTENANCE SIGNIFICANT ITEM (MSI)? Yes
- Function and Failure Data:** Function: Fuel Storage System; Functional Failure: Fuel storage; Failure Effect: Fails to store fuel
- Questions, Answers and Clarifications:**

Question	Answer	Remarks and Clarifications
Q1: Is the occurrence of a Functional Failure evident to the operating crew during the performance of their normal duties?	Yes	Yes, the occurrence of a Functional Failure will be evident to operating crew during the normal
Q2: Does the Functional Failure or secondary damage resulting from the Functional Failure have a direct adverse effect on operating safety?	No	No, the Functional Failure or secondary damage resulting from the Functional Failure will not have
Q3: Does the combination of a Hidden Functional Failure and one additional failure of a system related or backup function have an adverse effect on operating safety?	N/A	Not applicable for category 6
Q4: Does the Functional Failure have a direct adverse effect on operating capability?	Yes	Yes, the Functional Failure will have a direct adverse effect on operating capability
- Categorization Results:** Failure Effect Category (FEC): 6; FEC Description: Evident Operational
- Remarks:** [Empty text box]

5. After decision for all items is taken, the items list will display the results.

- Press Ok to close the failure effects list.


24.1.2.5 Step 5 – Task Selection

The purpose of this step is selection of appropriate maintenance type (types) for each failure cause, taking into consideration failure effect category (FEC) and other factors. MSG-3 document provides maintenance type selection guidelines for each FEC. The current MSG-3 step provides decision-making diagrams for selecting appropriate maintenance type.

- Select top element or highest manageable MSI item in the product tree.
- Choose "5-Task Selection" MSG-3 step in the button bar.
- List of failure causes will appear (only maintenance-significant items effects will appear):

ATA ...	Item	Function	Functional failure	Failure Effect	Failure Cause	FEC	FEC Name	Tasks Selected	Tasks Defined
28-10-00	Fuel Storage Syst...	Fuel storage	Fails to store fuel	Fuel leakage	Fuel tank leakage	6	Evident Operational	Yes	No
28-10-00	Fuel Storage Syst...	Fuel storage	Fails to store fuel	Fuel leakage	Drain valve leakage	6	Evident Operational	Yes	No
28-10-00	Fuel Storage Syst...	Enable fuel flow in...	Fails to allow flow inb...	Loss of redundanc...	Flapper valve fail...	9	Hidden Economic	Yes	Yes
28-10-00	Fuel Storage Syst...	Enable fuel flow in...	Fails to prevent flow...	Possible shift in fu...	Flapper valve fail...	9	Hidden Economic	Yes	Yes
28-10-00	Fuel Storage Syst...	Vent wing tank in ...	Fails to vent wing tan...	Loss of wing tank ...	Float vent valve (n...	9	Hidden Economic	Yes	Yes
28-10-00	Fuel Storage Syst...	Vent wing tank in ...	Fails to prevent fuel e...	Fuel may be spill...	Outer wing float val...	9	Hidden Economic	Yes	Yes
28-10-00	Fuel Storage Syst...	Allow interconnect...	Fails to interconnect...	Inability to balance...	Interconnect switch...	6	Evident Operational	Yes	No
28-10-00	Fuel Storage Syst...	Allow interconnect...	Fails to indicate interc...	Crew unaware of i...	Lighted indicator fa...	6	Evident Operational	Yes	No

- For each failure cause in the list, perform the following steps:
 - Press "Task Requirements Analysis" button (or double-click on the effect).
 - Decision diagram will appear. Select appropriate "Yes" or "No" answers for each question by clicking yellow boxes with answers:



Selected answers are marked by green background color.

Decision diagram is different for each failure effect category.

- c. Press Ok when done.
- d. Press "Task Definition" button.
- e. Remarks/Tasks dialog will appear – provide remarks on your decision and enter details of scheduled maintenance tasks to the table in the lower part of the screen:

MSG3 - Step 5 - Task Selection Information

Item: Fuel Storage System Function: Enable fuel flow in tank from outboard wing inboard ATA Number: 28-10-00

Failure: Fails to allow flow inboard Failure Effect Category (FEC): 9

Effect: Loss of redundancy of fuel flow from outboard to inboard in wing tanks. Other valves in wing al FEC Description: Hidden Economic

Cause: Flapper valve failed closed

Questions, Answers and Explanations

Question	Answer	Answer & Explanation (Based on Applicability & Effectiveness Criteria)
Is the lubrication or servicing task applicable and effective?	No	
Is a check to verify operation applicable and effective?	Yes	Yes, a check to verify operation will be applicable and effective
Is an inspection or functional check to detect degradation of the function (potential failure) applicable and effective?	No	
Is a restoration task to reduce the failure rate applicable and effective?	No	
Is a discard task to avoid failures or to reduce the failure rate applicable and effective?	No	
Is there a task or combination of tasks that are applicable and effective?	N/A	Not applicable for category 9

Task Definitions

TaskNumber	Task Type	Task Description	Interval	Interval Unit	Remarks	Interval Justification	Access
001	OP	Op. check of the wing flapper valves	8	flights			

OK Cancel


5. After decision for all items is taken, the items list will display the results.
6. Press Ok to close the failure effects list.

24.1.2.6 Step 6 – Task Interval

The purpose of this step is to review the provided maintenance tasks, set/change their intervals, perform task grouping by setting equal intervals etc.

1. Select top element or highest manageable MSI item in the product tree.
2. Choose "6-Task Interval" MSG-3 step in the button bar.

List of all tasks will appear (only maintenance-significant items effects will appear):



TaskNumber	Task Type	Task Description	Interval	Interval Unit	Remarks	Remarks	Access
001	OP	Op. check of the wing flapper valves	8	flights			
001	OP	Operational check of the wing flapper valves	8	flt/hrs			
002	NT	Operational check of wing tank 8 float valves	8	eng.cycles			
002	OP	Operational check of wing tank 8 float valves	8	flights			


3. Edit the tasks and their interval inside the table cells.

24.1.2.7 Step 7 – MSG-3 Report

The purpose of this step is to create and print out the final MSG-3 report for each system/subsystem (defined as Highest Manageable MSI during the MSG-3 analysis).

RAM Commander generates MS Word document with MSG-3 report for the selected highest manageable MSI item according to MS Word template. Template design (fonts, colors, table headers, language etc) could be changed by users.

1. Select Highest Manageable MSI item in the product tree.
2. Choose "7-MSG-3 Report" step in the button bar.
3. Report parameters dialog will appear:



MSG-3 Report Information

Highest Manageable Item Data

MSI ATA Number: 28-10-00 Revision: 3

MSI Name: Fuel Storage System Date: 12/21/09

Author: ALD Approve Date: 08/23/09

Workgroup: RAMS Approved By: John Smit

Update Date: 12/21/09

System Breakdown and Functional Description Document Link: Browse

System Design Features Description Document Link: C:\RAMC32\PRJ\TUTORIAL_MSG3\MSG3_FuelStorageSystem_Design.doc Browse

General Report Settings

Company name: ALD

Department name: Reliability&Safety

Product/Project Name: Xwing Fighter Spaceship

MSG-3 report template document: D:\RAMC32\LIB\MSG3_Template_Main.doc Browse

Generate Report Save Cancel

4. Provide product, subsystem, workgroup, author and company details which will appear on the report forms.
5. Provide MS Word template file name (if not default). The default template is located in the LIB subfolder of RAM Commander installation folder and file name is MSG3_Template_Main.doc.
6. Provide links word documents containing
 - a. system breakdown and functional description

b. system design features description

Contents of these documents will be embedded into the relevant positions of final MSG-3 report.

7. Press "Generate Report" button and the final MS Word report will be opened, see some page examples below:

ALD Ltd.



MSG-3 Analysis

FOR MSI

28-10-00 Fuel Storage System

Effectivity: Xwing Fighter Spaceship
Revision: 1
Date: 08/23/09



Company: ALD Department: Reliability&Safety MSI: 28-10-00	SCHEDULED MAINTENANCE DEVELOPMENT DATA Xwing Fighter Spaceship - Fuel Storage System	
---	---	--

FORM 0		MAINTENANCE SIGNIFICANT ITEM SELECTION (MSI)						
MSI Number: 28-10-00		ITEM: Fuel Storage System						
ATA Number	Description	Selection Criteria				MSI?	Highest Manageable Level	Remarks
		Could failure be Undetectable or not likely to be detected by the operating crew during normal duties?	Could failure Affect safety (on Ground or in Flight), including Safety/emergency System or Equipment?	Could Failure have Significant Operational Impact?	Could Failure have Significant Economic Impact?			
28-10-00	Fuel Storage System	Yes	No	Yes	No	Yes	28-10-00	
28-10-01	Fuselage tank	No	No	Yes	No	Yes	28-10-00	
28-10-03	Refueling pilot valve	No	No	No	No	No		
28-10-04	Drain valve-Center tank/collector box	Yes	No	No	Yes	Yes	28-10-00	
28-10-05	Pressure refueling adapter	No	No	No	No	No		
28-10-06	Check valve-flapper	No	Yes	No	Yes	Yes	28-10-00	
28-10-07	Interconnect valves	Yes	Yes	No	Yes	Yes	28-10-00	
28-10-08	Wing drain valve	No	No	No	No	No		
28-10-09	Wing root vent valve	No	No	Yes	No	Yes	28-10-00	
28-10-10	Center tank transfer jet pump	Yes	No	No	Yes	Yes	28-10-00	
28-10-11	Wing tank transfer jet pump	Yes	No	No	Yes	Yes	28-10-00	
28-10-12	Transfer inline check valve	No	No	No	No	No		

Prepared by: ALD	Date: 08/23/09	Workgroup: RAMS	Approval: John Smit	Revision: 1	Update Date: 08/23/09	Page: 5 / 18
---------------------	-------------------	--------------------	------------------------	----------------	--------------------------	-----------------

safety of the aircraft – emphasis is on Safety.

Typical examples of SSIs are: Wing and Empennage, Fuselage: Doorframes, Window frames, Engine Mounts, Entrance doors, access doors.

MSG-3 Structural Analysis for Project AAA on Drive D:

Name	ATA Number	Zone	Description	SSI ?	SI Type
[-] Aircraft					
[-] Landing Gear	32-00-00				
[-] Main Landing Gear	32-10-00				
[-] Nose/Tail Landing Gear	32-20-00				
[-] Doors	52-00-00				
[-] Passenger / Crew Doors	52-10-00				
[-] Main Entrance Door	52-11-00				
[-] Emergency Exits	52-20-00				
[-] Cargo / Baggage Doors	52-30-00				
[-] Service Doors	52-40-00				
[-] Fluid Service Doors	52-46-00				
[-] Landing Gear Doors	52-80-00				
[-] Fuselage Structure	53-00-00				
[-] Fuselage Bulkheads	53-05-00				
[-] Fuselage Main Structure	53-10-00				
[-] Fuselage Main Frame	53-11-00				
[-] Cockpit Window Structure	53-17-00				
[-] Nacelles / Pylon Structure	54-00-00				
[-] Nacelles / Pylon, Main Frame	54-10-00				
[-] Nacelle/Pylon, Frame/Spar/Rib	54-11-00				
[-] Nacelle/Pylon, Bulkhead/Firewall	54-12-00				
[-] Nacelle/Pylon, Plate Skin	54-14-00				

Detailed guide on this module is available on demand from ALD.

24.3 Zonal Analysis

Zonal Analysis Procedure permits appropriate attention to be given to electrical wiring installations. Thus, as well as determining zonal inspections, the logic provides a means to identify applicable and effective tasks to minimize contamination and to address significant wiring installation discrepancies that may not be reliably detected through zonal inspection. These dedicated tasks may subsequently be included in the Systems and Power Plant tasks.

In order to perform the Zonal Analysis, divide the aircraft externally and internally into zones as defined in ATA iSpec 2200 (Major zones, sub zones, areas). Each zone can include multiple elements. Those elements can be a structure element or L/HIRF element or any other aircraft element located in this zone.

MSG-3 Zonal Analysis for Project AAA on Drive D:

Name	Zone	Description	Analysis Type	Inspection Level
Aircraft			Not Defined	Not Defined
Lower Half of Fuselage (to Alt Pressure Bulkhead)	100	Нижняя половина фюзеляжа	Standard and Enhanced	Not Defined
Upper Half of Fuselage (to Alt Pressure Bulkhead)	200		Not Defined	Not Defined
Upper Half of Fuselage - Flight Compartment	210		Not Defined	Not Defined
Flight Compartment, Left	211		Not Defined	Not Defined
Flight Compartment, Right	212		Not Defined	Not Defined
Upper Half of Fuselage - Forward Vestibule	220		Not Defined	Not Defined
Upper Half of Fuselage - Passenger Cabin	230		Not Defined	Not Defined
Upper Half of Fuselage - Alt Vestibule	240		Not Defined	Not Defined
Empennage and Fuselage Tail	300		Not Defined	Not Defined
Power Plants and Pylons	400		Not Defined	Not Defined
Left Powerplant	410		Not Defined	Not Defined
Left Powerplant - Engine	411		Not Defined	Not Defined
Left Powerplant - Inlet	412		Not Defined	Not Defined
Left Powerplant - Fan Cows	413		Not Defined	Not Defined
Left Powerplant - Thrust Reverser Cows	414		Not Defined	Not Defined
Left Powerplant - Mixed Flow Nozzle	415		Not Defined	Not Defined
Right Powerplant	420		Not Defined	Not Defined
Left Pylon	430		Not Defined	Not Defined
Right Pylon	440		Not Defined	Not Defined
Left Wing	500		Not Defined	Not Defined
Right Wing	600		Not Defined	Not Defined
Landing Gear and Landing Gear Doors	700		Not Defined	Not Defined
Pressurized Hatches and Doors	800		Not Defined	Not Defined
Pressurized Doors of Service Compartments	810		Not Defined	Not Defined
Cargo Compartment Doors	820		Not Defined	Not Defined
Left Passenger Compartment Doors	830		Not Defined	Not Defined
Right Passenger Compartment Doors	840		Not Defined	Not Defined

Detailed guide on this module is available on demand from ALD.

24.4 L/HIRF Analysis

Lightning/High Intensity Radiated Field (L/HIRF) protection systems have been identified to develop a dedicated maintenance. The intent of this maintenance is to reduce the possibility that a single failure cause (such as a lightning strike), and the occurrence of a common failure cause (such as ED or AD) across redundant channels of L/HIRF protection, could impact aircraft airworthiness.

This section contains guidelines for development of scheduled maintenance tasks for aircraft L/HIRF protection systems. Each L/HIRF protection system item is evaluated in terms of its susceptibility to degradation from environmental deterioration and/or accidental damage. The L/HIRF protection system maintenance tasks are developed in support of the aircraft type certification and MRB report development.

L/HIRF maintenance relies on adequate protection provided by both external and internal L/HIRF protection components.

In order to perform the L/HIRF Analysis you need to have Zonal tree and may have Product Breakdown tree built in RAM Commander. See Zonal Analysis for more information.

L/HIRF Analysis: Parent Radome

Properties

Element Name: Lightning Diverters Zone Name: Radome

Related Protected Items: Radome structure

Analysis

1. Are characteristics of the protection components susceptible to Accidental Damage ? Yes Justification...

2. Are characteristics of the protection components susceptible to Environmental Deterioration ? No Justification...

3. Will the failure condition due to the expected degradation in combination with a L/HIRF event prevent the continued safe flight and landing of the Aircraft? No Justification...

Remarks:

L/HIRF Protection Analysis Ratings

Environmental Deterioration: Possible Inspection Level: GVI

Accidental Damage: Likely

Density: Low Inspection Interval: 24 Month /7500 f.h - 72/15000 f.h

Tasks Definition

Task Number	Zone	Task Description	Access	Task Interval	Inspection Level	Candidate
111-01	111	General Visual Inspection of the Radome lightning diverters for general condition, installation and proper attachment.	111A	24 month	GVI	Yes

OK Cancel

Detailed guide on this module is available on demand from ALD.

Index

- A -

Alpha 424
 ambiguity factor 300, 316
 APR 4761 538
 ATA Number 169
 Availability 340, 396

- B -

Basic event 460
 Bayes formula 481
 Beta 424
 Burn-in 169, 295

- C -

calculated field 130
 CCF 474
 Common Cause Failure 474
 Compensating Provisions 424
 Condemnation rate 169
 Corrective Action 424
 Cut Set 460

- D -

Decision Making 529
 Derating
 Derating curve 328
 Detection 424, 516
 DLCC 113
 Duane 380, 381

- E -

Effect of Failure 516
 Effective MTBF 361
 Efficiency 529
 End Effect 424
 Environment 165

Equivalent MTBF 361
 Esary-Proschan formula 487
 Event Tree
 Event Tree Analysis 497

- F -

failure analysis 111
 Failure Cause 424
 Failure Mode 424, 516
 Failure Mode Ratio 424
 fault isolation 316
 Fault Trees 460
 Feasibility 529
 FIDES 226, 228
 FMD 97 431
 FMEA 508
 FRACAS 113
 Frequency 459
 FTA 459
 Functional Hazard Analysis 538
 Fussell-Vesely 490

- H -

House event 460
 hybrid 238

- I -

Import Wizard 184
 Importance 459
 Importance & Sensitivity Analysis 490
 Importance&Sensitivity analysis 481
 Intensity 459

- J -

Junction temperature 220

- L -

Level of replace 297

- M -

Maintainability 297
 Maintainability allocation 302
 Markov
 Markov chain 406
 Markov chain analysis 406
 Steady-State Mode 406
 Time-Dependency Mode 406
 Master Minimum Equipment List 556
 MCS Cut-off 487
 Mct 299
 Mct max 301
 mean time between critical failures 340
 Mean Unavailability 487
 MIL-HDBK-472 297
 MIL-STD-1635 380
 MIL-STD-882 538
 Minimal Cut Set 460
 Minimal Cut Sets 459
 Mission Profile 286
 MMEL 556
 Monte-Carlo 340, 481
 MSG-3 571
 MTBCF 340, 362, 366
 MTTR 299

- N -

Next Higher Effect 424
 NHE 424
 No Shortage Probability 392, 396
 Non-Shortage Probability 391
 NPRD-2011 224
 NPRD-95 222, 224
 NSP 391

- O -

Occurrence 516

- P -

Pareto 286, 287
 Process and Design FMEA 508

- Q -

QS 9000 509
 QS-9000 508

- R -

RAM Commander 16
 RBD 340
 RCM 323
 reliability allocation 241
 Reliability Analysis 108, 286
 Reliability Block Diagram 340
 reliability growth 380
 Reliability-Centered Maintenance 323
 Report Generator 130
 RIAC System Reliability Toolkit 361
 RPN 516

- S -

SAE APR 4761 538
 Safety 113
 Sensitivity 459
 Severity 424, 516
 Spare Parts 391
 Spare parts calculation 392
 spare parts optimization 395
 Stress 328
 Stress/Strength 236
 substrate 238
 System Safety Assessment 538

- T -

Temperature curve 286

- U -

Unavailability 459, 487
 Uncertainty 459
 Undeveloped event 460

